



Controller FAQ

Looking for information on how to use your Vector Tankage controller with the various games it supports? Look no further!

Vectrex

PiTrex - Battlezone

The Vector Tankage controller has been designed to work with PiTrex Baremetal from the from the July 29 2025 version which is available from:

<http://vide.malban.de/pitrex/pitrex-baremetal-download>

In the root of the SD card you need to ensure that the battlezone.ini file contains the following configuration (should be the default supplied from the July 29 2025 version):

```
[BATTLE_ZONE]
YATES_INPUT = 0 ; or 1
STRAMASH_INPUT_1 = 0;
STRAMASH_INPUT_2 = 1;
IN_GAME_SETTINGS = 0 ; SET THIS TO 0 when using input 2!!!

ONLY_ONE_JOYSTICK = 0;
```

This config sets the game to use the Stramash Zone custom controller scheme for joystick port 2 for use with the Vector Tankage controller.

Ensure the controller is in 'VECTREX' mode and start button should start the game.

Stramash Zone

Using a regular controller, on the opening screen scroll down to "VECTREX STICK" and press button 3 until it says 'CUSTOM CONTROL'



Disconnect the standard controller and connect the Vector Tankage controller to port 1 and ensure it's in VECTREX mode. Pressing one of the fire buttons will start the game.

VecFever

Once you've started the game with a standard controller connect the Vector Tankage controller to port 1, select 'VECFEVER' mode and press the start button to play!

PC USB

MAME

Coming soon!

Battlezone II by Peter Hirschberg

Coming soon!