

## Prevent Raspi dropping WiFi

My Pi became randomly inaccessible over WiFi.

In /var/log/syslog I found:

```
{TIMESTAMP} raspberrypi dhcpcd[{PID}]: wlan0: carrier lost
```

It turned out the problem was that the Pi WiFi controller has power\_save on by default.

Command to read the current power saving mode (Stretch):

```
sudo iw wlan0 get power_save
```

Command to power\_save off

```
sudo iw wlan0 set power_save off
```

To make this permanent add the following line to /etc/rc.local:

```
/sbin/iw dev wlan0 set power_save off
```

```
sudo chmod -v +x /etc/rc.local
```

```
sudo systemctl enable rc-local.service
```