


|     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|
| GND | GND | GND | GND | GND | GND | GND | GND |
| RC7 | RC6 | RC5 | RC4 | RC3 | RC2 | RC1 | RC0 |


|     |     |     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|-----|-----|
| GND | GND | GND | GND | GND | GND | GND | GND |
| RE2 | RE2 | RE1 | RA5 | RA3 | RA2 | RA1 | RA0 |

|     |     |
|-----|-----|
| GND | RD0 |
| GND | RD1 |
| GND | RD2 |
| GND | RD3 |
| GND | RD4 |
| GND | RD5 |



This picture depicts the BotBoard07 Pro and its I/O ports. Please note that RC6 and RC7 are unavailable if the jumpers at JP1 to the RS-232 level converter are present, as the MAX232 interferes with their normal, non-serial operation. If you do not need the serial port for bootloading or communications, feel free to remove these jumpers to reclaim those I/O pins.

The diagram on the next page details the disposition of each I/O pin on the PIC.



**PCBs sponsored by**

