

LinuxCNC "G-Code" Quick Reference

| Code | Parameters | Quick Reference | Description |
|--|---|-------------------------------------|-------------|
| Motion | | | |
| (X Y Z A B C U V W apply to all motions) | | | |
| G0 | I J K or R, P P I J P Q I J P L | Rapid Move | |
| G1 | | Linear Move | |
| G2, G3 | | Arc Move | |
| G4 | | Dwell | |
| G5 | | Cubic Spline | |
| G5.1 | | Quadratic Spline | |
| G5.2 | | NURBS | |
| G38.2 - G38.5 | | Straight Probe | |
| G33 | | Spindle Synchronized Motion | |
| G33.1 | | Rigid Tapping | |
| G80 | Cancel Canned Cycle | | |
| Canned cycles | | | |
| (X Y Z or U V W apply to canned cycles, depending on active plane) | | | |
| G81 | R L (P) | Drilling Cycle | |
| G82 | R L (P) | Drilling Cycle, Dwell | |
| G83 | R L Q | Drilling Cycle, Peck | |
| G84 | R L (P) (\$) | Right-hand Tapping Cycle, Dwell | |
| G73 | R L Q | Drilling Cycle, Chip Breaking | |
| G74 | R L (P) (\$) | Left-hand Tapping Cycle, Dwell | |
| G85 | R L (P) | Boring Cycle, Feed Out | |
| G89 | R L (P) | Boring Cycle, Dwell, Feed Out | |
| G76 | P Z I J R K Q H L E (\$) | Threading Cycle | |
| Distance Mode | | | |
| G90, G91 | | Distance Mode | |
| G90.1, G91.1 | | Arc Distance Mode | |
| G7 | | Lathe Diameter Mode | |
| G8 | | Lathe Radius Mode | |
| Feed Rate Mode | | | |
| G93, G94, G95 | S (\$) | Feed Rate Mode | |
| Spindle Control | | | |
| M3, M4, M5 | S (\$) | Spindle Control | |
| M19 | R Q (P) (\$) | Orient Spindle | |
| G96, G97 | S D (\$) | Spindle Control Mode | |
| Coolant | | | |
| M7, M8, M9 | | Coolant Control | |
| Tool Length Offset | | | |
| G43 | H | Tool Length Offset | |
| G43.1 | H | Dynamic Tool Length Offset | |
| G43.2 | | Apply additional Tool Length Offset | |
| G49 | | Cancel Tool Length Compensation | |
| Stopping | | | |
| M0, M1 | | Program Pause | |
| M2, M30 | | Program End | |
| M60 | | Pallet Change Pause | |
| Units | | | |
| G20, G21 | (affects G2, G3, G81...G89, G40...G42) | Units (inch, mm) | |
| Plane Selection | | | |
| G17 - G19.1 | | Plane Select | |
| Cutter Radius Compensation | | | |
| G40 | D | Compensation Off | |
| G41,G42 | | Cutter Compensation | |
| G41.1, G42.1 | | Dynamic Cutter Compensation | |
| Path Control Mode | | | |
| G61 G61.1 | P Q | Exact Path Mode | |
| G61.1 | | Exact Stop Mode | |
| G64 | | Path Blending | |
| Return Mode in Canned Cycles | | | |
| G98, G99 | | Canned Cycle Return Level | |
| Other Modal Codes | | | |
| F | (\$) | Set Feed Rate | |
| S | | Set Spindle Speed | |
| T | | Select Tool) | |
| M48, M49 | | Speed and Feed Override Control | |
| M50 | | Feed Override Control | |
| M51 | | Spindle Speed Override Control | |
| M52 | | Adaptive Feed Control | |
| M53 | | Feed Stop Control | |
| G54-G59.3 | | Select Coordinate System | |
| Flow-control Codes | | | |
| o sub | | Subroutines, sub/endsub call | |
| o while | | Looping, while/endwhile do/while | |
| o if | | Conditional, if/else/endif | |
| o repeat | | Repeat a loop of code | |
| [] | | Indirection | |

| | | |
|--------------------------------|---------|-----------------------------------|
| o call | | Call named file |
| M70 | | Save modal state |
| M71 | | Invalidate stored state |
| M72 | | Restore modal state |
| M73 | | Save and Auto-restore modal state |
| Input/Output Codes | | |
| M62 - M65 | P | Digital Output Control |
| M66 | P E L Q | Wait on Input |
| M67 | T | Analog Output,Synchronized |
| M68 | T | Analog Output, Immediate |
| Non-modal Codes | | |
| M6 | T | Tool Change |
| M61 | Q | Set Current Tool |
| G10 L1 | P Q R | Set Tool Table |
| G10 L10 | P | Set Tool Table |
| G10 L11 | P | Set Tool Table |
| G10 L2 | P R | Set Coordinate System |
| G10 L20 | P | Set Coordinate System |
| G28, G28.1 | | Go/Set Predefined Position |
| G30, G30.1 | | Go/Set Predefined Position |
| G53 | | Move in Machine Coordinates |
| G52, G92 | | Coordinate System Offset |
| G92.1, G92.2 | | Reset G92 Offsets |
| G92.3 | | Restore G92 Offsets |
| M101 - M199 | P Q | User Defined Commands |
| Comments & Messages | | |
| :(...) | | Comments |
| (MSG,...) | | Messages |
| (DEBUG,...) | | Debug Messages |
| (PRINT,...) | | Print Messages |