

Enter Provisioning URL via the Yealink DECT web interface



Supported Yealink DECT models: W52P, W56P, W60P

For a complete step by step guide to provision the Yealink DECT phones for use with 3CX see the general configuration guides of 3CX at <https://www.3cx.com/support>.

Yealink WP series

- Yealink W52P
- Yealink W56P
- Yealink W60P
- [Enter Provisioning URL via the Yealink DECT web interface](#)
- [Supported Yealink DECT models: W52P, W56P, W60P](#)
- [Yealink WP series](#)
- [Configuring the provisioning server via the Yealink web interface:](#)
- [Step 1: Configure the base in 3CX](#)
- [Step 2: Enter the Information into device's Web Interface](#)

Configuring the provisioning server via the Yealink web interface:

Step 1: Configure the base in 3CX

1. Obtain the phone's MAC address.
2. In 3CX Management Console navigate to ⇒ "FXS/DECT".
3. Press "★ Add FXS/DECT".
4. Select the Brand of the phone (Yealink).
5. From the dropdown list select the model.
6. Enter the device's MAC address and press "OK".

Add FXS/DECT ×


Select Brand

Yealink ▼

Select model/device

Yealink W52P ▼

Mac Address

0015 


7. Optional settings include the phone's "Display Language", "Time Zone" and, if applicable, the network card interface in case the server has more than one IP address to which the phone shall be configured.

FXS/DECT Details

Enter name for Device
Yealink DECT Phones

Provisioning Method
Local LAN (in the office)


Provisioning Link: <http://192.168.179.42:5000/provisioning/xmu9s8mb39m4c/0015>.cfg

Mac Address
0015 

Select Interface
192.168.179.42

Language
English

Time Zone
Use global Timezone

Device Web Page Password
***** 

8. Copy the **"Provisioning Link"** shown above for future use.

9. Navigate to the **"Extensions"** tab of the desired **"FXS/Dect"** device to assign the extensions and click **"OK"**.

General Extensions

Extensions

101 Adrian Smith	
102 Dave Murray	
103 Russell Tobi	
Empty	
Empty	

Step 2: Enter the Information into device's Web Interface

Yealink | WS2P | WS6P

Status Account Network Features **Settings** Directory

Preference
Time & Date
Call Display
Upgrade
Auto Provision
Configuration

Auto Provision

PNP Active ☐ On ☐ Off

DHCP Active ☐ On ☐ Off

Custom Option(128~254)

DHCP Option Value

Server URL

User Name

☐ Friday
☒ Saturday

Autoprovision Now

Confirm Cancel

1. Point your web browser to your device's IP address.
2. Navigate to "**Settings** → **Auto Provision**".
3. In the "**Server URL**" field enter your "**Provisioning Link**" URL.
4. Press "**Confirm**" and then "**Autoprovision Now**".

You might also be interested in:



Registering a Handset to a
Gigaset N720 Base Station



Enter Provisioning URL via
the Gigaset N720 DECT

Get 3CX Free for 1 Year Today

Download On-Premise

Try in the Cloud