

NAME

mg_i_start, **mg_i_stop** - Start and stop a MAC group

SYNOPSIS

```
#include <sys/mac_provider.h>
```

int

```
prefix_group_start(mac_group_driver_t gh);
```

void

```
prefix_group_stop(mac_group_driver_t gh);
```

INTERFACE LEVEL

Evolving - This interface is still evolving. API and ABI stability is not guaranteed.

PARAMETERS

driver A pointer to the ring's private data that was passed in via the *mg_i_driver* member of the *mac_group_info*(9S) structure as part of the *mr_gget*(9E) entry point.

DESCRIPTION

The **mg_i_start()** and **mg_i_stop()** are optional entry points that allow a chance for the device driver to do anything that it needs to do to start and stop a group respectively. The group that is being operated on is identified by *gh*.

RETURN VALUES

Upon successful completion, the **mg_i_start()** interface should return **0**. Otherwise, it should return the appropriate error number.

SEE ALSO

mac(9E), *mac_capab_rings*(9E), *mr_gget*(9E), *mac_group_info*(9S)