

to LCD Display

to load cell

Load Cell
PRT-08231 for load cell

12VDC PS

to fuel injector

to pushbuttons
1. Test Start
2. Zero
3. Span

