



Firmware Update Tutorial

Download QMK Toolbox

Windows

- ▶ [Click to jump to download](#)

MacOS

- ▶ [Click to jump to download](#)


Flashing the firmware may cause the configuration to be cleared, please backup the configuration if necessary

Windows Tutorial

If you are using an older version of QMK Toolbox, the eeprom will not be cleared automatically when writing, please click Clear eeprom manually.

Otherwise, it will appear: the first restart after writing to normal use, after re-plugging or restarting the computer, the keyboard lights up red and the VIA-C does not recognize it.

- ▶ 1. Unzip the downloaded .exe program to any directory and open it. It may take tens of seconds to 3 minutes to open it for the first time, and then there will be a prompt to install the driver. Select Yes to install the driver [If you miss this step , at the top tool - install the driver to reinstall]
- ▶ 2. Click the "Open" button on the upper right, select the firmware file ending in .hex format>> [Firmware Download](#)
- ▶ 3. Check the automatic write
- ▶ 4. Connect the normal keyboard, click "Enter DFU" to make the keyboard enter DFU mode **【If your keyboard is not working properly, please refer to step 7 to enter DFU】**
- ▶ 5. After the keyboard enters the DFU mode correctly, if the third step checks the automatic writing, it will automatically write at this time
- ▶ 6. After the writing is completed, the keyboard will automatically restart, and it will prompt "** DFU mode keyboard has been disconnected"



- 7 If your keyboard is no longer working, or you cannot use Enter DFU to enter DFU, then plug in the keyboard, press the RESET key to enter Bootloader model



Reset key position

Mac OS Tutorials



If you open the QMK Toolbox, it prompts that the application is damaged or cannot be opened: you need to open the terminal (Terminal), enter "sudo spctl --master-disable" and press Enter, and enter the password after the password is prompted. There is no prompt during the input process. After entering, press Enter. If there is no error message, it is successful, and then you can reopen it.

- ▶ 1. After starting the application, click on the upper right corner to open it, and select the decompressed firmware in .hex format
- ▶ 2. Connect the keyboard, press the keyboard's Reset key to enter the DFU mode [[Refer to step 7 of the Windows tutorial](#)]. If you have already installed the shell and it is inconvenient to press the button, you can connect VIA-C, enter the settings - enter the bootloader, click jump, and you can also enter the DFU mode
- ▶ 4. If you enter the DFU mode correctly, the tool will prompt that the DFU mode keyboard is connected, and then click to clear the eeprom
- ▶ 5. After the prompt is cleared, click to start writing
- ▶ 6. After the firmware is written, it will automatically restart and disconnect the keyboard in DFU mode