



PS shortcut key

canvas adjustment



Mac OS only supports rotating the canvas clockwise, and rotating the canvas counterclockwise conflicts with the system

brush adjustment



1 means that the value increases by 1 every time you rotate 1 grid, and 10 means that the value increases by 10 every time you rotate 1 grid

- ▶ 不透明度
 - ▶ Set this key value to the knob to adjust the opacity of the brush. It needs to be set to the clockwise and counterclockwise keys of the knob at the same time. When turning, the opacity value of the brush will be increased or decreased according to the direction of the knob
- ▶ 画笔流量
 - ▶ Set this key value on the knob to adjust the flow rate of the brush. It needs to be set to the clockwise and counterclockwise keys of the knob at the same time. When turning, the value of the brush flow will increase or decrease according to the direction of the knob.
- ▶ 画笔平滑度
 - ▶ Set this key value to the knob to adjust the smoothness of the brush. It needs to be set to the clockwise and counterclockwise keys of the knob at the same time. When turning, the smoothness value of the brush will increase or decrease according to the direction of the knob



When using PS shortcut keys to adjust the "opacity, flow, smoothness" of the brush, it is not limited by the system



Translated to: [English](#)

Show original

Options ▼