



# IMPORTANT INFORMATION

---

This notice includes information related to your rosco\_m68k keyboard (revision one) product. Please read this sheet carefully and retain for your reference.

## 1. Errata – Power LED

The power LED (D69) **does not support an RGB LED as indicated by the silkscreen**. Instead, a regular LED should be mounted between pins 1(the leftmost pin) and 3 – a standard 5mm LED should fit perfectly in this configuration.

**Additionally, this LED should be mounted “backwards” when compared to the other LEDs, such that the anode (the long lead) is at pin 1.**

**Ensure you do not bridge any of the unconnected pins when soldering this LED.**

In command mode, this LED is controlled as LED1, and it should be lit when the keyboard first receives power.

## 2. Unused Connectors

There are several connectors and components on the board which exist for factory testing or future expansion only and should not be populated or used:

- J1
- J2
- D70
- Lower row of J3
- Unmarked pins on J4
- J5
- J7
- J8
- SW1
- U2

Populating or attempting to use any of these components may cause your board to operate incorrectly, and in certain cases may even cause irreparable damage.

**Warranty claims against boards where any of the above components are populated will be subject to a complete technical evaluation and are likely to be rejected.**