

BananaPro/Pi:CAN Bus

From BananaPro/Pi

CAN Bus

In order to port can4linux (<https://web.archive.org/web/20200129141042/http://sourceforge.net/projects/can4linux/>) to the BananaPi, the CAN module description is needed from the A20 hardware manual. can4linux is a character-driver-based Linux driver used already on desktop PCs and embedded platforms like Freescale FlexCAN (the i.MX series of micro controllers) or Xiliny Zynq.

There is a more detailed document about CAN on the A20 at [1]
(<https://web.archive.org/web/20200129141042/https://dl.linux-sunxi.org/A20/CAN%20Bus1.pdf>)

can4linux was succesful ported to the BananaPi. To use it, an external transceiver is required. Take care of the 3.3 V IO pins. Best to use a 3.3 V Transceiver like the TI SN65HVD230. The driver sould also work on the Banana Pro.

Retrieved from "http://wiki.lemaker.org/index.php?title=BananaPro/Pi:CAN_Bus&oldid=1219"