

2 INSTALLATION

2.13 Electrical Requirements

1. Heaters operate on 120 volts, 60 Hz, single phase. The maximum amperage requirement (starting current) is 4.8 amps per heater. The running current is 1.1 amps.
2. Heater must be grounded in accordance with the Canadian Electrical Code C22.1 (latest edition).
3. Wiring must not be exposed to direct radiant output.

2.14 Thermostat Wiring:

One Two-Stage Thermostat and
One Two-Stage Series Heater


The Burner box contains a 24 volt transformer that operates the control circuits. The thermostat is part of this circuit. When installing a “snap action” CE-2S or “mercury cell” 1F37-408 thermostat a three wire connection is required.

White - 24 volt from the heater to the thermostat terminal (R).

Black - 1st stage 24 volt from the thermostat (W1).

Red - 2nd stage 24 volt from the thermostat (W2).
See Figure 2.13.1.

When utilizing a thermostat that requires a constant 24 volt power supply such as the HL 201 or other programmable thermostat, a fourth wire will be required. Attach this wire to heater chassis. See Figure 2.13.1.



NOTE: 120V supply will incorporate a cord and plug, secured by a liquid-tight connector.
24V control wiring will incorporate 5 ft. (1.5m) cord, secured by a liquid-tight connector.

Figure 2.13.1

2 INSTALLATION

2.15 Thermostat Wiring:

One Two-Stage Thermostat and Multiple Two-Stage Series Heaters

The Burner box contains a 24 volt transformer that operates the control circuits. When more than one heater is operated with a single thermostat, the 24 volt control circuit of each heater must be isolated. A factory supplied isolation relay HL-RB must be installed. See Figure 2.15.1 for internal wiring. Heaters with factory installed relay boards are labeled "Equipped with HL-RB". See Figure 2.15.2. The thermostat is not part of the burner control circuit, therefore an external (installer-supplied) 24 volt transformer will be required to operate all HL-RB's. Each HL-RB draws .03 amps. All heaters equipped with the HL-RB will use three wires to operate the relays:

Connect 24 volt from installer supplied transformer to thermostat terminal (R).

White - Connect common 24 volt from installer supplied transformer to the 24 volt on heater.

Black - 1st stage 24 volt from the thermostat (W1).

Red - 2nd stage 24 volt from the thermostat (W2)

See Figure 2.15.2.

Wiring from thermostat to heater does not change due to thermostat type. Wiring from external transformer to thermostat may change. Refer to thermostat installation instructions.




Figure 2.15.1




Figure 2.15.2

2 INSTALLATION

2.16 Lighting Instructions

1. Purge main gas supply line at start-up.
2. Rotate heater's manual gas valve knob to the "ON" position.
3. Close electrical circuit.
4. If heater fails to light, turn off gas and wait five minutes before repeating the above procedure.

2.17 Shutdown Instructions

1. Open electrical circuit.
2. Rotate heater's manual gas valve knob to the "OFF" position.

Instructions pour l'allumage

1. Purger la conduite d'alimentation en gaz principale.
2. Tourner le bouton du robinet de gaz a commande manuelle jusqu'a ce qu'il se trouve en position de marche ("ON").
3. Fermer le circuit electrique.
4. Si l'appareil de chauffage ne s'allume pas, attendre 5 minutes avant de suivre de nouveau les instructions ci-dessus.

Pour eteindre l'appareil

1. Ouvrir le circuit electrique.
2. Tourner le bouton du robinet de gaz a commande manuelle de l'appareil de chauffage jusqu'a ce qu'il se trouve en position d'arret ("OFF").

3 THEORY OF OPERATION

3.1 Micro 60U24 Control

STANDBY

The Micro 60U24 circuit control continually checks for internal faults, safety circuit integrity and relay contact positioning.

STARTING CIRCUIT

Upon a call for heat, the control will verify that the burner and exhaust safety pressure switches are in their proper position. The fan relay energizes the fan, an operational static pressure is achieved and the normally open burner switch will close, initiating the ignition sequence. The glo-bar is powered and after 45 seconds the main gas valve opens.

FIRST STAGE RUNNING CIRCUIT

After ignition, the flame-rod monitors the main burner flame. If flame is lost, the control acts to close the gas valve within one second and a new trial sequence identical to the start-up is initiated. If proof is not established within 8.5 seconds, the unit will retry 2 times and proceed to a hard lock-out. The control can be reset by interrupting the power source or thermostat.

SECOND STAGE RUNNING CIRCUIT

Stage two on the gas valve is powered directly from the second stage of the thermostat. The gas valve will not pass gas unless the first stage sequence of operation has been completed. The thermostat will determine which stage is required to maintain the desired comfort level.

SHUTDOWN

When the thermostat is satisfied the fan will enter into a two minute post-purge cycle.

LOCKOUT CODES

In event of a component failure, a red LED diagnostic light located on the burner box end panel will flash a code identifying the fault. Lockout codes are summarized below.

LED STATUS	FAULT CODE
Initial flash on power up, then steady off	Normal Operation
Steady On	Module Failure/ Internal Fault
1 Flash	Ignition Fault
2 Flashes	APS1 Fault
3 Flashes	APS2 Fault
4 Flashes	Solenoid Valve Fault/ Leaky Valve/ Flame amplifier Fault
No flash upon initial 117 V power up	Transformer Fault




Figure 3.1.1




Figure 3.1.2

4 SERVICE

4.1 Maintenance

The gas fired infra-red heaters require a minimum of routine maintenance to keep them operating at peak performance.

1. Prior to the heating season heater operation must be verified by qualified service personnel.
2. Ensure that the blower impeller is kept clean. If dirt becomes a problem, installation of outside air intake duct for combustion is recommended. Oiling the blower motor will extend bearing life beyond the 30,000 hour minimum.
3. Keep the aluminum reflectors from accumulating deposited material.



WARNING

Use protective glasses when cleaning the heater.

4.2 Wash-down

During the wash-down of an animal confinement installation observe the following recommendations -



WARNING - ELECTRICAL HAZARD

1. Unplug the heater's 120 Volt cord & plug from the ceiling receptacle before power washing room.
2. Avoid direct contact of power-washer with heater control box.
3. Reflectors, radiant tubes and intake ducts can be thoroughly cleaned.
4. Allow heaters to dry thoroughly, reinstall cord & plug, start heater and operate for minimum of 15 minutes.
5. DO NOT allow heaters to sit for extended time periods (days) after wash-down before starting.

4.3 GENERAL TROUBLE SHOOTING

GENERAL TROUBLESHOOTING CHART FOR 2-STAGE SERIES EQUIPPED WITH MICRO 60U24 CONTROL

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
Thermostat closed. - NO LED FLASH CODE	1. Blown fuse. 2. Faulty thermostat. 3. Disconnected wire. 4. No 24 volt signal.	1. Replace. 2. Replace. 3. Repair. 4. Interrupt 120 volt supply, LED will flash once if 24 volt is present.
Thermostat closed. - LED CODE STEADY ON	1. Internal fault in circuit control module.	1. Replace.
Thermostat closed. - LED CODE 1 FLASH	1. Faulty glo-bar. 2. Faulty flame sensor. 3. Gas valve not opening. 4. Gas orifice plugged. 5. Restriction in main burner.	1. Replace. 2. Replace. 3. Replace. 4. Remove, clean and reinstall. 5. Remove, clean and reinstall.
Thermostat closed. - LED CODE 2 FLASHES	1. Burner pressure switch fault. 2. Burner switch bypassed.	1. Replace. 2. Remove jumper wires.
Thermostat closed. - LED CODE 3 FLASHES	1. Exhaust pressure switch fault. 2. Blocked flue.	1. Replace. 2. Clean.
Thermostat closed. - LED CODE 4 FLASHES	1. Wire disconnected on valve. 2. Gas valve fault. 3. Flame rod fault.	1. Reconnect. 2. Replace. 3. Replace.
Heater Operating - TUBE BOWING	1. Insufficient combustion air. 2. Overfired. 3. Ensure exchangers have room to expand. 4. Heater not supported properly. 5. Reflectors not positioned properly.	1. Check intake duct for blockage and sizing. 2. Check gas pressure. 3. Re-install vent connection. 4. Re-position hangers or chains. 5. Re-position.
Heater Operating - VENT CONDENSING	1. Stack length too long. 2. Light gauge flue pipe used. 3. Uninsulated vent pipe running through cold space. 4. Negative pressure in building. 5. Common vented heaters installed with individual thermostats.	1. Shorten stack. 2. Minimum 26 Ga. Required. 3. Insulate vent. 4. Install combustion air intake. 5. Install one thermostat.
Odor or fumes in space.	1. Vaporized solvents decomposing when contacting radiant tubes. 2. Lift trucks. 3. Loose tube connections.	1. Install exhaust fan at ceiling. 2. Install exhaust fan and repair. 3. Tighten to 50-60 lb.-ft.

5.1 BASIC PARTS LIST

<i>Part No.</i>	<i>Description</i>	<i>Part No.</i>	<i>Description</i>	<i>Part No.</i>	<i>Description</i>
TP-1	Control Box Cover	TP-61D	Burner Pressure Switch (Tridelta #FS6581-1047)	TP-218	Exhaust Pressure Tube (Vinyl)
TP-3	#8 x 1/4" Sheet Metal Screw		#8 x 1/2" Machine Screw	TP-219	Transformer 25V (HL-T)
TP-4	Control Box	TP-62	Heat Diffuser (Baffle)	TP-221	Glo-Bar Gasket
TP-5	Flange Gasket	TP-65	2" x 4" Outlet Box	TP-222	Flame Rod
TP-7	1/4-20 x 1/2" Machine Screw	TP-66	2" x 4" Outlet Box Cover	TP-224	Manifold (HL-MFD)
TP-7A	1/4-20 Hex Nut	TP-67	Strain Relief Bushing	HL-60MH	Micro-60 Harness
TP-9	Conduit Coupling	TP-68A	Control Box Gasket	HL-60MIL	Diagnostic LED Lights
TP-10	Conduit 1/2" x 4"	TP-70	Rubber Grommet	HL-78M	Micro-60 Self Diagnostic Board
TP-11	Glo-Bar Box	TP-76	#6-32 x 1" Machine Screw	NOTE: When ordering heater parts, please state the model and serial number of the heater.	
TP-12	Glo-Bar Box Cover	TP-80	#6-32 Hex Nut		
TP-13	#8 x 1/2" Self-Drilling Screw	TP-81	Flexible Gas Connector		
TP-14	Sight Glass Gasket	TP-83	1/2" Adapter Fitting	5.2 Optional Parts	
TP-15	Sight Glass	TP-101	1/2" x 2" Pipe Nipple		
TP-16	Sight Glass Washer	TP-104	Reflector End Cap (BR-ECR)		
TP-17	1/4-20 x 3/8" Thread-Cutting Screw	TP-105	Reflector Clip (BR-ECRC)		
TP-19B	Tube/Reflector Hanger (BR-4HGR)	TP-106	Air Inlet Gasket	<i>Item No.</i>	<i>Description</i>
TP-19C	Reflector Center Support (BR-4IH)	TP-122	Burner (50,000 to 100,000 BTUH)	SK-4VC	Vent Cap
TP-20	Refector (120")	TP-200	(TP-B1P)		(Required For Sidewall Venting on 200,000 BTU)
TP-21	Tube Clamp		Burner (125,000 to 200,000 BTUH)	BR-VCF	Exhaust Vent w/Flapper
TP-26	10 ft. Radiant Tube, Straight	TP-201	(TP-B2)		(Required on Unvented Models)
TP-26T	10 ft. Radiant Tube, Straight (AL-TI)		16" Burner Tube (HL-16P)	BR-VC	Wall Inlet Vent w/Screen
TP-31B	Control Box Bracket	TP-202	Gas Orifice (TP-46)	BR-4-VK	Side Wall Venting Kit (also SK4-VK)
TP-41	1/4-20 Keps Nut	TP-204	Glo-Bar Holder	TF-9	Truck Exhaust Terminal for Side Wall Venting
TP-44	Inlet Air Orifice w/Screen	TP-205	End Panel-Left		Wall Venting
TP-50	Globar Ignitor	TP-206	End Panel-Right	SK-6VC	Vent Cap (Required for Dual Side Wall Vents)
TP-54	Burner Box Divider	TP-207	"Z" Bracket		Side Shield Extension
TP-55	Fan Blower	TP-208	36E96 2-Stage Gas Valve	BR-NIR	Gas Cock
TP-56C	1/4" Atmosphere Tube (vinyl)	TP-210	(State N.G. Or L.P.)(HL-75)	TP-33B	
TP-57A	1/4 " Pressure Tube		3" x 1/2" Pipe Nipple		
TP-59	#8 Hex Nut/Lock Washer	TP-212	T'Stat Plug (HL-TP)		
TP-60H	Exhaust Pressure Switch (Tridelta #FS6628-1654)(State BTU's)	TP-213	Indicator lights (HL-L)		
		TP-216	Pressure Barb Fitting		
		TP-217			

