


Set Up : Correct Calibration

- ① Step 1: Make sure that the POWER is on, the EMERGENCY OFF is off, and the Aux is in.



- ## ② Step 2: Time to Calibrate!

- a. Check X value by pressing $+X 100$ and $-X 100$ in Repetrel and head moves left and right, respectively.
- b. Measure the distance between the starting position and ending position and make sure it moves exactly 100 mm.
- c. If the moving distance is inaccurate, adjust the X-value in motor scale. (settings \rightarrow printer \rightarrow hardware setup)
- d. Repeat for the Y-values.

