

1. Download and install the ST-Link USB driver from ST website under the following link

<https://www.st.com/en/development-tools/stsw-link009.html>

2. Short overview



STSW-LINK009

USB driver for ST-LINK/V2, ST-LINK/V2-1 and STLINK-V3

Data brief

Features

- Digitally signed driver
- WinUSB CoInstallers for 32-bit and 64-bit versions of Windows® 7, 8 and 10.

Description

This USB driver (STSW-LINK009) is for ST-LINK/V2, ST-LINK/V2-1 and STLINK-V3 boards and derivatives (STM8/STM32 discovery boards, STM8/STM32 evaluation boards and STM32 Nucleo boards). It declares to the system the USB interfaces possibly provided by the ST-LINK: ST Debug, Virtual COM port and ST Bridge interfaces.

The driver must be installed prior to connecting the device, in order to have a successful enumeration.

Note: ST-Link V2-1 and ST-Link V2-A are basically the same.