



SERIAL-TO-WIFI ADAPTER

APPLICATION PROGRAMMING GUIDE

2.5.1/3.5.1

Reference: GS-S2WF-APG
Version: SP-5.15
Date: 16-August-2013

Version	Date	Remarks
5.6	13-Apr-12	<ul style="list-style-type: none"> ▶ Document is updated for S2W ver 2.4.1/3.4.1 ▶ Merged with GS1500M S2W APG ▶ Network Connection Manager ▶ Network Interface MDNS Support ▶ ARP Cache ▶ GSLink Support
5.7	30-May-12	<ul style="list-style-type: none"> ▶ Updates to section 4.21 commands for Wi-Fi direct support for GS1500M
5.8	6-Jul-12	<ul style="list-style-type: none"> ▶ Updates for Profile Definitions ▶ Set Transmit Rate GS1500M support ▶ Bulk Mode Data Transfer GS1500M support
5.9	24-Jul-12	<ul style="list-style-type: none"> ▶ Updated 4.19.2 Node Startup Handling when using SPI interface
5.10	9-Aug-12	<ul style="list-style-type: none"> ▶ Updated 4.10.14 HTTPSEND command to reflect <CID> when sending data using POST method. ▶ Updated MULTICAST Reception description ▶ AT+FLASH commands removed as they are not supported ▶ Updated for GA releases 2.4.1 and 3.4.1
5.11	18-Sept-12	<ul style="list-style-type: none"> ▶ Updated to reflect ATO support on GS1500M ▶ Updated section 4.8.7 to reflect usage for PEAP with Certificates
5.12	1-Oct-12	<ul style="list-style-type: none"> ▶ Updated Bulk Data Mode data length description in section 3.4.1 ▶ Updated range and default values for scan time ▶ Updated AT+PHYMODE command description in section 4.7.7.1/2 ▶ Added support for client certificate and client key to Section 4.10.9 SSLOPEN and 4.10.13 HTTPOPEN ▶ Updated section 4.11.1, Start/Stop Webserver default value description
5.13	31-Oct-12	<ul style="list-style-type: none"> ▶ Updated default values of the factory defaults table in section 4.8.16
5.14	16-Aug-13	<ul style="list-style-type: none"> ▶ Updated to match release 2.4.3/3.4.3 ▶ Added at+webprovstop command section 4.16.3 ▶ Updated NCMAuto command (4.15.1) to reflect flag enable/disable parameter
5.15	16-Aug-13	<ul style="list-style-type: none"> ▶ Updated mDNS initialization ▶ Mac filter Support

		<ul style="list-style-type: none">▶ PS POLL feature support▶ Frame size configuration for NCM▶ GSLink Response timeout support.▶ HTTP redirect support.▶ Roaming Support▶ Web prov stop support
--	--	--

Copyright © 2009-2013 by GainSpan Corporation.

All rights reserved.

GainSpan Corporation

+1 (408) 627-6500

info@GainSpan.com

www.GainSpan.com

GainSpan and GainSpan logo are trademarks or registered trademarks of GainSpan Corporation.

Specifications, features, and availability are subject to change without notice.

Table of Contents

1	SYSTEM OVERVIEW	10
1.1	PURPOSE	10
1.2	SCOPE	10
1.3	OVERVIEW	10
1.4	TERMINOLOGY	10
1.5	STANDARDS	11
2	INTERFACE ARCHITECTURE	12
3	ADAPTER DESCRIPTION	14
3.1	SYSTEM INITIALIZATION	14
3.1.1	<i>External PA Auto Detection</i>	15
3.1.2	<i>Network Configurations</i>	15
3.1.3	<i>Profile Definition</i>	18
3.2	COMMAND PROCESSING MODE	21
3.3	AUTO CONNECTION	22
3.3.1	<i>Auto Connection Operation</i>	25
3.4	DATA HANDLING	25
3.4.1	<i>Bulk data Tx and Rx</i>	27
3.4.2	<i>Raw Data Handling (BACNET Support Only)</i>	29
3.4.3	<i>Unsolicited Data Handling</i>	30
3.4.4	<i>Software Flow Control</i>	30
3.4.5	<i>Hardware Flow Control</i>	30
3.5	SERIAL DATA HANDLING	31
3.6	CONNECTION MANAGEMENT	31
3.6.1	<i>Packet Reception</i>	31
3.6.2	<i>Remote Close</i>	31
3.6.3	<i>TCP Server Connections</i>	32
3.7	WIRELESS NETWORK MANAGEMENT	33
3.7.1	<i>Scanning</i>	33
3.7.2	<i>Association</i>	33
3.7.3	<i>Response Codes</i>	34
3.7.4	<i>Enhanced Asynchronous Messages</i>	36
3.7.5	<i>Exception Messages</i>	37
3.7.6	<i>Boot Messages</i>	38
3.7.7	<i>SSID and Passphrase</i>	38
4	COMMANDS FOR COMMAND PROCESSING MODE	40
4.1	COMMAND INTERFACE	40
4.1.1	<i>Interface Verification</i>	40
4.1.2	<i>Echo</i>	40
4.1.3	<i>Verbose</i>	40
4.1.4	<i>Help</i>	41
4.2	UART INTERFACE CONFIGURATION	41

4.2.1	UART Parameters	41
4.2.2	Software Flow Control	41
4.2.3	Hardware Flow Control	41
4.3	SPI INTERFACE CONFIGURATION	42
4.3.1	SPI Parameters	42
4.4	SERIAL TO Wi-Fi CONFIGURATION *	42
4.5	IDENTIFICATION INFORMATION	44
4.6	SERIAL TO Wi-Fi CONFIGURATION PROFILES	44
4.6.1	Save Profile	44
4.6.2	Load Profile	45
4.6.3	Selection of Default Profile	45
4.6.4	Restore to Factory Defaults	45
4.6.5	Output current configuration	45
4.7	Wi-Fi INTERFACE CONFIGURATION	46
4.7.1	MAC Address Configuration	46
4.7.2	Output MAC Address	46
4.7.3	Regulatory Domain Configuration	46
4.7.4	Regulatory Domain Information	47
4.7.5	Setting/Getting Scan Time	47
4.7.6	Scanning	48
4.7.7	Mode	49
4.7.8	Associate with a Network, or Start an Ad Hoc or Infrastructure (AP) Network	50
4.7.9	Disassociation	51
4.7.10	WPS	51
4.7.11	Status	52
4.7.12	Get RSSI	53
4.7.13	Set Transmit Rate	53
4.7.14	Get Transmit Rate	54
4.7.15	Set Retry count	56
4.7.16	Get Clients Information	56
4.7.17	MAC filter	56
4.7.18	Limited AP PS Mode	57
4.8	Wi-Fi SECURITY CONFIGURATION	57
4.8.1	Authentication Mode	57
4.8.2	Security Configuration	57
4.8.3	WEP Keys	58
4.8.4	WPA-PSK and WPA2-PSK Passphrase	58
4.8.5	WPA-PSK and WPA2-PSK KEY CALCULATION	58
4.8.6	WPA-PSK and WPA2-PSK KEY	59
4.8.7	EAP-Configuration	59
4.8.8	EAP	60
4.8.9	Certificate Addition	60
4.8.10	Certificate Deletion	61
4.8.11	Enable/Disable 802.11 Radio	61
4.8.12	Enable/Disable 802.11 Power Save Mode	61
4.8.13	Set Power Save Mode Used During Association	62
4.8.14	Enable/Disable Multicast Reception	62
4.8.15	Antenna Configuration **	63
4.8.16	To get currently active antenna **	64

4.8.17	Transmit power	64
4.8.18	Sync Loss Interval	64
4.8.19	External PA *	64
4.8.20	Association Keep Alive Timer *	64
4.8.21	IEEE Optimized PS Poll Interval	65
4.8.22	WLAN Keep Alive Interval **	65
4.8.23	Configure Antenna Diversity Feature **	65
4.9	NETWORK INTERFACE	66
4.9.1	Network Parameters.....	66
4.9.2	DHCP Client Support	66
4.9.3	Static Configuration of Network Parameters.....	67
4.9.4	MDNS Module Initialization	67
4.9.5	MDNS Host Name Registration	67
4.9.6	MDNS Host Name De-Registration	67
4.9.7	MDNS Services Registration.....	68
4.9.8	MDNS Services De-Registration.....	68
4.9.9	MDNS Services Announce.....	68
4.9.10	MDNS Service Discover.....	68
4.9.11	MDNS Module De-Initialization	69
4.9.12	DHCP Server	69
4.9.13	DNS Server.....	69
4.9.14	DNS Lookup (Client).....	69
4.9.15	Static Configuration of DNS (Client).....	70
4.9.16	Store Network Context	70
4.9.17	Restore Network Context.....	70
4.9.18	ARP CACHE ENABLE.....	71
4.9.19	ARP DELETE.....	71
4.9.20	ARP ENTRY LISTING.....	71
4.10	CONNECTION MANAGEMENT CONFIGURATION	71
4.10.1	Network Interface Filter.....	71
4.10.2	TCP Clients	72
4.10.3	UDP Clients	72
4.10.4	TCP Servers	73
4.10.5	UDP Servers.....	73
4.10.6	Output Connections.....	73
4.10.7	Closing a Connection.....	74
4.10.8	Closing All Connections.....	74
4.10.9	SOCKET Options Configuration.....	74
4.10.10	SSL Connection Open.....	75
4.10.11	Closing SSL connection.....	75
4.10.12	HTTP Client Configuration.....	76
4.10.13	HTTP Client Configuration Removal.....	77
4.10.14	HTTP Client Connection Open.....	78
4.10.15	HTTP Client Get/Post.....	78
4.10.16	Closing HTTP Client	79
4.10.17	Enable/Disable Bulk Mode Data Transfer	79
4.10.18	Enable / Disable Raw Ethernet Support.....	79
4.10.19	Unsolicited Data Transmission *	80
4.11	GSLINK.....	81

4.11.1	Start/Stop Webserver.....	81
4.11.2	Enabling/Disabling XML Parser on HTTP Data.....	81
4.11.3	XML Data Send.....	82
4.11.4	XML Data Receive	82
4.11.5	URI Modification	82
4.12	BATTERY CHECK *	83
4.12.1	Battery Check Start *	83
4.12.2	Battery Warning/Standby Level Set *	83
4.12.3	Battery Check Set *	83
4.12.4	Battery Check Stop *	84
4.12.5	Battery Value Get *	84
4.13	POWER STATE MANAGEMENT	84
4.13.1	Enable/Disable SoC Deep Sleep	84
4.13.2	Request Standby Mode	85
4.14	AUTO CONNECTION	86
4.14.1	Wireless Parameters	86
4.14.2	Network Parameters.....	86
4.14.3	Enable Auto Connection.....	87
4.14.4	Initiate Auto Connect	87
4.14.5	Initiate Auto Connect – TCP/UDP Level *	87
4.14.6	Exit from auto connect data Mode	87
4.14.7	Return to Auto Connect Mode.....	88
4.15	NETWORK CONNECTION MANAGER (NCM)	88
4.15.1	NCM Start/Stop	88
4.15.2	NCM Configuration	89
4.15.3	NCM AP Configuration Enable	89
4.15.4	Limited AP Parameter Restore	90
4.16	ROAMING	90
4.17	PROVISIONING	91
4.17.1	Web Provisioning Start	91
4.17.2	Web Provisioning Stop.....	93
4.17.3	Web Provisioning (Logo).....	93
4.17.4	Httpd redirection.....	93
4.18	RF TESTS.....	94
4.18.1	Module RF Tests GS1011M	94
4.18.2	RF Tests GS1500M	96
4.19	MISCELLANEOUS	102
4.19.1	Enhanced Asynchronous Notification.....	102
4.19.2	Node Start Up Handling.....	102
4.19.3	Firmware Upgrade *.....	103
4.19.4	SPI Interface Handling.....	103
4.19.5	Pin connection for SPI Interface.....	104
4.19.6	Factory Default Section	105
4.19.7	Set System Time.....	106
4.19.8	Set System Time Using SNTP.....	106
4.19.9	Get System Time.....	107
4.19.10	GPIO Out HIGH/LOW	107
4.19.11	Error Counts.....	107
4.19.12	Version.....	107

4.19.13	Ping.....	108
4.19.14	Trace Route	108
4.19.15	Memory Trace.....	109
4.19.16	Reset	109
4.19.17	WLAN statistics.....	109
4.20	OVER THE AIR FIRMWARE UPGRADE USING EXTERNAL FLASH.....	111
4.20.1	FWUP Configuration.....	111
4.20.2	FWUP Start.....	112
4.21	GS1500M WiFi DIRECT (P2P) COMMANDS **	113
4.21.1	P2P mode configuration **.....	113
4.21.2	Set P2P Device **.....	113
4.21.3	Set WPS configuration **	114
4.21.4	Set P2P Attribute **.....	114
4.21.5	P2P Find **.....	114
4.21.6	P2P Stop Find **.....	115
4.21.7	P2P Listen **.....	115
4.21.8	P2P Group Owner Start **.....	115
4.21.9	Provisioning Discovery **.....	116
4.21.10	Group Form (Group Owner Negotiation) **.....	117
4.21.11	Client Join **.....	120
4.21.12	Invitation Procedures **.....	120
4.21.13	P2P Disconnect **.....	121
4.21.14	P2P Store/Restore NW Connection **.....	121
5	REFERENCES	122
6	APPENDIX.....	123
6.1	DATA HANDLING USING ESC SEQUENCES ON UART INTERFACE	123
6.2	DATA HANDLING USING ESC SEQUENCES ON SPI INTERFACE	127

*** Not Supported on the GS1500M**

**** Not Supported on the GS1011M**

Figures

Figure 1: Overall Architecture of the Adapter	Error! Bookmark not defined.
Figure 2: Operating Modes of the Adapter	Error! Bookmark not defined.
Figure 3: Creation and Use of a TCP Client	Error! Bookmark not defined.
Figure 4: Creation and Use of a TCP Server	Error! Bookmark not defined.
Figure 5: Creation and Use of a UDP Client	Error! Bookmark not defined.
Figure 6: Creation and Use of a UDP Server	Error! Bookmark not defined.
Figure 7: TCP Client Operation in Auto Connect Mode	Error! Bookmark not defined.
Figure 8: TCP Server Operation in Auto Connect Mode	Error! Bookmark not defined.
Figure 9: UDP Client Operation in Auto Connect Mode	Error! Bookmark not defined.
Figure 10: UDP Server Operation in Auto Connect Mode	Error! Bookmark not defined.
Figure 11: Data Processing Flow	Error! Bookmark not defined.

Tables

Table 1: Glossary of Terms	Error! Bookmark not defined.
Table 2: Profile Parameters	Error! Bookmark not defined.

1 System Overview

1.1 Purpose

This document describes the operation and serial command interface for the GainSpan GS1011M or GS1500M *Serial2WiFi Adapter*. The Serial2WiFi Adapter enables embedded devices with a UART/SPI interface to gain access to an IP network over an 802.11-compliant (Wi-Fi®) wireless network connection, using only serial commands.

1.2 Scope

This document reviews the architecture of the Serial2WiFi software and provides the programmer with necessary command syntax required to manage the Wi-Fi interface and send and receive network messages. This document assumes that the reader is generally familiar with GainSpan SOC products, Internet Protocol (IP) networks and the operation and management of 802.11 wireless devices.

1.3 Overview

The Serial2WiFi stack is used to provide Wi-Fi Capability to any devices having a serial interface. This approach offloads WLAN, TCP/IP stack and network management overhead to the Wi-Fi chip, allowing a small embedded host (for example an MCU) to communicate with other hosts on the network using a Wi-Fi wireless link. The host processor can use serial commands to configure the Serial2WiFi Adapter and to create wireless and network connections.

1.4 Terminology

Table 1: Glossary of Terms

<i>Term</i>	<i>Explanation</i>
AP	Access Point
API	Application Programmer's Interface
BSSID	Basic Service Set Identifier
CID	Connection Identifier
CPL	Clock Polarity
CPH	Clock Phase
DHCP	Dynamic Host Configuration Protocol
DIN	Data Input

<i>Term</i>	<i>Explanation</i>
DOUT	Data Output
IP	Internet Protocol
MSPI	Master SPI
MTU	Maximum Transfer Unit
PSK	Pre-shared key
RSSI	Received Signal Strength Indication
SSID	Service Set Identifier
SPI	Serial Peripheral Interface
SSPI	Slave SPI
TCP	Transmission Control Protocol
UART	Universal Asynchronous Receiver/Transmitter
UDP	User Datagram Protocol
WEP	Wired Equivalent Privacy
WPA	Wi-Fi Protected Access
PA	Power Amplifier

1.5 Standards

The following standards and conventions are considered in this design:

- ▶ IEEE 802.11 a/b/g
- ▶ ITU V.25ter AT Command Set

2 Interface Architecture

The overall architecture of the Serial2WiFi interface is depicted in Figure 1. Tx and Rx Data Handlers pass messages to, and from, the TCP/IP network. Commands related to management of the Serial2WiFi interface and the network connections are intercepted by a Command Processor. A Serial Data Handler translates data to and from a UART/SPI-compatible format.




Figure 1: Overall Architecture of the Adapter

The system is composed of the following modules:

- ▶ System Initialization (section 3.1)
- ▶ Command Processor (section 3.2)
- ▶ Data Handlers (section 3.4)
- ▶ Serial Data Handler (section 3.5)
- ▶ Network Connection Manager (section 3.6)
- ▶ Wireless Connection Management (section 3.7)

The software for the Serial2WiFi Adapter is mainly driven using a state machine. Upon powering on, the required initialization of all the modules is performed and then the state machine is entered. This state machine is event-driven and processes the events received from either the serial port or from the Wi-Fi / Network interface as well as internal events from its own modules. The state machine calls the appropriate handler for a given event per the current state.

The Serial2WiFi Adapter has three distinct operating modes (Figure 2). In the default **command processing operating** mode, commands to configure and manage the interface are sent over the serial interface. In the default mode, the node accepts commands entered by the Host CPU and processes each

of the commands. All commands are available in this mode. The User can establish a data connection here and send data.

In ***auto connection*** mode, data sent over the serial interface is transparently sent over the IP network to a single, pre-configured IP address/port pair, where data from that address is transparently sent over the UART/SPI to the serial host. With Auto mode, the IP Layer connections are already established and the data is sent directly to the target destination. In this mode, the node does not accept all commands. To accept commands the node needs to be brought back to “Command Processing” mode.

In ***data processing*** mode, data can be sent to, or received from, any of 16 possible connections. Each connection consists of a TCP or UDP path to a destination IP address and port. Auto connection mode is entered using a serial command (section 4.14.4) and terminated using a special escape sequence (section 3.4).

For each mode, configuration parameters are stored in non-volatile memory. In addition to factory-default parameter values, two user-defined profiles (0 and 1) are available. The parameter set to be used is determined by a user command (section 4.6.3).

3 Adapter Description

3.1 System Initialization

Upon startup, the Serial2WiFi interface performs the following actions, depicted graphically in Figure 2.

- ▶ During the initialization process, the module will search for a saved configuration file. The configuration file include the auto connection settings, default profile and profile settings. If a saved configuration file is available, it is loaded from non-volatile memory. If no saved configuration file, the default settings will be applied. If there are no saved parameters, the factory-default configuration is loaded.
- ▶ The Serial2WiFi application is initialized based on the profile settings.
- ▶ If auto connection is enabled, the interface will attempt to associate with the specified network, previously set by the user (section 4.14.1). Once associated, it will establish a TCP or UDP connection within the specified parameters. If successful, the interface will enter the Auto Connect mode, where all data received on the serial port is transmitted to the network destination and vice versa.
- ▶ If auto-connection is disabled or fails, the interface enters the command processing state.




Figure 2: Operating Modes of the Adapter

Upon power-up, the UART interface defaults to 9600 baud, using 8 bit characters with no parity bits and one stop bit. Similarly SPI interface defaults to Mode#0 (CPL=0, CPH=0). Any changes to this configuration that were made in a previous session using the ATB command (section 4.2.1) will be lost when power is lost. To make changes in the UART/SPI parameters that will persist across power cycling, the relevant changes must be saved into the power-on profile using AT&W (section 4.6.1) and AT&Y (section 4.6.3).

3.1.1 External PA Auto Detection

Upon startup, the Serial2WiFi interface performs an auto detection of External PA. This detection is done through the GPIO pin 12. If this GPIO is “high” during startup, meaning the external PA is present; the adapter enables the external PA and forces the adapter to go into and out of standby mode for a moment just to make any changes effective for the external PA configuration. On the GS1011M modules this pin is configured internally, so software by default configures the modules appropriately.

3.1.2 Network Configurations

Once associated, the adapter supports instances of four types of network entities: TCP client, TCP server, UDP client and UDP server. Each client, or server, is associated with one or more of a possible 16 **Connection Identifiers**, where the CID is a single hexadecimal number. More than one such entity can exist simultaneously; and a TCP server can have multiple connections, each with its own CID. When the adapter is in Auto Connect mode (section 3.3), the entity called for by the Profile is created automatically upon startup. In Command modes, servers and clients are created using specific serial commands (section 4.10).

A TCP client (Figure 3) is created with the serial command AT+NCTCP (section 4.10.1). The client attempts to create a TCP network connection with the destination IP address and port specified within the command. If successful, it issues a CONNECT response with the CID of the client. Data can then be sent to the remote server using the <Esc>S *n* sequence (section 3.4) with the appropriate CID. Data from the server is passed back to the Host, with the CID to identify its source.




Figure 3: Creation and Use of a TCP Client




Figure 4: Creation and Use of a TCP Server

Figure 4 schematically depicts the corresponding sequence for a TCP server. A server is created with the serial command AT+NSTCP; it receives a CID, but listens passively until a remote client requests a connection. If that connection is successfully created, a second CONNECT message and a new CID are provided to the Host. It is this second CID that is used to send data to the remote client and identify received data from that client. A TCP server may support multiple clients, each with a unique CID.

A UDP client's life is depicted in Figure 5. The client is created with the serial command AT+NCUDP and receives a CID. The UDP client is associated with a specific destination port and address.




Figure 5: Creation and Use of a UDP Client

Finally, Figure 6 shows a UDP server. The server is created with AT+NSUDP and is assigned a CID. Individual clients do not receive unique CIDs; data sent using the UDP server must be accompanied with the destination IP address and port, and data received via the server is modified with the identifying source address and port number.

Please note that the CID returned for a new tcp/udp connection should be in ascending order(increment by 1) even the previous connection does not exists. Once it reaches the maximum connection number(15), it starts from the first(0).




Figure 6: Creation and Use of a UDP Server

3.1.3 Profile Definition

The configuration parameter values that define the behavior of the Adapter are grouped into Profiles. These profiles are stored in non-volatile memory when not in use. The default configuration supports single Profile. The contents of a profile are listed in Table 2.

Table 2: Profile Parameters

<i>Parameter</i>	<i>Values</i>	<i>Reference</i>
General Wireless Parameters		
802.11 Operating Mode	BSS, IBSS, Limited AP	4.7.6
Transmit Power Configuration		4.8.16
802.11 Transmit Retry Count		4.7.15
Power Save Mode	Enabled, Disabled	4.8.12
802.11 Radio Mode	Enabled, Disabled	4.8.11
Auto Connect Mode, Wireless Interface Settings		
802.11 Operating Mode	BSS, IBSS	4.14.1
Operating Channel	1 to 14	4.14.1
SSID Parameter	Any valid SSID	4.14.1
BSSID Parameter	Any valid BSSID	4.14.1
Maximum Scan Time		4.4
Auto Connect Mode, Network Interface Settings		
Mode	Server, Client	4.14.2
Protocol	TCP, UDP	4.14.2
Server Port Number	Any valid port	4.14.2
Server IP Address	Any valid IP address	4.14.2
Host Name	Valid Domain name	4.14.2

Parameter	Values	Reference
Wireless Interface Security Configuration		
Authentication Mode	Open, Shared	4.8.1
PSK Valid	Valid, Invalid	4.8.5
PSK-SSID	Any valid SSID; used for PSK key computation.	4.8.5
WEP Key Configuration		4.8.3
WPA Passphrase		4.8.4
TCP/IP Configuration		
DHCP Mode	Enabled, Disabled	4.9.2
IP Address	Valid IP address	4.9.3
Net Mask Address	Valid mask	4.9.3
Default Gateway Address	Valid IP address	4.9.3
DNS1	Valid DNS1 IP address	4.9.7
DNS2	Valid DNS2 IP address	4.9.7
UART Configuration		
Echo Mode	Enabled, Disabled	4.1.2
Verbose Mode	Enabled, Disabled	4.1.3
Bits Per Character	5,6,7,8	4.2.1
Number of Stop Bits	1,2	4.2.1
Parity Type	No, Odd, Even	4.2.1
Software Flow Control Mode	Enabled, Disabled	4.2.2
Hardware Flow Control Mode	Enabled, Disabled	4.2.3
Baud Rate		4.2.1

<i>Parameter</i>	<i>Values</i>	<i>Reference</i>
Limits and Timeouts		
Network Connection Timeout	Units of 10 milliseconds	4.4
Auto Association Timeout	Units of 10 milliseconds	4.4
TCP Connection Timeout	Units of 10 milliseconds	4.4
Association Retry Count		4.4
Nagle Wait Time	Units of 10 milliseconds	4.4
Scan Time	Units of milliseconds	4.4
Ncm L4 reconnect interval	Units of milliseconds	4.4
Ncm L4 reconnect count	Units in numbers.	4.4
SPI Configuration		
SPI clock polarity and clock phase	0,1	4.3.1

3.2 Command Processing Mode

In command mode, the application receives commands over the serial port. Commands are processed line by line. “Verbose Mode”, when referring to commands being executing, refers to the displaying of status of any command executed in ASCII (human readable) format. When the verbose mode is disabled, the output will simply be in numeric digits, each digit indicating a particular status. Verbose Mode is enabled by default.

- ▶ If “echo” is enabled then each character is echoed back on the serial port
- ▶ Each command is terminated with a *carriage return* <CR> or *line feed* <LF>
- ▶ Each response is started with a carriage return <CR> and line feed<LF>, with the exception of the responses to the following commands:
 - a) The response to the following group of commands starts with a line feed <LF> only:
 - AT+WA
 - AT+NSTAT
 - AT+WPAPSK=<SSID>,<Passphrase>
 - AT+NSET=<IP Address>,<Subnet Mask>,<Gateway IP Address>(valid after association)
 - AT+TRACEROUTE=<IP Address>
 - AT+PING=<IP Address>
 - ATA
 - AT+NDHCP after association
 - b) The response to the following group of commands starts with a line feed and carriage return: <LF><CR>.
 - AT+HTTPOPEN=<IP Address>
- ▶ Each response is terminated with a carriage return <CR> and line feed <LF>
- ▶ If the characters “A” and “/” are entered at the beginning of a line (after <CRLF>), then the previous command is executed
- ▶ Once a complete line (ending with <CR or LF>) is entered, then the command contained therein is processed and an appropriate response returned

Unless otherwise specified, if verbose mode is enabled, then the response to a successful command is the characters “OK”. The response to an unsuccessful command is the word “ERROR”, followed by a detailed error message, if available. If verbose mode is disabled, command responses is numerical with OK having a value of 0 and error codes represented by positive integers.

The commands are described in Section 4. Possible response codes are described in 3.7.3

3.3 Auto Connection

If auto connection is enabled (section 0), then upon startup the Adapter will:

- ▶ Attempt to associate to or from the specified network, for a maximum time of *Auto Associate Timeout* (section 4.4)
- ▶ On successful association, attempt to establish a network connection based on the specified parameters
- ▶ On successful connection establishment, enter the pass-through auto connect mode
- ▶ On failure, enter the command processing state

In TCP client mode, the connection is considered established only when the client successfully connects to the server specified in the parameters. The client address may be fixed or obtained from a DHCP server. The client port is selected at random during creation of the client. The connection is attempted for a maximum time based on the *Network Connection Timeout*, specified in units of 10 milliseconds (section 4.4). Data is sent to, and received from, this server. If the connection is terminated, auto-connect mode also terminates and the command processing state is entered.




Figure 7: TCP Client Operation in Auto Connect Mode

The TCP server IP address may be fixed in the profile or obtained from DHCP. The port for connection attempts to be made is obtained from the profile. In TCP server mode, the connection is considered established when the first client connects to the server. Data is sent to, and received from, this client. If the client disconnects, the adapter waits for the next client to connect.




Figure 8: TCP Server Operation in Auto Connect Mode

In UDP client mode, the connection is considered established when the client is created. The client IP address may be fixed or obtained from DHCP. The client port number is set at random upon creation of the client. Data is sent to and received from the configured server.




Figure 9: UDP Client Operation in Auto Connect Mode

In UDP server mode, the connection is considered established when data is received from any client. The UDP server IP address may be fixed or obtained by DHCP. The port is set by the profile. Data received from any client is output on the serial port and data received on the serial port is transmitted to the client based on the last packet was received.




Figure 10: UDP Server Operation in Auto Connect Mode

In TCP and UDP server mode, even where no connection is established, the serial host may take control of the Serial2WiFi interface by issuing a specific escape sequence, described in section 3.3.1.

3.3.1 Auto Connection Operation

Auto Connect Mode acts as a cable replacement so that the interface acts like a serial interface. The node automatically establishes the wireless and network connections by using parameter values from the current active Profile and transfers data transparently between the Host and Target in data mode. No status information is sent to the Host. If connection is lost, status is sent to the Host, and host will need to re-initiate the connection to the network.

In auto connection mode the Adapter:

- ▶ Receives characters from the serial port and transmits them over the Wi-Fi connection
- ▶ Receives data from the Wi-Fi connection and transmits it on the serial port

The serial host may gain control of the interface by issuing the *escape sequence* “+++”, followed by a one-second gap where no characters are received on the serial port or by asserting GPIO8. When this sequence is encountered, the Adapter suspends auto connection mode and resumes command processing. The Host then may make changes in the network configuration or other parameters as needed. However, the Adapter does not accept any new TCP/UDP client/server or auto connection requests since auto connection exists in the background. The ATO command (terminated by the ASCII character “O”, not the number 0) is used to return to auto connection mode.

In auto connection mode, the Nagle Algorithm Wait Time (section 4.4) can be used to buffer any characters to be sent, in order to avoid sending a large number of packets with small payloads onto the network. The wait time is specified in units of 10 milliseconds. This functionality is available for both UDP and TCP connections.

3.4 Data Handling

In Data Processing Mode, data transfers are managed using various *escape sequences*. Each escape sequence starts with the ASCII character 27 (0x1B); this is equivalent to the ESC key. The encoding of data and related commands are described in the following pages. This encoding is used for both transmitted and received data.

The network destination, or destination source, for a given data packet is established by means of a **Connection Identifier**, and represented as a single hexadecimal number. Data is transferred on a per CID basis. Data is normally buffered until the end-of-data escape sequence is received. However, if the amount of data exceeds the size of the data buffer, the data received, thus far, is sent immediately. The data buffer size depends on the implementation, but is usually one MTU (1400 bytes).

The process of sending a data packet is depicted in Figure 11. The sequence Esc S or Esc U is sent to initiate the data transfer. This sequence is followed by a single-digit CID; if the CID is valid, the subsequent characters are assembled into a data stream, terminated by Esc E, Esc C, Esc S or Esc U. With a terminating sequence, the data is sent via the requested network connection and the system either returns to command processing or to further data processing.

Escape sequences like Esc S, Esc u and Esc U support only ASCII data handling while Esc Z, Esc Y and Esc y supports all types of data (ASCII, Binary etc.) handling.

Please refer to Appendix 6 for a complete description of all the Escape sequences used for data handling.




Figure 11: Data Processing Flow

Table 3: Data handling responses at completion

Operation	Escape Sequence	Description
Send and Return to Command Mode Sequence	<Esc>C	This sequence causes transmission of the data received on the serial interface on a TCP server/client or UDP client connection. After, the currently selected connection is closed and the interface returns to Command Mode. Any buffered data is sent before the connection is closed. This can be issue from the serial host once the data transmissions start on a socket using <Esc>S<CID> sequence.
Success Indication	<Esc>O	“OK”: This sequence is sent to the serial host by the Serial2WiFi Adapter upon successful completion of the <Esc>S<CID>, <Esc>E, <Esc>U<CID> or <Esc>C commands.
Failure Indication	<Esc>F	“FAILURE”: This sequence is sent to the host by the Serial2WiFi Adapter if an <Esc>S, <Esc>E, <Esc>U, or <Esc>C command failed.

The contents of < > are either a byte or byte stream, except for <Esc>; literals outside brackets are ASCII characters.

3.4.1 Bulk data Tx and Rx

In Bulk Data Mode, data transfers are managed using *escape sequences (Esc Z, Esc Y and Esc y)*. Each escape sequence starts with the ESC key (ASCII character 27 (0x1B)). Encoding is used for both transmitted and received data. Enable bulk data by using command “AT+BDATA=” (1 is enable and 0 is disable).

The format of a bulk data frame for TCP client, TCP server, or UDP client is:

```
<Esc>Z<CID><Data Length xxxx 4 ascii char><data>
```

The contents of < > are a byte or byte stream.

- ▶ CID is connection identifier (UDP, TCP, etc.; as derived when TCP socket is created by issuing the command: AT+NCTCP, for example.)
- ▶ Data Length is 4 ascii char represents decimal value i.e. 1400 byte (0x31 0x34 0x30 0x30).
- ▶ The Data Length range should be 1 to 1400 bytes when sending to GainSpan module from Host and it will be 1 to 1500 bytes when Host is receiving from GainSpan module
- ▶ User Data size **must match** the specified Data Length. Ignore all command or esc sequence in between data pay load. User should send the specified length of data to the adapter irrespective of

any asynchronous events happened on the adapter so that the adapter can start receiving next commands.

For example, if CID value is 3, then:

- ▶ To send a 5 byte user data (e.g. ABCDE) for a TCP client connection, the format will be:
 <ESC>Z30005ABCDE
- ▶ To send a 512 byte user data for a TCP client connection, the format will be:
 <ESC>Z30512<512 bytes of user data>

To send data on UDP server, the bulk data frame format is:

<Esc>Y<CID><Ip address>:<port>:<Data Length xxxx 4 ascii char><data>

When receiving data on UDP server, the format of a bulk data frame is:

<Esc>y<CID><IP address><space><port><horizontal tab><Data Length xxxx 4 ascii char><data>

Table 4: Escape Sequences.

Operation	Escape Sequence	Description
Bulk Data transfer on TCP Server/Client and UDP Client connection	<Esc>Z<CID>Data Len 4 digit ascii<Data>	To improve data transfer speed, one can use this bulk data transfer. This escape sequence is used to send and receive data on a TCP Client/Server and UDP client connection. Example: <Esc>Z40005Hello where 4 is the CID, 0005 is the 5 byte data length and Hello is the data to be sent.
Bulk Data Send on UDP sever connection	<Esc>Y<CID> remote address: remote port:Data Len 4 digit ascii<Data>	This escape sequence is used when sending UDP data on a UDP server connection. When this command is used, the remote address and remote port is transmitted in ASCII text encoding and terminated with a ':' character. Example: <Esc>Y4192.168.1.1:52:0005Hello where 4 is the CID, 0005 is the 5 byte data length and Hello is the data to be sent.
Bulk Data Receive on UDP Server Connection	<Esc>y<CID> remoteaddress<space>r emote port<horizontal tab>Data length in 4 digit ascii<Data>	This escape sequence is used when receiving UDP data on a UDP server connection. When this sequence is used, the remote address and remote port is transmitted in ASCII text encoding and separated by a space () character. Example: <Esc>y4192.168.1.1<space>52<horizontal tab>0005Hello where 4 is the CID, 0005 is the 5 byte data length and Hello is the data received.

The contents of < > are either a byte or byte stream, except for <Esc>; literals outside brackets are ASCII characters.

3.4.2 Raw Data Handling (BACNET Support Only)

In Raw Data Mode, data transfers are managed using *escape sequences*. Each escape sequence starts with the ASCII character 27 (0x1B), the equivalent to the ESC key. The encoding of data is described below. Encoding is used for both transmitted and received data. The Raw Ethernet Support Enable command (4.10.17) must be issued before sending or receiving raw data through the Adapter.

The format of a raw-data frame is:

```
<Esc>:R:<Length>:<DstAddr><SrcAddr><EtherType><Raw-Payload>
```

The contents of < > are a byte or byte stream.

- ▶ Length is the size of DstAddr, SrcAddr, EtherType and Raw-Payload
- ▶ DstAddr is the destination MAC address

- ▶ SrcAddr is the source MAC address
- ▶ EtherType is the type of the Ethernet packet. For example, for BACNET-over-Ethernet, the EtherType is 0x0000.
- ▶ Raw-Payload is the raw data

3.4.3 Unsolicited Data Handling

In Unsolicited Data Mode (data transmission without association), data transfer is managed using *escape sequences*. Each escape sequence starts with the ASCII character 27 (0x1B), equivalent to the ESC key. The encoding of data is described below. This encoding is used for transmitted data only. The unsolicited data transmission Enable command (4.10.17) must be issued before sending unsolicited data through the Adapter.

The format of an unsolicited data frame is:

<ESC>D/d<Payload>

The Payload contents are byte or byte stream.

3.4.4 Software Flow Control

Software flow control (for UART interface) works only with ASCII data transfers and cannot be used for binary data. For SPI interface and use of flow control see section 4.18.4

If software flow control is enabled, and the interface receives an XOFF character from the serial host, it stops sending to the host until it receives an XON character. If the Adapter is receiving data over the wireless connection during the time that XOFF is enabled, it is possible for the wireless buffer to become full before XON is received. In such a case, data from the network will be lost.

If software flow control is enabled, then the interface sends an XOFF character to the host when it will be unable to service the serial port. The XON character is sent when the interface is once again able to accept data over the serial port.

Note: With initialization, the Adapter treats the serial channel as clear with no restrictions on data transmission or reception; no explicit XON is transmitted by the Adapter or required from the Host, even if flow control is enabled.

3.4.5 Hardware Flow Control

The Hardware Flow control is a handshake mechanism between the Serial host and S2W adapter on UART interface, using two additional CTS and RTS connections. This feature prevents the UART hardware FIFO overflow on S2W adapter due to high speed data transmission from/to the S2W adapter. If hardware flow control is enabled, an RTS/CTS handshake will occur between the serial host and the Adapter. This is a hardware feature and available only for UART interface.

The S2W adapter uses both CTS and RTS signals as “low” to indicate the readiness to send or receive data from serial host.

3.5 Serial Data Handling

The Serial Data Handler receives and transmits data to and from the hardware serial controller. Data read from the serial port is passed to:

- ▶ The command processor in command mode
- ▶ The Tx data handler in data mode
- ▶ The auto connection mode processor for data transfer in auto connection mode

Then Data is transferred on the serial port from:

- ▶ The command processor in order to output responses to commands
- ▶ The Rx data handler in order to output incoming packets
- ▶ The auto connection handler in order to output incoming data
- ▶ The connection manager in order to output status indications
- ▶ The wireless connection manager in order to output status indications

When configured in Auto Connection Mode, the Adapter enters directly into Data Processing Mode after the completing the connection without sending any status information to the Host.

3.6 Connection Management

The connection management module is responsible for processing connection-related events. The interface provides UDP and TCP sockets (similar to the familiar BSD network sockets). Each socket may represent either a server or client connection. Each connection has a unique, single-digit hexadecimal value (0 to F), for the CID. The allowed maximum number of connections (up to 16) may be specified at compile time. Note that this single pool of CID's is used for TCP, UDP, Server and Client connections.

3.6.1 Packet Reception

When a packet is received on any open connection, and the application is not currently in auto-connect mode, the packet is transferred on the UART/SPI in the form described in Section 3.4 above. Received data payloads are encoded with the appropriate Escape sequence. The connection ID is used to inform the serial host of the origin of an IP data packet. The source IP address and port are provided along with the data when a UDP packet is received.

If auto-connect mode is enabled and a packet is received on the auto-connected CID, the packet data is sent without modification over the UART/SPI to the serial host.

3.6.2 Remote Close

If a TCP connection is terminated by disconnection from the remote end, an unsolicited ASCII-format response of the form `DISCONNECT Connection ID` is sent to the serial host, and the specified CID should be considered unavailable. If the connection ends because the remote server has shut down, the

unsolicited response `ERROR: SOCKET FAILURE` Connection ID will be sent to the host. Note that a data packet from the remote client or server containing the same ASCII characters `CLOSE` Connection ID is treated as data rather than a command and forwarded to the serial host.

3.6.3 TCP Server Connections

Upon deployment of incoming TCP connections on a socket, the incoming connection is allowed if the limit on the maximum number of connections has not been reached. There is an unsolicited response of the form `CONNECT <server CID> <new CID> <ip> <port>`, where:

- ▶ Server CID is the CID of the server where the connection has arrived
- ▶ New CID is the CID allocated for this client connections
- ▶ IP and port of the client encoded in the binary encoding used for UDP server data packets described in section 3.4 above is sent to the serial host. The host can use the IP address to ascertain the source of the TCP connection request. The TCP server has no timeout limitation for an incoming connect request. It waits indefinitely, until a `CLOSE` command is received.

Note that if Verbose mode is disabled (section 4.1.3), the word `CONNECT` in the unsolicited response is replaced by the number 7.

3.7 Wireless Network Management

3.7.1 Scanning

The Serial2WiFi interface can instruct the Wi-Fi radio to scan for access points and ad hoc networks with a specified SSID, BSSID and/or channel for a specified scan time. Scanning can be performed to find networks with a specific SSID or BSSID, networks operating on a specific radio channel or a combination of these constraints.

3.7.2 Association

The Serial2WiFi interface performs all the actions required to join an infrastructure IP network:

- ▶ Scan for a specific AP (AT+WS, section 4.7.6)
- ▶ Authenticate the specified network using the configured authentication mode (AT+WAUTH, section 4.8.1)
- ▶ Associate to the AP (AT+WA, section 4.7.8)
- ▶ Perform security negotiation if required
- ▶ Change state to Wireless Connected
- ▶ Initialize the networking stack using the configured static IP address or via DHCP (AT+NDHCP, section 4.9.2)

In ad hoc mode, the interface can:

- ▶ Scan for a specified Ad-hoc Network
- ▶ Join the ad hoc network, if it exists
- ▶ If the ad hoc network does not exist, create a new ad hoc network to join
- ▶ Perform security negotiation, if required
- ▶ Change state to Wireless Connected
- ▶ Initialize the networking stack using the configured static IP address or via DHCP

3.7.3 Response Codes

The possible responses sent by the Adapter to the serial host are enumerated in Table . The table below reflects all characters including <CR> or <LF> that would be seen on the interface.

Table 5: Response Codes.

No	ASCII CHAR	Response	ASCII STRING	Meaning
1	0	S2W_SUCCESS	"\r\nOK\r\n"	Command Request Success.
2	1	S2W_FAILURE	"\r\nERROR\r\n"	Command Request Failed.
3	2	S2W_EINVAL	"\r\nERROR: INVALID INPUT\r\n"	Invalid Command or Option or Parameter.
4	3	S2W_SOCK_FAIL	"\r\nERROR: SOCKET FAILURE <CID>\r\n"	Socket Operation Failed.
5	4	S2W_ENOCID	"\r\nERROR: NO CID\r\n"	All allowed CID's in use, so there was no CID to assign to the new connection.
6	5	S2W_EBADCID	"\r\nERROR: INVALID CID\r\n"	Invalid Connection Identifier.
7	6	S2W_ENOTSUP	"\r\nERROR: NOT SUPPORTED\r\n"	Operation or Feature not supported.
8	7	S2W_CON_SUCCESS	"\r\nCONNECT <CID>\r\n\r\nOK\r\n"	TCP/IP connection successful. <CID> = the new CID in hexadecimal format. Followed by command request success
9	8	S2W_ECIDCLOSE	"\r\nDISCONNECT <CID>\r\n"	TCP/IP connection with the given CID is closed. This response is sent to the host when a connection is closed either by the remote device or by the serial host.
10	9	S2W_LINK_LOST	"\r\nDISASSOCIATE D\r\n"	Not associated to a wireless network.
11	10	S2W_DISASSO_EVT	"\r\n\r\nDisassociation Event\r\n\r\n"	Wireless network association lost.

No	ASCII CHAR	Response	ASCII STRING	Meaning
12	11	S2W_STBY_TMR_EVT	"\r\nOut of StandBy-Timer\r\n"	Wake up from Standby due to RTC timer expiration.
13	12	S2W_STBY_ALM_EVT	"\r\n\r\n\r\nOut of StandBy-Alarm\r\n\r\n\r\n"	Wake up from Standby due to receipt of an Alarm signal.
14	13	S2W_DPSLEEP_EVT	"\r\n\r\n\r\nOut of Deep Sleep\r\n\r\n\r\n\r\nOK\r\n"	Wake from Deep Sleep followed by command request success
15	14	S2W_BOOT_UNEXPECTED_EVT	"\r\n\r\n\r\nUnExpected Warm Boot(Possibly Low Battery)\r\n\r\n\r\n"	Unexpected reset. Possible reasons: external reset or low battery
16	15	S2W_ENOIP	"\r\n\r\nERROR: IP CONFIG FAIL\r\n\r\n"	IP configuration has failed. This message also can come asynchronously when there is a DHCP renew fails.
17	16	Boot Message	"\r\n\r\nSerial2WiFi APP\r\n\r\n"	Boot message for Mlx modules.
18	17	Boot Message	"\r\n\r\nSerial2WiFi APP-Ext.PA\r\n\r\n"	Boot message for MEx modules
19	18	Nwconnection success	"\r\n\r\nNWCONN-SUCCESS\r\n\r\n"	The L2+L3 connection success message for the ncm auto connection
20	19	S2W_NEWIP	"\r\n\r\nIP CONFIG-NEW IP\r\n\r\n"	DHCP renewal success with a new IP address.

3.7.4 Enhanced Asynchronous Messages

NO	Message	Subtype	Meaning
1	ERROR: SOCKET FAILURE <CID>	0	Socket Operation Failed
2	CONNECT <CID>	1	TCP/IP connection successful. <CID> = the new CID in hexadecimal format.
3	DISCONNECT <CID>	2	TCP/IP connection with the given CID is closed. This response is sent to the host when a connection is closed by the remote device.
4	Disassociation Event	3	Wireless network association lost.
5	Out of StandBy-Timer	4	Wake up from Standby due to RTC timer expiration.
6	Out of StandBy-Alarm	5	Wake up from Standby due to receipt of an Alarm signal.
7	Out of Deep Sleep	6	Wake from Deep Sleep.
8	UnExpected Warm Boot(Possibly Low Battery)	7	Unexpected reset. Possible reasons: external reset or low battery.
9	ERROR: IP CONFIG FAIL	8	IP configuration has failed. This message comes asynchronously when there is a DHCP renew fails.
10	Serial2WiFi APP	9	Initial Boot message
	Serial2WiFi APP -Ext.PA	A	
11	ERROR	B	Error message for the l4 connection fail with ncm auto.
12	NWCONN-SUCCESS	C	The L2+L3 connection success message for the ncm auto connection.
13	IP CONFIG-NEW IP	D	DHCP renewal success with a new IP address.

3.7.5 Exception Messages

The possible exception messages sent by the Adapter to the serial host are enumerated in Table 6.

Table 6: Exception Messages.

<i>No</i>	<i>ASCII STRING</i>	<i>Meaning</i>
1	\n\rAPP Reset-Wlan SW Reset\r\n	Adapter reset due to WLAN processor software reset.
2	"\n\rAPP Reset-APP SW Reset\r\n"	Adapter reset due to app processor software reset...
3	\n\rAPP Reset-Wlan-Wd\r\n	Adapter reset due to WLAN processor watchdog.
4	\n\rAPP Reset-App-Wd\r\n	Adapter reset due to app processor watchdog
5	\n\rAPP Reset-Wlan Except\r\n	Adapter reset due to WLAN processor software abort or assert.
6	\n\rAPP Reset-FW-UP-FAILURE\r\n	Adapter reset due to firmware upgrade failure.
7	\n\rAPP Reset-FW-UP-SUCCESS\r\n	Adapter reset due to firmware upgrade success.
8	\n\rAPP Reset-FW-UP-RECOVERY\r\n	Adapter reset due to firmware upgrade failure with one of the flash image updated successfully.

If the exception is due to one of the WLAN wd/SW Reset/Except, then the adapter send memory dump information of its WLAN registers to the serial host starts with the message \r\n---MEM-DUMP-START:\r\n and end with the message \n\r---MEM-DUMP-END:\r\n.

3.7.6 Boot Messages

The possible boot messages sent by the Adapter to the serial host are enumerated in Table 7.

Table 7: Boot Messages.

NO	ASCII STRING	Meaning
1	\r\n Serial2WiFi APP\r\n	Normal Serial2WiFi adapter boot message with internal PA.
2	\r\nSerial2WiFi APP-Ext.PA\r\n	Normal Serial2WiFi adapter boot message with external PA.
3	\r\n Factory Default CheckSum Error\r\n	The factory default section contains invalid data. This comes along with either one of the above boot message.

3.7.7 SSID and Passphrase

Rules:

- 1- The S2W adapter accepts the following ASCII characters for SSID and passphrase.

Category	Accepted Characters
Numerical	0-9
Alphabets	a-z and A-Z
Special characters	SP ! # \$ % & ' () * + , - . / : ; < = > ? @ [\] ^ _ ` { } ~ ”

Note: SP = space

- 2- The SSID or Passphrase parameter may be captured within or without double quotation marks (“SSID”).
- 3- The quotation mark (“”) may not be used as the first character of the SSID or passphrase.
- 4- If comma (,) is a part of the SSID, then SSID parameter needs to be framed with double quotation marks (“SS,ID”).

Expected SSID	Input SSID	Remarks
TEST	TEST	Valid (satisfies rule 2)
TEST	“TEST”	Valid (satisfies rule 2)
TE”ST	TE”ST	Valid (satisfies rule 3)
TE”ST	“TE”ST”	Invalid (<i>breaks rule 3</i>)
TE,ST	“TE,ST”	Valid (satisfies rule 4)
TE,ST	TES,T	Invalid (<i>breaks rule 4</i>)
TE,S”T	“TE,S”T”	Invalid (<i>breaks rule 3 and 4</i>)

4 Commands for Command Processing Mode

This section provides a list of Serial2WiFi commands and their effects. Formatting and processing of commands was described in section 3.2 above. Parameters are generally ASCII characters, e.g. ATEn with $n=1$ is the series of ASCII characters 'A', 'T', 'E', and '1'. Where some parameters are optional, mandatory parameters are denoted by `< >` and optional parameters by `[]`. If a parameter is mandatory, any associated sub-parameters are also mandatory; sub-parameters of an optional parameter are optional. Parameters must always be provided in the order given in the command description. When an optional parameter is not supplied, the comma delimiters must still be included in the command. Every command starts with the characters "AT"; any other initial characters will cause an error to be returned.

Command Response: In most cases, valid commands return the characters OK if verbose mode is enabled and 0 if verbose mode is not enabled. Invalid inputs return ERROR: INVALID INPUT if verbose is enabled and 2 if it is not. Exceptions to this rule are noted explicitly below.

4.1 Command Interface

4.1.1 Interface Verification

The command AT can be issued to verify that the interface is operating correctly; it should return a successful response OK (or 0 if verbose mode is disabled).

4.1.2 Echo

ATEn

If n is 0, echo is disabled and if n is 1, echo is enabled.

If echo is enabled, every character received on the serial port is transmitted back on the serial port. This command returns the standard command response (section 4) to the serial interface. By default echo is enabled in s2w adapter.

4.1.3 Verbose

ATVn

If n is 0, verbose responses is disabled and if n is 1, verbose responses is enabled.

If verbose mode is disabled, the status response is in the form of numerical response codes. If verbose mode is enabled, the status response is in the form of ASCII strings. Verbose Mode is enabled by default.

This command returns the standard command response (section 4) to the serial interface.

4.1.4 Help

AT?

This command is no longer supported.

4.2 UART Interface Configuration

4.2.1 UART Parameters

ATB=<baudrate>[[,<bitsperchar>][,<parity>][,<stopbits>]]

All standard baud rates are supported.

Allowed baud rates include: 9600, 19200, 38400, 57600, 115200, 230400, 460800 and 921600.

Parity is *n* for no parity, *e* for even parity and *o* for odd parity.

Allowed values are 5, 6, 7 or 8 bits/character, with 1 or 2 stop bits

The new UART parameters take effect immediately. However, they are stored in RAM and will be lost when power is lost unless they are saved to a profile using AT&W (section 4.6.1). The profile used in that command must also be set as the power-on profile using AT&Y (section 4.6.3).

This command returns the standard command response (section 4) to the serial interface with the new UART configuration.

4.2.2 Software Flow Control

AT&Kn

If *n* is 0, software flow control is disabled. If *n* is 1, software flow control is enabled.

The use of software flow control is described in section 3.4.4 above.

This command returns the standard command response (section 4) to the serial interface.

4.2.3 Hardware Flow Control

AT&Rn

If *n* is 0, hardware flow control is disabled. If *n* is 1, hardware flow control is enabled. This command returns the standard command response (section 4) to the serial interface.

The use of software flow control is described in section 3.4.5 above.

4.3 SPI Interface Configuration

4.3.1 SPI Parameters

The command to set the SPI clock phase and clock polarity parameter is as follows:

```
AT+SPICONF=<clockpolarity>, <clockphase>
```

If clock polarity is 0, then inactive state of serial clock is low.

If clock polarity is 1, then inactive state of serial clock is high.

If clock phase is 0, then data is captured on the first toggling edge of the serial clock (clock phase zero), after the falling edge of slave select signal.

If clock phase is 1, then data is captured on the second edge of the serial clock (clock phase 180), after the falling edge of slave select signal.

Default is clock polarity 0 and clock phase 0.

The new SPI parameters take effect after node reset/restart. However, they are stored in RAM and will be lost when power is lost unless they are saved to a profile using AT&W (section 4.6.1). The profile used in that command must also be set as the power-on profile using AT&Y (section 4.6.3).

This command returns the standard command response (section 4) to the serial interface with the new SPI configuration.

4.4 Serial to Wi-Fi Configuration *

ATS_n=*p*

n is the parameter id to set and *p* is the value to set the parameter to. The parameters available are described in Table . **Not Supported on the GS1500M.**

Table 8: Configuration Parameters for Network Association.

Parameter ID	Name	Description	Citation
0	Network Connection Timeout	The maximum amount of time allowed establishing the network connection in Auto Connect Mode. Measured in units of 10 milliseconds. Allowed values: 1 to 65535 (but the TCP/IP stack limits the maximum timeout value). Default value: 1000 (10 seconds). If the connection attempt is a TCP client connection, and TCP Connection Timeout below is less than Network Connection Timeout, the value of Network Connection Timeout will be ignored.	4.4

Parameter ID	Name	Description	Citation
1	Auto Associate Timeout	The maximum amount of time allowed associating to the desired wireless network in Auto Connect Mode, in units of 10 milliseconds. Allowed values: 1 to 65535. Default value: 500 (5 seconds).	4.4
2	TCP Connection Timeout	The maximum amount of time allowed establishing a TCP client connection, in units of 10 milliseconds. Allowed values: 1 to 65535 (but the TCP/IP stack limits the maximum timeout value). Default value: 500 (5 seconds). Note that 0 corresponds to the default TCP/IP stack timeout (75 seconds).	4.10.1
3	Association Retry Count	Not currently supported.	3.1.3
4	Nagle Algorithm Wait Time	The maximum time for serial data sent in Auto Connect Mode to be buffered, in units of 10 milliseconds. Allowed values: 1 to 65535 (but the amount of data is limited by available buffer size). Default value: 10 (100 ms).	3.3.1
5	Scan Time	The maximum time for scanning in one radio channel, in units of milliseconds. Allowed values: 5 to 16000 (but at the high limit a 14-channel scan will consume 4 minutes). Default value: 150 (150 ms).	3.7.1
6	Ncm L4 Retry Period	The time in period between each L4 connection retry with ncm auto in units of 10 milliseconds. Default vale is 50 (500 msec)	
7	Ncm L4 Retry Count	The retry counts for L4 connection with ncm auto. Default value is 20.	
8	Frame size configuration auto connection	The maximum size of the frame to be send for auto connect mode. The default value is 1400 and the range is from 1 to 1400. This is again depend on the s2w nagle time. In case of TCP this size may not match with the real size of the frame comes out from the adapter as the tcp nagle time also come in to picture there.	

This command returns the standard command response (section 4) to the serial interface.

4.5 Identification information

ATIn

n is the ID of the information to obtain. The responses are listed in Table . These responses are provided as ASCII strings in addition to the standard command response (section 4).

Table 9: Application Information.

Information ID	Description
0	OEM identification
1	Hardware version
2	Software version

4.6 Serial to Wi-Fi Configuration Profiles

Adapter configuration parameters can be stored and recalled as a Profile; see 3.1.3 for a detailed description of the profile parameters.

4.6.1 Save Profile

The command to save the current profile is

AT&W*n*

n shall be 0 for profile 0. (Higher values are allowed if more profiles are configured at compile time.)

Upon deployment of this command, the current configuration settings are stored in non-volatile memory under the specified profile. Note that, in order to ensure that these parameters are restored after power cycling the adapter, the command AT&Y (section 4.6.3) must also be issued, using the same profile number selected here.

This command returns the standard command response (section 4) or ERROR (1, if verbose disabled) ,if the operation failed.

4.6.2 Load Profile

The command to load a profile is

ATZn

n shall be 0 for profile 0. (Higher values are allowed if more profiles are configured at compile time.)

Upon deployment of this command, the currently configured settings are set to those stored in non-volatile memory under the specified profile. This command returns the standard command response (section 4) to the serial interface. The s2w adapter uses profile 0 as the default profile.

4.6.3 Selection of Default Profile

The command to select the default profile is

AT&Yn

n shall either be 0 for profile 0. (Higher values are allowed if more profiles are configured at compile time.)

The settings from the profile that is chosen as the default profile are loaded from non-volatile memory when the device is started.

In addition to the standard status responses, this command returns ERROR or 1, based on verbose settings, if a valid input cannot be executed.

4.6.4 Restore to Factory Defaults

The command to reset to factory defaults is

AT&F

Upon deployment of this command, the current configuration variables are reset to the factory defaults. These defaults are defined by macro values in the configuration header, and can be modified at compile time. Issuing this command resets essentially all configuration variables *except* the IEEE MAC address. Only the command AT+NMAC (section 4.7.1) changes the MAC address.

This command returns the standard command response (section 4) to the serial interface.

4.6.5 Output current configuration

The command to output the configuration is

AT&V

Upon deployment of this command, the current configuration and the configuration of the saved profiles are output on the serial port in ASCII format in addition to the standard command response (section 4). The details of the profile parameters are described in section 3.1.3.

4.7 Wi-Fi Interface Configuration

4.7.1 MAC Address Configuration

AT+NMAC=<MAC ADDRESS>

Upon deployment of this command, the Adapter sets the IEEE MAC address as specified. The format of the MAC address is an 8-byte colon-delimited hexadecimal number. An example is shown below:

AT+NMAC=00:1d:c9:00:01:a2

The MAC address is used in the 802.11 protocol to identify the various nodes communicating with an Access Point and to route messages within the local area (layer 2) network. Fixed MAC addresses issued to network interfaces are hierarchically structured and are intended to be globally unique. Before issuing a MAC address to a given Adapter, ensure that no other local device is using that address.

The MAC address supplied in the AT+NMAC command is saved to flash memory, and will be used on each subsequent cold boot (from power off) or warm boot (from Standby).

An alternative command is :

AT+NMAC2=<MAC ADDRESS>

This stores the MAC address in RTC RAM. Each warm boot (from Standby) will use the MAC address stored in RTC RAM (from the most recent AT+NMAC2= command), but if power to the device is lost, the next cold boot will use the MAC address stored in flash memory (from the most recent AT+NMAC= command). This command is particularly useful in cases where writing to flash memory is undesirable.

In addition to the standard command responses (section 4) , this command returns ERROR or 1, based on verbose settings, if a valid input cannot be executed.

GS1500M: A reset must be issued after configuring the MAC address for the MAC address change to take effect in case of GS1500M.

4.7.2 Output MAC Address

AT+NMAC=?

Upon deployment of the command, the Adapter outputs the current MAC address of the wireless interface to the serial port, in addition to the usual command responses (section 4) . The alternate command is

AT+NMAC2=?

may also be used, and returns the same value.

4.7.3 Regulatory Domain Configuration

AT+WREGDOMAIN=<Regulatory Domain>

This command sets the regulatory domain as per the Regulatory Domain parameter passed. The supported regulatory domains are:

- FCC → supported Channel range is 1 to 11.
- ETSI → supported Channel range is 1 to 13.
- TELEC → supported Channel range is 1 to 14.

The corresponding values for this regulatory domain that needs to be passed as the parameter are:

- FCC: 0
- ETSI : 1 (except GS1011MExS)
- TELEC: 2
- ETSI: 3 (for GS1011MExS)

The default regulatory domain is FCC. The Regulatory domain set is required only once since it is being updated in the flash. This command returns the standard command response (section 4) to the serial interface.

4.7.4 Regulatory Domain Information

AT+WREGDOMAIN=?

Upon reception of the command, the Adapter outputs the current Regulatory domain of the wireless interface to the serial port as the following format:

REG_DOMAIN=FCC or ETSI or TELEC, in addition to the standard command responses.

4.7.5 Setting/Getting Scan Time

The command to set the minimum and maximum scan time per channel:

AT+WST=<Min scan time>,<Max scan time>

Min scan time is the minimum scan time per channel,

Max scan time is the maximum scan time per channel. The Max scan time should be always greater than or equal to Min scan time. Both parameters are in milliseconds.

The allowed range of Min and Max scan time is 5 to 16000

This command also modifies the scan time configured with the ATS5 command(section 4.4).

To view the scan time:

AT+WST=?

This command returns the min and max scan time in milliseconds to the serial interface as follows:

MinScanTime=x

MaxScanTime=y

Both commands return the standard command response (section 4) to the serial interface.

By default, minimum and maximum scans time are set to 150 milliseconds.

4.7.6 Scanning

The command to scan for access points or ad hoc networks is

AT+WS[=<SSID>[,<BSSID>][,<Channel>][,<Scan Time>]]

Upon deployment of the command, the Adapter scans for networks with the specified parameters, and displays the results. Scanning can be performed to find networks with specific SSID or in a particular operating channel, or a combination of these parameters. Scanning for a specific SSID employs active scanning, in which probe requests are transmitted with the SSID fields being filled appropriately.

The SSID is a string containing between 1 and 32 ASCII characters, Refer section 3.7.6 for details.

This command does not support scan based on the BSSID.

The Scan Time is in units of Milliseconds with a range of 5-16000. Without issue, adapter uses the default scan time. The default minimum and maximum scan time is 150 milliseconds. This default scan time can be overridden with the command specified above (section 4.7.5)

Upon completion, the adapter reports the list of networks and information for each network along with the standard command response (section 4) one per line, in the following format to the serial interface

<space><BSSID>,<space><SSID>,<space><Channel>,<space><space><Type><space>,<space><RSSI>
><space>,<space><Security>

Also this sends out the total number of networks found as follows (after send out the above information to the serial interface).

“No. Of AP Found:<n><CR><LF>”

Where n is the total number of networks found during scan.

Type is INFRA for an infrastructure network and ADHOC for an ad hoc network.

Note:

1. In case of GS1500M/GS1550M, scan command is NOT supported in AP mode
2. Refer Appendix (Section 6.3) for GS1550M supported 802.11a channel list

4.7.7 Mode

The command to set the wireless mode:

```
AT+WM=n[,beacon interval,disable broadcast ssid,pre scan*]
```

If *n* is 0, the mode is set to *infrastructure*; if *n* is 1, the mode is set to *ad hoc*.

If *n* is 2, the mode is set to limited AP so that the adapter can act as a limited wireless Access Point. In this mode the second parameter, beacon interval is valid and the range is 50 to 1500 milliseconds. The third parameter, disable broadcast ssid, is valid in this case and valid values are:

- ▶ If disable broadcast ssid is 1, the limited AP sends beacons with ssid as broadcast.
- ▶ If disable broadcast ssid is 0 or not specified then limited AP sends beacons with ssid as the ssid. This is the default value.
- ▶ If *n* is 3, the mode is set to P2P. This mode is applicable for GS1500M only. Refer 4.21.1 section for more details.

*The fourth parameter is valid only for GS1500M/GS1550M. Its optional parameter. If disabled, it will skip pre-scanning during limited AP switch over. If enabled, before switching to limited AP, it will do scan on all channels. Since GS1500M/GS1550M does not support scanning in limited AP mode, its required to enable pre scan for web provisioning(refer section 4.16.1). If web provisioning is not required then one can disable the pre-scan to minimize the limited AP configuration time.

S2W Adapter uses infrastructure(0) as the default mode.

This command returns the standard command response (section 4) to the serial interface.

4.7.7.1 Set PHY Mode **

Not Supported on the GS1011.

To set PHY mode:

```
AT+WPHYMODE=<PHY mode>
```

PHY mode can take following parameters:

1	802.11 b only
2	802.11b/g/n only
3	802.11g only
4	802.11a (5GHz)

Note: 802.11a mode is supported only in GS1550M

4.7.7.2 Get PHY Mode **

Not Supported on the GS1011.

The command to get PHY mode:

AT+ WPHYMODE=?

This command will return one of the following values:

1	802.11 b only
2	802.11b/g/n
3	802.11g only
4	802.11a (5GHz)

4.7.7.3 Set country code **

Not Supported on the GS1011.

To set country string :

AT+WCCOUNTRY=<country string>

Where country string is two characters in length. Its applicable only for limited AP mode. By default country code is set to 'US'

Some of the valid country codes are US,JP,GB,FR

Example:

AT+WCCOUNTRY=US

AT+WCCOUNTRY=JP

4.7.8 Associate with a Network, or Start an Ad Hoc or Infrastructure (AP) Network

The command to associate to an access point, to join an ad hoc network or to create an ad hoc/ infrastructure (AP)/ network is

AT+WA=<SSID>[, [<BSSID>] [, <Ch>] , [Rssi Flag]]

In infrastructure mode (section 4.7.7, n is 0), the adapter will attempt to associate with the requested network. In ad hoc mode (section 4.7.7, n is 1), if a network with the desired SSID or channel or both is not found, then a new network is created. However, if the BSSID was specified in the request and the applicable BSSID is not found, the Adapter will report an error and will not create an ad hoc network.

In AP mode (section 4.7.7, n is 2), the adapter creates an infrastructure network (limited AP) with the SSID passed

The SSID is a string containing between 1 and 32 ASCII characters. Refer section 3.7.6 for details.

Rssi Flag is an optional parameter with values:

1 is for associate to the AP specified by SSID with highest RSSI value.

0 or not issue this parameter, associate to the AP specified by SSID without considering RSSI value. This is the default settings.

Upon completion, the adapter reports its IP address to the serial interface in the following format:

<LF><4 spaces>IP<14 spaces>SubNet<9 spaces>Gateway<3 spaces>

<space><IP address>:<space><SubNet address>:<space><Gateway address>

In addition to the usual status responses, this command will return ERROR or 1 (depending on verbose status) if a valid command was issued but association failed.

In adhoc and AP modes, the radio should be on in active mode (section 4.8.11)

Refer Appendix(Section 6.3) for GS1550M supported 802.11a channel list

4.7.9 Disassociation

AT+WD

An equivalent command is

ATH

The interface disassociates from the current infrastructure or ad hoc network, if associated. This command returns the standard command response (section 4) to the serial interface.

Note: For GS1500M, if AT+WD command is used in P2P mode, will result in P2P disconnect.

4.7.10 WPS

The command to associate to an AP using WPS is

AT+WWPS=<METHOD>[,PIN]

- ▶ METHOD is push button (1) or pin (2).
- ▶ PIN is the pin for PIN method.

Upon execution of this command, the adapter uses either push button or pin method as per the METHOD parameter to associate to the WPS enabled AP. The PIN is optional and is valid for pin method only.

In addition to the usual status responses this command returns the following information to the serial host on success case:

- ▶ SSID=<ssid>
- ▶ CHANNEL=<channel>
- ▶ PASSPHRASE=<passphrase> for wpa/wpa2 security;
- ▶ WEP KEY=<wep key> for WEP security;
- ▶ WEPKEYINDEX=<key index> for WEP security

The above information is send to the serial interface with one information element per line.

This command returns ERROR or 1 (depending on verbose status) if a valid command was issued but WPS failed.

On success case the serial host should issue the AT+NDHCP=0/1 to establish the L3 connection.

4.7.11 Status

The command to retrieve information about the current network is

AT+NSTAT=?

Upon deployment of this command, the adapter reports the current network configuration to the serial host:

- ▶ MAC address;
- ▶ WLAN state;
- ▶ SSID;
- ▶ Mode;
- ▶ Security;
- ▶ Channel;
- ▶ BSSID;
- ▶ Network configuration: IP Address, Subnet mask, Gateway address, DNS1 address, DNS2 address;
- ▶ TX count;
- ▶ RX count.
- ▶ RSSI value

in addition to the usual status response.

An alternate command is:

AT+WSTATUS

The adapter reports the current network configuration to the serial host:

- ▶ Mode;
- ▶ Channel;
- ▶ SSID;
- ▶ BSSID;
- ▶ Security;

if the adapter associated to an Access Point. If no association is present, the error message NOT ASSOCIATED is returned, in addition to the standard command response (section 4).

4.7.12 Get RSSI

AT+WRSSI=?

Upon deployment of this command, the current RSSI value (in dBm) is output on the serial port in ASCII format, in addition to the standard command response.

4.7.13 Set Transmit Rate

AT+WRATE=<value>

Upon deployment of this command, the current transmit rate is set the value provided. While setting the transmission rate, one of the following values should be used. The default setting is 0, means auto rate.

1. GS1011M

Value	Corresponding Transmission Rate Set
0	Auto
2	1 MBPS
4	2 MBPS
11	5.5 MBPS
22	11 MBPS

2. GS1500M

Value	Corresponding Transmission Rate Set
0	Auto
2	1 MBPS
4	2 MBPS
11	5.5 MBPS
22	11 MBPS
12	6 MBPS
18	9 MBPS
24	12 MBPS
36	18 MBPS
48	24 MBPS

72	36 MBPS
96	48 MBPS
108	54 MBPS
13	6.5 MBPS
26	13 MBPS
39	19.5 MBPS
52	26 MBPS
78	39 MBPS
104	52 MBPS
117	58.5 MBPS
130	65 MBPS
720	7.2 MBPS
1440	14.4 MBPS
2170	21.7 MBPS
2890	28.9 MBPS
4330	43.3 MBPS
5780	57.8 MBPS
7220	72.2 MBPS

This command returns the standard command response (section 4) to the serial interface.

4.7.14 Get Transmit Rate

Obtain the current transmit rate of the data frame. AT+WRATE=?

Upon deployment of this command, the current transmit rate used is output on the serial port in ASCII format in following format along with the standard command response

- GS1011M

Value	Corresponding Transmission Rate Set
0	Auto
2	1 MBPS
4	2 MBPS
11	5.5 MBPS
22	11 MBPS

2. GS1500M

Value	Corresponding Transmission Rate Set
0	Auto
2	1 MBPS
4	2 MBPS
11	5.5 MBPS
22	11 MBPS
12	6 MBPS
18	9 MBPS
24	12 MBPS
36	18 MBPS
48	24 MBPS
72	36 MBPS
96	48 MBPS
108	54 MBPS
13	6.5 MBPS
26	13 MBPS
39	19.5 MBPS
52	26 MBPS
78	39 MBPS
104	52 MBPS
117	58.5 MBPS
130	65 MBPS
720	7.2 MBPS
1440	14.4 MBPS
2170	21.7 MBPS
2890	28.9 MBPS
4330	43.3 MBPS
5780	57.8 MBPS
7220	72.2 MBPS

4.7.15 Set Retry count

AT+WRETRY=<retrycount>

Upon deployment of this command, the current wireless retry count is set to the supplied value. The transmission retry count determines the maximum number of times a data packet is retransmitted, if an 802.11 ACK is not received. (Note that the count includes the initial transmission attempt.) The valid range is 4 to 7 with default value 5 for GS1011M and 7 for GS1500M

This command returns the standard command response (section 4) to the serial interface.

4.7.16 Get Clients Information

The command to get the information about the clients associated to the adapter when it act as a Limited AP or P2p GO (GS1500M):

AT+APCLIENTINFO=?

Upon issuing this command, mac address and the IP of each of the client associated to the Limited AP is displayed in a table format. The IP address will be the one assigned to the client using DHCP. In case the client assigned with the IP statically, “****” is displayed.

The table format displayed will be as below:

<i>No</i>	<i>MacAddr</i>	<i>IP</i>
-----------	----------------	-----------

Each row in the tabular display ends with “\r\n”. This command returns the standard command response (section 4) also to the serial interface.

4.7.17 MAC filter

The command to set the mac filter is:

AT+ MACFILTER=<LIST TYPE>,<ACTION>,<MAC ADDRESS>

List Type:

0-> Allow list and 1-> deny list.

Action:

0->To add to list.

1-> to delete from the list.

Mac Address:

Mac address to add/delete. The format of the MAC address is an 6-byte colon-delimited hexadecimal number. An example is shown below

AT+ MACFILTER=0,0,00:1d:c9:00:00:01

This command returns the standard command response (section 4) also to the serial interface.

4.7.18 Limited AP PS Mode

The command to enable/disable the ps poll feature in limited AP mode is:

AT+PSSTA=<Enable/Disable>,<OPERATION>,<MAC ADDRESS>

Enable/Disable: whether to enable or disable the PS POLL feature.0->disable,1->enable

Operation: 0-> Add the mac address of station , 1->Delete the mac address of the station.

Mac Address: mac Address of the station. The format of the MAC address is an 6-byte colon-delimited hexadecimal number.This command configures the power save in limited AP mode. This command returns the standard command response (section 4) to the serial interface.

4.8 Wi-Fi Security Configuration

4.8.1 Authentication Mode

AT+WAUTH=n

n is:

- ▶ 0- None
- ▶ 1 – Open
- ▶ 2 – Shared with WEP

Note that this command configures the authentication mode, but any required encryption keys must be set using the key commands described below. This authentication mode command is specific to WEP encryption; if WPA/WPA2 operation is employed, the authentication mode may be left at the default value “None”. This command returns the standard command response (section 4) to the serial interface.

4.8.2 Security Configuration

The S2w adapter supports a strict security configuration.

AT+WSEC= n

Where *n* is:

- ▶ 0 – Auto security (All)
- ▶ 1 – Open security
- ▶ 2 – Wep security
- ▶ 4 – Wpa-psk security
- ▶ 8 – Wpa2-psk security
- ▶ 16 – Wpa Enterprise
- ▶ 32 – Wpa2 Enterprise
- ▶ 64 - Wpa2-aes+tkip security

The s2w adapter supports either one of the above value with default security configuration as auto. This strict security compliance is not applicable for WPS feature. This command returns the standard command response (section 4) to the serial interface.

4.8.3 WEP Keys

AT+WWEpn=<key>

n is the key index, between 1 and 4, and key are either 10 or 26 hexadecimal digits corresponding to a 40-bit or 104-bit key. Some examples:

AT+WWEp1=123456abdc

AT+WWEp3=abcdef12345678901234567890

Upon receiving a valid command, the relevant WEP key is set to the value provided. This command returns the standard command response (section 4) to the serial interface.

4.8.4 WPA-PSK and WPA2-PSK Passphrase

The command to set the WPA-PSK and WPA2-PSK passphrase is

AT+WWPA=<passphrase>

The passphrase is a string containing between 8 and 63 ASCII characters, used as a seed to create the WPA *pre-shared key* (PSK).

If the comma (,) is a part of the passphrase, then the passphrase parameter is to be framed in double quotation marks ("passphrase"). Refer section 3.7.7 for details.

Upon receiving the command, the PSK passphrase is reset to the value provided. This command returns the standard command response (section 4) to the serial interface.

4.8.5 WPA-PSK and WPA2-PSK KEY CALCULATION

Computation of the PSK from the passphrase is complex and consumes substantial amounts of time and energy. To avoid recalculating this quantity every time the adapter associates, the adapter provides the capability to compute the PSK once and store the resulting value. The key value is stored in the SRAM copy of the current profile; the profile needs to be saved in flash memory for this value to persist during a transition to Standby. The command to compute and store the value of the WPA/WPA2 PSK, derived from the passphrase and SSID value, is

AT+WPAPSK=<SSID>,<PASSPHRASE>

The passphrase is a string containing between 8 and 63 ASCII characters, used as a seed to create the PSK. The SSID is a string of between 1 and 32 ASCII characters. Refer section 3.7.7 for details

Each Parameter of the above command separated by comma (,). If the comma(,) is a part of the SSID or PASSPHRASE, then SSID and PASSPHRASE parameters is to be framed in double quotation marks ("SSID","PASSPHRASE").

When the command is issued, the adapter immediately responds with "<LF>Computing PSK from SSID and PassPhrase". Computation of the passphrase can be time-consuming! When it is

complete, the adapter will issue the usual OK or 0. Invalid inputs will result in ERROR: INVALID INPUT or 2, as usual.

Upon receiving the command, the adapter computes the PSK from the SSID and passphrase provided, and stores those values in the current profile. The current profile parameters PSK Valid, PSK-SSID, and WPA Passphrase are updated, and can be queried with AT&V (4.6.5). The next time the adapter associates to the given SSID, the PSK value is used without being recalculated.

After the PSK has been computed, the commands AT&W (to save the relevant profile) and AT&Y (to ensure that the profile containing the new PSK is the default profile) should be issued. The PSK will then be available when the adapter awakens from Standby. Refer to sections 0 and 4.6.3 for more information on profile management.

4.8.6 WPA-PSK and WPA2-PSK KEY

The command to configure the WPA / WPA2 PSK key directly is

```
AT+WPSK=<PSK>
```

This command directly sets the pre-shared key as provided. The argument is a 32-byte key, formatted as an ASCII hexadecimal number; any other length or format is considered invalid. Example:

```
AT+WPSK= 0001020304050607080900010203040506070809000102030405060708090001
```

This command returns the standard command response (section 4) to the serial interface.

After the PSK has been entered, the commands AT&W (to save the relevant profile) and AT&Y (to ensure that the profile containing the new PSK is the default profile) should be issued. The PSK will then be available when the adapter awakens from Standby. Refer to sections 0 and 4.6.3 for more information on profile management.

4.8.7 EAP-Configuration

AT+WEAPCONF=<Outer Authentication>,<Inner Authentication>,<user name>,<password>[,<PEAP with certificate>]

Upon execution of this command, the adapter set the Outer authentication, Inner authentication, user name and password for EAP Security. This command returns the standard command responses (section 4).

The valid outer authentication values are:

Eap-FAST: 43

Eap-TLS: 13

Eap-TTLS: 21

Eap-PEAP: 25

The valid Inner Authentication values are:

Eap-MSCHAP: 26

Eap-GTC: 6

The user name is an ascii string with maximum length of 32 ascii characters.

The password is an ascii string with maximum length of 32 ascii characters.

For PEAP with certificates set the optional parameter to 1. For example

`AT+WEAPCONF = 25,26,gsn,GSDemo123,1”` (PEAP v0 with Certificate)

`AT+WEAPCONF = 25,6,gsn,GSDemo123,1”` (PEAP v1 with Certificate)

4.8.8 EAP

The command to configure certificate for EAP-TLS is

`AT+WEAP=< Type >,< Format >,< Size >,< Location ><CR><ESC>W <data of size above>`

- ▶ Type: CA certificate(0)/ Client certificate(1)/ Private Key(2)
- ▶ Format: Binary(0)/Hex(1)
- ▶ Size: size of the file to be transferred.
- ▶ Location: Flash(0)/Ram(1)

Note: There is a carriage return after <location>

This command enables the adapter to receive the certificate for EAP-TLS. This command stores the certificate in flash or RAM, depending on the parameter. Upon deployment of this command, the interface returns the standard command response (section 4) or ERROR, 1 (verbose disabled), if the operation failed.

4.8.9 Certificate Addition

The command to configure the certificate for SSL/HTTPS connection :

`AT+TCERTADD=<Name>,<Format>,<Size>,<Location><CR><ESC>W<data of size above>`

- ▶ Name: Name of the certificate
- ▶ Format: Binary(0)/Hex(1)
- ▶ Size: Size of the file to be transferred.
- ▶ Location : Flash (0)/Ram(1)

Note: There is a carriage return after <location>

This command enables the adapter to receive the certificate for SSL/HTTPS connection. It stores the certificate in flash or ram depends on the parameter. Upon deployment of this command, the interface returns the standard command response (section 4) or ERROR, 1 (verbose disabled), if the operation failed.

4.8.10 Certificate Deletion

AT+TCERTDEL=<certificate name>

This command deletes the SSL/HTTPS/EAP-TLS certificate stored in flash/ram by name.

In the case of EAP-TLS certificate names are:

- ▶ TLS_CA
- ▶ TLS_CLIENT
- ▶ TLS_KEY

Upon deployment of this command, the interface returns the standard command response (section 4) or ERROR, 1 (verbose disabled), if the operation failed.

4.8.11 Enable/Disable 802.11 Radio

AT+WRXACTIVE=*n*

If *n* is 0, the radio is disabled and if *n* is 1, the radio is enabled with default setting as disabled.

This command returns the standard command response (section 4) to the serial interface. If WRXACTIVE = 1, the 802.11 radio receiver is always on. This minimizes latency and ensures that packets are received at the cost of increased power consumption. The GainSpan SOC cannot enter Deep Sleep (section 4.13.1) even if it is enabled (PSDPSLEEP=1). Power Save mode (section 4.8.12) can be enabled but will not save power, since the receiver is left on. If WRXACTIVE = 0, the receiver is switched off after association is complete. If Power Save mode is not enabled (WRXPS not issued or WRXPS=0), the receiver will not be turned on again unless WRXACTIVE = 1 is received. Packets will not be received, and disassociation could occur. If Power Save mode is enabled (WRXPS=1) prior to issuing WRXACTIVE = 0, the receiver will be turned off, but will turn on again when it is time to listen for the next beacon from the Access Point. If Deep Sleep is also enabled, the receiver will turn off, and the SOC will enter Deep Sleep when all pending tasks are completed, but again the system will be awakened to listen to the next beacon. If a transition to Standby is requested and occurs (section 4.13.2), the SOC will remain in Standby for the requested period, and will **not** awaken to receive a beacon during that time.

4.8.12 Enable/Disable 802.11 Power Save Mode

AT+WRXPS=*n*

If *n* is 0, Power Save is disabled and if *n* is 1, Power Save is enabled with default setting as enabled.

This command returns the standard command response (section 4) to the serial interface. In 802.11 Power Save Mode, the node (in this case, the Serial2WiFi Adapter) will inform the Access Point that it will become inactive, and the Access Point will buffer any packets addressed to that node. In this case, the GainSpan SOC radio receiver is turned off between beacons. The node will awaken to listen to periodic beacons from the Access Point that contains a Traffic Indication Map (TIM) that will inform the Station if packets are waiting for it. Buffered packets can be retrieved at that time, using **PSPoll** commands sent by the node. In this fashion, power consumed by the radio is reduced (although the benefit obtained depends on traffic load and beacon timing), at the cost of some latency. The latency encountered depends in part on the timing of beacons, set by the Access Point configuration. Many Access Points default to 100msec between beacons; in most cases this parameter can be adjusted.

4.8.13 Set Power Save Mode Used During Association

The command to configure 802.11 Power Save Mode to be *used during the association* is

AT+WAPSM=<Value>

Based on the <value> provided, the following scheme is adopted for power save mode:

Default Radio Rx Mode			
Value	Active Mode	PS Poll Mode	OFF
0	Receiver is kept active ON throughout the joining procedure. (Default)		
1	Receiver is active ON throughout the joining procedure	Receiver is active ON but is in PS Poll mode during time consuming key calculation during the joining procedure	Receiver is active ON but turned OFF during time consuming key calculation during the joining procedure
2	Receiver is active ON throughout the joining procedure	Receiver is kept PS POLL mode throughout the joining procedure	Receiver is kept PS POLL mode throughout the joining procedure
3	Receiver is active ON throughout the joining procedure	Receiver is kept PS POLL mode throughout the joining procedure	Receiver is kept ON in PS POLL mode but turned OFF during time consuming key calculation during the association procedure

4.8.14 Enable/Disable Multicast Reception

Multicast AND broadcast reception are tied together.

AT+MCSTSET=n

	Power save Parameter	Listen beacon Parameter	Listen Multicast Parameter	Radio State
1	Disable (=0) At+wxactive=1	Don't Care	Don't Care	Radio is always ON
2	Disable (=0) At+wxactive=1	Disable at+wxps=0	Don't Care	Setting Not Valid – Radio will be always ON
3	Enable (=1) At+wxactive=0	Disable at+wxps=0	Don't Care	Setting Not Valid – radio will be in PS mode turning ON and OFF every listen interval or DTIM depending on “listen multicast” setting

4	Enable (=1) At+wrxactive=0	Enable at+wrxps=1	Disable	Radio is turned ON based on listen interval; see below for listen interval setting
5	Enable (=1) At+wrxactive=0	Enable at+wrxps=1	Enable	Radio is turned ON based on DTIM interval

n = 0, 802.11 MAC layer multicast + broadcast reception is disabled.

n = 1, 802.11 MAC layer multicast + broadcast reception is enabled.

By default the 802.11 MAC layer multicast + broadcast reception is enabled. This command returns the standard command response (section 4) to the serial interface.

Reception of all higher layer (IP and above) multicast AND broadcast packets is disabled when selecting the AT+MCSTSET=0 option. When disabled, the ability for the node to receive higher layer broadcast traffic such as ARP responses, that are needed to establish IP layer communication, is also disabled.

While the GainSpan node supports MAC layer multicast reception when AT+MCSTSET=1, it DOES NOT SUPPORT IGMP group membership packet and associated IGMP packet transmission.

Enabling 802.11 MAC layer multicast by issuing the AT+MCSTSET=1 command enables IP layer multicast packet reception at the moment 802.11 MAC layer multicast + broadcast reception is enabled and DOES NOT ENABLE IP layer multicast traffic in the traditional IETF definition of IP multicast. The GainSpan node will still not have the ability of advertising its subscription to an IP multicast group to routers above it through IGMP group membership messages even when AT+MCSTSET=1 is issued.

GS1500M: RXPS cannot be set to zero for GS1500M. For example, the radio must be in active mode or PS mode. It cannot be turned OFF completely. The following table shows valid combinations for the above two parameters for GS1500M.

4.8.15 Antenna Configuration **

Not Supported on the GS1011.

The command to set the antenna configuration is

AT+ANTENNA=<antenna>

	1	2
GS1500M	PCB antenna	UFL antenna
GS1550M	Antenna#1	Antenna#2

By default antenna is configured to value 2.

This command returns the standard command response (section 4) to the serial interface.

4.8.16 To get currently active antenna **

Not Supported on the GS1011M.

at+antenna=?

This command returns currently active antenna number(1 or 2)

4.8.17 Transmit power

AT+WP=<power>

On reception of this command, the transmit power is set to the supplied value. The desired power level shall be specified in ASCII decimal format. The value of the parameter can range from 0 to 7 for internal PA GS101x, with a default value of 0 (for maximum RF output) and from 2 to 15 for external PA GS101x, with default value of 2 (for maximum RF output).

GS1500M the default value is 0. Output power is as specified in the GS1500M datasheet. This command returns the standard command response (section 4) to the serial interface.

4.8.18 Sync Loss Interval

AT+WSYNCINTRL=<n>

n is the number of beacon interval.

On execution of this command the adapter set the sync loss interval for n times the beacon interval so that if the adapter does not receive the beacon for this time it informs the user this event as “Dissociation event”. The default value of sync loss interval is 100. This command accept the sync loss interval from 1 to 65535.

This command returns the standard command response (section 4) to the serial interface.

4.8.19 External PA *

Not Supported on the GS1500M.

AT+EXTPA=<n>

n=1 to enable the external PA

n=0 to disable external PA

If enabled ,this command forces the adapter to standby and comes back immediately and causing all configured parameters and network connection will be lost.

This command returns the standard command response (section 4) to the serial interface.

4.8.20 Association Keep Alive Timer *

Not Supported on the GS1500M.

AT+PSPOLLINTRL=<n>

On execution of this command, the adapter will set the keep-alive time interval for n seconds. This keep-alive timer will fire for every n seconds once the adapters associated. This timer will keep the adapter in associated state even there is no activity between AP and adapter. The default vale is 45 seconds. This command accepts keep-alive timer interval from 0 to 65535 seconds. The value 0 disables this timer.

This command returns the standard command response (section 4) to the serial interface.

4.8.21 IEEE Optimized PS Poll Interval

AT+WIEEESPOLL=<n>[,listen beacon interval]

n is 0, to disable this feature and n is 1 for enable this feature. If it is enabled, then the second parameter listens during the beacon interval and at valid beacon intervals where the WLANA wakes up for listening to the beacon. Although this is a 16bit value, the maximum recommended is 10.

Note: **Disabling this feature (i.e n=0) is not Supported on the GS1500M.**

On execution of this command, the adapter will set the listen interval for n beacons. This command accepts interval from 1 to 65535 beacons.

The parameters set using this command will come in to force only at the time of Association done after the command is issued.

This command returns the standard command response (section 4) to the serial interface.

For GS1500M, the use of listen interval for wakeup depends on the multicast parameter. If multicast reception is enabled, then the wakeup is based on DTIM interval. If multicast reception is disabled, then the wakeup is based on listen interval. If not set, the default value of listen interval for GS1500M is 50.

4.8.22 WLAN Keep Alive Interval **

Not Supported on the GS1011M.

AT+ WKEEPALIVE=<n>

On execution of this command, the adapter will set the keep-alive interval for n seconds. This keep-alive timer will fire for every n seconds once the adapters associated. This timer will keep the adapter in associated state even there is no activity between AP and adapter. The default keep alive timer (value is 45 seconds . This command accepts keep-alive timer interval from 0 to 255 seconds. The value 0 disables this timer.

This command returns the standard command response (section 4) to the serial interface.

4.8.23 Configure Antenna Diversity Feature **

Not Supported on the GS1011M and GS1500M.

at+antdiv=<enable>[,<antSwitchPeriod>,<antSwitchRssiAvg>,<antEvalDuration>]

Antenna diversity will be disabled by default. It is enabled using the above command. The parameters can be changed using the same command.

1. antSwitchPeriod: The periodicity of antenna switch. The antenna evaluation duration is excluded from this.

2. `antSwitchRssiAvg`: The value of average rssi at the end of `antSwitchPeriod` below which antenna switch will be done.
3. `antEvalDuration`: The duration for which the alternate antenna is evaluated for the sake of antenna switching.

This command returns the standard command response (section 4) to the serial interface.

Example:

To enable antenna diversity feature:

```
at+antdiv=1,10,-65,5
```

To disable antenna diversity feature:

```
at+antdiv=0
```

Detailed description:

By default Antenna#2 is configured as active antenna. Average RSSI will be measured at the end of 'antSwitchPeriod' (for e.g. 10 seconds). If average RSSI is below the configured threshold 'antSwitchRssiAvg' (for e.g. -65 dbm), then it will switch to other antenna (for e.g. Antenna#1). After switching wait for shorter evaluation duration 'antEvalDuration' (for e.g. 5 seconds). At the end of evaluation period the average RSSI will be read. If current average RSSI of new antenna is greater than or equal to the average RSSI of previous antenna, then stay on the current antenna. Otherwise switch back to previous antenna.

4.9 Network Interface

4.9.1 Network Parameters

Note that IP addresses in the network commands are to be given in ASCII dotted-decimal format.

4.9.2 DHCP Client Support

```
AT+NDHCP=n[ ,hostname]
```

If *n* is 0, DHCP is disabled and if *n* is 1, DHCP is enabled.

hostname is a string with maximum character length of 15. This will be displayed by Access Points as the hostname in the DHCP Clients table

If the interface is associated with a network, enabling DHCP will cause an attempt to obtain an IP address using DHCP from that network. Thus issuing this command with *n*=1 will cause the Adapter to attempt to refresh an existing DHCP address. If the Adapter is not associated when the command is received, future associations will attempt to employ DHCP. If the adapter fails to obtain an address via DHCP it will return an error response `ERROR: IP CONFIG FAIL` if verbose is enabled, or `F(0x0F)` if verbose is disabled.

If the interface is not associated, this command returns the standard command response (section 4) else it returns the ip address information along with the standard command response (section 4) in the following format:

```
<LF><4 spaces>IP<14 spaces>SubNet<9 spaces>Gateway<3 spaces><CR><LF>
<space><IP address>:<space><SubNet address>:<space><Gateway address>
```

By default, DHCP is disabled.

Note:

If the dhcp renewal failed then the adapter closes all the sockets opened and send an error message “ERROR: IP CONFIG FAIL” to the serial interface. The host can re-issue the network config command (section 4.9.2) to redo the dhcp procedure again

If the dhcp renewal success with a new ip address then the adapter closes all the sockets opened and send a message “IP CONFIG-NEW IP” with the new ip information in the above mentioned format to the serial interface. The host can use this new IP and able to open sockets.

4.9.3 Static Configuration of Network Parameters

AT+NSET=<Src Address>,<Net-mask>,<Gateway>

Upon deployment of this command, any previously-specified network parameters are overridden, and the Adapter is configured to use the newly-specified network parameters for the current association, if associated, and for any future association. The use of DHCP is disabled if the network parameters are configured statically. The DNS address can be set using AT+DNSSET (4.9.14).

This command returns the standard command response (section 4) to the serial interface.

4.9.4 MDNS Module Initialization

AT+MDNSSTART

This command starts the mdns module of the adapter. This command returns the standard command response (section 4) to the serial interface.

4.9.5 MDNS Host Name Registration

A unique name shall be given to each of the node. AT+MDNSHNREG=[<Host name>],<Domain name>

Domain name : shall always “local” that is ‘.local’ domain

Host name : is optional. If host name is not given, factory default name concatenated with last 3 bytes of the mac address shall be taken.

Example: if the factory default host name is “GAINSPAN” and the mac address of the node is “00-1d-c9-00-22-97”, then AT+MDNSHNREG=,local

Will take the host name as “GAINSPAN_002297”

This command returns the standard command response (section 4) to the serial interface.

4.9.6 MDNS Host Name De-Registration

AT+MDNSHNDEREG==<host name>,<Domain name>

Domain name : is the domain name registered using above command

Host name : is host name registered using above command.

This command returns the standard command response (section 4) to the serial interface.

4.9.7 MDNS Services Registration

AT+MDNSSRVREG=<ServiceInstanceName>,[<ServiceSubType>],<ServiceType>,<Protocol>,<Domain>,<port>,<Default Key=Val>,<key 1=val 1>,<key 2=val 2>.....

ServiceInstanceName : Name of the service

ServiceSubType: Service sub type if any.

ServiceType: is the service type

Protocol: Protocol used(-tcp/_udp)

Domain: Domain and it should be "local"

Port: is the port used for the communication(80 for HTTP)

Default Key: is a number.0 indicates no default key=val to added

Adapter support a two default key value pairs to be used with iPhone/Android applications. 1-Provisioning, 2- Over the Air Fw Up

Example: AT+MDNSSRVREG=LightSensor,,_http,_tcp,local,80

This command returns the standard command response (section 4) to the serial interface.

4.9.8 MDNS Services De-Registration

AT+MDNSSRVDEREG=<ServiceInstanceName>,[<ServiceSubType>],<ServiceType>,<Protocol>,<Domain>

The parameters are same as the above command.

This command returns the standard command response (section 4) to the serial interface.

4.9.9 MDNS Services Announce

AT+MDNSANNOUNCE

This command returns the standard command response (section 4) to the serial interface.

4.9.10 MDNS Service Discover

AT+MDNSSD=[<Service sub type>],<Service type>,<Protocol>,<Domain>

ServiceSubType: Service sub type if any.

ServiceType: is the service type

Protocol: Protocol used(-tcp/_udp)

Domain: Domain and it should be "local"

This command returns the standard command response (section 4) to the serial interface.

Example: AT+MDNSSD=,_http,_tcp,local

4.9.11 MDNS Module De-Initialization

AT+MDNSSTOP

This command stops the mdns module of the adapter. This command returns the standard command response (section 4) to the serial interface.

4.9.12 DHCP Server

The adapter support DHCP server and the command to start/stop the server is

AT+DHCPSEVR=<Start/Stop>[,<Dns Option Disable>,<Gateway Option Disable>]

Start/Stop: 1 is for start the server and 0 is for stop the server.

Dns Option Disable: 1 is for disable and 0 is for enable with enable as default.

Gateway Option Disable : 1 is for disable and 0 is for enable with enable as default.

Prior to start the server, the adapter should be configured with a valid static ip address (using command described in section 4.9.3, both Src address and Gateway should be same) and created or configure to create a limited AP network.

This DHCP server can support maximum 32 client connections with server ip as the statically configured IP address and client ip address starts from the next ip address of the configured static IP address.

This command returns the standard command response (section 4) to the serial interface

4.9.13 DNS Server

AT+DNS=1/0,<url>

1 is for start the server and 0 is for stop the server.

URL is the DNS name associated to the DNS IP address.

Prior to start the server, the DHCP server (section 4.9.4) should be started and created or configure to create a limited AP network. This DNS server use the same DHCP server ip address as it ip address.

This command returns the standard command response (section 4) to the serial interface.

4.9.14 DNS Lookup (Client)

Receive an IP address from a host name.

AT+DNSLOOKUP=<URL> , [<RETRY> , <TIMEOUT-S> , <CLEAR CACHE ENTRY>]

where URL is the hostname to be identified. Upon deployment of this command, the Adapter queries the DNS server to obtain the IP address corresponding to the hostname provided in URL, and returns the address if found. Retry and timeout are optional; if they are not given, or if 0 values are provided, the default value of 2 is used. Timeout is in seconds.

The retry range is 0 to 10 and timeout range is 0 to 20.

CLEAR CACHE ENTRY: 1 is for clear the entry from DNS cache and 0 is for keep it in cache, with default is 0.

In addition to the standard command response, the interface returns ERROR (1, if verbose disabled) if a valid command was issued but DNS lookup failed.

Note: The DNS protocol has a TTL field to keep the entry valid for the “TTL” amount of time by the stack. If any DNS query request is sent by application to the stack for a record whose TTL is valid, then a new query request is not sent out and the value from the existing DNS entry is given back. If user wants to get new DNS lookup each time, then they should use the clear cache entry parameter.

4.9.15 Static Configuration of DNS (Client)

```
AT+DNSSET=<DNS1 IP> , [ <DNS2 IP> ]
```

This command sets the values of the DNS server addresses to be used by the adapter. The second address, DNS2 IP, is optional but should not be same as DNS1 IP. This command returns the standard command response (section 4) to the serial interface.

This static configuration of DNS set will take effect only in the case of static IP address on the adapter.

4.9.16 Store Network Context

Store the network context and configuration prior to a transition to Standby.

```
AT+STORENWCONN
```

This command will preserve network connection parameters (layer 2 and layer 3 information) in RTC memory when the GainSpan SOC is sent to Standby mode using the Request Standby command (4.13.2). Note that CID's are lost when the transition to Standby occurs. In addition to the standard response (section 4) this command returns “DISASSOCIATED” or 9 (based on verbose setting) if the interface is not associated state.

With Arp cache enabled this command store the ARP entries to the non-volatile memory.

For the GS1500M, if a device is operating in P2P mode as a client or GO, then this command can be used to store the P2P context.

4.9.17 Restore Network Context

```
AT+RESTORENWCONN
```

This command reads the layer 3 (IP) network connection parameters saved by Store Network Context (4.9.3), and reestablishes the connection that existed before the transition to Standby. If needed, the node will re-associate and re-authenticate with the specified SSID. In addition to the usual status responses, this command returns ERROR or 1 (based on verbose setting) if it is called prior to storing the network connection, or after storing the network connection but before a transition to Standby has occurred.

With Arp cache enabled, this command re-store the ARP entries stored in the non-volatile memory to the adapter's network stack.

GS1500M: In case of GS1500M, once the system goes to standby and comes out, the L2 connection is lost. “restore connection” will always initiate a L2 connection after coming out of standby. If a device is operating in P2P mode, as a client or GO, then this command can be used to restore the P2P context.

4.9.18 ARP CACHE ENABLE

The adapter supports caching of the ARP entries(max 8) in its nonvolatile memory and available across standby wakeup cycle.

AT+NARPCACHEEN=<Enable>

Enable : 1 to start the caching and 0 to stop the caching.

The adapter starts caching ARP entries and upon the store network command (section 4.9.15) update to its nonvolatile memory.

The adapter starts caching ARP entries and stores it to in nonvolatile memory. ARP aging is not supported. When L2 connection is lost, the ARP entries will also be invalidated.

Returns the standard command response (section 4) to the serial interface.

4.9.19 ARP DELETE

AT+NARPCACHEDEL

The standard command response (section 4) to the serial interface.

4.9.20 ARP ENTRY LISTING

AT+NARP=?

The interface get the ARP entries present in the adapter's network stack and send to the serial interface in the following format:

Macaddress<space>:<space>IP address

The Macaddress format is xx:xx:xx:xx:xx:xx and the Ip address format is xxx.xxx.xxx.xxx

This command returns the standard command response (section 4) to the serial interface.

4.10 Connection Management Configuration

All connection commands, except for the transport of Raw Ethernet data (section 4.10.16), use the embedded TCP/IP Network Stack functions to perform the required actions. Connection identifiers, denoted as <CID> below, are to be sent as single hexadecimal characters in ASCII format.

4.10.1 Network Interface Filter

The s2w adapter supports a feature called network interface filter which controls the traffic to the network stack so that unwanted tcp/udp/icmp packets can be dropped before giving to the network stack. This feature prevents the DOS attacks. By defaults this feature is disabled.

The command to enable/disable this feature is:

AT+L2CONFIG=<Protocol>,<Enable/Disable>

Protocol : 1→ICMP, 2→udp and tcp

0 → disable

1 → enable

Both parameters should be configured as bit wise:

Ex: AT+L2CONFIG=1,1 → enable filter for icmp reception so that no icmp pkts will not go to network stack.

AT+L2CONFIG=1,1 → disable above

AT+L2CONFIG=2,2 → enable filter for udp and tcp reception so that no udp/tcp pkts with an invalid port will not go to network stack.

AT+L2CONFIG=2,0 → disable above.

AT+L2CONFIG=3,3 → enable filter for icmp/udp and tcp

AT+L2CONFIG=3,0 → disable above .

This command returns the standard command response (section 4) to the serial interface.

4.10.2 TCP Clients

Open a TCP client connection .

AT+NCTCP=<Dest-Address> , <Port>

Upon deployment of this command, the interface attempts to open a socket and connect to the specified address and port. The connection attempt shall timeout if a socket has not been opened after a delay equal to TCP Connection Timeout.

On successful connection, the interface sends CONNECT<space><CID> to the serial host along with the standard response, where CID is the newly allocated connection identifier. ERROR or 1 is returned if a timeout occurs.

Note:

By default the TCP keep alive option is disabled but the user can enable it using the command described in section 4.10.8.

The default TCP retransmission timeout is infinite, but the user can change it using the command described in section 4.10.8

To detect the abnormal disconnection in L3 Layer after establishing the TCP connection on the S2W adapter, the user should configure the proper values of the above two timeouts.

4.10.3 UDP Clients

Open a UDP client.

AT+NCUDP=<Dest-Address> , <Port> [< , Src.Port>]

Dest-Address is the destination (server) ip address

Port is the destination (server) port

Upon deployment of this command, the interface opens a UDP socket capable of sending data to the specified destination address and port. If a source port is provided, the socket will bind to the specified port. On successful completion, the interface sends `CONNECT<space><CID>` to the serial host, followed by standard response. where CID is the newly allocated connection identifier. The port range 0xBAC0 (47808) to 0xBACF (47823) may not be used for destination port.

4.10.4 TCP Servers

Start a TCP server.

```
AT+NSTCP=<Port>,[max client connection]
```

Upon deployment of this command, the interface opens a socket on the specified port and listens for connections.

max client connection is an optional parameter which restrict the tcp server to accept that much client connections and the value range is from 1 to 15.

On successful creation of the server, `CONNECT<space><CID>` followed by standard command response (section 4) is sent to the serial host, where CID is the newly allocated connection identifier, followed by OK or 0. Up to 16 total CID's can be supported by the application, so a TCP server can support up to 15 distinct client connections, if no other entity has assigned CID's.

4.10.5 UDP Servers

Start a UDP server.

```
AT+NSUDP=<Port>
```

Upon deployment of this command, the interface:

- ▶ Allocates a CID for this connection. If no CID is available, the command fails.
- ▶ If a valid CID was allocated, a UDP socket is opened on the specified port.
- ▶ If the socket is successfully created, `CONNECT<space><CID>` is sent to the serial host, followed by standard command response. where CID is the allocated connection identifier.

The port range 0xBAC0 (47808) to 0xBACF (47823) may not be used.

4.10.6 Output Connections

```
AT+CID=?
```

This command returns the current CID configuration for all existing CID's:

- ▶ CID number, In decimal format.
- ▶ CID type;
- ▶ Protocol;
- ▶ Local port;
- ▶ Remote port;
- ▶ Remote IP address

followed by the usual status response. If no valid CID's are present, the message "<space>No valid Cids" is sent to serial interface, followed standard command response.

4.10.7 Closing a Connection

AT+NCLOSE=<CID>

Upon deployment of this command, the connection associated with the specified CID is closed, if it is currently open. On completion of this command the CID is free for use in future connections. If an invalid CID is provided, the command returns ERROR: INVALID CID or 5, depending on verbose status else it returns the standard command response (section 4)

4.10.8 Closing All Connections

AT+NCLOSEALL

Upon execution of this command, all open connections are closed and returns the standard command response (section 4).

4.10.9 SOCKET Options Configuration

Configure a socket identified by a CID.

AT+SETSOCKOPT=<CID>,<Type>,<Parameter>,<Value>,<Length>

Upon execution of this command the adapter configure the socket identified by CID with the value passed.

CID: is the socket identifier received after opening a connection.

Type: is the type of the option to be set

- ▶ SOCKET: 65535
- ▶ IP : 0
- ▶ TCP: 6

Parameter: The Option name to be set. Accepts hex values.

- ▶ TCP_MAXRT : 10(Hex)
- ▶ TCP_KEEPALIVE: 4001(Hex)
- ▶ SO_KEEPALIVE: 8(Hex)
- ▶ TCP_KEEPALIVE_CNT: 4005(Hex)

Value: The value to be set. This in seconds (Ex: 30 → 30 seconds)

Length: The length of the value in bytes (Ex: in above case it is 4, basically it tells the type of the value is integer, Short or Char)

Integer →4

Short →2

Char →1

This command returns the standard command response (section 4) to the serial interface.

Example:

Set the TCP retransmission timeout to 20 seconds is `AT+SETSOCKOPT=0,6,10,20,4`

Where 0 is the CID.

Similarly, to enable the TCP Keepalive is:

`AT+SETSOCKOPT= 0,65535,8,1,4` → Enable `SO_KEEPALIVE` option at base socket level. Without enabling this `TCP_KEEPALIVE` will not work. `AT+SETSOCKOPT= 0,6,4001,600,4` → Enable `TCP_KEEPALIVE` option at TCP level with timeout as 600 seconds.

Note: The default keepalive count is 8 so the minimum keepalive timeout is $8 \times 75 = 600$ seconds. To reduce the keepalive timeout further, set the Keepalive count first to an appropriate value and set the keepalive timeout.

Ex: To set the keep alive timeout to 75 seconds:

`AT+SETSOCKOPT =0,6,4005,1,4` → Configure TCP Keep Alive Probe Sending count at just 1.

`AT+SETSOCKOPT= 0,6,4001,75,4` → Enable `TCP_KEEPALIVE` option at TCP level with 75 seconds as Keep Alive timeout.

4.10.10 SSL Connection Open

`AT+SSLOPEN=<CID>,[<certificate name>, <client certificate name,<client key name>]`

Upon execution of this command, the adapter opens an SSL connection over the TCP connection identified by the CID. For this SSL connection, the adapter uses the certificate stored in memory that is identified by the certificate name. Prior issuing this command, a valid TCP connection should exist with connection identifier as CID. This command returns the standard command response or ERROR if the operation fails.

The client certificate name and client key name are required for SSL client authentication.

Note: Certificates and key must be in DER format.

4.10.11 Closing SSL connection

`AT+SSLCLOSE=<CID>`

Upon reception of this command, the adapter closes the existing SSL connection identified by CID. This command returns normal response codes or ERROR if the operation fails.

4.10.12 HTTP Client Configuration

AT+HTTPCONF=<Param>,<Value>

Upon reception of this command the adapter configures the HTTP parameters. The 'param' is the HTTP header and is one of the following:

- ▶ GSN_HTTP_HEADER_AUTHORIZATION (2)
- ▶ GSN_HTTP_HEADER_CONNECTION (3)
- ▶ GSN_HTTP_HEADER_CONTENT_ENCODING (4)
- ▶ GSN_HTTP_HEADER_CONTENT_LENGTH (5)
- ▶ GSN_HTTP_HEADER_CONTENT_RANGE (6)
- ▶ GSN_HTTP_HEADER_CONTENT_TYPE (7)
- ▶ GSN_HTTP_HEADER_DATE (8)
- ▶ GSN_HTTP_HEADER_EXPIRES (9)
- ▶ GSN_HTTP_HEADER_FROM (10)
- ▶ GSN_HTTP_HEADER_HOST (11)
- ▶ GSN_HTTP_HEADER_IF_MODIFIED_SINCE (12)
- ▶ GSN_HTTP_HEADER_LAST_MODIFIED (13)
- ▶ GSN_HTTP_HEADER_LOCATION (14)
- ▶ GSN_HTTP_HEADER_PRAGMA (15)
- ▶ GSN_HTTP_HEADER_RANGE (16)
- ▶ GSN_HTTP_HEADER_REFERER (17)
- ▶ GSN_HTTP_HEADER_SERVER (18)
- ▶ GSN_HTTP_HEADER_TRANSFER_ENCODING (19)
- ▶ GSN_HTTP_HEADER_USER_AGENT (20)
- ▶ GSN_HTTP_HEADER_WWW_AUTHENTICATE (21)
- ▶ GSN_HTTP_REQUEST_URL (23)

The 'value' is a string that depends on the above parameters.

This command returns standard command response (section 4) or ERROR, if the operation fails.

4.10.13 HTTP Client Configuration Removal

Remove an http client configuration.

AT+HTTPCONFDEL=<Param>

Upon reception of this command the adapter removes the HTTP configuration specified by the param. The 'param' is the HTTP header and is one of the following:

- ▶ GSN_HTTP_HEADER_AUTHORIZATION (2)
- ▶ GSN_HTTP_HEADER_CONNECTION (3)
- ▶ GSN_HTTP_HEADER_CONTENT_ENCODING (4)
- ▶ GSN_HTTP_HEADER_CONTENT_LENGTH (5)
- ▶ GSN_HTTP_HEADER_CONTENT_RANGE (6)
- ▶ GSN_HTTP_HEADER_CONTENT_TYPE (7)
- ▶ GSN_HTTP_HEADER_DATE (8)
- ▶ GSN_HTTP_HEADER_EXPIRES (9)
- ▶ GSN_HTTP_HEADER_FROM (10)
- ▶ GSN_HTTP_HEADER_HOST (11)
- ▶ GSN_HTTP_HEADER_IF_MODIFIED_SINCE (12)
- ▶ GSN_HTTP_HEADER_LAST_MODIFIED (13)
- ▶ GSN_HTTP_HEADER_LOCATION (14)
- ▶ GSN_HTTP_HEADER_PRAGMA (15)
- ▶ GSN_HTTP_HEADER_RANGE (16)
- ▶ GSN_HTTP_HEADER_REFERER (17)
- ▶ GSN_HTTP_HEADER_SERVER (18)
- ▶ GSN_HTTP_HEADER_TRANSFER_ENCODING (19)
- ▶ GSN_HTTP_HEADER_USER_AGENT (20)
- ▶ GSN_HTTP_HEADER_WWW_AUTHENTICATE (21)
- ▶ GSN_HTTP_REQUEST_URL (23)

This command returns standard command response (section 4) or ERROR, if the operation fails.

4.10.14 HTTP Client Connection Open

AT+HTTPOPEN=<host >[, <Port Number>, <SSL Flag>, <certificate name>,<proxy>,<Connection Timeout>,<client certificate name>,<client key name>]

This command opens an HTTP client on the adapter and connects to the server specified by the host name or IP address.

- ▶ Host: Host is either the Fully Qualified Domain Name of the Server or the IP address of the server to which the HTTP client will open the connection e.g. www.gainspan.com or 74.208.130.221
- ▶ Port Number: Port number of the server to which the HTTP client will open the connection. The client can specify the port when the server is running on a non-standard port. Default is the standard port – 80 for HTTP and 443 for HTTPS.
- ▶ SSL Flag: 0 – SSL Disabled, 1 – SSL Enabled. Default is SSL Disabled
- ▶ Certificate Name: The name of the CA Certificate to be used for Server Certificate Authentication in case SSL is enabled. The CA Certificate must be provisioned before this.

It uses the certificate configured on the adapter identified by the certificate name.

- ▶ Proxy: This flag is used only during HTTPS connection through proxy 1 – The HTTPS connection is through proxy server.
- ▶ Connection Timeout: This parameter provides the maximum time limit for setting up of the connection with the server.
- ▶ The client certificate name and client key name are required for SSL client authentication. The certificate and key must be provisioned before using this parameter

Note: Certificates and Key must be in DER format.

It returns the normal response code and the CID of the HTTP client connection on success.

4.10.15 HTTP Client Get/Post

Get/Post HTTP data on the HTTP client.

AT+HTTPSEND=<CID>,<Type>,<Timeout>,<Page>[,Size of the content]<CR><LF>

ESC<H><CID><Content of above size>

This command sends a get or post HTTP request to the server. The content can be transferred using the escape sequence mentioned previously.

- ▶ CID : HTTP client identifier.
- ▶ Type: GSN_HTTP_METHOD_GET (1) / GSN_HTTP_METHOD_POST (3)
- ▶ Page: The page/script being accessed e.g. /index.html
- ▶ Timeout: timeout value in seconds.
- ▶ Size: Actual Content size, Optional in case of GET

In case the HTTP connection is opened with SSL encryption enabled, this command encrypt the data based with encrypt key in SSL connection structure for the specific CID. This encryption happens before Network Layer and the Encrypted data will be sent through the network layer

Response: Receive is implicit in AT+HTTPSEND based on the HTTPS Server's response to the sent data. Received data is asynchronous and should be handled accordingly.

The response from the server is sent to the host in one or more chunks with max size of 1024 bytes. Each chunk is of the format:

<Esc>H<1 Byte - CID><4 bytes – Length of the data><data>

The data part of first chunk of the response will have the status line at the beginning . The status line contains the status code and the status phrase . This will be in the format:

<status code><space><status phrase>\r\n

After the last chunk, OK/ERROR is sent to the host.

4.10.16 Closing HTTP Client

AT+HTTPCLOSE=<CID>

Upon execution of this command the adapter closes the HTTP client connection identified by the CID and returns the standard command response (section 4).

4.10.17 Enable/Disable Bulk Mode Data Transfer

AT+BDATA=1/0

Where 1 is for enable and 0 is for disable this mode with default value 0(disable), This command returns the standard response (section 4) to the serial interface.

4.10.18 Enable / Disable Raw Ethernet Support

AT+NRAW=<0 | 1 | 2>

The results of this command are summarized in Table .

Table 10: Raw Ethernet Support Options.

<i>Information ID</i>	<i>Description</i>
0	Disable Raw Ethernet frame transmission / reception.
1	Enable Raw Ethernet frames with NON-SNAP 802.2LLC headers.
2	Enable all Raw Ethernet frames.

When selection 1 is chosen, 802.3 frames are presumed to include an 802.2 header which is not a SNAP header. These frames are used, for example, for sending BACNET data over Ethernet. A frame of this type has the format:

<ESC>R: <Length>: <DstAddr><SrcAddr>0x0000<Raw-Payload>

On the receiving side, frames with 802.2 headers which are not a SNAP header, are sent directly to serial interface and DATA Frames with UDP port range 0xBAC0 to 0xBACF will be ignored.

When selection 2 is chosen, the 802.2 header (presumed to be a SNAP header) is removed, and a raw Ethernet II frame payload is expected, as per the format below:

<ESC>R:<Length>:<DstAddr><SrcAddr><EtherType><Raw-Payload>

On the receiving side, frames with 802.2 headers that are not SNAP headers and DATA Frames with UDP port ranges 0xBAC0 to 0xBACF are sent directly to serial interface.

This frame format is used for sending IP data over BACNET.

Length is size of DstAddr, SrcAddr, EtherType and Payload.

If the Adapter receives DATA Frames, where the 802.2 LLC headers' SSAP and DSAP are not both 0xAA, these frames are presumed to be 802.3 frames, and are sent to the Adapter's serial port as described above.

If the Adapter received DATA Frames with UDP port range 0xBAC0 to 0xBACF, they are presumed to be BACNET/IP frames, BacNet Ip frame, and are sent to the Adapter's serial port as described above.

This command returns standard command response (section 4).

4.10.19 Unsolicited Data Transmission *

Not Supported on the GS1500M.

The adapter supports unsolicited data transmission (data transmission without association).

AT+UNSOLICITEDTX=<Frame Control>,<Sequence Control>,<Channel>,<Rate>,<WmmInfo>,
<Receiver Mac>,<Bssid of AP>,<Frame Length>

This command enables the unsolicited data transmission with the parameters configured. After issuing this command, the user needs to send the payload data as following:

<ESC>D/d <PayLoad of the above Frame length>

- ▶ Frame Control: is the 802.11 frame control field. It should be limited to all data frames and management frames like beacons, association requests and probe responses.
- ▶ Sequence Control: is the sequence number of the frame. This field consists of 12 bits (LSB) fragment number and 4 bit (MSB) sequence number (0-65535).
- ▶ Channel: is the channel on which the data to be sent.
- ▶ Rate: is the rate at which the data to be send and the possible values are:

RATE_1MBPS = 130,

RATE_2MBPS = 132,

RATE_5_5MBPS = 139,

RATE_11MBPS = 150

- ▶ WmmInfo: is the wmm information to be sent.

- ▶ Receiver Mac: is the remote MAC address of the frame to be sent.
- ▶ Bssid: is bssid of the AP.
- ▶ Frame Length: is the length of the payload. The maximum size of the frame is limited to 1400 bytes.

This command returns standard command response (section 4).

4.11 GSLINK

The adapter provides mechanism to send and receive raw HTTP Data as well as the data in XML format. The data can be sent and received either as a complete data as part of HTTP message as one (raw HTTP method) or it can be sent and received as XML data and each element can be sent and received individually.

This is the case when the GainSpan node is acting as HTTP Server and is sending or receiving data. In case of GainSpan node being HTTP Client it would know the type of communication it is doing with the server and can choose the raw HTTP or XML format of communication because the communication is initiated by the GainSpan node.

The raw HTTP communication means the complete XML data is sent or received by the Host as one data unit. In case of XML format, each element of the XML can be written individually and could be received individually helping the host parse and process easily.

4.11.1 Start/Stop Webserver

AT+WEBSERVER=<0 = Stop/ 1 =start>, <user name>, <password>, [0 = SSL enable/1 = SSL disable], [idle timeout],[Response timeout]

This command will start/stop the webserver and register/deregister the default URI (/gainspan/profile/mcu). This URI can be modified using the command specified in section 4.11.5.

Default value of idle timeout is 5 seconds

Response timeout restricts the mcu to respond within specified time. If user wants to use the default username and password from factory default area, please issue “DEFAULT”, i.e at+webserver=1,DEFAULT,DEFAULT

If username and password were not provided in factory default area, “admin” will be used for both parameters

This command returns standard command response (section 4).

4.11.2 Enabling/Disabling XML Parser on HTTP Data

AT+XMLPARSE=<0 = Disable/ 1 =Enable>

This command enables the XML parser on http data send and receive by the adapter.

This command returns standard command response (section 4).

4.11.3 XML Data Send

AT+XMLSEND=<CID>, <Type>, <Timeout>, <Page URI>, <Root tag name> [, <N>]
 <ESC>G<CID><len><tagname>:<value>

- ▶ CID is the id of the http connection opened.
- ▶ Type is either POST or GET or GETRESP(6) or POSTRESP(7)
- ▶ Timeout is the http timeout for the get/post
- ▶ Page URI is the URI of the page
- ▶ Root tag name is the Root Tag of XML data.
- ▶ N is the number elements in the xml string.

ESC G is to send N times, one for each tag.

len is the length of the string including < tag name> :< value>

Prior to issue this command the http connection should be opened using AT+HTTPOPEN command(section 4.10.13).

This command returns standard command response (section 4) once it finishes the all data transmission.

4.11.4 XML Data Receive

The adapter receive the XML data from http connection and send to the serial interface using ESC sequence. The details are below:

The adapter sends the XML data to the serial interface when it is configured as a HTTP server is :

ESC K<CID><Length><type><URI>

- ▶ This is sent once the URL is fetched by the Remote Http client.

ESC G <CID>< Length><tag name>:<value>

- ▶ This is sending repeatedly for each tag for the XML data.

CID is the CID allocated by the adapter(1byte ascii (0-F))

Length is the length of the string including < tag name> :< value> in 4 byte ascii decimal value

Type is POST(3) or GET(1)

4.11.5 URI Modification

AT+URI_RECV=<URI>[,Content Type]

This command modifies the default adapter UR. The default URI is /gainspan/profile/mcu.

Also reserved URIs like /gainspan/system cannot be used.

Content type for the URI, the default value is set to “application/xml”.

Valid values for content types:

- 0: to set application/xml
- 1 :to set application/json
- 2 :to set application/html
- 3 :to set img/gif

This command returns standard command response (section 4) once it finishes the all data transmission.

4.12 BATTERY CHECK *

Not Supported on the GS1500M.

4.12.1 Battery Check Start *

Not Supported on the GS1500M.

AT+BCHKSTRT=<Batt.chk.freq>

The unit of Batt.chk.freq is in number of packets send out from the Serial2WiFi adapter.

The valid range for the parameter Batt.chk.freq is between 1 and 100. Upon deployment of this command, the adapter performs a check of the battery voltage each Batt.chk.freq number of sent packets, and stores the resulting value in nonvolatile memory; only the most recent value is stored. Note that battery checks are performed during packet transmission to ensure that they reflect loaded conditions. Battery checks can be used to ensure that a battery-powered system is provided with sufficient voltage for normal operation. Low supply voltages can result in data corruption when profile data is written to flash memory.

This command returns standard command response (section 4) or ERROR, if the operation fails..

4.12.2 Battery Warning/Standby Level Set *

Not Supported on the GS1500M.

Set the battery warning/standby level to enable the adapter's internal battery measuring logic.

AT+BATTTLVLSET=<Warning Level>,<Warning Freq>,<Standby Level>

Upon execution of this command the adapter's internal battery level monitoring logic starts. This command should be executed before the battery check start command (4.11.1).

Warning Level: The battery voltage, in millivolts. When the adapter battery voltage is less than this level, it sends the message "Battery Low" to the serial interface.

Warning Freq: is the frequency at which the adapter sends the "Battery Low" message to the serial interface once the adapter's battery check detected low battery.

Standby Level: The battery voltage, in millivolts, When the adapter battery voltage reaches this level, it sends the message "Battery Dead" to the serial interface and goes to long standby.

This command returns standard command response (section 4).

4.12.3 Battery Check Set *

Not Supported on the GS1500M.

Set/Reset the battery check period after battery check has been started.

AT+BCHK=< Batt.chk.freq >

The valid range for the parameter `Batt.chk.freq` is between 1 and 100. Upon receipt, the adapter records the new value of the battery check frequency so that adapter performs the battery voltage check with the new value set. This command returns standard command response (section 4).

The same command can be used to get the current configured battery check period, the usage as follows

```
AT+BCHK=?
```

This command returns the battery check frequency along with standard command response (section 4).

4.12.4 Battery Check Stop *

Not Supported on the GS1500M.

```
AT+BCHKSTOP
```

Upon deployment of this command, battery check is halted. This command returns standard command response (section 4).

4.12.5 Battery Value Get *

Not Supported on the GS1500M.

Retrieve the results of battery check operations.

```
AT+BATTVALGET
```

This command should return a message with the latest value, e.g. `Battery Value: 3.4 V`, followed by the standard command response.

If this command is issued before issuing the command to start battery checks, it returns `ERROR` or `1`, depending on the current verbose setting.

4.13 Power State Management

4.13.1 Enable/Disable SoC Deep Sleep

Enable the GainSpan SOC's power-saving Deep Sleep processor mode.

```
AT+PSDPSLEEP
```

When enabled, the SOC will enter the power-saving Deep Sleep mode when no actions are pending. In Deep Sleep mode, the processor clock is turned off, and SOC power consumption is reduced to less than 1 mW (about 0.1 mA at 1.8 V). Note that other components external to the SOC may continue to dissipate power during this time, unless measures are taken to ensure that they are also off or disabled.

The processor can be awakened by sending data on the serial port from the host. However, several milliseconds are required to stabilize the clock oscillator when the system awakens from Deep Sleep. Since the clock oscillator must stabilize before data can be read, the initial data will not be received; “dummy” (discardable) characters or commands should be sent until an indication is received from the application.

Similar command to enable the deepsleep with a timeout and alarm :

AT+PSDPSLEEP=[<timeout>,< ALARM1 POL >,< ALARM2 POL >

- ▶ ALARM1 POL is the polarity of the transition at pin 31 of the SOC will trigger an alarm input and waken the GainSpan SOC from deepsleep. A value of 0 specifies a high-to-low transition as active; a value of 1 specifies low-to-high.
- ▶ ALARM2 POL is the polarity of the transition at pin 36 that triggers an alarm input, using the same convention used for Alarm1. Upon reception of this command the adapter goes to the deepsleep state for timeout milliseconds and comes out. The maximum value of the timeout parameter can be the highest integer possible by 32 bit value.

These commands do not return any response code to the serial interface. The s2w adapter sends the message “Out of Deep Sleep” along with the standard response (section 4) once it comes out from deep sleep.

4.13.2 Request Standby Mode

Request a transition to ultra-low-power Standby operation.

AT+PSSTBY=x[, <DELAY TIME> , <ALARM1 POL> , <ALARM2 POL>]

The parameters are:

- ▶ x is the Standby time in milliseconds. If a delay time (see below) is provided, the Standby count begins after the delay time has expired.
- ▶ DELAY TIME is the delay in milliseconds from the time the command is issued to the time when the SOC goes to Standby.
- ▶ ALARM1 POL is the polarity of the transition at pin 31 of the SOC which will trigger an alarm input and waken the GainSpan SOC from Standby. A value of 0 specifies a high-to-low transition as active; a value of 1 specifies low-to-high.
- ▶ ALARM2 POL is the polarity of the transition at pin 36 that triggers an alarm input, using the same convention used for Alarm1.

The parameters DELAY TIME, ALARM1 POL, and ALARM2 POL are optional. Specifying an alarm polarity also enables the corresponding alarm input.

This command does not return any response code to the serial interface. When this command is issued, the GainSpan SOC will enter the ultra-low-power Standby state (after the optional delay time if present), remaining there until x milliseconds have passed since the command was issued, or an enabled alarm input is received. Any current CID's are lost on transition to Standby. On wakeup, the adapter sends the message Out of Standby-<reason of wakeup> or the corresponding error code (section 3.6.3), depending on verbose status.

In Standby, only the low-power clock and some associated circuits are active. Serial messages sent to the UART port will not be received. The radio is off and packets cannot be sent or received. Therefore, before requesting a transition to Standby, the requesting application should ensure that no actions are needed from the interface until the requested time has passed, or provide an alarm input to awaken the SOC when needed. The alarm should trigger about 10 msec prior to issuance of any serial commands.

The Standby clock employs a 34-bit counter operating at 131,072 Hz, so the maximum possible Standby time is 131,072,000 milliseconds, or about 36.4 hours. Standby is not entered until all pending tasks are completed, and a few milliseconds are required to store any changes and enter the Standby state; a similar

delay is encountered in awaking from Standby at the end of the requested time. Therefore, we do not recommend Standby times less than about 32 milliseconds.

GS1500M: In case of GS1500M, once the system goes to standby and comes out, the L2 connection is lost. “restore connection” will always initiate a L2 connection after coming out of standby.

4.14 Auto Connection

4.14.1 Wireless Parameters

Set the auto connection wireless parameters for the current profile.

AT+WAUTO=<mode> , <SSID> , [<BSSID>] , [channel]

- ▶ Mode is 0 for Infrastructure, 1 for Ad-hoc mode and 2 for Limited AP mode;
- ▶ SSID is the SSID of the AP or Limited AP or Ad-hoc Network to connect to;
- ▶ BSSID is the BSSID of the AP or Ad-hoc Network to connect to;
- ▶ Channel is the operating channel.

All other parameters required to configure the wireless connection are taken from the current Profile (3.1.3). This command returns standard command response (section 4).

4.14.2 Network Parameters

Set the network parameters for auto connection operation for the current profile.

AT+NAUTO=<Type> , <Protocol> , <Destination IP/Host name> , <Destination Port> , [Src Port]

- ▶ Type is 0 for Client and 1 for Server;
- ▶ Protocol is 0 for UDP and 1 for TCP;
- ▶ Destination IP is the IP address of the remote system (optional if the Adapter is acting as a server). Host Name is Domain name of the remote system. The adapter accepts either the destination ip or host name. the maximum length of the host name can be 32 ascii characters.
- ▶ Destination Port is the port number to connect to on the remote system.
- ▶ Src Port is the source port to bind and it is valid only for udp client case. This parameter is an optional one for udp client and not valid for other protocol type.

This command returns standard command response (section 4). In Limited AP mode use UDP/TCP server type if using auto connection.

4.14.3 Enable Auto Connection

ATCn

n is 0 to disable auto connection or 1 to enable auto connection.

Upon receipt of this command, the configuration setting in non-volatile memory is modified according to the parameter value in the command; the resulting change (if any) takes effect on the next reboot, or the next issuance of an ATA command.

This command returns standard command response (section 4).

4.14.4 Initiate Auto Connect

ATA

On reception of this command, the interface initiates the auto connection procedure as described in section 3.3 above, using the parameters specified by the AT+WAUTO and AT+NAUTO commands (4.14.1 and 4.14.2). The adapter responds with the IP address, subnet mask, and Gateway IP address, followed by CONNECT<space>CID and OK or 0 (per verbose status), if the connection is successful. If the connection attempt is unsuccessful the adapter returns ERROR or 1 (per verbose status). After the connection is established, the adapter enters the data transfer mode described in section 3.3 above.

If the adapter is already associated with a wireless network, the alternative command ATA2 below may be used.

Note:

The gpio8 should be keep low for the autoconnection, since a low to high transition of this gpio exit the auto connection data mode.

4.14.5 Initiate Auto Connect – TCP/UDP Level *

Not Supported on the GS1500M.

Initiate auto connection when the Adapter is already associated with an Access Point.

ATA2

This command requires a pre-existing wireless association. On reception of this command, the interface establishes a network connection to a TCP or UDP server with the parameters specified by the AT+NAUTO command (4.14.2). This command assumes a pre-existing association and should not be issued unless such exists. If the connection successful it returns CONNECT<space>CID followed by standard command response. If a valid command input was received, but the connection cannot be established due to a socket bound failure, the message ERROR: SOCKET FAILURE or 3 (per verbose settings) is returned.

4.14.6 Exit from auto connect data Mode

In auto connect mode the adapter opens a serial data pipe to pass the serial data from/to the host MCU to/from the remote machine. In this mode all serial input treated as data. To enable the command mode without breaks the connection the adapter provides the following mechanisms:

1. +++ and wait for 1 second. After this the adapter exit the data mode and it can able to accept the AT commands to change the configuration.

2. Make the gpio8 high. With this also the adapter exit the data mode and it can able to accept the AT commands to change the configuration.

4.14.7 Return to Auto Connect Mode

The command to return to auto connect mode is

ATO

If the interface receives this command after it has exited the auto connect mode with +++ or gpio8 high, it shall return to auto connect mode. If the connection no longer exists, the interface attempts to reestablish the previous connection, and returns to data mode if the reconnection is successful. If the Adapter was not previously connected when this command is received, it returns an error.

This command returns standard command response (section 4) to the serial interface.

4.15 Network Connection Manager (NCM)

The adapter supports network connection manager which manage L2, L3 and L4 level connection automatically. The parameters for L2, L3 and L4 can be configured using commands specified in section 4.14.1 and 4.14.2. The security parameters can be configured using the commands specified in section 4.8.

4.15.1 NCM Start/Stop

AT+NCMAUTO=<Mode>,<Start/Stop>[,Level] ,[<Nvds store flag>]

Mode: 0 is for station mode and 1 is for Limited AP mode.

Start/Stop : 1 is for start the NCM and 0 is for stop the NCM

Level: 0 is for L2+L3 Connection and 1 is for L2+L3+L4 connection.

Nvds store flag: 0 is for storing the NCM Start/Stop information in the persistent storage when the store persistent information command (at&w0) is issued by the host. 1 is for disabling the storage of this information. The default value is 0. This parameter is valid for NCM in station mode only.

If the NCM Start/Stop is stored in persistent storage, then the adapter will take the appropriate action for successive boots.

This command starts the NCM by connecting to the AP (if the mode configured as station) or create a limited AP (if the mode configured as limited AP) with the pre-configured parameters. Once it connected any of the L2,L3 and L4 disconnection triggers the NCM and it starts do the L2,L3 and L4 re-connection.

This command returns standard command response (section 4) to the serial interface.

Once the connection is established the adapter returns the following message to the serial interface.

For L2+L3:

IP address

“NWCONN-SUCCESS”

For L2+L3+L4:

IP address

“NWCONN-SUCCESS”

“CONNECT <cid>”

For limited AP, the first two parameters are only valid and it outputs the same message for L2+L3 to the serial interface.

Note:

If the dhcp renewal success with a new ip address then the adapter close the sockets opened(L4) and send a message “IP CONFIG-NEW IP” with the new ip information to the serial interface and it retain the L4 connection if the ncm is started with L4 support.

4.15.2 NCM Configuration

The NCM use some configurable parameters for its state machine. These parameters can be configured using the command

AT+NCMAUTOCONF=<Conf Id>,<Value>

Conf Id: is the id corresponding to the NCM configuration parameters.

- ▶ 0 → CPU Wait Period (1 to 65355 msec, default is 1000 msec)
- ▶ 1 → Power Save Period(not supported) (1 to 65355 msec, default is 1000 msec)
- ▶ 2 → Know channel scan period (1 to 65355 msec, default is 1000 msec)
- ▶ 3 → Specific channels scan period(not supported) (1 to 65355 msec, default is 1000 msec)
- ▶ 4 → All Channel scan Period (1 to 65355 msec, default is 1000)
- ▶ 5 → L3 Connect Period (1 to 65355 msec, default is 1000 msec)
- ▶ 8 → Known channel scan retry count (1 to 65355, default is 10)
- ▶ 9 → Specific channels scan retry count(not supported) (1 to 65355, default is 10)
- ▶ 10 → All Channel scan retry count (1 to 65355, default is 10)
- ▶ 11 → L3 Connect retry count (1 to 65355, default is 100)
- ▶ This command returns standard command response (section 4) to the serial interface.

Note:

The L4 configuration parameters(L4 retry count and period) can be configured using ATS6/7 command, details are in section 4.4.

4.15.3 NCM AP Configuration Enable

The NCM AP parameters can be configured using the auto connect Commands specified in section 4.8 and 4.14.1. However, these commands are used for both station and Limited AP mode. To distinguish the parameters for Limited AP mode, the adapter provides a command:

AT+APCONF=<Enable>

Enable: 1 if for limited AP mode and 0 is for station mode, with default value as 0.

Once it enabled, the parameters configured using commands in section 4.14 and 4.8 goes to limited AP.

This command returns standard command response (section 4) to the serial interface.

By Default the adapter use parameters stored at the factory default section(section 4.19.6) to start the limited AP with ncmauto command. If the adapter does not find the factory default section with a valid parameter it uses the following values:

SSID : GainSpanProv

Channel: 1

Security : 0(open)

Wep Key: 1234567890

Wep Key Index: 1

Wep Key length: 5

Wpa passphrase : GSDemo123

Beacon Interval : 100

DHCP server enable: TRUE(1)

DNS Server Enable :TRUE(1)

IP Address: 192.168.240.1

Subnet mask: 255.255.255.0

Gateway: 192.168.240.1

Dhcp start Ip address: 192.168.240.2

DNS name : config.gainspan

UserName : admin

Pwd : admin

4.15.4 Limited AP Parameter Restore

Restore the limited AP parameters to the factory default .

AT+FACTORYRESTORE

This command restore the limited AP parameters for the ncmauto command to the values present in the factory default section of the adapter. If valid values are not present , then it restore the values described in the above command.

This command returns standard command response (section 4) to the serial interface.

4.16 ROAMING

The adapter supports Roaming. Roaming is supported under following conditions

- APs have the Same SSID and same Security
 - WPA/WPA2 Enterprise security is not supported

- APs can be on different channels
- The S2W Adapter in Radio PS-Poll or Active Receive Mode
- Only RSSI is used. PER and other statistics are not used.

This feature will be bundled with Network Connection Manager(NCM) and roaming parameters are configured with below AT command.

AT+NCMAUTOCONF=<Param ID>, <Param Value>

Param ID values

16 →Roaming Feature Enabled/Disabled (Default: Disabled)

17→Lower RSSI Threshold (Default: -70db)

18 →Higher RSSI Threshold (Default: -50db)

19 →Time between Background Scans (Default: 1000ms)

20 →Number of Times Low Threshold is crossed before roaming trigger is enabled – N1 (Default: 3)

21 →Maintain L3 – there is common DHCP Server. (Default: Maintain L3 enabled)

4.17 PROVISIONING

4.17.1 Web Provisioning Start

The adapter supports provisioning through web pages and the command to start is:

AT+WEBPROV=<user name>,<password>[,SSL Enabled,Param StoreOption,ideltimeout,ncmautoconnect]

Prior to issuing this command the adapter should be in an ad hoc or limited AP network with a valid ip address. Upon reception of this command the adapter starts a web server. It returns the normal response code OK or ERROR depends on the success or failure condition.

Once the adapter returns the success response (“OK”), the user can open a webpage on the PC (where the ad hoc network was created) with the IP address of the adapter and the HTTP client application (e.g. Internet Explorer).

If the adapter is configured as limited AP, the DHCP and DNS server should be started prior to issuing this command. Once the adapter returns the success response (“OK”), the user can open a webpage on the PC or smartphone that is connected to the limited AP.

User can configure both L2 and L3 level information on the provisioning web pages. Submit button stores all the configured information in the adapter and logout/boot button presents all provisioned information to the serial host and resets the adapter.

The size of the username and password is limited to 16 characters.

SSL Enabled: 1 is for start the webserver with SSL, 0 is start the web server without SSL.

It is required to load the server certificate and server key prior to start the SSL enabled web server.

The command to load the certificate is:

▶ AT+TCERTADD=SSL_SERVER,0,<Server certificate length>,0

<ESC>W<data of size Server certificate length >

and the command to load the key is:

▶ AT+TCERTADD=SERVER_KEY,0,< key length>,0

<ESC>W<data of size key length >

Param Store Option: This option select the provisioned parameters store location.

0 is for send the provisioned info to the serial interface(HOST), and it is the default value.

1 is for store the provisioned info to the adapter profile.

2 is for do both above.

The provisioned information sends to serial host is:

- ▶ SSID=<ssid>
- ▶ CHNL=<channel>
- ▶ CONN_TYPE=<connType> /* either BSS or IBSS */
- ▶ MODE=<mode> /* 0 -> 802.11b */
- ▶ SECURITY=<security> (1->open,2->wep, 3-> wpa/wpa2 personal,4 wpa/wpa2 enterprise)
- ▶ WEP_ID=<wep ID>
- ▶ WEP_KEY=<wep key>
- ▶ PSK_PASS_PHRASE=<psk PassPhrase>
- ▶ DHCP_ENBL=<0/1>
- ▶ STATIC_IP=<static IP address>
- ▶ SUBNT_MASK=<subnet Mask>
- ▶ GATEWAY_IP=<gateway>
- ▶ AUTO_DNS_ENBL=<0 /1>
- ▶ PRIMERY_DNS_IP=<primary DNS server IP>
- ▶ SECNDRY_DNS_IP<secondary DNS IP>
- ▶ AP-SSID=< ssid>
- ▶ AP-CHNL=<Channel>
- ▶ AP-BEACON-INTRL=<interval> (100-1600)
- ▶ AP-SECURITY=<security> (1->open,2->wep, 3-> wpa/wpa2 personal,4 wpa/wpa2 enterprise)
- ▶ AP-PSK_PASS_PHRASE=<passphrase>
- ▶ AP-WEP-ID=<id> (1-4)
- ▶ AP-WEP-KEY=<wep key>
- ▶ AP- STATIC_IP=<static IP address>

- ▶ AP -SUBNT_MASK=<subnet Mask>
- ▶ AP- GATEWAY_IP=<gateway>
- ▶ AP-DHCPSRVR-ENABLE=<0/1>
- ▶ AP-DHCPSRVR-STARTIP=<Ip address>
- ▶ AP-DHCPSRVR-NO-CONN=<number> (1-32)
- ▶ AP-DNSSRVR-ENABLE=<0/1>
- ▶ AP-DNS-DOMAIN-NAME=<dns name>
- ▶ NEW_USER_NAME<new User Name>
- ▶ NEW_PASS=<new Password>

Idle timeout option: idle time out for web provisioning.

ncm auto connect option:

1: is to start ncm after storing the parameters.

0: will not start the ncm .

This command returns standard command response (section 4) or ERROR, if the operation fails.

4.17.2 Web Provisioning Stop

The command to stop web provisioning is:

AT+WEBPROVSTOP

This command stops the web provisioning and returns standard command response (section 4) or ERROR, if the operation fails.

4.17.3 Web Provisioning (Logo)

The adapter supports adding the Logo that will appear on the web pages used for provisioning.

AT+WEBLOGOADD=<size>

<Esc>L<Actual File content>

<size> is measured in bytes and the maximum size is 1788 bytes. This command is typically done at the manufacturing line in the factory. This command can be done only once. There is no command to delete the Logo. This command returns standard command response (section 4) to the serial interface.

4.17.4 Httpd redirection

The adapter supports adding the redirection URL

AT+ NURIREDIR=<URL>

Where <URL> is the address of the redirection page. Maximu URL length is 64.

4.18 RF Tests

The adapter supports different types of frame transmission for RF capability measurement. It supports asynchronous data transmission/reception and modulated/un-modulated wave transmission.

4.18.1 Module RF Tests GS1011M

4.18.1.1 Asynchronous Frame Transmission

Enable the asynchronous frame transmission.

AT+RFFRAMETXSTART=<Channel>,<Power>,<Rate>,<No.Of.Times>,<Fr.Intrvel>,<FrameControl>,<DurationId>,<Sequence Control>,<frameLen>,<Preamble>,<Scrambler>[,<DstMac>,<Src Mac>]

This command enables the asynchronous data transmission with the parameter configured. After issuing this command the user needs to send the payload data as following,

<ESC>A/a <PayLoad of the above Frame length>

- ▶ Channel: the channel on which the data to be send.
- ▶ Power: the power in db at that frame to be sent. The value of this parameter can range from 0 to 7 for internal PA and from 2 to 15 for external PA.
- ▶ Rate: the rate at which the data can be sent and the possible values are:

RATE_1MBPS = 2,
RATE_2MBPS = 4,
RATE_5.5MBPS = 11,
RATE_11MBPS = 22

- ▶ No. Times: the number of asynchronous frames to be sent. (1-65535)
- ▶ Fr. Interval: the interval between each frame, in microseconds. (1-65535)
- ▶ Frame Control: expects only the lower byte (B0...B7) of 802.11 frame control field, which includes protocol version, Type and Subtype. All the higher order bits (B8...B15) are made zero for this command.

i.e. Frame control field of beacon frame is: 128

Higher Byte B15 – B8	Sub Type B7-B4	Type B3- B2	Protocol Version B1 – B0
00000000	1000	00	00

*Note: This command is intended to transfer **only** data & a few Management frames like Beacon/Probe request/Probe response/Association request.*

- ▶ DurationId: duration id information to be sent. (0-65535)
- ▶ Sequence Control: the sequence number of the frame. This field consists of 12 bits(LSB) fragment number and 4 bit (MSB)sequence number. (0-65535)
- ▶ frameLen: the length of the payload. The maximum size of the frame is limited to 1400 bytes.

- ▶ Preamble: the short (1) or long (0) preamble.
- ▶ Scrambler: the ON(0) or OFF(1) scrambler field of the frame
- ▶ DstMac: the MAC address through which the frame to be send.
- ▶ Src Mac: MAC address for the WiFi Bridge.

Example: **AT+RFFRAMECTXSTART=1,3,4,2,200,0,11,0,30,0,1,00:1d:c9:00:07:a2**
<ESC>A123456789012345678901234567890

Please check the wireless sniffer to see the frame on air.

The AT+RFSTOP (section 4.16.4) command should be issued prior to successive frame transmission command.

Since this command is meant for use during RF testing or Regulatory testing, when Asynch Frame transmission is used, no CSMA/CA is done, and so device will output data regardless of whether the channel is clear or not.

This command returns standard command response (section 4) to the serial interface.

4.18.1.2 Asynchronous Frame Reception

AT+RFRXSTART=<Channel>[,<Sendtouser>]

- ▶ Channel: is the channel on which the data to be received.
- ▶ Sendtouser: is a flag (0/1) which instructs the adapter to send the received data to the serial interface.

The Frame Transmission/Reception Stop command (4.15.4) will send the status information of the received frames to the serial interface.

Example: **AT+RFRXSTART=1,1** → this will send the received data to the serial interface
AT+RFRXSTART=1,0 → this will not send the received data to the serial interface

In both case the received frame information is stored in SRAM and once issue the command AT+RFSTOP sends the received frame information to the user through serial. We recommend using the second option. This command returns standard command response (section 4) to the serial interface.

4.18.1.3 Modulated/Un-Modulated Wave Transmission

Enable the modulated/un-modulated wave transmission .

AT+RFWAVETXSTART=<Modulated>,<Channel>,<Rate>,<PreambleLong>,<ScramblerOff>,<Cont.Tx>,<Power>,<Ssid>[,Length]

- ▶ Modulated : is the flag to tell whether the wave transmission should be modulated(1) or un-modulated (0)
- ▶ Channel: is the channel on which the data to be received.
- ▶ Rate: the rate at which the wave transmission should happen.
TX_RATE 1mbps = 0,
TX_RATE 2 mbps = 1,
TX_RATE 5.5 mbps = 2,
TX_RATE 11 mbps = 3,

- ▶ PreambleLong: is long preamble (1) or short preamble (0).
- ▶ ScramblerOff: is the scrambler field OFF (0) or ON (1).
- ▶ Cont.Tx: is the wave transmission is continuous (1) or not (0).
- ▶ Power: is the power in db at which the wave transmission should happen. The value of this parameter can range from 0 to 7 for internal PA and from 2 to 15 for external PA.
- ▶ Ssid: is the ssid of the network created for the wave transmission.
- ▶ Length: the length of the frame to be transmitted and the maximum size should be 255.

Example: AT+RFWAVETXSTART=1,4,2,1,1,1,3,aaa ->(modulated)

AT+RFWAVETXSTART=0,4,3,0,1,1,3,bbb -->(un-modulated)

This command returns standard command response (section 4) or ERROR if it fails.

4.18.1.4 Frame Transmission/Reception Stop

AT+RFSTOP

Upon reception of this command the adapter stops any of the frame transmission/reception RF tests started. This command sends the status information of the received asynchronous frames to the serial interface other than the normal command response if this command issued for the asynchronous frame reception stop.

Example:

AT+RFSTOP (if this command issued after AT+RFRXSTART, then it sends the following information to the serial interface)

Total frames received =xxxx
Correct frames received =xxxx
Incorrect frames received =xxx
FCS Error frames received =xxx

4.18.2 RF Tests GS1500M

4.18.2.1 Asynchronous Frame Transmission

The command to enable the asynchronous frame transmission is:

AT+RFFRAMETXSTART=<Channel>,<Power>,<Rate>,<No.Of.Times>,<frameLen>,<Preamble>,<Scrambler>,<AIFSN>,<short guard>,<data pattern>

This command enables the asynchronous data transmission with the parameter configured.

- ▶ Channel: the channel on which the data to be send.
- ▶ Power: the power in db at which the frame to be sent. The value of this parameter can range from 0 to 30.
- ▶ Rate: the rate at which the data can be sent and the possible values are 0 to 19:

Data Rate Index	Data Rate (mbps)
0	1
1	2
2	5.5
3	11
4	6
5	9
6	12
7	18
8	24
9	36
10	48
11	54
12	HT20 MCS0 6.5
13	HT20 MCS1 13
14	HT20 MCS2 19.5
15	HT20 MCS3 26
16	HT20 MCS4 39
17	HT20 MCS5 52
18	HT20 MCS6 58.5
19	HT20 MCS7 65

- ▶ No. Times: the number of asynchronous frames to be sent. (1-65535)
- ▶ frameLen: the length of the payload. (32 to 1500). 802.11 header is added on top of the payload
- ▶ Preamble: the short (1) or long (0) preamble.
- ▶ Scrambler: the ON(0) or OFF(1) scrambler field of the frame

- ▶ AIFSN: Arbitration Inter-Frame Space Number (0 to 252). This can be used for interframe spacing, where Interframe spacing = SIFS+AIFSN*slot time

AIFSN	Inter Frame Space	802.11b (Slottime = 20 μ s)	802.11g (Slottime = 9 μ s)
0	SIFS	10 μ s	10 μ s
1	PIFS	SIFS + 1 x Slottime = 30 μ s	SIFS + 1 x Slottime = 19 μ s
2	DIFS	SIFS + 2 x Slottime = 50 μ s	SIFS + 2 x Slottime = 28 μ s
..			
252	maximum interframe space		

- ▶ Short guard : Short guard ON(1)/OFF(0).
Only valid for 11n rates. Guard Interval is the period of time that is used to minimize inter-Symbol interference caused in multipath environments when the beginning of a new symbol arrives at the receiver before the end of the last symbol is done. If Short Guard is ON, symbol time reduced from 4 microseconds to 3.6 microseconds (i.e. reduced by 400 nano seconds).
- ▶ Data Pattern: Possible values are given below:

0	All ZEROs
1	All ONEs
2	Repeating 10
3	PN7 Pseudo random 7. Repeat pseudo random string of size 7. (i.e. 1527123 1527123 1527123 ...)
4	PN9 Pseudo random 9
5	PN15 Pseudo random 15

Example:

AT+RFFRAME_TXSTART=1,10,4,10,500,0,0,0,2

Please check the wireless sniffer to see the frame on air.

The AT+RFSTOP (section 4.15.2.4) command should be issued prior to successive frame transmission command.

Since this command is meant for use during RF testing or Regulatory testing, when Asynch Frame transmission is used, no CSMA/CA is done, and so device will output data regardless of whether the channel is clear or not.

This command returns standard command response (section 4) to the serial interface.

4.18.2.2 Asynchronous Frame Reception

The command to enable the asynchronous frame reception is:

AT+RFRXSTART=<Channel>

- ▶ Channel: is the channel on which the data to be received.

The Frame Transmission/Reception Stop command (4.15.2.4) will send the status information of the received frames to the serial interface.

Example: **AT+RFRXSTART=1**

This command returns standard command response (section 4) to the serial interface.

4.18.2.3 Modulated/Un-Modulated Wave Transmission

The command to enable the modulated/un-modulated wave transmission:

AT+RFWAVETXSTART=<Unmodulated/TX99/TX100>,<Channel>,<Rate>,<PreambleLong>,<ScramblerOff>,<Power>,<short guard>,<Data Pattern>

- ▶ Modulated : is the flag to tell whether the wave transmission should be un-modulated (0) or modulated with 99% duty cycle (1) or modulated with 100% duty cycle (2)
- ▶ Channel: is the channel that the data to be transmitted.
- ▶ Rate: the rate at which the wave transmission should happen. Only applies to TX99/TX100 mode. Use 0 for un-modulated transmission.

Data Rate Index	Data Rate (mbps)
0	1
1	2
2	5.5
3	11
4	6
5	9
6	12
7	18
8	24
9	36

10	48
11	54
12	HT20 MCS0 6.5
13	HT20 MCS1 13
14	HT20 MCS2 19.5
15	HT20 MCS3 26
16	HT20 MCS4 39
17	HT20 MCS5 52
18	HT20 MCS6 58.5
19	HT20 MCS7 65

- ▶ **PreambleLong:** is long preamble (1) or short preamble (0). Only applies to TX99/TX100 mode. Use 0 for un-modulated transmission.
- ▶ **ScramblerOff:** is the scrambler field OFF (0) or ON (1). Only applies to TX99/TX100 mode. Use 0 for un-modulated transmission.
- ▶ **Power:** is the power in db at which the wave transmission should happen. The value of this parameter can range from 0 to 10 for un-modulated and 0 to 30 for TX99/TX100 modulated.
- ▶ **Short guard :** Short guard ON(1)/OFF(0). Only valid for 11n rates. Guard Interval is the period of time that is used to minimize inter-symbol interference caused in multipath environments when the beginning of a new symbol arrives at the receiver before the end of the last symbol is done. If Short Guard is ON, symbol time reduced from 4 microseconds to 3.6 microseconds (i.e. reduced by 400 nano seconds).
- ▶ **Data Pattern:** Only applies to TX99/TX100 mode. Use 0 for un-modulated transmission.

Possible values are:

0	All ZEROs
1	All ONEs
2	Repeating 10
3	PN7 (Pseudo random 7)
4	PN9 (Pseudo random 9)
5	PN15 (Pseudo random 15)

Example:

AT+RFWAVETXSTART=1,1,4,1,0,10,0,0 →(TX99 modulated)

AT+RFWAVETXSTART=0,1,0,0,0,10,0,0 →(un-modulated)

This command returns standard command response (section 4) or ERROR if it fails.

4.18.2.4 Frame Transmission/Reception Stop

The command to stop any of the RF tests transmission/reception is:

AT+RFSTOP

Upon reception of this command the adapter stops any of the frame transmission/reception RF tests started. This command sends the status information of the received asynchronous frames to the serial interface other than the normal command response if this command issued for the asynchronous frame reception stop.

Example:

AT+RFSTOP (if this command issued after AT+ RFRXSTART, then it sends the following information to the serial interface)

Total frames received =xxxx

Correct frames received =xxxx

Incorrect frames received =xxx

FCS Error frames received =xxx

4.19 Miscellaneous

4.19.1 Enhanced Asynchronous Notification

S2w Adapter supports an enhanced asynchronous notification method.

AT+ASYNCMSGFMT=n

n is

- ▶ 0 – Disable this feature
- ▶ 1 – Enable this feature

This command returns standard command response (section 4) to the serial interface. Default is disabled

Enabling this feature results with all asynchronous messages going to the serial interface with a header. Also during these asynchronous message transfer s2w adapter make the GPIO 19 high. The asynchronous message format is as shown below:

<ESC><TYPE><SUBTYPE><LENGTH><MESSAGE>

TYPE – Type of message and the length is one byte. For asynchronous message , it is 0x41 (Ascii value A)

SUBTYPE – Message subtype and the length of this field is one byte. Normally this field contains the ascii value of the subtype message. Refer section 3.7.4 for subtype values.

LENGTH – Length of the asynchronous message in hex. This field length is 2 bytes.

MESSAGE – Exact asynchronous message as string. Refer section 3.7.4 for all enhanced asynchronous messages.

4.19.2 Node Start Up Handling

For proper synchronization between host micro controller (MCU) and S2w node, the following steps must be followed:

- ▶ In case of UART interface, during boot up host MCU shall send dummy 'AT' command and wait for response from the S2w node. The host MCU must continuously send these dummy 'AT' commands till 'OK' response is received from S2w node.
- ▶ In case of SPI interface, during boot up host MCU must check the status of host wake-up signal (GPIO#28 of the module). Once host wake-up signal is HIGH, then the host must read the "Serial2WiFi APP" banner which is queued for transmission at the GainSpan node's SPI interface at this point. To do so, it can simply repeatedly transmit idle characters (F5) over the SPI line and read the characters transmitted by the GainSpan node ("Serial2WiFi APP" banner) until it sees that the GPIO28 line has been brought LOW, indicating that all characters have been read from the GainSpan node. This completes the initialization process. At this point, the host MCU can send 'AT' commands to the GainSpan node. MCU should not issue a reset using the ext_reset_n signal until this initialization process is completed
- ▶ If for some reason host MCU getting reset, then S2w adapter must be explicitly reset using EXT_RESET pin and the MCU should wait for the wake-up signal(GPIO#28) become high in

case of SPI interface. However if reset provision is not available, then host MCU must continuously send dummy 'AT' commands till 'OK' response is received from S2w adapter.

4.19.3 Firmware Upgrade *

Not Supported on the GS1500M

AT+FWUP= <SrvIp>,<SrvPort>,<SrcPort>,[<retry>]

This command starts the firmware upgrade procedure over the wireless link.

- ▶ SrvIp is the IP address of the firmware upgrade server;
- ▶ SrvPort is the server port number to be used for firmware upgrade;
- ▶ SrcPort is the adapter port number to be used for firmware upgrade.
- ▶ Retry is the number of times the node will repeat the firmware upgrade attempt if failures are encountered. The default value is 10 and the retry count ranges from 0 to 0xffffffff.

When a valid command has been received, the adapter returns the message: Firmware upgrade is going on, Please wait.... followed with the status message OK or 0, which applies only to the validity of the command. After attempting to upgrade the firmware, the node sends an additional message describing the result of the actual firmware upgrade attempt.

After a successful firmware upgrade, the Adapter will reset and boot up using the updated firmware; when startup is complete, it will issue the message APP Reset-FW-UP-SUCCESS.

If the firmware upgrade attempt failed, the Adapter will reset and boot up with the old firmware, and issue the message APP Reset-FW-UP-FAILURE.

If the firmware upgrade attempt failed after successful upgrade of one flash image (flash0), the adapter will reset and boot up, issue the message APP Reset-FW-UP-RECOVERY, associate back to the network with previous settings and try to upgrade the firmware again. The retry count decides how many times this can be done.

If the node is not associated, the adapter returns ERROR or 1, based on verbose settings.

4.19.4 SPI Interface Handling

In the case of SPI interface, the GS101X node acts as slave and will communicate to master SPI controller. By default, SPI interface supports Motorola protocol with clock polarity 0 and clock phase 0. For more detailed specification of SPI frame format and timing characteristics refer GS1011M data sheet.

Note: The SPI version of the firmware is a separate file compared to the UART and would need to be programmed into the module for support of SPI interface.

Since SPI data transfer works in full duplex mode, its required to make use of special octet to indicate idle data. Similarly if host MCU is sending data at higher rate flow control mechanism is required. In order differentiate these special control codes (such as idle pattern , flow control codes and other control octets) from user data, byte stuffing mechanism is incorporated.

SPI transmit data handling procedure:

The SPI data transfer layer makes use of an octet (or byte) stuffing procedure. The Control Escape octet is defined as binary 11111011 (hexadecimal **0xFB**), most significant bit first. Each special control pattern is replaced by a two octet sequences consisting of the Control Escape octet followed by the original octet exclusive-or'd (XOR) with hexadecimal **0x20**. Receiving implementations must correctly process all Control Escape sequences. Escaped data is transmitted on the link as follows:

Pattern	Encoded as	Description
0xFD	0xFB 0xDD	<i>Flow control XON</i>
0xFA	0xFB 0xDA	<i>Flow control XOFF</i>
0x00	0xFB 0x20	Inactive link detection
0xFB	0xFB 0xDB	Control ESCAPE
0xF5	0xFB 0xD5	<i>IDLE character</i>
0xFF	0xFB 0xDF	Inactive link detection
0xF3	0xFB 0xD3	SPI link ready indication

One dedicated GPIO signal (*GS_SPI_HOST_WAKEUP: GPIO#28*) is available for data ready indications from Slave GS1011M node to Master Host controller. This *GS_SPI_HOST_WAKEUP* signal is asserted high during valid data transmission period, so that the host (master SPI) starts pulling out data by giving SPI clock and *GS_SPI_HOST_WAKEUP* signal is de-asserted once transmission is completed. Master host controller must provide clock as long as *GS_SPI_HOST_WAKEUP* signal is active.

Special character (*GS_SPI_IDLE*) will be transmitted during idle period (if there is no more data to transmit) and must be dropped at the receiving Host.

SPI receive data handling procedure:

Since byte stuffing is used, each Control Escape octet must be removed and the next immediate octet is exclusive-or'd (XOR) with hexadecimal **0x20**. If received buffer has reached the upper water mark, then *XOFF* character will be sent out informing the host to stop transmitting actual data. After receiving *XOFF* character host must stop transmitting actual data and can send *IDLE* bytes, until the *XON* is received. Once the host receives *XON*, then it may resume the valid data transmissions.

Special control byte *IDLE* will be dropped at receiver.

4.19.5 Pin connection for SPI Interface

Host MCU	S2W Node	Remarks
MSPI_DOUT	SSPI_DIN	
MSPI_DIN	SSPI_DOUT	
MSPI_SS	SSPI_SS	
MSPI_CLK	SSPI_CLK	
GPIO	GPIO#28	Host wake-up signal
Ground	Ground	

4.19.6 Factory Default Section

The Serial2Wifi adapter stores the factory defaults to its flash; currently supporting the MAC addresses and the following fields as factory default. If the factory default MAC address location contains a valid address, then the Serial2Wifi adapter reads and uses it as the MAC address, otherwise it use the default MAC as it MAC address.

The factory default location starts at 126Kbytes of second application flash (i.e. physical address 0x0801f800) and the Serial2Wifi stores the factory default MAC address in the following format:

Checksum(1 byte)	Length (1 byte)	Mac address (6 byte) in Hex
------------------	-----------------	-----------------------------

Checksum : the simple byte wise of both length and MAC address.

Length : the length in bytes of MAC address and length (here it is 7).

Mac Address : the MAC address. The user can override the factory default MAC address by using the AT commands mentioned in section 4.7.1.

The other fields of the factory default section stores in the following format.

CheckSum (1 byte)	Type (1 byte)	Length (1 byte)	Data
-------------------	---------------	-----------------	------

Element	Type Code	Size (in bytes)	Default Values	Comments	Format
SSID	0x02	1-63	GSDemoProv	SSID for the Limited AP used for Provisioning	ASCII
Channel	0x03	1	11	Channel for the Limited AP used for Provisioning	Hex
Security Type	0x04	1	WPA2-Personal (AES)	Type of Security for Limited AP <ul style="list-style-type: none"> • Open • WEP • WPA-Personal (TKIP) • WPA2-Personal (AES) • WPA2-Personal (TKIP+AES) 	Hex
WEP ID	0x05	1	NA	If WEP is used for Limited AP Security	Hex
WEP Key	0x06	5 or 13	NA	40 bit or 104 bit WEP Key is WEP is used for Limited AP Security	Hex
Passphrase	0x07	8-63	GSDemo123	Passphrase if WPA/WPA2 Personal is used for Limited AP Security	ASCII

User name	0x08		admin	User Name for the Web Provisioning	ASCII
Password	0x09		admin	Password for the Web Provisioning	ASCII
Manufacturer	0x0A		GainSpan	Used for WPS 2.0	ASCII
Model Name	0x0B		GS1011M	Used for WPS 2.0	ASCII
Model Type	0x0C		1011	Used for WPS 2.0	ASCII
Device Name	0x0D		GainSpan WiFi Module	Used for WPS 2.0	ASCII
Host Name	0x0E			Host Name used for MDNS	ASCII

4.19.7 Set System Time

AT+SETTIME=[<dd/mm/yyyy>,<HH:MM:SS>],[System time in milliseconds since epoch(1970)]

Upon execution of this command the adapter set its system time to the time specified as the parameters and returns the standard command response. The adapter expects either one of the time parameters.

This command does not take care of the day light savings. The reference will be with respect to UTC/GMT.

4.19.8 Set System Time Using SNTP

AT+NTIMESYNC= <Enable>,<Server IP>,<Timeout>,<Periodic>,<frequency>

Upon execution of this command the adapter set the system time using the SNTP.

- ▶ Enable: **1** - start doing the time sync using SNTP. **0** - Stop the time sync
- ▶ Server IP: SNTP server IP
- ▶ Timeout: Time to wait for server response and in seconds.
- ▶ Periodic: Time sync to be done one time or periodically. 1- periodic, 0 - one time
- ▶ Frequency: If the periodic flag is set, time difference between each time sync and it is in seconds

This command returns OK/ ERROR/ INVALID INPUT. The time set by this command can be verified using the AT+GETTIME=?

Note that the time set will be UTC/GMT.

4.19.9 Get System Time

AT+GETTIME=?

Upon reception of this command the adapter sends the current system time in formatted and in milliseconds since epoch (1970) followed by the standard command response to the serial interface. The time format comes on the serial interface as follows:

=<dd/mm/yyyy>,<HH:MM:SS>,System time in milliseconds since epoch(1970).

4.19.10 GPIO Out HIGH/LOW

Set/Reset (high/low) a GPIO pin.

AT+DGPIO=<GPIO-NO>,<SET/RESET(0/1)>

This command sets the GPIO 'GPIO-NO' pin level to high or low as per the SET/RESET parameter and returns the standard command response (section 4)

Note: Only the GPIO Pins which are not mixed with the any used IOs like UART/SPI etc. that can be set high/low with this command.

The supported GPIOs and the corresponding numbers are:

- ▶ Gpio10: 10
- ▶ Gpio11: 11
- ▶ Gpio30: 30
- ▶ Gpio31 : 31

4.19.11 Error Counts

Get the error count statistics.

AT+ERRCOUNT=?

This command returns error count information to the interface followed by the standard command response (section 4).

The error counts include:

- ▶ Watchdog reset counts
- ▶ Software reset counts
- ▶ WLAN abort/assert counts

4.19.12 Version

AT+VER=?

The command returns version information followed by the standard command response (section 4). to the serial host:

- ▶ Serial-to-Wi-Fi version;
- ▶ GainSpan Embedded Platform Software version;

- ▶ WLAN firmware version.

The command to get more details of the s2w version is

AT+VER=??

This command returns more information along with the above response of the s2w binary followed by the standard command response (section 4). to the serial host:

- ▶ Serial-to-Wi-Fi binary type
- ▶ Serial-to-Wi-Fi Release type

4.19.13 Ping

AT+PING=<Ip>,[[<Trails>], [<timeout>], [<Len>], [<TOS>], [<TTL>], [<PAYLOAD>]]

Upon deployment of this command the device sends a *ping* to the remote machine specified by the IP address.

- ▶ IP is the IP address of the server to which the command is directed;
- ▶ Trails indicate the number of *ping* requests to send. The default value is 0; in this case, *ping* will continue until terminated as described below.
- ▶ Timeout is the timeout in milliseconds for each *ping* response to come after send out a ping request; the valid range is 1000-99000. The default value is 3000.
- ▶ Len is the length of the *ping* packet; the valid range is 0 to 1024. The default value is 56.
- ▶ TOS is the type of service; the valid range is 0-99. The default value is 0.
- ▶ TTL is the time to live; the valid range is 0-255. The default value is 30.
- ▶ Payload is the data to be sent in each *ping* packet. The payload length should be in the range 0-16; the payload may contain valid alphanumeric characters (0-9, a-e).

To terminate a Ping sequence, issue <Esc> C.

4.19.14 Trace Route

Start a *trace route* operation.

AT+TRACEROUTE=<Ip>,[[<Interval>], [<MaxHops>], [<MinHops>], [<TOS>]]

Parameters:

- ▶ IP is the IP address of the remote server;
- ▶ Interval is the interval in milliseconds between each request; the valid range is 1000-99000. The default value is 1000.
- ▶ MaxHops is the maximum time-to-live; the valid range is 2-99. The default value is 30.
- ▶ MinHops is the minimum time-to-live; the value given should be greater than 1 and less than MaxHops. The default value is 1.
- ▶ TOS is the type of service; the valid range is 0-99. The default value is 0.

Upon reception of this command the adapter starts the trace route operation and returns the following information to serial interface along with the standard command response(section 4).

<LF>Tracing Route to<space><IP address><space>over a max hops<space>< MaxHops><CR><LF>

During this trace route operation the adapter sends the ping delays and the next hop ip address information to the serial interface one at a line in the following format:

<CR><LF><current TTL ><2 space><1st RTT in 4 bytes>ms<2 space><2nd RTT in 4 bytes>ms<2 space><3rd RTT in 4 bytes>ms<2 space><ip address of hop>

Once the trace route operation complete, the adapter sends the message”<CR><LF><CR><LF> Trace Complete<CR><LF>” to the serial interface.

4.19.15 Memory Trace

AT+MEMTRACE

Upon reception of this command the adapter sends the memory trace information to the serial interface along with standard command response.

The memory trace information contains the following :

- ▶ Number Of Allocation
- ▶ Number Of Free
- ▶ Current Used Memory in bytes
- ▶ Peak Memory Usage in bytes
- ▶ Memory Details of currently used allocations in the following format:
- ▶ <address>,<line number>,<size>,<module name>
- ▶ Number of Allocations to be freed

4.19.16 Reset

The command to reset the adapter:

AT+RESET

This command forcefully reset the adapter and comes out with a fresh boot message “<LF><CR>APP Reset-APP SW Reset<CR><LF>”.

4.19.17 WLAN statistics

Not Supported on the GS1011

AT+WSTAT

The host uses this command to request that the GS1500M send statistics that it maintains., including Rx, Tx and encryption errors. Wireless statistics counters silently wrap. It is the responsibility of the host to read the counters periodically before the wrap loses information.

When the statistics are sent to the host, the GS1500M clears them so that a new set of statistics are collected for the next report.

This command returns the statistics counters in the following order separated by comma.

<tx_packets>, <tx_bytes>, <tx_unicast_pkts>, <tx_unicast_bytes>, <tx_multicast_pkts>,

<tx_multicast_bytes>, <tx_broadcast_pkts>, <tx_broadcast_bytes>, <tx_rts_success_cnt>,
 <tx_packet_per_BE>, <tx_packet_per_BK>, <tx_packet_per_VI>, <tx_packet_per_VO>,
 <tx_errors_per_BE>, <tx_errors_per_BK>, <tx_errors_per_VI>, <tx_errors_per_VO>,
 <tx_errors>, <tx_failed_cnt>, <tx_retry_cnt>, <tx_mult_retry_cnt>, <tx_rts_fail_cnt>,
 <tx_unicast_rate>,
 <rx_packets>, <rx_bytes>, <rx_unicast_pkts>, <rx_unicast_bytes>, <rx_multicast_pkts>,
 <rx_multicast_bytes>, <rx_broadcast_pkts>, <rx_broadcast_bytes>, <rx_fragment_pkt>,
 <rx_errors>, <rx_crcerr>, <rx_key_cache_miss>, <rx_decrypt_err>, <rx_duplicate_frames>,
 <rx_unicast_rate>,
 <tkip_local_mic_failure>, <tkip_counter_measures_invoked>, <tkip_replays>,
 <tkip_format_errors>, <ccmp_format_errors>, <ccmp_replays>

Some additional description of counters:

tx_packet_per_BE	Tx packets for Best Effort traffic class
tx_packet_per_BK	Tx packets for BacKground traffic class
tx_packet_per_VI	Tx packets for Video traffic class
tx_packet_per_VO	Tx packets for Voice traffic class
tx_errors	Number of packets which failed Tx, due to all failures
tx_failed_cnt	Number of data packets that failed Tx
tx_retry_cnt	Number of Tx retries for all packets
tx_rts_fail_cnt	Number of RTS Tx failed count
rx_fragment_pkt	Number of fragmented packets received
rx_errors	Number of Rx errors due to all failures
rx_crcerr	Number of Rx errors due to CRC errors
rx_key_cache_miss	Number of Rxerrors due to a key not being plumbed
rx_decrypt_err	Number of Rx errors due to decryption failure
rx_duplicate_frames	Number of duplicate frames received
tkip_local_mic_failure	Number of TKIP MIC errors detected

tkip_counter_measures_invoked	Number of times TKIP countermeasures were invoked
tkip_replays	Number of frames that replayed a TKIP encrypted frame received earlier
tkip_format_errors	Number of frames that did not conform to the TKIP frame format
ccmp_format_errors	Number of frames that did not conform to the CCMP frame format
ccmp_replays	Number of frames that replayed a CCMP encrypted frame received earlier

4.20 Over the Air Firmware Upgrade Using External Flash

This set of commands is for firmware upgrade when the external flash is available to download the binaries that are to be upgraded. This module uses the HTTP client to download the binaries from an HTTP server. AT+HTTPCONF command is used to configure any header/s need to be present in the http GET request. Along with this command following two commands are used :

4.20.1 FWUP Configuration

AT+SOTAFWUPCONF=<param>,<value>

The table below gives the valid <param> and the description of the respective <value> . <value> is in string format

Param	Value
0	Server IP address
1	Server Port
2	Proxy present (0 – Not Present. 1- Present)
3	Proxy server IP (Required only if Param 2 is equal to 1)
4	Proxy server Port (Required only if Param 2 is equal to 1)
5	SSL enabled (0- Not enabled. 1- Enabled)
6	CA certificate name (If it's already been added using at+tcertadd command)
7	WLAN binary request URL

8	App 0 binary Request URL
9	App1 binary request URL
13	MAC binary request URL. (GS1500M only)

Note: In case of HTTP/S through Proxy, the request URL should be Absolute path and not the Relative path.

This command returns the standard command response (section 4) to the serial host.

4.20.2 FWUP Start

Firmware upgrade procedure.

AT+SOTAFWUPSTART=<value>

This command uses the header configured using at+httpconf command and other required parameters configured using the at+sotafwupconf command, starts the http connection, download the new images and starts updating the firmware.

The <value> indicates which of the 3 binaries need to be upgraded.

Value	Description	Note
3	Upgrade only the App0 and App1 binaries	
4	Upgrade only the WLAN binary	In case of GS1500M upgrade WLAN binary and MAC binary
7	Upgrade all the 3 binaries	In case of GS1500M upgrade all the 4 binaries

This command returns the standard command response (section 4) to the serial host.

4.21 GS1500M WiFi Direct (P2P) Commands **

This section contains P2P specific commands and applicable for GS1500M only.

Not Supported on the GS1011M

4.21.1 P2P mode configuration **

Not Supported on the GS1011M

AT+WM=3

If the P2P mode is being started for the first time, the command AT+WM=3 must be issued after executing AT+P2PSETDEV and AT+P2PSETWPS commands described in the next section. Once the parameters are set, P2P mode can be set directly.

If parameters are not configured then, default parameters will be used for P2P mode operation.

To switch back to other WLAN modes, the AT+WM command must be given again with appropriate value. Refer Section 4.7.7 for more details

For example, to switch back to WLAN STA mode, AT+WM=0 must be given.

4.21.2 Set P2P Device **

Not Supported on the GS1011M

AT+P2PSETDEV=<go intent>,<reg class>,<listen channel>,<operating channel>,<config methods>,<country>

This command is used to set the important P2P device related attributes using single set command and this must be the first command for starting P2P operation.

Parameters:

1. go intent – 0 to 15, group owner intent value to be used for group negotiation
2. reg class
 - 81 – 11g channels 1 to 13
 - 82 – 11g channel 14
 - 115 – 11a channels 36 to 48
 - 124 – 11a channels 149 to 161
3. listen channel – 1 byte value indicating channels 1 to 14
4. operating channel – 1 byte value indicating channels 1 to 14
5. config methods – 2 byte value indicating the WPS config methods supported
6. country – indicates the country to operate in. Valid country code strings are US,JP and EU. Country code string must be in upper case

4.21.3 Set WPS configuration **

Not Supported on the GS1011M

AT+P2PSETWPS=<device name>,<primary device type category>,<primary device type subcategory>,<uuid>,[Num secondary device types],[secondary dev type category],[secondary dev type subcategory],...up to 5 tuples

This command is used to set the important P2P WPS related attributes using single set command.

Parameters:

1. device name – 32 character string. This is the device name used to uniquely identify the device
2. primary device type category – A 2 byte device category value. Refer to P2P specification document for device categories.
3. primary device type subcategory – A 2 byte device subcategory value. Refer to P2P specification document for device subcategories.
4. uuid – 16 byte UUID

4.21.4 Set P2P Attribute **

Not Supported on the GS1011M

AT+P2PSETATTR=<attribute ID><attribute value>

The following attributes are supported:

Attribute Id	Attribute	Attribute value	Description
1	Intra BSS distribution	0 – disable 1 – enable	By default, intra-bss distribution is enabled. This is used to disable it.

4.21.5 P2P Find **

Not Supported on the GS1011M

AT+P2PFIND=<timeout>,<type>

1. timeout
If timeout is not specified, then it is considered as infinite i.e., the system will be in find phase forever or until stopped explicitly using “at+p2pstopfind.”
If timeout is specified, then it indicates P2P find duration in seconds.
2. type – 0 (full scan) or 1 (social) or 2 (progressive). social scan only channels 1,6,11. progressive scans all channels.

Command Response:

The format is similar to scan results, as given below.

p2p-dev-found<MAC address>,<device address>,<primary device category>,<primary device subcategory>,<secondary device category>,<secondary device subcategory>,<device name>,<channel>,<config methods>,<device capabilities>,<group capabilities>

For example,

p2p-dev-found 02:b5:64:63:30:63,02:b5:64:63:30:63, 0006,0050,f204,0001,,wireless pc,6,2388,33,49

Note:

1. Mac addr,devaddr,type, config methods, device cap and group cap values are displayed in hex
2. P2P find is NOT supported in GO mode

4.21.6 P2P Stop Find **

Not Supported on the GS1011M

AT+P2PSTOPFIND

This stops the P2P find that is currently in progress. This command returns the standard command response (section 4) to the serial interface.

4.21.7 P2P Listen **

Not Supported on the GS1011M

AT+P2PLISTEN=[timeout]

This command is used to start listening to P2P devices. In this state, it responds to provision discovery requests.

The timeout is an optional parameter specifying the listen duration in seconds. If not specified, it is infinite and can be stopped using AT+P2PSTOPFIND

4.21.8 P2P Group Owner Start **

Not Supported on the GS1011M

AT+P2PGOSTART=<channel>,[ssid-postfix],[persistent],[persistent group id]

1. channel is the channel on which the GO must be started
2. ssidPostfix is an optional parameter that specifies the postfix to be used for the ssid
For example: AT+P2PGOSTART=6,gsnode
The GO will be started on channel 6 with ssid "DIRECT-gsnode".
3. persistent flag is used to indicate if this is a persistent group.
4. persistent group id gives the identifier of the persistent group. If the persistent group with the given id exists, then it is invoked; otherwise a new persistent group is created and stored with the given id. Currently only 1 persistent group information can be saved.

Response:

p2p-go-started<ssid>,<channel>,<GO dev address>,<psk> | <passphrase>,<Display PIN>

Typical example,

p2p-go-started DIRECT-gsnode,6,00:1d:c9:01:02:03,xyghjsef,46859976

4.21.8.1 Invoking Persistent Group **

Not Supported on the GS1011M

Invoke a persistent group that was created earlier. In this case, the persistent group ID is specified.

AT+P2PGOSTART

Example usage given below:

AT+P2PGOSTART=,,1,1

4.21.9 Provisioning Discovery **

Not Supported on the GS1011M

AT+P2PPD=<peer address>,<config method>

Sends provisioning discovery request to given peer with the given config method and wait for provisioning discovery response.

Parameters:

1. peer address: MAC address of the peer P2P device to send provisioning discovery request.
2. config method: Config method to use.
 - 0 – Request peer to push button
 - 1 – request peer to display PIN that we would use for connect/join
 - 2 – request peer to enter PIN we would display

Response:

1. If the config method is push button, then the peer will push the button upon receiving the provisioning discovery request. When the provisioning discover response comes back, the following response is sent to host: p2p-prov-disc-resppbc
Upon receiving this response, the host should issue connect or join command.
2. If the config method is “display” (option 1), then peer will display the PIN on receiving the provisioning discovery request that we would use in connect/join command. Once the provisioning discovery response comes back, the following response is sent to host: p2p-prov-disc-respenter pin
Upon receiving this response, the host should issue connect or join command with the PIN displayed on the peer
3. If the config method is “keypad” (option 2), then peer will enter the PIN that we would display. Once the provisioning discovery response comes back from peer, the following response is sent to host:
p2p-prov-disc-respdisplay pin <PIN>
Upon receiving this response, the host should issue connect or join command with displayed PIN.

Note:

Before issuing provision discovery command, make sure find is in progress, otherwise it will return ERROR.

4.21.10 Group Form (Group Owner Negotiation) **

Not Supported on the GS1011M

To start P2P group formation with a discovered P2P peer.

```
AT+P2PGRPFORM=<peer address>,<channel>,<WPS method>,[PIN],[GO
intent],[auth],[persistent]
```

Group formation includes group owner negotiation, provisioning and establishing data connection.

Parameters:

1. peer address: MAC address of the peer P2P device to connect to.
2. channel: channel on which to connect.
3. WPS method:
 - a. 4: Use push button for provisioning(PBC)
 - b. 2: Display configuration information. i.e., Display a PIN that peer has to enter
 - c. 3: Key-in configuration information. i.e., enter the PIN using keypad, which was displayed by peer
4. PIN : WPS pin, if the above selected option is DISPLAY or KEYPAD method.
5. GO intent: GO intent value to be used for GO negotiation. If not specified, default value will be used.
6. Auth: If auth is specified as 1, 1500 is in listen mode, and it can respond to GO-Negotiation requests
7. persistent: Set if the group should be a persistent group. If not specified, it is taken as zero i.e., not a persistent P2P group.

Note: If any of the above parameter is not specified, then it will be considered to be not set.

Response:

1. p2p-go-neg-complete client,<ssid>,<channel>,<GO device address>,<passphrase> | <psk>

This format is used when a new group is created and the device becomes a client.

Typical example,

```
p2p-group-started client,DIRECT-gs,6,02:1d:c9:01:02:03,GSDemo123
```

2. p2p-go-neg-complete GO,<ssid>,<channel>,<GO device address>,<passphrase> | <psk>

This format is used when a new group is created and the device becomes a GO.

Typical example,

```
p2p-go-neg-complete GO,DIRECT-aR,11,02:1d:c9:90:6a:bb,E4JWHKo3
```

3. p2p-go-neg-fail <reason>

Typical use cases are described in the next section.

4.21.10.1 Group Formation using PBC Method **

Not Supported on the GS1011M

For group formation using PBC method, the following commands are entered on your device and peer device:

```
own>at+p2pgrpform=02:1d:c9:01:02:03,6,4,,15,1,0
```

```
peer>at+p2pgrpform=02:1d:c9:01:02:04,6,4,, 4,0,0
```

4.21.10.2 Group Formation using Display Method **

Not Supported on the GS1011M

For group formation using Display Method, the following commands are entered on your device and peer device after discovering devices using p2pfind.

At the peer where the PIN needs to be entered, the following command should be given:

```
peer>at+p2pgrpform=02:1d:c9:01:02:04,6,1,<PIN>,1,4,0,0
```

The GO negotiation should happen between the two devices followed by provisioning and connection and the following response is given out:

```
own>p2p-group-started GO,DIRECT-gs,6,02:1d:c9:01:02:04,GSDemo123
```

```
peer>p2p-group-started client,DIRECT-gs,6,02:1d:c9:01:02:03,GSDemo123
```

4.21.10.3 Group Formation using Keypad Method **

Not Supported on the GS1011M

For group formation using Keypad method, the following commands are entered on your device and peer device after discovering devices using p2pfind.

```
own>at+p2pgrpform=02:1d:c9:01:02:03,6,2,<PIN>,1,15,1,0
```

At the peer where the PIN needs to be displayed, the following command should be given:

```
peer>at+p2pgrpform=02:1d:c9:01:02:04,6,3,<PIN>,0,4,0,0
```

The GO negotiation should happen between the two devices followed by provisioning and connection and then the following response is given out:

```
own>p2p-group-started GO,DIRECT-gs,6,02:1d:c9:01:02:04,GSDemo123
```

```
peer>p2p-group-started client,DIRECT-gs,6,02:1d:c9:01:02:03,GSDemo123
```

4.21.10.4 Provision Discovery Request Handling **

Not Supported on the GS1011M

Upon receiving provisioning discovery request, depending on WPS config method, one of the following response is sent to host.

PBC Method :

p2p-prov-disc-req pbc<peer address>,<device address>,<primary device category>,<primary device subcategory>,<secondary device category>,<secondary device subcategory>,<device name>,<config methods>,<device capability>,<group capability>

The user action upon receiving this should be following:

AT+P2PPROVOK

or

AT+P2PPROVNOK

Display Method :

p2p-prov-disc-req display-pin <PIN> <peer address>,<device address>,>,<primary device category>,<primary device subcategory>,<secondary device category>,<secondary device subcategory>,<,<device name>,<config methods>,<device capability>,<group capability>

The user action should be to show the PIN on a display and issue following command:

AT+P2PGRPFORM=...

or

AT+P2PPROVOK

or

AT+P2PPROVNOK

Keypad Method :

p2p-prov-disc-req enter-pin <peer address>,<device address>,>,<primary device category>,<primary device subcategory>,<secondary device category>,<secondary device subcategory>,<device name>,<config methods>,<device capability>,<group capability>

The user action should be to enter PIN as follows:

AT+P2PGRPFORM=...

or

AT+P2PPROVOK=<PIN>

or

AT+P2PPROVNOK

4.21.11 Client Join **

Not Supported on the GS1011M

AT+P2PJOIN=<GO device address or interface address>,<wps method>,[pin]

Parameters:

1. GO device address or interface address – device address or interface address of group owner
2. wps method – WPS method to use for WPS procedure
 - 0 – pbc
 - 1 – display
 - 2 – keypad
3. pin is optional. It should be entered in following cases:
 - a. If wps_method is keypad, then the entered pin is passed (displayed by peer)
 - b. if wps_method is display, then the pin displayed by us is passed (keyed by peer)

Response:

1. p2p-join-success-client <ssid>,<channel>,<GO device address>, <psk>

This format is used when the device connects as a client to an already existing group.

Typical example,

p2p-join-success-client DIRECT-gs,6,02:1d:c9:01:02:03,
6219f1d891f752c00bb4a850dd4a26bc1d74e79791a2db6da0f97ba2ca1921ca

2. p2p-join-fail <reason>

4.21.12 Invitation Procedures **

Not Supported on the GS1011M

Sends an invitation request to the given peer address.

AT+P2PINVITE=<peer address>,[GO device address]

This command sends an invitation request to the given peer address to join an active group. The invitation is sent to request the peer to join the group for which this device is a GO or to request the peer to join the group for which the device address is specified.

Note: This does not support sending invitation to invoke a persistent group.

Parameters:

1. peer address – address of peer device to which invitation has to be sent.
2. GO device address – Device address of Group Owner(GO) of group to which the peer should join.

4.21.13 P2P Disconnect **

Not Supported on the GS1011M

Disconnect P2P client or Group owner.

AT+WD

If the device is in P2P mode, then this command does the following,

- a. If the device is connected as a client to a group, then it disconnects
- b. If the device is operating as a GO, then it stops GO operation

4.21.14 P2P Store/Restore NW Connection **

Not Supported on the GS1011M

The store (AT+STORENWCON) and restore NW connection (AT+RESTORENWCONN) commands store and restore P2P context also. If a device is operating in P2P mode as a client or Group Owner(GO), then store/restore can be used to store the context, go to standby and restore the context. The device will perform the necessary setup and continue to operate in the previous mode.

Refer Section 4.9.15 and 4.9.16 for command syntax.

5 References

- [1] GS1011M or GS1011 Data Sheet, GS1011-DS, GainSpan Corporation

- [2] IEEE Standard for Information technology-Telecommunications and information exchange between systems-Local and metropolitan area networks-Specific requirements - Part 11: Wireless LAN Medium Access Control (MAC) and Physical Layer (PHY) Specifications, 802.11-2007, IEEE, www.ieee.org

- [3] V.250, Serial asynchronous automatic dialing and control, and V.251, Procedure for DTE-controlled call negotiation, International Telecommunications Union, www.itu.int

- [4] **Communications Networks**, A. Leon-Garcia and I. Widjaja, McGraw-Hill 2000, p. 582

- [5] **AN023 – Battery Level Check**, GainSpan Corporation

6 Appendix

6.1 Data handling using Esc Sequences on UART Interface

<i>Flow Control</i>	<i>Data Mode (Data Type)</i>	<i>Connection Type</i>	<i>Description and Escape Command Sequence</i>
SW or HW	Normal (ASCII Text)	TCP client TCP server	<p>This escape sequence selects the specified Connection ID as the current connection. This switches the connection to be used without exiting from the Data mode of operation. Use this sequence to send data from a TCP server, TCP client or UDP client (must be done before data can be received by that client).</p> <p>Module send and receive sequence:</p> <p><Esc>S<CID><data><Esc>E</p> <p>Example:</p> <p>To send user data (e.g. Hello) on CID 1, the format will be:</p> <p><Esc>S1Hello<Esc>E</p>
SW or HW	Normal (ASCII Text)	UDP client	<p>If UDP client is configured with unicast destination server IP address, then:</p> <p>Module send and receive sequence:</p> <p><Esc>S<CID><data><Esc>E</p> <p>If UDP client is configured with broadcast destination server IP address (i.e. 255.255.255.255), then:</p> <p>Module expects to receive the following data sequence from Host:</p> <p><Esc>S<CID><data><Esc>E</p> <p>Module sends the following data sequence to Host:</p> <p><Esc>u<CID><IPAddress><space><port><horizontal tab><data><Esc>E</p>
SW or HW	Normal (ASCII Text)	UDP server	<p>This escape sequence is used when sending and receiving UDP data on a UDP server connection. When this command is used, the remote address and remote port is transmitted.</p> <p>Module expects to receive the following data sequence</p>

Flow Control	Data Mode (Data Type)	Connection Type	Description and Escape Command Sequence
			<p>from Host:</p> <p><Esc>U<CID><IP Address>:<port>:<data><Esc>E</p> <p>Module sends the following data sequence to Host:</p> <p><Esc>u<CID><IPAddress><space><port><horizontal tab><data><Esc>E</p> <p>Example:</p> <p>When Module sends data (e.g. Hello) on CID 0, the format will be:</p> <p><Esc>u0192.168.0.101<space>1001<horizontal tab>Hello<Esc>E</p>

Flow Control	Data Mode (Data Type)	Connection Type	Description and Escape Command Sequence
SW or HW	Normal (Binary)	NA	Binary data transfer with software or hardware flow control are not supported with ESC sequence.
SW or HW	Bulk (ASCII Text)	TCP client TCP server	<p>To improve data transfer speed , one can use this bulk data transfer. This sequence is used to send and receive data on TCP client, TCP server, or UDP client connection.</p> <p>Module send and receive sequence:</p> <p style="padding-left: 40px;"><Esc>Z<CID><data length><data></p> <p>Example:</p> <p>To send a 5 byte user data (e.g. Hello) on CID 1, the format will be: <Esc>Z10005Hello</p>
SW	Bulk (ASCII Text or Binary)	UDP client	<p>If UDP client is configured with an unicast destination server IP address, then</p> <p>Module send and receive sequence:</p> <p style="padding-left: 40px;"><Esc>Z<CID><Data Length><data></p> <p>If UDP client is configured with a broadcast destination server IP address (i.e. 255.255.255.255), then:</p> <p>Module expects to receive the following data sequence from Host:</p> <p style="padding-left: 40px;"><Esc>Z<CID><Data Length><data></p> <p>Module sends the following data sequence to Host:</p> <p style="padding-left: 40px;"><Esc>y<CID><IPAddress><Space><Port><horizontal tab><data length><data></p>
SW or HW	Bulk (ASCII Text)	UDP server	<p>This escape sequence is used when sending and receiving UDP bulk data on a UDP server connection. When this command is used, the remote address and remote port is transmitted.</p> <p>Module expects to receive the following data sequence from Host:</p> <p style="padding-left: 40px;"><Esc>Y<CID><IP address>:<port>:<data length><data></p>

<i>Flow Control</i>	<i>Data Mode (Data Type)</i>	<i>Connection Type</i>	<i>Description and Escape Command Sequence</i>
			<p>Module sends the following data sequence to Host:</p> <p><Esc>y<CID><IPAddress><Space><Port><horizontal tab><data length><data></p> <p>Example:</p> <p>When receiving a 5 byte user data (e.g. Hello) on CID 1, the format will be:</p> <p><Esc>y0192.168.0.101<space>1001<horizontal tab>0005Hello</p>
HW	Bulk (Binary)	TCP client TCP server UDP client	<p>To improve data transfer speed , one can use this bulk data transfer. This sequence is used to send and receive data on TCP client, TCP server, or UDP client connection.</p> <p>Module send and receive sequence:</p> <p><Esc>Z<CID><data length><data></p> <p>Example:</p> <p>To send a 5 byte user data (e.g. Hello) on CID 1, the format will be: <Esc>Z10005Hello</p>
SW	Bulk (Binary)	NA	Binary data transfer with software flow control not supported.

6.2 Data handling using Esc Sequences on SPI Interface

<i>Data Mode (Data Type)</i>	<i>Connection Type</i>	<i>Description and Escape Command Sequence</i>
Normal (ASCII Text)	TCP client TCP server	<p>1. Data transfer is transparent due to byte stuffing at SPI driver level.</p> <p>2. Byte stuffing must be incorporated in Host controller as per the Adaptor guide.</p> <p>Module send and receive sequence: <Esc>S<CID><data><Esc>E or Auto mode</p>
Normal (ASCII Text)	UDP client	<p>If UDP client is configured with an unicast destination server IP address, then:</p> <p>Module send and receive sequence: <Esc>S<CID><data><Esc>E</p> <p>If UDP client is configured with a broadcast destination server IP address (i.e. 255.255.255.255), then:</p> <p>Module expects to receive the following data sequence from MCU: <Esc>S<CID><data><Esc>E</p> <p>Module sends the following data sequence to MCU: <Esc>u<CID><IP Address><space><port><horizontal tab><data><Esc>E</p>
Normal (ASCII Text)	UDP server	<p>This escape sequence is used when sending and receiving UDP data on a UDP server connection. When this command is used, the remote address and remote port is transmitted.</p> <p>Module expects to receive the following data sequence from Host: <Esc>U<CID><IP Address>:<port>:<data><Esc>E</p> <p>Module send the following data sequence to Host: <Esc>u<CID><IP Address><space><port><horizontal tab><data><Esc>E</p> <p>Example:</p> <p>When receiving user data (e.g. Hello) on CID 0, the format will be:</p>

Data Mode (Data Type)	Connection Type	Description and Escape Command Sequence
		<Esc>u0192.168.0.101<space>1001<horizontal tab>Hello<Esc>E
Normal (Binary)	NA	Binary data transfer with software flow control is not supported with ESC sequence.
Normal (ASCII Text or Binary)	NA	Hardware flow control is not supported.
Bulk (ASCII Text or Binary)	TCP client TCP server	<p>1. Data transfer is transparent due to byte stuffing at SPI driver level.</p> <p>2. Byte stuffing must be incorporated in Host controller as per the Adaptor guide.</p> <p>Module send and receive sequence:</p> <p><Esc>Z<CID><Data Length><data></p> <p>Example: To send a 5 byte user data (e.g. Hello) on CID 1, the format will be: <Esc>Z10005Hello</p>
Bulk (ASCII Text or Binary)	UDP client	<p>If UDP client is configured with an unicast destination server IP address, then:</p> <p>Module sends and receives the following data sequence:</p> <p><Esc>Z<CID><Data Length><data></p> <p>If UDP client is configured with a broadcast destination server IP address (i.e. 255.255.255.255), then:</p> <p>Module expects to receive the following data sequence from Host:</p> <p><Esc>Z<CID><Data Length><data></p> <p>Module sends the following data sequence to Host:</p> <p><Esc>y<CID><IP Address><Space><Port><horizontal tab><data length><data></p>
Bulk (ASCII Text or Binary)	UDP server	This escape sequence is used when sending and receiving UDP bulk data on a UDP server connection. When this command is used, the remote address and remote port is transmitted.

<i>Data Mode (Data Type)</i>	<i>Connection Type</i>	<i>Description and Escape Command Sequence</i>
		<p>Module receives from Host the following data sequence: <Esc>Y<CID><IP address>:<port>:<data length><data></p> <p>Module sends the following data sequence to Host: <Esc>y<CID><IP Address><Space><Port><horizontal tab><data length><data></p> <p>Example:</p> <p>When receiving a 5 byte user data (e.g. Hello) on CID 1, the format will be:</p> <p><Esc>y0192.168.0.101<space>1001<horizontal tab>0005Hello</p>