

DHT11 SENSOR

```
#include "DHT.h"

#define DHTPIN 2

#define DHTTYPE DHT11

DHT dht(DHTPIN,DHTTYPE);

void setup()

{
    Serial.begin(9600);

    dht.begin();
}

void loop()

{
    float t=dht.readTemperature();

    if(isnan(t))

    {
        return;
    }

    Serial.print("% Temp:");

    Serial.print(t);

    Serial.println(" *C");

    delay(2000);
}
```

