

DB 70 EA F1 DB EA F1 9B	DC 71 EB F2 DC EB F2 9C	DD 72 EC F3 DD EC F3 9D	DE 73 ED F4 DE ED F4 9E	DF 74 EE F5 DF EE F5 9F	E0 75 EF F6 E0 EF F6 A0	E1 76 F0 F7 E1 F0 F7 A1	E2 77 F1 F8 E2 F1 F8 A2	E3 78 F2 F9 E3 F2 F9 A3	E4 79 F3 F10 E4 F3 F10 A4	E5 80 F4 F11 E5 F4 F11 A5
7C 1 60 \ 1 7C 60 -	7E 2 5C \ 2 7E 5C 1C	31 3 21 ! 3 31 21 -	32 4 40 @ 4 32 40 -	33 5 23 # 5 33 23 -	34 6 24 \$ 6 34 24 -	35 7 25 % 7 35 25 -	36 8 5E ^ 8 36 5E 1E	37 9 26 & 9 37 26 -	38 10 2A * 10 38 2A -	39 11 2B # 11 39 2B -
1B 19 1B 1B -	09 20 09 09 -	71 21 51* 21 11 11 D1	77 22 57* 22 17 17 D7	65 23 45* 23 05 05 C5	72 24 52* 24 12 12 D2	74 25 54* 25 14 14 D4	79 26 59* 26 19 19 D9	75 27 55* 27 15 15 D5	69 28 49* 28 09 09 C9	70 29 56* 29 16 16 D6
36 CMND	37 CONTROL	61 38 41* 38 01 01 C1	73 39 53* 39 13 13 D3	64 40 44* 40 04 04 C4	66 41 46* 41 06 06 C6	67 42 47* 42 07 07 C7	68 43 48* 43 08 08 C8	6A 44 4A* 44 0A 0A CA	6B 45 4B* 45 0B 0B CB	71 46 51* 46 11 11 D1
53 ALL CAPS	54 SHIFT	7A 55 5A* 55 1A 1A DA	78 56 58* 56 18 18 D8	63 57 43* 57 03 03 C3	76 58 56* 58 16 16 D6	62 59 42* 59 02 02 C2	6E 60 4E* 60 0E 0E CE	6D 61 4D* 61 0D 0D CD	7C 62 5C* 62 1C 1C DC	7D 63 5D* 63 1D 1D DD
20 20 20 20 -										SPACE

ALL CAPS ON  
WHEN LIGHT  
IS LIT.

#### NOTES:

1. A DASH (-) IN THE 5th LOCATION MEANS IGNORE CMND KEY IF DEPRESSED.  
ANYTHING ELSE MEANS IGNORE SHIFT AND/OR CONTROL KEY IF DEPRESSED.
2. ONLY THOSE KEYS WITH AN ASTERISK (\*) ARE AFFECTED BY THE ALL CAPS KEY.  
WHEN ALL CAPS IS OFF THE CODES ARE AS SHOWN. WHEN ALL CAPS IS ON  
THE "JUST KEY" CODE CHANGES TO THE "SHIFT + KEY" CODE.
3. ONLY THOSE KEYS WITH ‡ ARE AFFECTED BY THE CURSOR LOCK KEY.  
WHEN CURSOR LOCK IS OFF THE CODES ARE AS SHOWN.  
WHEN CURSOR LOCK IS ON THE "JUST KEY" CODES CHANGE TO THE "SHIFT +  
KEY" CODES.

## KEYBOARD PHYSICAL