

SRV INSTRUCTIONS

1. KEEP SRV ALWAYS IN LINE UP CONDITION BY OPENING BOTH UPSTREAM AND DOWNSTREAM- SRV-MOV-01 & SRV-MOV-02 VALVES RESPECTIVELY.
2. ENSURE THAT SRV OUTLET LINE IS ALWAYS LINED UPTO 70KL SUMP TANK.
3. ENSURE THAT OUTLET VALVES OF 70KL SUMP TANK ARE IN CLOSED CONDITION.
4. ENSURE REGULAR MONITORING OF THE LEVEL OF 70KL SUMP TANK BY TAKING PHYSICAL DIP AT REGULAR INTERVALS.
5. PRESSURE ON THE PRESSURE GAUGE MOUNTED ON THE SRV (PG-01C) SHOULD BE 10Kg/cm².
6. ENSURE REGULAR MONITORING OF THE PRESSURE OF NITROGEN CYLINDERS FROM THE GAUGES.
7. ENSURE THAT RESETTING/MODIFICATION IF SET POINT GAUGE PRESSURE IS TO BE DONE AFTER TAKING PREMISSION FROM OFFICER IN CHARGE.
8. ENSURE REFILLING OF NITROGEN CYLINDERS IF PRESSURE IS AS LOW AS PER SPECIFICATION.