



You can read the recommendations in the user guide, the technical guide or the installation guide for SAMSUNG ML-2160. You'll find the answers to all your questions on the SAMSUNG ML-2160 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SAMSUNG ML-2160
User guide SAMSUNG ML-2160
Operating instructions SAMSUNG ML-2160
Instructions for use SAMSUNG ML-2160
Instruction manual SAMSUNG ML-2160

User's Guide

ML-216x Series
ML-216xW Series

BASIC

This guide provides information concerning installation, basic operation and troubleshooting on windows.

ADVANCED

This guide provides information about installation, advanced configuration, operation and troubleshooting on various OS environments.
Some features may not be available depending on models or countries.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://sOMEMANUALS.COM/dref/4128961)
<http://sOMEMANUALS.COM/dref/4128961>

Manual abstract:

Some features may not be available depending on models or countries. ASIC Available supplies 39 40 41 43 44 46 49 1. Introduction Key benefits Features by models Useful to know About this user's guide Safety information Machine overview Control panel overview Turning on the machine Installing the driver locally Reinstalling the driver 4 6 8 9 10 15 18 20 21 22 Available maintenance parts Storing the toner cartridge Redistributing toner Replacing the toner cartridge Cleaning the machine Tips for moving & storing your machine 4. Troubleshooting Tips for avoiding paper jams Clearing paper jams Understanding the status LED 51 52 55 2. Learning the Basic Usage Printing a demo page Media and tray Basic printing 24 25 34 5. Appendix Specifications Regulatory information Copyright 59 68 78 3. Maintenance Ordering supplies and accessories 38 2 1. Introduction This chapter provides information you need to know before using the machine. · Key benefits · Features by models · Useful to know · About this user's guide · Safety information · Machine overview · Control panel overview · Turning on the machine · Installing the driver locally · Reinstalling the driver 4 6 8 9 10 15 18 20 21 22 Key benefits Environmentally friendly Convenience · To save toner and paper, this machine supports the Eco feature (see "Easy Eco Driver" on page 159). · To save paper, you can print multiple pages on a single sheet of paper (see "Using advanced print features" on page 141). · To save paper, you can print on both sides of the paper (manual doublesided printing) (see "Using advanced print features" on page 141). · To save electricity, this machine automatically conserves electricity by substantially reducing power consumption when not in use. · Easy Capture Manager allows you to easily edit and print whatever you captured using the Print Screen key on the keyboard (see "Understanding Easy Capture Manager" on page 160). · Samsung Easy Printer Manager and Samsung Printer Status (or Smart Panel) are a program that monitors and informs you of the machine's status and allows you to customize the machine's settings (see "Using Samsung Easy Printer Manager" on page 164). · AnyWeb Print helps you screen-capture, preview, scrap, and print the screen more easily than when you use the ordinary program (see "Samsung AnyWeb Print" on page 158). · Smart Update allows you to check for the latest software and install the latest version during the printer driver installation process. This is available only for Windows OS users. · If you have Internet access, you can get help, support application, machine drivers, manuals, and order information from the Samsung website, www.samsung.com > find your product > Support or Downloads. Print with excellent quality and speed · You can print with a resolution of up to 1,200 x 1,200 dpi effective output. · Fast, on-demand printing. · For single-side printing, 20 ppm (A4) or 21 ppm (Letter). Key benefits Wide range of functionality and application support · Using the USB cable or a network cable - You can connect and set various wireless network settings using a USB cable or a network cable. · Using the Wi-Fi Direct - You can conveniently print from your mobile device using the Wi-Fi or Wi-Fi Direct feature. · Supports various paper sizes (see "Print media specifications" on page 61). · Print watermark: You can customize your documents with words, such as "Confidential" (see "Using advanced print features" on page 141). · Print posters: The text and pictures of each page of your document are magnified and printed across the multiple sheets of paper and can then be taped together to form a poster (see "Using advanced print features" on page 141). · You can print in various operating systems (see "System requirements" on page 64).



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

· Your machine is equipped with a USB interface.

See "Introducing wireless set up methods" on page 105. Supports various wireless network setting method · Using the WPS (Wi-Fi Protected Setup™) button

- You can easily connect to a wireless network using the WPS button on the machine and the access point (a wireless router). Features by models Some features and optional goods may not be available depending on model or country. Operating System Operating System Windows Macintosh Linux Unix ML-216x Series ML-216xW Series Software Software PCL printer driver SPL printer driver PS printer driver XPS printer driver a Samsung Easy Printer Manager SyncThru™ Web Service a. For XPS driver, it is only supported for windows through the Samsung website (www.samsung.com) ML-216x Series ML-216xW Series Features by models Variety feature Features Hi-Speed USB 2.0 Network Interface Ethernet 10/100 Base TX wired LAN Network Interface 802.11b/g/n wireless LAN IPv6 Eco printing(Easy Eco Driver)a Wi-Fi Protected Setup™ (WPS) Manual duplex (2-sided) printing a. Setting the ECO settings is available from the windows driver.

ML-216x Series ML-216xW Series (: Included, Blank: Not available) Useful to know Where can I download the machine's driver? ·Visit www.samsung.com/printer to download the latest machine's driver, and install it on your system. Printouts are blurry. ·The toner level might be low or uneven.

Shake the toner cartridge. ·Try a different print resolution setting. ·Replace the toner cartridge. Where can I purchase accessories or supplies? ·Inquire at a Samsung distributor or your retailer. ·Visit www.

samsung.com/supplies. Select your country/region to view product service information. The machine does not print. ·Open the print queue list and remove the document from the list (see "Canceling a print job" on page 35). ·Remove the driver and install it again (see "Installing the driver locally" on page 21). ·Select your machine as your default machine in your Windows. The status LED flashes or remains constantly on. ·Turn the product off and on again. ·Check the meanings of LED indications in this manual and troubleshoot accordingly (see "Understanding the status LED" on page 55).

A paper jam has occurred. ·Open and close the top cover (see "Front view" on page 16). ·Check the instructions on removing jammed paper in this manual and troubleshoot accordingly (see "Clearing paper jams" on page 52). About this user's guide This user's guide provides information for your basic understanding of the machine as well as detailed steps to explain machine usage. 1 2 General icons Icon Text Caution Description Gives users information to protect the machine from possible mechanical damage or malfunction. Provides additional information or detailed specification of the machine function and feature. Read the safety information before using the machine. If you have a problem using the machine, refer to the troubleshooting chapter.

Terms used in this user's guide are explained in the glossary chapter. All illustrations in this user's guide may differ from your machine depending on its options or model you purchased.

The screenshots in this user's guide may differ from your machine depending on the machine's firmware/driver version. The procedures in this user's guide are mainly based on Windows 7. Note Conventions Some terms in this guide are used interchangeably, as below: . . . Document is synonymous with original.

Paper is synonymous with media, or print media. Machine refers to printer or MFP.

1. Introduction 9 Safety information These warnings and precautions are included to prevent injury to you and others, and to prevent any potential damage to your machine. Be sure to read and understand all of these instructions before using the machine.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

After reading this section, keep it in a safe place for future reference. 4 Operating environment Warning 3 Important safety symbols Do not use if the power cord is damaged or if the electrical outlet is not grounded.

Explanation of all icons and signs used in this chapter Hazards or unsafe practices that may result in severe personal injury or death. Hazards or unsafe practices that may result in minor personal injury or property damage. This could result in electric shock or fire. Do not place anything on top of the machine (water, small metal or heavy objects, candles, lit cigarettes, etc.). This could result in electric shock or fire. · If the machine gets overheated, it releases smoke, makes strange noises, or generates an odd odor, immediately turn off the power switch and unplug the machine. · The user should be able to access the power outlet in case of emergencies that might require the user to pull the plug out. This could result in electric shock or fire. Do not bend, or place heavy objects on the power cord.

Stepping on or allowing the power cord to be crushed by a heavy object could result in electric shock or fire. Do not remove the plug by pulling on the cord; do not handle the plug with wet hands. This could result in electric shock or fire. Warning Caution Do not attempt. 1. Introduction 10 Safety information 5 Caution During an electrical storm or for a period of non-operation, remove the power plug from the electrical outlet. This could result in electric shock or fire. Be careful, the paper output area is hot. Burns could occur. If the machine has been dropped, or if the cabinet appears damaged, unplug the machine from all interface connections and request assistance from qualified service personnel.

Otherwise, this could result in electric shock or fire. If the machine does not operate properly after these instructions have been followed, unplug the machine from all interface connections and request assistance from qualified service personnel. Otherwise, this could result in electric shock or fire. If the plug does not easily enter the electrical outlet, do not attempt to force it in. Call an electrician to change the electrical outlet, or this could result in electric shock.

Do not allow pets to chew on the AC power, telephone or PC interface cords. This could result in electric shock or fire and/or injury to your pet. Operating method Caution Do not forcefully pull the paper out during printing. It can cause damage to the machine. Be careful not to put your hand between the machine and paper tray.

You may get injured. This machine's power reception device is the power cord. To switch off the power supply, remove the power cord from the electrical outlet. Be care when replacing paper or removing jammed paper. New paper has sharp edges and can cause painful cuts. When printing large quantities, the bottom part of the paper output area may get hot. Do not allow children to touch. Burns can occur. When removing jammed paper, do not use tweezers or sharp metal objects. It can damage the machine.

1. Introduction 11 Safety information Do not allow too many papers to stack up in the paper output tray. It can damage the machine. Do not block or push objects into the ventilation opening. This could result in elevated component temperatures which can cause damage or fire. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. Before moving the machine, turn the power off and disconnect all cords. The information below are only suggestions based on the units weight. If you have a medical condition that prevents you from lifting, do not lift the machine. Ask for help, and always use the appropriate amount of people to lift the device safely.

Then lift the machine: 6 Caution · If the machine weighs under 20 kg (44.09 lbs), lift with 1 person. If the machine weighs 20 kg (44.09 lbs) - 40kg (88.18 lbs), lift with 2 people.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

If the machine weighs more than 40 kg (88.18 lbs), lift with 4 or more people. Installation / Moving · · Warning Do not place the machine in an area with dust, humidity, or water leaks. This could result in electric shock or fire. The machine could fall, causing injury or machine damage.

Do not place the machine on an unstable surface. The machine could fall, causing injury or machine damage. Use only No.26 AWG or larger, telephone line cord, if necessary. Otherwise, it can cause damage to the machine. 1. Introduction 12 Safety information 7 Use the power cord supplied with your machine for safe operation. If you are using a cord which is longer than 2 meters (6 feet) with a 110 V machine, then the gauge should be 16 AWG or larger. Otherwise, it can cause damage to the machine, and could result in electric shock or fire. Make sure you plug the power cord into a grounded electrical outlet.

Otherwise, this could result in electric shock or fire. Do not overload wall outlets and extension cords. This can diminish performance, and could result in electric shock or fire. Do not put a cover over the machine or place it in an airtight location, such as a closet. If the machine is not well-ventilated, this could result in fire. The machine should be connected to the power level which is specified on the label. If you are unsure and want to check the power level you are using, contact the electrical utility company. a. AWG: American Wire Gauge Maintenance / Checking Caution Unplug this product from the wall outlet before cleaning the inside of the machine. Do not clean the machine with benzene, paint thinner or alcohol; do not spray water directly into the machine.

This could result in electric shock or fire. When you are working inside the machine replacing supplies or cleaning the inside, do not operate the machine.

You could get injured. Keep cleaning supplies away from children. Children could get hurt.

Do not disassemble, repair or rebuild the machine by yourself. It can damage the machine. Call a certified technician when the machine needs repairing. 1.

Introduction 13 Safety information · Do not remove any covers or guards that are fastened with screws.

· Fuser units should only be repaired by a certified service technician. Repair by non-certified technicians could result in fire or electric shock. · The machine should only be repaired by a Samsung service technician. To clean and operate the machine, strictly follow the user's guide provided with the machine.

Otherwise, you could damage the machine. Keep the power cable and the contact surface of the plug clean from dust or water. Otherwise, this could result in electric shock or fire. Do not burn any of the supplies such as toner cartridge or fuser unit. This could cause an explosion or uncontrollable fire. When storing supplies such as toner cartridges, keep them away from children.

Toner dust can be dangerous if inhaled or ingested. When changing the toner cartridge or removing jammed paper, be careful not to let toner dust touch your body or clothes. Toner dust can be dangerous if inhaled or ingested. When toner gets on your clothing, do not use hot water to wash it. Hot water sets toner into fabric. Use cold water. Using recycled supplies, such as toner, can cause damage to the machine. 8 Supply usage In case of damage due to the use of recycled supplies, a service fee will be charged. Caution Do not disassemble the toner cartridge. Toner dust can be dangerous if inhaled or ingested.

1. Introduction 14 Machine overview 9 Accessories Power cord Quick installation guide Output stacker a Software CD b Misc. accessories c a. Refer to the Quick Install Guide to attach the output stacker to the machine. b.

The software CD contains the printer drivers and software applications. c. Miscellaneous accessories included with your machine may vary by country of purchase and specific model. 1. Introduction 15 Machine overview 10 Front view · This illustration may differ from your machine depending on its model.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)
<http://somenmanuals.com/dref/4128961>

· Some features and optional goods may not be available depending on model or country (see "Features by models" on page 6). 4 5 3 2 1 2 Control panel Tray handle 3 4 Tray Output tray 5 6 Output support Top cover 7 Toner cartridge 1. Introduction 16 Machine overview 11 Rear view · This illustration may differ from your machine depending on its model. · Some features and optional goods may not be available depending on model or country (see "Features by models" on page 6). 1 2 1 USB port 2 Power receptacle 1. Introduction 17 Control panel overview This control panel may differ from your machine depending on its model. There are various types of control panels. 3 Configures the wireless network connection easily without a computer (see "Wireless network setup" on page 104). · Configuration sheet - Press and hold this button for about 10 seconds until the green LED blinks slowly, and release. 1 2 (WPS) · Prints supplies info report / error report - Press and hold this button for about 15 seconds until the green LED on, and release.

· Manual print - Press this button each time you load a sheet of paper in the tray if you have selected Manual Feeder for Source in your printer driver. 3 4 1 Toner LED Shows the status of the toner (see "Status LED" on page 56). 2 (Status LED) Shows the status of your machine (see "Status LED" on page 56). 1. Introduction 18 Control panel overview 3 · Prints the screen - Press this button and the green LED will start blinking. If you want to print only the active screen, release the button when the green LED stops blinking. If you want to print the whole screen, release the button while it's blinking. 4 (Power) You can turn the power off or wake the machine up from the sleep mode with this button. · Print Screen can only be used in the Windows and Macintosh operating systems. · You can only use this function with USB-connected machine.

· When printing the active window/whole monitor screen using the print screen button, the machine may use more toner depending on what is being printed. · You can only use this function if the machine's Easy Printer Manager program is installed if you are a macintosh OS user, you need to enable Screen Print Settings from the Easy Printer Manager to use the Print Screen feature. · Configuration sheet - Press and hold this button for about 10 seconds until the green LED blinks slowly, and release. · Prints supplies info report / error report - Press and hold this button for about 15 seconds until the green LED on, and release. · Manual print - Press this button each time you load a sheet of paper in the tray if you have selected Manual Feeder for Source in your printer driver.

1. Introduction (Print screen) 19 Turning on the machine 1 Connect the machine to the electricity supply first. 2 1 2 press (power) on the control panel. If you want to turn the power off, press (power) on the control panel. 1.

Introduction 20 Installing the driver locally A locally connected machine is a machine directly attached to your computer using the cable. If your machine is attached to a network, skip the following steps below and go on to installing a network connected machine's driver (see Advanced Guide). 3 Select Install Now. · If you are a Macintosh or Linux OS user, refer to the "Software installation" on page 82. · The installation window in this User's Guide may differ depending on the machine and interface in use. · Selecting Custom Installation allows you to choose which programs to install. · Only use a USB cable no longer than 3 meters (118 inches). 12 Windows 1 Make sure that the machine is connected to your computer and powered on. 4 5 Read License Agreement, and select I accept the terms of the License Agreement.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)
<http://somenmanuals.com/dref/4128961>

Then, click Next.

Follow the instructions in the installation window. If the "Found New Hardware Wizard" appears during the installation procedure, click Cancel to close the window. 2 Insert the supplied software CD into your CD-ROM drive. The software CD should automatically run and an installation window will appear. 1. Introduction 21 Reinstalling the driver If the printer driver does not work properly, follow the steps below to reinstall the driver. 13 Windows 1 2 3 4 Make sure that the machine is connected to your computer and powered on. From the Start menu, select Programs or All Programs > Samsung Printers > your printer driver name > Uninstall. Follow the instructions in the installation window. Insert the software CD into your CD-ROM drive and install the driver again (see "Installing the driver locally" on page 21).

1. Introduction 22 2. Learning the Basic Usage After installation is complete, you may want to set the machine's default settings. Refer to the next section if you would like to set or change values. This chapter provides information about the overall menu structure and the basic setup options.

- Printing a demo page · Media and tray · Basic printing 24 25 34 Printing a demo page Print a demo page to make sure that the machine is operating correctly (Windows only). To print a demo page: · Open the Printing Preferences (see "Opening printing preferences" on page 35) > Samsung tab > Demo page 2. Learning the Basic Usage 24 Media and tray This chapter provides information on how to load print media into your machine. · Using print media that does not meet these specifications may cause problems or require repairs. Such repairs are not covered by Samsung's warranty or service agreements.
- Make sure not to use the inkjet photo paper with this machine. It could cause damage to the machine. · Using inflammable print media can cause a fire. · Use designated print media (see "Print media specifications" on page 61).

2 The use of inflammable media or foreign materials left in the printer may lead to overheating of the unit and, in rare cases may cause a fire. 1 1 Paper width guide 2 Tray 1 Tray overview To change the size, you need to adjust the paper guide. If you do not adjust the guide, it may cause paper registration, image skew, or jamming of the paper. 2. Learning the Basic Usage 25 Media and tray 2 Loading paper in the tray 3 Place the paper with the side you want to print facing up and open the output tray. 1 Open the tray.

Then, adjust the tray size to the media size you are loading (see "Tray overview" on page 25). 2 1 1 2 2 Flex or fan the edge of the paper stack to separate the pages before loading papers. 2. Learning the Basic Usage 26 Media and tray 4 Squeeze the paper width guide and slide it to the edge of the paper stack without causing it to bend. The settings made from the machine driver override the settings on the control panel. a To print in application, open an application and start the print menu. b Open Printing Preferences (see "Opening printing preferences" on page 35). c Press the Paper tab in Printing Preferences, and select an appropriate paper type. For example, if you want to use a label, set the paper type to Label. d Select Manual Feeder in paper source, then press OK.

e Start printing in application. · Do not push the paper width guide too far causing the media to warp. · Do not use a paper with a leading-edge curl, it may cause a paper jam or the paper can be wrinkled. · If you do not adjust the paper width guide, it may cause paper jams. 5 When you print a document, set the paper type and size for the tray (see "Setting the paper size and type" on page 33).

2. Learning the Basic Usage 27 Media and tray 3 Manual feeding in the tray The manual feeder can hold special sizes and types of print material, such as postcards, note cards, and envelopes (see "Print media specifications" on page 61).



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

· When printing on special media, you must follow the loading guidelines (see "Printing on special media" on page 28). · When the machine is in a power save mode, the machine does not feed paper from the manual feeder. Wake up the machine by pressing the power button before using the manual feeder. Tips on using the manual feeder · Load only one type, size and weight of print media at a time in the manual feeder. · If you select Paper > Source > Manual Feeder for the paper source in your software application, you need to press (Print screen) or (WPS) button each time you print a page and load only one type, size and weight of print media at a time on the manual tray. · To prevent paper jams, do not add paper while printing when there is still paper in the manual feeder. · Print media should be loaded face up with the top edge going into the manual feeder first and be placed in the center of the tray. · To ensure printing quality and to prevent paper jams, only load the available paper (see "Print media specifications" on page 61). · Flatten any curl on postcards, envelopes, and labels before loading them into the manual feeder. 4 Printing on special media The table below shows the special media usable in each tray. 2. Learning the Basic Usage 28 Media and tray The media types are shown in the Printing Preferences. To get the highest printing quality, select the proper media type from the Printing Preferences window > Paper tab > Paper Type (see "Opening printing preferences" on page 35).

For example, if you want to print on labels, select Labels for Paper Type. Types Cotton Recycled Archive a. The paper types available manual feeding in tray. Traya When using special media, we recommend you feed one sheet at a time (see "Print media specifications" on page 61). (: Included, Blank: Not available) To see for paper weights for each sheet, refer to "Print media specifications" on page 61. Traya Envelope Printing successfully on envelopes depends upon the quality of the envelopes. Types Plain Thick Thin Bond Color CardStock Labels Envelope Preprinted 2. Learning the Basic Usage 29 Media and tray To print an envelope, place it as shown in the following figure. . . . Do not use stamped envelopes. Do not use envelopes with clasps, snaps, windows, coated lining, selfadhesive seals, or other synthetic materials.

Do not use damaged or poorly made envelopes. Be sure the seam at both ends of the envelope extends all the way to the corner of the envelope. 1 2 1 2 Acceptable Unacceptable · If you select Envelope from the Printing Preferences window, but the printed images get easily erased, select Thick Envelope and try printing again. However, this might cause some noise when printing. · When selecting envelopes, consider the following factors: -Weight: should not exceed 90 g/m2 otherwise; jams may occur.

-Construction: should lie flat with less than 6 mm curl and should not contain air. -Condition: should not be wrinkled, nicked, nor damaged. -Temperature: should resist the heat and pressure of the machine during operation. · Use only well-constructed envelopes with sharp and well-creased folds. · · Envelopes with a peel-off adhesive strip or with more than one flap that folds over to seal must use adhesives compatible with the machine's fusing temperature for 0.

1 second (about 170°C (338 °F)). The extra flaps and strips might cause wrinkling, creasing, or jams, and may even damage the fuser. For the best print quality, position margins no closer than 15 mm from the edges of the envelope. Avoid printing over the area where the envelope's seams meet. 2. Learning the Basic Usage 30 Media and tray Labels To avoid damaging the machine, use only labels designed for use in laser printers. · -Condition: Do not use labels with wrinkles, bubbles, or other indications of separation.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)

<http://somemanuals.com/dref/4128961>

Make sure that there is no exposed adhesive material between labels. Exposed areas can cause labels to peel off during printing, which can cause paper jams. Exposed adhesive can also cause damage to machine components.

Do not run a sheet of labels through the machine more than once. The adhesive backing is designed for only a single pass through the machine. Do not use labels that are separating from the backing sheet or are wrinkled, bubbled, or otherwise damaged. . . . When selecting labels, consider the following factors:

-Adhesives: Should be stable at your machine's fusing temperature. Check your machine's specifications to view the fusing temperature (about 170°C (338°F)). -Arrangement: Only use labels with no exposed backing between them. Labels can peel off sheets that have spaces between the labels, causing serious jams. -Curl: Must lie flat with no more than 13 mm of curl in any direction. 2. Learning the Basic Usage 31 Media and tray Card stock/ Custom-sized paper Preprinted paper When loading preprinted paper, the printed side should be facing up with an uncurled edge at the front.

If you experience problems with paper feeding, turn the paper around. Note that print quality is not guaranteed. . In the software application, set margins at least 6.4 mm (0.25 inches) away from the edges of the material.

. Must be printed with heat-resistant ink that will not melt, vaporize, or release hazardous emissions when subjected to the machine's fusing temperature for 0.1 second (about 170°C (338°F)). Preprinted paper ink must be non-flammable and should not adversely affect machine rollers. Before you load preprinted paper, verify that the ink on the paper is dry. During the fusing process, wet ink can come off preprinted paper, reducing print quality.

. . 2. Learning the Basic Usage 32 Media and tray 5 Setting the paper size and type After loading paper in the paper tray, set the paper size and type. Open the Printing Preferences (see "Opening printing preferences" on page 35) and set the paper size and type in the Paper tab. If you want to use special-sized paper such as billing paper, select Custom in the Paper tab in the Printing Preferences (see "Opening printing preferences" on page 35). 2. Learning the Basic Usage 33 Basic printing For special printing features, refer to the Advanced Guide (see "Using advanced print features" on page 141). 3 Select your machine from the Select Printer list. 6 Printing If you are a Macintosh or Linux user, refer to the "Macintosh printing" on page 151 or "Linux printing" on page 153. The following Printing Preferences window is for Notepad in Windows 7. 1 2 Open the document you want to print.

Select Print from the File menu. 4 The basic print settings including the number of copies and print range are selected within the Print window. To take advantage of the advanced printing features, click Properties or Preferences from the Print window (see "Opening printing preferences" on page 35). 5 To start the print job, click OK or Print in the Print window. 2. Learning the Basic Usage 34 Basic printing 7 Canceling a print job If the print job is waiting in the print queue or print spooler, cancel the job as follows: . You can access this window by simply double-clicking the machine icon () in the Windows task bar. 4 Click Properties or Preferences. 8 Opening printing preferences . The Printing Preferences window that appears in this user's guide may differ depending on the machine in use. However, the composition of the Printing Preferences window is similar. . When you select an option in Printing Preferences, you may see a warning mark or .

An mark means you can select that certain option but it is not recommended, and an mark means you cannot select that option due to the machine's setting or environment. You can check the machine's current status using the Printer Status button (see "Using Samsung Printer Status" on page 167).



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

1 2 3 Open the document you want to print. Select Print from the file menu. Select your machine from the Select Printer.

2. Learning the Basic Usage 35 Basic printing Using a favorite setting The Presets option, which is visible on each preferences tab except for the Samsung tab, allows you to save the current preferences for future use. To save a Presets item, follow these steps: Select more options and click (Update), settings will be added to the Presets you made. To use a saved setting, select it from the Presets dropdown list. The machine is now set to print according to the settings you have selected.

To delete saved settings, select it from the Presets dropdown list and click (Delete). 1 2 Change the settings as needed on each tab. Enter a name for the item in the Presets input box. 9 You can also restore the printer driver's default settings by selecting Default Preset from the Presets drop-down list. Using help Click the option you want to know on the Printing Preferences window and press F1 on your keyboard. 10 3 Click saved. (Add). When you save Presets, all current driver settings are Eco printing The Eco function cuts toner consumption and paper usage. The Eco function allows you to save print resources and lead you to eco-friendly printing. To Eco Printing, click the below: See "Easy Eco Driver" on page 159.

2. Learning the Basic Usage 36 3. Maintenance This chapter provides information about purchasing supplies, accessories and maintenance parts available for your machine. · Ordering supplies and accessories · Available supplies · Available maintenance parts · Storing the toner cartridge · Redistributing toner · Replacing the toner cartridge · Cleaning the machine · Tips for moving & storing your machine 38 39 40 41 43 44 46 49 Ordering supplies and accessories Available accessories may differ from country to country. Contact your sales representatives to obtain the list of available supplies, and maintenance parts.

To order Samsung-authorized supplies, accessories, and maintenance parts, contact your local Samsung dealer or the retailer where you purchased your machine. You can also visit www.samsung.com/supplies, and then select your country/region to obtain the contact information for service. 3.

Maintenance 38 Available supplies When supplies reach the end of their life spans, you can order the following types of supplies for your machine: Average yielda Approx. 1,500 pages Type Toner cartridge Part name MLT-D101S a. Declared yield value in accordance with ISO/IEC 19752. Depending on the options, percentage of image area, and job mode used, the toner cartridge's lifespan may differ. When purchasing new toner cartridges or other supplies, these must be purchased in the same country as the machine you are using.

Otherwise, new toner cartridges or other supplies will be incompatible with your machine due to different configurations of toner cartridges and other supplies according to the specific country conditions. Samsung does not recommend using non-genuine Samsung toner cartridge such as refilled or remanufactured toner. Samsung cannot guarantee non-genuine Samsung toner cartridge's quality. Service or repair required as a result of using non-genuine Samsung toner cartridges will not be covered under the machine's warranty. 3.

Maintenance 39 Available maintenance parts To purchase maintenance parts, contact the source where you bought the machine. Replacing maintenance parts can be performed only by an authorized service provider, dealer, or the retailer where you bought the machine. The warranty does not cover the replacement of any maintenance parts once it has reached its "Average yield". Maintenance parts are replaced at specific intervals to avoid print quality and paper feed problems resulting from worn parts, see table below. The purpose of which is to maintain your machine in top working condition.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)

<http://somemanuals.com/dref/4128961>

The maintenance parts below should be replaced when the life span of each item has been met. Average yielda Approx. 30,000 pages Approx. 30,000 pages Approx. 30,000 pages Approx.

30,000 pages Parts Fuser unit Transfer roller Feed roller Pickup roller a. It will be affected by the operating system used, computing performance, application software, connecting method, media type, media size and job complexity. 3. Maintenance 40 Storing the toner cartridge Toner cartridges contain components that are sensitive to light, temperature and humidity. Samsung suggests users follow these recommendations to ensure optimal performance, highest quality, and longest life from your new Samsung toner cartridge. Store this cartridge in the same environment in which the printer will be used. This should be in controlled temperature and humidity conditions. The toner cartridge should remain in its original and unopened package until installation if original packaging is not available, cover the top opening of the cartridge with paper and store in a dark cabinet. Opening the cartridge package prior to use dramatically shortens its useful shelf and operating life. Do not store on the floor.

If the toner cartridge is removed from the printer, follow the instructions below to store the toner cartridge properly. . . . Store the cartridge inside the protective bag from the original package. Store lying flat (not standing on end) with the same side facing up as if it were installed in the machine. Do not store consumables in any of the following conditions: -Temperature greater than 40°C (104°F). -Humidity range less than 20% and greater than 80%.

-An environment with extreme changes in humidity or temperature. -Direct sunlight or room light. -Dusty places. -A car for a long period of time. -An environment where corrosive gases are present.

-An environment with salty air. 3. Maintenance 41 Storing the toner cartridge 1 3 Handling instructions . . . Do not touch the surface of the photoconductive drum in the cartridge. Do not expose the cartridge to unnecessary vibrations or shock. Never manually rotate the drum, especially in the reverse direction; this can cause internal damage and toner spillage. Estimated cartridge life Estimated cartridge life the life of the toner cartridge (or imaging unit) yield depends on the amount of toner that print jobs require. The actual print yield may vary depending on the print density of the pages you print on, operating environment, percentage of image area, printing interval, media type and/or media size. For example, if you print a lot of graphics, the consumption of the toner is higher and you may need to change the cartridge more often. 2 Toner cartridge usage Samsung Electronics does not recommend or approve the use of non-Samsung brand toner cartridges in your printer including generic, store brand, refilled, or remanufactured toner cartridges. Samsung's printer warranty does not cover damage to the machine caused by the use of a refilled, remanufactured, or non-Samsung brand toner cartridges.

3. Maintenance 42 Redistributing toner When the toner cartridge is near the end of its life: . . White streaks or light printing occurs and/or density variation side to side. The Toner LED blinks orange. If this happens, you can temporarily improve print quality by redistributing the remaining toner in the cartridge.

In some cases, white streaks or light printing will still occur even after you have redistributed the toner. . Before opening the top cover, close the output support first. . If toner gets on your clothing, wipe it off with a dry cloth and wash clothing in cold water. Hot water sets toner into fabric. 1 2 3. Maintenance

43 Replacing the toner cartridge . Before opening the top cover, close the output support first.

. Do not use sharp objects such as a knife or scissors to open the toner cartridge package.



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide

<http://somemanuals.com/dref/4128961>

They might scratch the drum of the cartridge. · If toner gets on your clothing, wipe it off with a dry cloth and wash clothing in cold water. Hot water sets toner into fabric. · Shake the toner cartridge thoroughly, it will increase the initial print quality.

· Do not touch the green underside of the toner cartridge. Use the handle on the cartridge to avoid touching this area. 3. Maintenance 44 Replacing the toner cartridge When a toner cartridge has reached the end of life, the machine will stop printing. 3.

Maintenance 45 Cleaning the machine If printing quality problems occur or if you use your machine in a dusty environment, you need to clean your machine regularly to keep it in the best printing condition and use your machine longer. · Cleaning the cabinet of the machine with cleaning materials containing large amounts of alcohol, solvents, or other strong substances can discolor or distort the cabinet. · If your machine or the surrounding area is contaminated with toner, we recommend you use a cloth or tissue dampened with water to clean it. If you use a vacuum cleaner, toner blows in the air and might be harmful to you. · During the printing process, paper, toner, and dust particles can accumulate inside the machine. This buildup can cause print quality problems, such as toner specks or smearing. Cleaning the inside of the machine clears and reduces these problems. 4 Cleaning the outside Clean the machine cabinet with a soft, lint-free cloth. Dampen the cloth slightly with water, but be careful not to let any water drip onto or into the machine. 5 Cleaning the inside During the printing process, paper, toner, and dust particles can accumulate inside the machine.

This buildup can cause print quality problems, such as toner specks or smearing. Cleaning the inside of the machine clears and reduces these problems. 3.

Maintenance 46 Cleaning the machine · Use a dry lint-free cloth to clean the machine. · If your machine has a power switch, turn the power switch off before cleaning the machine. · Before opening the top cover, close the output support first. 1 2 3. Maintenance 47 Cleaning the machine 6 Cleaning the pickup roller · Use a dry lint-free cloth to clean the machine. · If your machine has a power switch, turn the power switch off before cleaning the machine. 3.

Maintenance 48 Tips for moving & storing your machine · · When moving the machine, do not tilt or turn it upside down. Otherwise, the inside of the machine may be contaminated by toner, which can cause damage to the machine or reduce print quality. When moving the machine, make sure at least two people are holding the machine securely. 3. Maintenance 49 4.

Troubleshooting This chapter gives helpful information for what to do if you encounter an error. · Tips for avoiding paper jams · Clearing paper jams · Understanding the status LED 51 52 55 This chapter gives helpful information for what to do if you encounter an error. If your machine has a display screen, check the message on the display screen first to solve the error. If you cannot find a solution to your problem in this chapter, refer to the Troubleshooting chapter in the Advanced User's Guide (see "Troubleshooting" on page 174). If you cannot find a solution in the User's Guide or the problem persists, call for service.

Tips for avoiding paper jams By selecting the correct media types, most paper jams can be avoided. To avoid paper jams, refer to the following guidelines: · · · · · Ensure that the adjustable guides are positioned correctly (see "Tray overview" on page 25). Do not overload the tray. Ensure that the paper level is below the paper capacity mark on the inside of the tray. Do not remove paper from the tray while your machine is printing. Flex, fan, and straighten paper before loading.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Do not use creased, damp, or highly curled paper. Do not mix paper types in a tray. Use only recommended print media (see "Print media specifications" on page 61). 4.

Troubleshooting 51 Clearing paper jams To avoid tearing the paper, pull the jammed paper out slowly and gently. 1 In tray 4. Troubleshooting 52 Clearing paper jams 2 Inside the machine · The fuser area is hot. Take care when removing paper from the machine. · Before opening the top cover, close the output support first. 4. Troubleshooting 53 Clearing paper jams If you do not see the paper in this area, stop and go to next step: 4. Troubleshooting 54 Understanding the status LED The color of the LED indicates the machine's current status. · Some LEDs may not be available depending on model or country. · To resolve the error, look at the error message and its instructions from the troubleshooting part.

· You can also resolve the error with the guidelines from the Samsung Printer Status window or Smart Panel program window. · If the problem persists, call a service representative. 4. Troubleshooting 55 Understanding the status LED 3 Status LED Status Off Blinking Green On Blinking (Status LED) Red On · The cover is opened. Close the cover.

· There is no paper in the tray when receiving or printing data. Load paper in the tray ("Loading paper in the tray" on page 26). · The machine has stopped due to a major error. Blinking Orange On A paper jam has occurred (see "Clearing paper jams" on page 52). Upgrading firmware.

The machine is off-line or save mode. · When the backlight slowly blinks, the machine is receiving data from the computer. · When the backlight blinks rapidly, the machine is printing data. The machine is on-line and can be used. Waiting for a (Print screen) button to be pressed for manual printing. Description 4.

Troubleshooting 56 Understanding the status LED 4 Toner LED/ WPS LED Status Description Small amount of toner is left in the cartridge. The estimated cartridge life of toner is close. Prepare a new cartridge for replacement. You may temporarily increase the printing quality by redistributing the toner (see "Redistributing toner" on page 43).

A toner cartridge has almost reached its estimated cartridge life. It is recommended to replace the toner cartridge (see "Replacing the toner cartridge" on page 44). All toner cartridges are at normal capacity. The machine is connecting to a wireless network. The machine is connected to a wireless network (see "Using the WPS button" on page 107). The machine is disconnected from a wireless network. The machine is in power save mode. The machine is in ready mode or the machine's power is off. Blinking (Toner LED) Orange On Off Blinking (WPS LED)b Blue On Off On (Power LED) Blue Off a. Estimated cartridge life means the expected or estimated toner cartridge life, which indicates the average capacity of print-outs and is designed pursuant to ISO/IEC 19752.

The number of pages may be affected by operating environment, printing interval, graphics, media type and media size. Some amount of toner may remain in the cartridge even when red LED is on and the printer stops printing. b. Wireless model only (see "Features by models" on page 6). 4.

Troubleshooting 57 5. Appendix This chapter provides product specifications and information concerning applicable regulations. · Specifications · Regulatory information · Copyright 59 68 78 Specifications 1 General specifications The specification values listed below are subject to change without notice. See www.samsung.com.

com for possible changes in information. Items Dimension Weight Noise Levela Print mode Temperature Operation Storage (packed) Humidity Operation Storage (packed) Power ratingb 110 volt models 220 volt models Less than 50 dB (A) 10 to 32°C (50 to 90°F) -20 to 40°C (-4 to 104°F) 10 to 80% RH 20 to 95% RH AC 110 - 127 V AC 220 - 240 V Width x Length x Height Machine with consumables Ready mode Description 332 x 215 x 178 mm (13.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

07 x 8.46 x 7.01 inches) 4.95 kg (10.91 lbs) Less than 26 dB (A) 5. Appendix 59 Specifications Items Power consumption Average operating mode Ready mode Power save mode Power off mode Wireless d a. b. c.

d. Description Less than 310W Less than 30 W Less than 0.9 W (ML-216x Series), Less than 1.2 W (ML-216xW Series) Less than 0.45 W (0.1 Wc) T77H262 / SPW-B4319S Module Sound Pressure Level, ISO 7779. Configuration tested: basic machine installation, A4 paper, simplex printing. See the rating label on the machine for the correct voltage (V), frequency (hertz) and type of current (A) for your machine. For the machine that has a power switch. Wireless model only (see "Features by models" on page 6).

5. Appendix 60 Specifications 2 Print media specifications Print media weight/Capacity Type Size Dimensions Tray Letter Legal US Folio A4 Plain paper Oficio JIS B5 ISO B5 Executive A5 Envelope Monarch Envelope No. 10 Envelope Envelope DL Envelope C5 110 x 220 mm (4.33 x 8.66 inches) 162 x 229 mm (6.38 x 9.02 inches) 216 x 279 mm (8.5 x 11 inches) 216 x 356 mm (8.5 x 14 inches) 216 x 330 mm (8.5 x 13 inches) 210 x 297 mm (8.27 x 11.69 inches) 216 x 343 mm (8.5 x 13.5 inches) 182 x 257 mm (7.17 x 10.12 inches) 176 x 250 mm (6.93 x 9.84 inches) 184 x 267 mm (7.25 x 10.5 inches) 148 x 210 mm (5.83 x 8.27 inches) 98 x 191 mm (3.87 x 7.5 inches) 105 x 241 mm (4.12 x 9.5 inches) 75 to 90 g/m² (20 to 24 lbs bond) · 10 sheets 75 to 90 g/m² (20 to 24 lbs bond) · 1 sheet 71 to 85 g/m² (19 to 23 lbs bond) · 150 sheets of 80 g/m² (21 lbs bond) Manual feeding in trayb 71 to 85 g/m² (19 to 23 lbs bond) · 1 sheet 5. Appendix 61 Specifications Print media weight/Capacity Type Size Dimensions Tray Refer to the Plain paper section Thick paper Refer to the Plain paper section 86 to 120 g/m² (23 to 32 lbs bond) · 50 sheets of 120 g/m² (32 lbs bond) Refer to the Plain paper section Thin paper Refer to the Plain paper section Refer to the Plain paper section Cotton Refer to the Plain paper section Refer to the Plain paper section Colored Refer to the Plain paper section Refer to the Plain paper section Pre-printed Refer to the Plain paper section Refer to the Plain paper section Recycled Refer to the Plain paper section 60 to 70 g/m² (16 to 19 lbs bond) · 160 sheets of 60 g/m² (16 lbs bond) · 1 sheet 2 Manual feeding in trayb 86 to 120 g/m² (23 to 32 lbs bond) · 1 sheet 75 to 90 g/m² (20 to 24 lbs bond) 75 to 90 g/m² (20 to 24 lbs bond) · 150 sheets of 80 g/m² (21 lbs bond) · 1 sheet 75 to 90 g/m² (20 to 24 lbs bond) 75 to 90 g/m² (20 to 24 lbs bond) · 150 sheets of 80 g/m² (21 lbs bond) · 1 sheet 75 to 90 g/m² (20 to 24 lbs bond) 75 to 90 g/m² (20 to 24 lbs bond) · 150 sheets of 80 g/m² (21 lbs bond) · 1 sheet 60 to 90 g/m² (16 to 24 lbs bond) 60 to 90 g/m² (16 to 24 lbs bond) · 150 sheets of 80 g/m² (21 lbs bond) · 1 sheet 5. Appendix 62 Specifications Print media weight/Capacity Type Size Dimensions Tray Letter, Legal, Oficio, US Folio, A4, JIS B5, ISO B5, Executive, A5 Letter, Legal, Oficio, US Folio, A4, JIS B5, ISO B5, Executive, A5, Postcard 4x6 Bond paper Refer to the Plain paper section Refer to the Plain paper section Refer to the Plain paper section · 10 sheets · 1 sheet Refer to the Plain paper section 120 to 150 g/m² (32 to 40 lbs bond) · 10 sheets Refer to the Plain paper section 121 to 163 g/m² (32 to 43 lbs bond) · 10 sheets 121 to 163 g/m² (32 to 43 lbs bond) · 1 sheet Manual feeding in trayb 120 to 150 g/m² (32 to 40 lbs bond) · 1 sheet Labels Card stock Archive Refer to the Plain paper section · 100 sheets · 1 sheet Minimum size (custom) Maximum size (custom) 76 x 127 mm (3 x 5 inches) 216 x 356 mm (8.5 x 14 inches) 60 to 163 g/m² (16 to 43 lbs bond) a. Maximum capacity may differ depending on media weight, thickness, and environmental conditions.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

b. Feed one sheet at a time. c. The smoothness of the labels used in this machine is 100 to 250 (sheffield). This means the numeric level of smoothness.

5. Appendix 63 Specifications 3 System requirements Microsoft® Windows® Requirement (recommended) Operating system CPU Windows® 2000 Windows® XP Windows Server® 2003 Windows Server® 2008 Windows Vista® Windows® 7 · Support for DirectX® 9 graphics with 128 MB memory (to enable the Aero theme). · DVD-R/W Drive Windows Server® 2008 R2 Intel® Pentium® IV 1 GHz (x86) or 1.4 GHz (x64) processors (2 GHz or faster) 512 MB (2 GB) 10 GB Intel® Pentium® II 400 MHz (Pentium III 933 MHz) Intel® Pentium® III 933 MHz (Pentium IV 1 GHz) Intel® Pentium® III 933 MHz (Pentium IV 1 GHz) Intel® Pentium® IV 1 GHz (Pentium IV 2 GHz) Intel® Pentium® IV 3 GHz Intel® Pentium® IV 1 GHz 32-bit or 64-bit processor or higher RAM 64 MB (128 MB) 128 MB (256 MB) 128 MB (512 MB) 512 MB (2 GB) 512 MB (1 GB) 1 GB (2 GB) free HDD space 600 MB 1.5 GB 1.25 GB to 2 GB 10 GB 15 GB 16 GB 5. Appendix 64 Specifications · Internet Explorer 6.0 or higher is the minimum requirement for all Windows operating systems. · Users who have administrator rights can install the software. · Windows Terminal Services is compatible with your machine. · For Windows 2000, Services Pack 4 or higher is required. Macintosh Requirements (Recommended) Operating system CPU · Intel® processors Mac OS X 10.4 · PowerPC G4/ G5 · Intel® processors Mac OS X 10.5 · 867 MHz or faster Power PC G4/ G5 · Intel® processors · Intel® processors 1 GB (2 GB) 2 GB 1 GB 4 GB RAM · 128 MB for a powerPC based Mac (512 MB) · 512 MB for an Intel-based Mac (1 GB) 512 MB (1 GB) 1 GB Free HDD space 1 GB Mac OS X 10.6 Mac OS X 10.

7 5. Appendix 65 Specifications Linux Items Fedora 5~13 (32/64 bit) OpenSUSE® 10.2, 10.3, 11.0, 11.1, 11.2 (32/64 bit) SuSE 10.1 (32 bit) Operating system Ubuntu 6.06, 6.10, 7.04, 7.10, 8.04, 8.10, 9.04, 9.10, 10.04 (32/64 bit) Mandriva 2007, 2008, 2009, 2009.1, 2010 (32/64 bit) Debian 4.0, 5.0 (32/64 bit) Redhat® Enterprise Linux WS 4, 5 (32/64 bit) SuSE Linux Enterprise Desktop 10, 11 (32/64 bit) CPU RAM Free HDD space Pentium IV 2.4GHz (Intel Core™2) 512 MB (1 GB) 1 GB (2 GB) Requirements 5. Appendix 66 Specifications 4 Network environment Network and wireless models only (see "Features by models" on page 6). You need to set up the network protocols on the machine to use it as your network machine. The following table shows the network environments supported by the machine. Items Network interface · 802.11b/g/n Wireless LAN · Windows 2000/Server 2003 /Server 2008/XP/Vista/7/Server 2008 R2 Network operating system · Various Linux OS · Mac OS X 10.4 ~ 10.7 · Unix · TCP/IPv4 · DHCP, BOOTP Network protocols · DNS, WINS, Bonjour, SLP, UPnP · Standard TCP/IP Printing (RAW), LPR, IPP, WSD · SNMPv 1/2/3, HTTP, IPSec · TCP/IPv6 (DHCP, DNS, RAW, LPR, SNMPv 1/2/3, HTTP, IPSec) Wireless security · Authentication: Open System, Shared Key, WPA Personal, WPA2 Personal (PSK) · Encryption: WEP64, WEP128, TKIP, AES Specifications 5. Appendix 67 Regulatory information This machine is designed for a normal work environment and certified with several regulatory statements. When using this product, these basic safety precautions should always be followed to reduce risk of fire, electric shock, and injury to persons: 5 Laser safety statement The printer is certified in the U.

S. to conform to the requirements of DHHS 21 CFR, chapter 1 Subchapter J for Class I(I) laser products, and elsewhere is certified as a Class I laser product conforming to the requirements of IEC 608251 : 2007. Class I laser products are not considered to be hazardous.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

The laser system and printer are designed so there is never any human access to laser radiation above a Class I level during normal operation, user maintenance or prescribed service condition. 6 Warning Never operate or service the printer with the protective cover removed from laser/scanner assembly. The reflected beam, although invisible, can damage your eyes. Ozone safety This product's ozone emission rate is under 0.1 ppm. Because ozone is heavier than air, keep the product in a place with good ventilation. 5.

Appendix 68 Regulatory information 7 9 Power saver This printer contains advanced energy conservation technology that reduces power consumption when it is not in active use. When the printer does not receive data for an extended period of time, power consumption is automatically lowered. ENERGY STAR and the ENERGY STAR mark are registered U.S. marks.

For more information on the ENERGY STAR program see <http://www.energystar.gov> For ENERGY STAR certified models, the ENERGY STAR label will be on your machine. Check if your machine is ENERGY STAR certified. China only 8 Recycling Recycle or dispose of the packaging material for this product in an environmentally responsible manner.

5. Appendix 69 Regulatory information 10 Correct disposal of this product (Waste electrical & electronic equipment) The United States of America only Dispose unwanted electronics through an approved recycler. To find the nearest recycling location, go to our website: www.samsung.com/recyclingdirect Or call, (877) 278 - 0799 (Applicable in the european union and other european countries with separate collection systems) This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract.

This product and its electronic accessories should not be mixed with other commercial wastes for disposal. 11 Radio frequency emissions FCC information to the user This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: · · This device may not cause harmful interference, and This device must accept any interference received, including interference that may cause undesired operation. 5. Appendix 70 Regulatory information This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: · · · Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio TV technician for help.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Canadian radio interference regulations This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus", ICES-003 of the Industry and Science Canada. Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe B prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques", ICES-003 édictée par l'Industrie et Sciences Canada. 12 United states of america Federal communications commission (FCC) Intentional emitter per FCC Part 15 Low power, Radio LAN type devices (radio frequency (RF) wireless communication devices), operating in the 2.

4 GHz/5 GHz Band, may be present (embedded) in your printer system. This section is only applicable if these devices are present. Refer to the system label to verify the presence of wireless devices. Wireless devices that may be in your system are only qualified for use in the United States of America if an FCC ID number is on the system label. Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

5. Appendix 71 Regulatory information The FCC has set a general guideline of 20 cm (8 inches) separation between the device and the body, for use of a wireless device near the body (this does not include extremities). This device should be used more than 20 cm (8 inches) from the body when wireless devices are on. The power output of the wireless device (or devices), which may be embedded in your printer, is well below the RF exposure limits as set by the FCC. This transmitter must not be collocated or operation in conjunction with any other antenna or transmitter. Operation of this device is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device. FCC statement for wireless LAN use: While installing and operating this transmitter and antenna combination the radio frequency exposure limit of 1m W/cm² may be exceeded at distances close to the antenna installed. Therefore, the user must maintain a minimum distance of 20cm from the antenna at all times. This device cannot be colocated with another transmitter and transmitting antenna. 13 Russia only Wireless devices are not user serviceable.

Do not modify them in any way. Modification to a wireless device will void the authorization to use it. Contact manufacturer for service. 14 Germany only 5.

Appendix 72 Regulatory information 15 Turkey only If you cut off the moulded plug, get rid of it straight away. You cannot rewire the plug and you may receive an electric shock if you plug it into a socket. Important warning: 16 Replacing the fitted plug (for UK only) You must earth this machine. The wires in the mains lead have the following color code: · Green and Yellow: Earth Important The mains lead for this machine is fitted with a standard (BS 1363) 13 amp plug and has a 13 amp fuse. When you change or examine the fuse, you must re-fit the correct 13 amp fuse. You then need to replace the fuse cover. If you have lost the fuse cover, do not use the plug until you have another fuse cover. Contact the people from you purchased the machine. The 13 amp plug is the most widely used type in the UK and should be suitable. However, some buildings (mainly old ones) do not have normal 13 amp plug sockets. You need to buy a suitable plug adaptor.

Do not remove the moulded plug. · Blue: Neutral · Brown: Live If the wires in the mains lead do not match the colors marked in your plug, do the following: You must connect the green and yellow wire to the pin marked by the letter "E" or by the safety 'Earth symbol' or colored green and yellow or green.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](#)

<http://somemanuals.com/dref/4128961>

You must connect the blue wire to the pin which is marked with the letter "N" or colored black. You must connect the brown wire to the pin which is marked with the letter "L" or colored red. You must have a 13 amp fuse in the plug, adaptor, or at the distribution board.

5. Appendix 73 Regulatory information 17 EC Certification Declaration of conformity (European countries) Certification to 1999/5/EC Radio Equipment & Telecommunications Terminal Equipment Directive (FAX) This Samsung product has been self-certified by Samsung for pan-European single terminal connection to the analogue public switched telephone network (PSTN) in accordance with Directive 1999/5/EC. The product has been designed to work with the national PSTNs and compatible PBXs of the European countries: In the event of problems, you should contact the Euro QA Lab of Samsung Electronics Co., Ltd. in the first instance. The product has been tested against TBR21. To assist in the use and application of terminal equipment which complies with this standard, the European Telecommunication Standards Institute (ETSI) has issued an advisory document (EG 201 121) which contains notes and additional requirements to ensure network compatibility of TBR21 terminals. The product has been designed against, and is fully compliant with, all of the relevant advisory notes contained in this document. Approvals and Certifications · Hereby, Samsung Electronics, declares that this [ML-216x Series] is in compliance with the essential requirements and other relevant provisions of Low Voltage Directive (2006/95/EC), EMC Directive (2004/108/EC). · Hereby, Samsung Electronics, declares that this [ML-216xW Series] is in compliance with the essential requirements and other relevant provisions of R&TTE Directive 1999/5/EC.

The declaration of conformity may be consulted at www.samsung.com, go to Support > Download center and enter your printer (MFP) name to browse the EuDoC. January 1, 1995: Council Directive 2006/95/EC Approximation of the laws of the member states related to low voltage equipment. January 1, 1996: Council Directive 2004/108/EC, approximation of the laws of the Member States related to electromagnetic compatibility. March 9, 1999: Council Directive 1999/5/EC on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity. A full declaration, defining the relevant Directives and referenced standards can be obtained from your Samsung Electronics Co., Ltd. representative. 5.

Appendix 74 Regulatory information European radio approval information (for products fitted with EU-approved radio devices) Low power, Radio LAN type devices (radio frequency (RF) wireless communication devices), operating in the 2.4 GHz/5 GHz band, may be present (embedded) in your printer system which is intended for home or office use. This section is only applicable if these devices are present. Refer to the system label to verify the presence of wireless devices. Wireless devices that may be in your system are only qualified for use in the European Union or associated areas if a CE mark with a Notified Body Registration Number and the Alert Symbol is on the system label.

No limitations at this time 18 Regulatory compliance statements Wireless guidance Low power, Radio LAN type devices (radio frequency (RF) wireless communication devices), operating in the 2.4 GHz/5 GHz Band, may be present (embedded) in your printer system. The following section is a general overview of considerations while operating a wireless device. Additional limitations, cautions, and concerns for specific countries are listed in the specific country sections (or country group sections). The wireless devices in your system are only qualified for use in the countries identified by the Radio Approval Marks on the system rating label.

If the country you will be using the wireless device in, is not listed, contact your local Radio Approval agency for requirements.



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide
<http://somemanuals.com/dref/4128961>

Wireless devices are closely regulated and use may not be allowed. The power output of the wireless device or devices that may be embedded in your printer is well below the RF exposure limits as known at this time. Because the wireless devices (which may be embedded into your printer) emit less energy than is allowed in radio frequency safety standards and recommendations, manufacturer believes these devices are safe for use. Regardless of the power levels, care should be taken to minimize human contact during normal operation. The power output of the wireless device or devices that may be embedded in you printer is well below the RF exposure limits as set by the European Commission through the R&TTE directive. European states qualified under wireless approvals:

EU countries European states with restrictions on use: EU In France, the frequency range is restricted to 2454-2483.5 MHz for devices above 10 mW transmitting power such as wireless EEA/EFTA countries 5. Appendix 75 Regulatory information As a general guideline, a separation of 20 cm (8 inches) between the wireless device and the body, for use of a wireless device near the body (this does not include extremities) is typical. This device should be used more than 20 cm (8 inches) from the body when wireless devices are on and transmitting.

This transmitter must not be collocated or operation in conjunction with any other antenna or transmitter. Some circumstances require restrictions on wireless devices. Examples of common restrictions are listed below: Radio frequency wireless communication can interfere with equipment on commercial aircraft. Current aviation regulations require wireless devices to be turned off while traveling in an airplane. IEEE 802.11 (also known as wireless Ethernet) and Bluetooth communication devices are examples of devices that provide wireless communication. In environments where the risk of interference to other devices or services is harmful or perceived as harmful, the option to use a wireless device may be restricted or eliminated. Airports, Hospitals, and Oxygen or flammable gas laden atmospheres are limited examples where use of wireless devices may be restricted or eliminated. When in environments where you are uncertain of the sanction to use wireless devices, ask the applicable authority for authorization prior to use or turning on the wireless device. Every country has different restrictions on the use of wireless devices.

Since your system is equipped with a wireless device, when traveling between countries with your system, check with the local Radio Approval authorities prior to any move or trip for any restrictions on the use of a wireless device in the destination country. 19 If your system came equipped with an internal embedded wireless device, do not operate the wireless device unless all covers and shields are in place and the system is fully assembled. Wireless devices are not user serviceable. Do not modify them in any way. Modification to a wireless device will void the authorization to use it.

Contact manufacturer for service. Only use drivers approved for the country in which the device will be used. See the manufacturer System Restoration Kit, or contact manufacturer Technical Support for additional information. Israel only 5. Appendix 76 Regulatory information 20 China only 5.

Appendix 77 Copyright © 2011 Samsung Electronics Co., Ltd. All rights reserved. This user's guide is provided for information purposes only. All information included herein is subject to change without notice. Samsung Electronics is not responsible for any direct or indirect damages, arising from or related to use of this user's guide. . . . Samsung and the Samsung logo are trademarks of Samsung Electronics Co., Ltd. Microsoft, Windows, Windows Vista, Windows 7, and Windows Server 2008 R2 are either registered trademarks or trademarks of Microsoft Corporation. TrueType, LaserWriter, and Macintosh are trademarks of Apple Computer, Inc.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

All other brand or product names are trademarks of their respective companies or organizations. Refer to the 'LICENSE.txt' file in the provided CD-ROM for the open source license information. REV. 1.1 5. Appendix 78 User's Guide ML-216x Series ML-216xW Series ADVANCED ADVANCED This guide provides information about installation, advanced configuration, operation and troubleshooting on various OS environments. Some features may not be available depending on models or countries. BASIC This guide provides information concerning installation, basic operation and troubleshooting on windows.

ADVANCED Using advanced print features 141 150 151 153 155 1.

Software installation Installation for Macintosh Reinstallation for Macintosh Installation for Linux Reinstallation for Linux 83 84 85 87 Using Direct Printing Utility (Windows only) 149 Using memory/hard drive features Macintosh printing Linux printing Unix printing 2. Using a network-connected machine Useful network programs Wired network setup Installing driver over the network IPv6 configuration Wireless network setup Samsung MobilePrint 89 90 93 101 104 136 4. Useful management tools Samsung AnyWeb Print Easy Eco Driver Understanding Easy Capture Manager Using SyncThru™ Web Service Using Samsung Easy Printer Manager Using Samsung Printer Status Using Smart Panel 158 159 160 161 164 167 169 Using the Linux Unified Driver Configurator 171 3. Special features Altitude adjustment Changing the default print settings Setting your machine as a default machine 138 139 140 5. Troubleshooting Paper feeding problems Power and cable connecting problems Printing problems 175 176 177 80 DVANCED Printing quality problems Operating system problems 181 189 81 1.

Software installation This chapter provides instructions for installing essential and helpful software for use in an environment where the machine is connected via a cable. A locally connected machine is a machine directly attached to your computer using the cable. If your machine is attached to a network, skip the following steps below and go on to installing a network connected machine's driver (see Installing driver over the network93). · Installation for Macintosh · Reinstallation for Macintosh · Installation for Linux · Reinstallation for Linux 83 84 85 87 · If you are a Windows OS user, refer to the "Installing the driver locally" on page 21 for installing the machine's driver. · Only use a USB cable no longer then 3 meter (118 inches).

Installation for Macintosh 1 2 3 4 5 6 7 8 9 10 11 12 13 Make sure that the machine is connected to your computer and powered on. Insert the supplied software CD into your CD-ROM drive. Double-click the CD-ROM icon that appears on your Macintosh desktop. Double-click the MAC_Installer folder > Installer OS X icon. Click Continue. Read the license agreement and click Continue. Click Agree to agree to the license agreement. When the message that warns that all applications will close on your computer appears, click Continue. Click Continue on the User Options Pane. Click Install.

All components necessary for machine operations will be installed. If you click Customize, you can choose individual components to install. Enter the password and click OK. Installing software requires you to restart your computer. Click Continue Installation. After the installation is finished, click Close. 14 15 16 17 Open the Applications folder > Utilities > Print Setup Utility. ·For Mac OS X 10.5 -10.7, open the Applications folder > System Preferences and click Print & Fax.

Click Add on the Printer List. ·For Mac OS X 10.5 -10.7, click the "+" folder icon; a display window will pop up. Click Default Browser and find the USB connection.

·For Mac OS X 10.5-10.7, click Default and find the USB connection. For Mac OS X 10.4, if Auto Select does not work properly, select Samsung in Print Using and your machine name in Model.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

For Mac OS X 10.5-10.7, if Auto Select does not work properly, select Select a driver to use. and your machine name in Print Using. Your machine appears on the Printer List, and is set as the default machine. 18 Click Add. 1. Software installation 83 Reinstallation for Macintosh If the printer driver does not work properly, uninstall the driver and reinstall it. 1 2 3 4 5 6 Make sure that the machine is connected to your computer and powered on. Insert the supplied software CD into your CD-ROM drive.

Double-click the CD-ROM icon that appears on your Macintosh desktop. Double-click the MAC_Installer folder > Uninstaller OS X icon. Enter the password and click OK. When the uninstall is done, click OK. If a machine has already been added, delete it from the Print Setup Utility or Print & Fax. 1. Software installation 84 Installation for Linux You need to download Linux software packages from the Samsung website to install the printer software (<http://www.samsung.com> > find your product > Support or Downloads). The installation program added the Unified Driver Configurator desktop icon and the Unified Driver group to the system menu for your convenience.

If you have any difficulties, consult the on-screen help that is available through your system menu or from the driver package Windows applications, such as Unified Driver Configurator or Image Manager. 1 Installing the Unified Linux Driver 2 1 2 Make sure that the machine is connected to your computer and powered on. When the Administrator Login window appears, type "root" in the Login field and enter the system password. Installing the Smart Panel 1 2 Make sure that the machine is connected to your computer and powered on. When the Administrator Login window appears, type in root in the Login field and enter the system password.

You must log in as a super user (root) to install the machine software. If you are not a super user, ask your system administrator. You must log in as a super user (root) to install the machine software. If you are not a super user, ask your system administrator. 3 4 5 6 7 From the Samsung website, download the Unified Linux Driver package to your computer.

Right-click the Unified Linux Driver package and extract the package. Double click cdroot > autorun. When the welcome screen appears, click Next. When the installation is complete, click Finish. 3 4 5 From the Samsung website, download the Smart Panel package to your computer. Right-click the Smart Panel package and extract the package. Double click cdroot > Linux > smartpanel > install.sh. 1. Software installation 85 Installation for Linux 3 Installing the Printer Settings Utility 1 2 Make sure that the machine is connected to your computer and powered on.

When the Administrator Login window appears, type "root" in the Login field and enter the system password. You must log in as a super user (root) to install the machine software. If you are not a super user, ask your system administrator. 3 4 5 From the Samsung website, download the Printer Settings Utility package to your computer. Right-click the Printer Settings Utility package and extract the package. Double click cdroot > Linux > psu > install.sh. 1. Software installation 86 Reinstallation for Linux If the printer driver does not work properly, uninstall the driver and reinstall it. 1 2 Make sure that the machine is connected to your computer and powered on.

When the Administrator Login window appears, type "root" in the Login field and enter the system password. You must log in as a super user (root) to uninstall the printer driver. If you are not a super user, ask your system administrator. 3 Click the icon at the bottom of the desktop. When the Terminal screen appears, type in the following.

[root@localhost root]#cd /opt/Samsung/mfp/uninstall/ [root@localhost uninstall]#./uninstall.sh 4 5 6 Click Uninstall. Click Next. Click Finish.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

1. Software installation 87 2. Using a network-connected machine This chapter gives you step-by-step instructions for setting up a network connected machine and software. · Useful network programs · Wired network setup · Installing driver over the network · IPv6 configuration · Wireless network setup · Samsung MobilePrint 89 90 93 101 104 136 Supported optional devices and features may differ according to your model (see "Features by models" on page 6). 6). Useful network programs There are several programs available to setup the network settings easily in a network environment. For the network administrator especially, managing several machines on the network is possible. 2 SyncThru™ Web Admin Service Web-based machine management solution for network administrators. SyncThru™ Web Admin Service provides you with an efficient way of managing network devices and lets you remotely monitor and troubleshoot network machines from any site with corporate internet access. · Download this program from <http://solution.samsungprinter.com>. · Before using the programs below, set the IP address first. · Some features and optional goods may not be available depending on model or country (see "Features by models" on page 6). 1 3 SyncThru™ Web Service The web server embedded on your network machine allows you to do the following tasks (see "Using SyncThru™ Web Service" on page 103): · · · Check the supplies information and status. Customize machine settings. Set the email notification option. When you set this option, the machine status (toner cartridge shortage or machine error) will be sent to a certain person's email automatically. Configure the network parameters necessary for the machine to connect to various network environments. SetIP This utility program allows you to select a network interface and manually configure the IP addresses for use with the TCP/IP protocol. · · · See "IPv4 configuration using SetIP (Windows)" on page 90. See "IPv4 configuration using SetIP (Macintosh)" on page 91. See "IPv4 configuration using SetIP (Linux)" on page 92. · · The machine that does not support the network interface, it will not be able to use this feature (see "Rear view" on page 17). · TCP/IPv6 is not supported by this program. 2. Using a network-connected machine 89 Wired network setup You must set up the network protocols on your machine to use it on your network. You can use network after connecting network cable to a corresponding port on your machine. · For models that do not have the display screen on the control panel, use the SyncThru™ Web Service or SetIP program. -See "Using SyncThru™ Web Service" on page 161. -See "Setting IP address" on page 90. · For models that have the display screen on the control panel, configure the network setting by pressing panel. 4 · The machine without the (WPS) (Cancel or Stop/Clear) button: Press the button for more than ten seconds on the control panel. Using this Network Configuration Report, you can find your machine's MAC address and IP address. For example: · · 5 MAC Address: 00:15:99:41:A2:78 IP Address: 165.254.192.192 (Menu) button > Network on the control panel Setting IP address · The machine that does not support the network interface, it will not be able to use this feature (see "Rear view" on page 17) · TCP/IPv6 is not supported by this program. Printing a network configuration report You can print Network Configuration Report from the machine's control panel that will show the current machine's network settings. This will help you to set up a network. · The machine has the display screen: Press the (Menu) button on the control panel and select Network > Network Config.

(Network Configuration)> Yes. The machine does not have the display screen: Press the (Cancel or Stop/Clear) button for more than five seconds on the control panel.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

First, you have to set up an IP address for network printing and managements. In most cases a new IP address will be automatically assigned by a DHCP (Dynamic Host Configuration Protocol) server located on the network. IPv4 configuration using SetIP (Windows) Before using the SetIP program, disable the computer firewall from Control Panel > Security Center > Windows Firewall. 2. Using a network-connected machine · 90 Wired network setup 1 2 3 4 5 6 7 Install this program from the supplied CD-ROM by double-click Application > SetIP > Setup.exe. Follow the instructions in the installation window. Connect your machine to the network with a network cable.

Turn on the machine. From the Windows Start menu, select All Programs > Samsung Printers > SetIP > SetIP. Click the icon (third from left) in the SetIP window to open the TCP/IP configuration window. Enter the machine's new information into the configuration window as follows. In a corporate intranet, you may need to have this information assigned by a network manager before proceeding.

Find the machine's MAC address from the Network Configuration Report (see "Printing a network configuration report" on page 90) and enter it without the colons. For example, 00:15:99:29:51:A8 becomes 0015992951A8. 8 Click Apply, and then click OK. The machine will automatically print the Network Configuration Report. Confirm that all the settings are correct.

IPv4 configuration using SetIP (Macintosh) Before using the SetIP program, disable the computer firewall from System Preferences > Security > Firewall. The following instructions may differ for your model. 1 2 3 Connect your machine to the network with a network cable. Insert the Installation CD-ROM, and open the disk window, select MAC_Installer > MAC_Printer > SetIP > SetIPApplet.html. Double-click the file and Safari will automatically open, then select Trust. The browser will open the SetIPApplet.html page that shows the printer's name and IP address information. 2. Using a network-connected machine 91 Wired network setup 4 5 Click the icon (third from left) in the SetIP window to open the TCP/IP configuration window.

Enter the machine's new information into the configuration window. In a corporate intranet, you may need to have this information assigned by a network manager before proceeding. 3 4 Click to open the TCP/IP configuration window. Enter the machine's new information into the configuration window. In a corporate intranet, you may need to have this information assigned by a network manager before proceeding. Find the machine's MAC address from the Network Configuration Report (see "Printing a network configuration report" on page 90) and enter it without the colons. For example, 00:15:99:29:51:A8 becomes 0015992951A8. Find the machine's MAC address from the Network Configuration Report (see "Printing a network configuration report" on page 90) and enter it without the colons. For example, 00:15:99:29:51:A8 becomes 0015992951A8. 6 7 Select Apply, then OK, and OK again.

Quit Safari. 5 The machine will automatically print the Network Configuration Report. IPv4 configuration using SetIP (Linux) Before using the SetIP program, disable the computer firewall from System Preferences or Administrator. The following instructions may vary from your model or operating systems. 1 2 Open /opt/Samsung/mfp/share/utills/.

Double-click the SetIPApplet.html file. 2. Using a network-connected machine 92 Installing driver over the network · The machine that does not support the network interface, it will not be able to use this feature (see "Rear view" on page 17). · Some features and optional goods may not be available depending on model or country (see "Features by models" on page 6).

3 Select Install Now. 6 Windows 1 Make sure that the machine is connected to the network and powered on. Also, your machine's IP address should have been set (see "Setting IP address" on page 90).



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

If the "Found New Hardware Wizard" appears during the installation procedure, click Cancel to close the window. The Custom Installation allows you to select the machine's connection and choose individual components to install. Follow the instructions on the window. 2 Insert the supplied software CD into your CD-ROM drive. The software CD should automatically run and an installation window will appear. 4 Read License Agreement, and select I accept the terms of the License Agreement. Then, click Next.

The program searches for the machine. 2. Using a network-connected machine 93 Installing driver over the network If your machine is not found on the network or locally, an error message appears. Select the option you want and click Next. Following command-line are effective and operated when command is used with /s or /S. But /h, /H or /? are exceptional commands that can be operated solely. 5 The searched machines will be shown on the screen. Select the one you wish to use and click OK. Command- line /s or Definition Starts silent installation. Description Installs machine drivers without prompting any UIs or user intervention.

Printer port name can be specified as IP address, hostname, USB local port name or IEEE1284 port name. For example ·/p"xxx.xxx.xxx.xxx" in where, "xxx.xxx.xxx.xxx" means IP address for network printer. /p"USB001", /P"LPT1:", /p"hostname" If the driver searched only one machine, the confirmation window appears. /S /p"<port name>" or /P"<port name>" Network Port will be created by use of Standard TCP/ IP Port monitor.

For local port, this port must exist on system before being specified by command. Specifies printer port. 6 Follow the instructions in the installation window.

Silent installation Mode Silent installation mode is an installation method that does not require any user intervention. Once you start the installation, the machine driver and software are automatically installed on you computer. You can start the silent installation by typing /s or /S in the command window.

Command-line Parameters Following table shows commands that can be used in the command window. · When installing the driver silently in Korean, type inSetup.exe /s / L"0x0012". 2.

Using a network-connected machine 94 Installing driver over the network Command- line /a"<dest_path>" or /A"<dest_path>" Definition Specifies destination path for installation. Description Since machine drivers should be installed on the OS specific location, this command applies to only application software. Command- line /nd or /ND Definition Commands not to set the installed driver as a default machine driver. Description It indicates installed machine driver will not be the default machine driver on your system if there are one or more printer drivers installed. If there is no installed machine driver on your system, then this option won't be applied because Windows OS will set installed printer driver as a default machine driver. This command provides a way to install a printer instance that uses installed printer driver files without installing an additional driver. This command provides a way to remove only specified printer instance from your system without effecting other printer drivers. It will not remove printer driver files from your system. The destination path should be a fully qualified path. /i"<script filename>" or /I"<script filename>" Specifies customized install script file for custom operation.

The script filename should be a fully qualified Note: This customized script filename. file is prior than default installer setting in setup package but not prior than command-line parameters. /n"<Printer name>" or /N"<Printer name>" Specifies printer name. Printer instance shall be created as specified printer name. Customized script file can be assigned for customized silent installation.

This script file can be created or modified through provided installer customizing utility or by text editor.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

/x or /X Uses existing machine driver files to create printer instance if it is already installed. /up "<printer name>" or /UP "<printer name>" Removes only specified printer instance and not the driver files. With this parameter, you can add printer instances as your wishes. 2.

Using a network-connected machine 95 Installing driver over the network 7 Command- line /d or /D Definition Uninstalls all device drivers and applications from your system. Description This command will remove all installed device drivers and application software from your system. It will install all supported Windows OS platform's machine drivers to system and share it with specified <share name> for point and print. This command will open Printers and Faxes folder after the silent installation. It will create a log file to a specified folder. Macintosh 1 2 3 4 5 6 7 8 9 Make sure that the machine is connected to your network and powered on. Insert the supplied software CD into your CD-ROM drive. Double-click the CD-ROM icon that appears on your Macintosh desktop. Double-click the MAC_Installer folder > Installer OS X icon. Click Continue.

Read the license agreement and click Continue. Click Agree to agree to the license agreement. When the message which warns that all applications will close on your computer appears, click Continue. Click Continue on the User Options Pane. /v "<share name>" or /V "<share name>" Shares installed machine and add other available platform drivers for Point & Print. /o or /O /f "<log filename>" or /F "<log filename>" Opens Printers and Faxes folder after installation. Specifies log filename. The default log file is created in the system temp folder if not specified. Shows Command-line Usage. /h, /H or /? If you have not set the IP address yet, click Set IP address and refer to "IPv4 configuration using SetIP (Macintosh)" on page 91.

If you want to set the wireless setting, refer to "Setup using Macintosh" on page 120. 2. Using a network-connected machine 96 Installing driver over the network 10 11 12 13 14 15 16 17 Click Install. All components necessary for machine operations will be installed. If you click Customize, you can choose individual components to install.

Enter the password and click OK. Installing software requires you to restart your computer. Click Continue Installation. After the installation is finished, click Close. Open the Applications folder > Utilities > Print Setup Utility.

·For Mac OS X 10.5-10.7, open the Applications folder > System Preferences and click Print & Fax. Click Add on the Printer List. ·For Mac OS X 10.5-10.7, click the "+" icon. A display window will pop up. For Mac OS X 10.4, click IP Printer.

·For Mac OS X 10.5-10.7, click IP. Select HP Jetdirect - Socket in Protocol. 19 20 Enter the queue name in the Queue input field. If you cannot determine the queue name for your machine server, try using the default queue first. For Mac OS X 10.4, if Auto Select does not work properly, select Samsung in Print Using and your machine name in Model. ·For Mac OS X 10.5-10.

7, if Auto Select does not work properly, choose Select Printer Software and your machine name in Print Using. 21 Click Add. Your machine appears in the Printer List, and is set as the default machine. 8 Linux You need to download Linux software packages from the Samsung website to install the printer software (www.samsung.

com > find your product > Support or Downloads). To install other software: · See "Installing the Smart Panel" on page 85. When printing a document containing many pages, printing performance may be enhanced by choosing Socket for Printer Type option. · See "Installing the Printer Settings Utility" on page 86. 18 Enter the machine's IP address in the Address input field.

2. Using a network-connected machine 97 Installing driver over the network Install the Linux driver and add network printer Add a network printer 1 2 3 4 5 6 7 8 9 10 11 12 Make sure that the machine is connected to your network and powered on.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Also, your machine's IP address should have been set. Download the Unified Linux Driver package from the Samsung website. Extract the UnifiedLinuxDriver.tar.gz file and open the new directory. Double-click the Linux folder > install.sh icon. The Samsung installer window opens.

Click Continue. The add printer wizard window opens. Click Next. Select network printer and click Search button. The machine's IP address and model name appears on list field. 9 1 2 3 4 5 6 7 8 Double-click the Unified Driver Configurator. Click Add Printer. The Add printer wizard window opens. Click Next.

Select Network printer and click the Search button.

The printer's IP address and model name appears on list field. Select your machine and click Next. Enter the printer description and click Next. After the machine is added, click Finish. Select your machine and click Next.

Input the printer description and Next. After the machine is added, click Finish. When installation is done, click Finish. UNIX · Make sure your machine supports the UNIX operating system before installing the UNIX printer driver (see "Features by models" on page 6) · The commands are marked with "", when typing the commands, do not type "".

Using a network-connected machine 98 Installing driver over the network To use the UNIX printer driver, you have to install the UNIX printer driver package first, then setup the printer. You can download the UNIX printer driver package from the Samsung website (www.samsung.com > find your product > Support or Downloads). 6 Run the install script. "/install" install is the installer script file which is used to install or uninstall the UNIX Printer Driver package. Use "chmod 755 install" command to give the permission to the installer script. Installing the UNIX printer driver package The installation procedure is common for all variants of UNIX OS mentioned. 1 2 3 From the Samsung website, download and unpack the UNIX Printer Driver package to your computer.

Acquire root privileges. "su -" Copy the appropriate driver archive to the target UNIX computer. 7 8 Execute the ". /install c" command to verify installation results. Run "installprinter" from the command line. This will bring up the Add Printer Wizard window. Setup the printer in this window referring to the following procedures. On some UNIX OS, for example on Solaris 10, just added printers may not be enabled and/or may not accept jobs. In this case run the following two commands on the root terminal: "accept <printer_name>" See administration guide of your UNIX OS for details. "enable <printer_name>" 4 Unpack the UNIX printer driver package.

For example, on IBM AIX, use the following commands. "gzip -d < enter the package name \ tar xf -" 5 Go to the unpacked directory. 2. Using a network-connected machine 99 Installing driver over the network Uninstalling the printer driver package The utility should be used to delete the printer installed in the system. a Run "uninstallprinter" command from the terminal.

It will open the Uninstall Printer Wizard. The installed printers are listed in the drop-down list. b Select the printer to be deleted. c Click Delete to delete the printer from the system. d Execute the "."

/install d" command to uninstall the whole package. e To verify removal results, execute the ". /install c" command. 4 5 6 7 8 9 10 11 12 Specify any printer description in the Description field. This is optional. Specify the printer location in the Location field. Type the IP address or DNS name of the printer in the Device textbox for network-connected printers. On IBM AIX with jetdirect Queue type, only the DNS name is possible-numeric IP address is not allowed.

Queue type shows the connection as lpd or jetdirect in the corresponding list box. Additionally, usb type is available on Sun Solaris OS.

Select Copies to set the number of copies. Check the Collate option to receive copies already sorted. Check the Reverse Order option to receive copies in the reverse order.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Check the Make Default option to set this printer as default. Click OK to add the printer. To re-install it, use the command ". /install" to reinstall the binaries. Setting up the printer To add the printer to your UNIX system, run 'installprinter' from the command line. This will bring up the Add Printer Wizard window.

Setup the printer in this window according to the following steps: 1 2 3 Type the name of the printer.

Select the appropriate printer model from the model list. Enter any description corresponding to the type of the printer in the Type field. This is optional. 2.

Using a network-connected machine 100 IPv6 configuration IPv6 is supported properly only in Windows Vista or higher.

7 The Add Printer Wizard window appears. Follow the instructions in the window. If the IPv6 network seems to not be working, set all the network setting to the factory defaults and try again using Clear Setting. If the machine does not work in the network environment, activate IPv6. Refer to the next section followed by.

In the IPv6 network environment, follow the next procedure to use the IPv6 address. Activating IPv6 10 From the control panel 1 2 3 4 5 6 Connect your machine to the network with a network cable. Turn on the machine. Print a Network Configuration Report that will check IPv6 addresses (see "Printing a network configuration report" on page 90). Select Start > Control Panel > Printers and Faxes. Click Add a printer in the left pane of the Printers and Faxes windows. Click Add a local printer in the Add Printer windows. 1 2 3 4 5 Press the (Menu) button on the control panel. Press Network > TCP/IP (IPv6) > IPv6 Activate. Select On and press OK.

Turn the machine off and turn it on again. Reinstall your printer driver. 2. Using a network-connected machine 101 IPv6 configuration Setting IPv6 addresses

The machine supports the following IPv6 addresses for network printing and managements. . . . Link-local Address: Self-configured local IPv6 address (Address starts with FE80). Stateless Address: Automatically configured IPv6 address by a network router. Stateful Address: IPv6 address configured by a DHCPv6 server. Manual Address: Manually configured IPv6 address by a user. For models that do not have the display screen on the control panel, you need to access SyncThruTM Web Service first using the IPv4 address and follow the below procedure to use IPv6. 11 From the SyncThruTM Web Service 1 2

Access a web browser, such as Internet Explorer, from Windows.

Enter the machine IP address (http://xxx.xxx.xxx.xxx) in the address field and press the Enter key or click Go. If it's your first time logging into SyncThruTM Web Service you need to log-in as an administrator.

Type in the below default ID and password. -ID: admin -Password: sec00000 DHCPv6 address configuration (Stateful) If you have a DHCPv6 server on your network, you can set one of the following options for default dynamic host configuration. 1 2 3 Press the (Menu) button on the control panel. Press Network > TCP/IP (IPv6) > DHCPv6 Config. Press OK to select the required value you want.

-DHCPv6 Addr.: Always use DHCPv6 regardless of router request. -DHCPv6 Off: Never use DHCPv6 regardless of router request. -Router: Use DHCPv6 only when requested by a router. 3 4 5 6 When the SyncThruTM Web Service window opens, move the mouse cursor over the Settings of the top menu bar and then click Network Settings. Click TCP/IPv6 on the left pane of the website. Check the IPv6 Protocol check box to activate IPv6. Check the Manual Address check box. Then, the Address/Prefix text box is activated. 2.

Using a network-connected machine 102 IPv6 configuration 7 8 9 Enter the rest of the address (e.g.,:3FFE:10:88:194::AAAA. "A" is the hexadecimal 0 through 9, A through F). Choose the DHCPv6 configuration. Click the Apply button. Using SyncThruTM Web Service 1 2 Start a web browser, such as Internet Explorer, that supports IPv6 addressing as a URL.



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide
<http://somemanuals.com/dref/4128961>

Select one of the IPv6 addresses (Link-local Address, Stateless Address, Stateful Address, Manual Address) from Network Configuration Report (see "Printing a network configuration report" on page 90). Enter the IPv6 addresses (e.g. ,: http://[FE80::215:99FF:FE66:7701]). 3 Address must be enclosed in '[']' brackets. 2. Using a network-connected machine 103 Wireless network setup · Make sure your machine supports wireless networking. Wireless networking may not be available depending on the model (see "Features by models" on page 6).

· If the IPv6 network seems to not be working, set all the network settings to the factory defaults and try again using Clear Setting. Wireless network name and network key Wireless networks require higher security, so when an access point is first set up, a network name (SSID), the type of security used, and a Network Key are created for the network. Ask your network administrator about this information before proceeding with the machine installation. 12 Getting started Understanding your network type Typically, you can only have one connection between your computer and the machine at a time. Infrastructure mode This is an environment generally used for homes and SOHOs (Small Office/ Home Office).

This mode uses an access point to communicate with the wireless machine. Ad hoc mode This mode does not use an access point. The wireless computer and wireless machine communicate directly. 2. Using a network-connected machine 104 Wireless network setup 13 Introducing wireless set up methods You can set wireless settings either from the machine or the computer. Choose the setting method from the below table. Some wireless network installation types may not be available depending on the model or country. Set up method From the machine's control panel Connecting method Using the WPS (recommended) () Description & Reference · See "Machines with a display screen" on page 108. · See "Machines without a display screen" on page 109. Using the menu button () · See "Using the menu button" on page 110.

2. Using a network-connected machine 105 Wireless network setup Set up method Connecting method Access point via USB cable (recommended) (From the computer) Description & Reference · Windows user, see "Access point via USB cable" on page 111. · Macintosh user, see "Access point via USB cable" on page 120. · Windows user, see "Access point via WPS button (without a USB cable connection)" on page 115. · Macintosh user, see "Setting the access point using the WPS button" on page 124. · Windows user, see "Ad hoc via USB cable" on page 117. · Macintosh user, see "Ad hoc via USB cable" on page 126. · See "Using a network cable" on page 128. · See "Setting up Wi-Fi Direct" on page 131. Access point via WPS button (without a USB cable connection) (,) Ad hoc via USB cable () Using a network cable Other set up methods Setting the Wi-Fi Direct for mobile printing If problems occur during wireless set up or driver installation, refer to the troubleshooting chapter (see "Troubleshooting" on page 133).

2. Using a network-connected machine 106 Wireless network setup 14 Choosing your type Using the WPS button There are two methods available to connect your machine to a wireless network If your machine and an access point (or wireless router) support Wi-Fi Protected Setup™ (WPS), you can easily configure the wireless network settings by pressing the (WPS) button on the control panel without a computer. using the (WPS) button on the control panel. The Push Button Configuration (PBC) method allows you to connect your machine to a wireless network by pressing both the (WPS) button on the control panel of your machine and the WPS (PBC) button on a Wi-Fi Protected Setup™ WPS-enabled access point (or wireless router) respectively. The Personal Identification Number (PIN) method helps you connect your machine to a wireless network by entering the supplied PIN information on a Wi-Fi Protected Setup™ WPS-enabled access point (or wireless router).



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Factory default in your machine is PBC mode, which is recommended for a typical wireless network environment. · If you want to use the wireless network using the infrastructure mode, make sure that the network cable is disconnected from the machine. Using the WPS (PBC) button or entering the PIN from the computer to connect to the access point (or wireless router) varies depending on the access point (or wireless router) you are using. Refer to the user's guide of the access point (or wireless router) you are using. · When using the WPS button to set the wireless network, security settings may change. To prevent this, lock the WPS option for the current wireless security settings. The option name may differ depending on the access point (or wireless router) you are using. You can change the WPS mode in control panel (Wireless > OK > WPS Setting). (Menu) > Network > Items to prepare · · · Check if the access point (or wireless router) supports Wi-Fi Protected Setup™ (WPS). Check if your machine supports Wi-Fi Protected Setup™ (WPS). Networked computer (PIN mode only) 2. Using a network-connected machine 107 Wireless network setup Machines with a display screen Connecting in PBC mode Connecting in PIN mode 1 2 Press and hold the 2 seconds. (WPS) button on the control panel for more than 1 Press and hold the 2 seconds. (WPS) button on the control panel for more than The eight-digit PIN appears on the display. You need to enter the eight-digit PIN within two minutes on the computer that is connected to the access point (or wireless router).

The messages are displayed on the display screen in the order below: aConnecting: The machine is connecting to the wireless network. bConnected: When the machine is successfully connected to the wireless network, the WPS LED light stays on. cSSID Type: After completing the wireless network connection process, the AP's SSID information is displayed on the LCD display. The machine starts waiting for up to two minutes until you press the WPS (PBC) button on the access point (or wireless router). 2 Press the WPS (PBC) button on the access point (or wireless router). The messages are displayed on the display screen in the order below: aConnecting: The machine is connecting to the access point (or wireless router). bConnected: When the machine is successfully connected to the wireless network, the WPS LED light stays on. cAP SSID: After completing the wireless network connection process, the AP's SSID information appears on the display. 2. Using a network-connected machine 108 Wireless network setup Machines without a display screen Connecting in PBC mode Connecting in PIN mode 1 The network configuration report, including PIN, must be printed (see "Printing a network configuration report" on page 90).

In ready mode, Press the (Cancel or Stop/Clear) button for more than five seconds on the control panel. The machine without the (WPS) (Cancel or Stop/Clear) button: Press the 1 Press and hold the (WPS) button on the control panel for about 2 - 4 seconds until the status LED blinks quickly. The machine starts connecting to the wireless network. The LED blinks slowly for up to two minutes until you press the PBC button on the access point (or wireless router). button formore than ten seconds on the control panel.

You can find your machine's PIN. 2 Press the WPS (PBC) button on the access point (or wireless router). aThe light blinks fast on the WPS LED. The machine is connecting to the access point (or wireless router). bWhen the machine is successfully connected to the wireless network, the WPS LED light stays on. 2 3 Press and hold the (WPS) button on the control panel for more than 4 seconds until the status LED stays on. The machine starts connecting to the access point (or wireless router). You need to enter the eight-digit PIN within two minutes on the computer that is connected to the access point (or wireless router).



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)
<http://somenmanuals.com/dref/4128961>

The LED blinks slowly for up to two minutes until you enter the eightdigit PIN. The WPS LED blinks in the order below: aThe light blinks fast on the WPS LED. The machine is connecting to the access point (or wireless router). bWhen the machine is successfully connected to the wireless network, the WPS LED light stays on. 2. Using a network-connected machine 109 Wireless network setup Re-connecting to a network When the wireless function is off, the machine automatically tries to re-connect to the access point (or wireless router) with the previously used wireless connection settings and address. Disconnecting from a network To disconnect the wireless network connection, press the the control panel for more than two seconds.

· (WPS) button on When the Wi-Fi network is in idle mode: The machine is immediately disconnected from the wireless network and the WPS LED turns off. When the Wi-Fi network is being used: While the machine waits until the current job is finished, the light blinks fast on the WPS LED. Then, the wireless network connection is automatically disconnected and the WPS LED turns off. In the following cases, the machine automatically re-connects to the wireless network: · The machine is turned off and on again. · The access point (or wireless router) is turned off and on again. · 15 Canceling the connection process To cancel the wireless network connection when the machine is connecting to the wireless network, press and release the (Cancel or Stop/Clear) or (Power)button on the control panel. You need to wait 2 minutes to reconnect to the wireless network. Using the menu button Some menus may not appear in the display depending on options or models. If so, it is not applicable to your machine Before starting, you will need to know the network name (SSID) of your wireless network and the network key if it is encrypted. This information was set when the access point (or wireless router) was installed.

If you do not know about your wireless environment, please ask the person who set up your network. 2. Using a network-connected machine 110 Wireless network setup Access point via USB cable After completing the wireless network connection, you need to install a machine driver to print from an application (see "Installing driver over the network" on page 93). Items to prepare · Access point Network-connected computer Software CD that was provided with your machine A machine installed with a wireless network interface USB cable · · 1 2 3 Press the (Menu) button on the control panel. Press Network > Wireless > WLAN Settings.

Press the OK to select the setup method you want. · Wizard (recommended): In this mode, the setup is automatic. The machine will display a list of available networks from which to choose. After a network is chosen then printer will prompt for the corresponding security key. · Custom: In this mode, users can give or edit manually their own SSID , or choose the security option in detail.

· Creating the infrastructure network 16 Setup using Windows 1 2 3 4 5 6 Check whether the USB cable is connected to the machine. Turn on your computer, access point, and machine. Insert the supplied software CD into your CD-ROM drive. Select the Wireless Setting and Installation option. Read the License Agreement, and select I accept the terms of the License Agreement. Then, click Next. The software searches the wireless network. If the software has failed to search the network, check if the USB cable is connected properly between the computer and machine, and follow the instructions in the window. 2. Using a network-connected machine Shortcut to the Wireless Setting program without the CD: If you have installed the printer driver once, you can access the Wireless Setting program without the CD.

From the Start menu, select Programs or All Programs > Samsung Printers > your printer driver name > Wireless Setting Program.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

111 Wireless network setup · If wireless network set up has been set before, the Wireless Network Setting Information window appears. If you want to reset the wireless settings, check the check box and click Next. · For models that support the WPS button (without a USB cable connection), the window shown below will appear. 7 Select the method to use from the wireless set up method window. · Configure the wireless settings manually.: Go to step 8. · Configure the wireless settings by pressing the WPS button on the access point.: Connect to the wireless network by press the WPS button on the access point (or wireless router). · With a USB Cable: Connect the USB cable and click Next, then go to step 7.

· Using the WPS Button: See "Access point via WPS button (without a USB cable connection)" on page 115. · Follow the instructions in the window. When you are done configuring the wireless network settings, go to step 11. 8 After searching, the window shows the wireless network devices. Select the name (SSID) of the access point you are using and click Next.

2. Using a network-connected machine *112 Wireless network setup* If you cannot find the network name you want to choose, or if you want to set the wireless configuration manually, click Advanced Setting. · Enter the wireless Network Name: Enter the SSID of the access point (SSID is case-sensitive). · Operation Mode: Select Infrastructure. · Authentication: Select an authentication type.

Open System: Authentication is not used, and encryption may or may not be used, depending on the need for data security. Shared Key: Authentication is used. A device that has a proper WEP key can access the network. WPA Personal or WPA2 Personal: Select this option to authenticate the print server based on a WPA Pre-Shared Key. This uses a shared secret key (generally called Pre Shared Key pass phrase), which is manually configured on the access point and each of its clients. · Encryption: Select the encryption (None, WEP64, WEP128, TKIP, AES, TKIP AES). · Network Key: Enter the encryption network key value. · Confirm Network Key: Confirm the encryption network key value. · WEP Key Index: If you are using WEP Encryption, select the appropriate WEP Key Index. The wireless network security window appears when the access point has security settings.

The wireless network security window appears. The window may differ according to its security mode: WEP or WPA. · WEP Select Open System or Shared Key for authentication and enter the WEP security key. Click Next. WEP (Wired Equivalent Privacy) is a security protocol preventing unauthorized access to your wireless network. WEP encrypts the data portion of each packet exchanged on a wireless network using a 64-bit or 128-bit WEP encryption key. · WPA Enter the WPA shared key and click Next. WPA authorizes and identifies users based on a secret key that changes automatically at regular intervals. WPA also uses TKIP (Temporal Key Integrity Protocol) and AES (Advanced Encryption Standard) for data encryption. 2.

Using a network-connected machine *113 Wireless network setup* 9 The window shows the wireless network settings and checks if the settings are correct. Click Next. · For the DHCP method If the IP address assignment method is DHCP, check if DHCP is shown in the window. If it shows Static, click Change TCP/IP to change the assignment method to DHCP. · For the Static method If the IP address assignment method is Static, check if Static is shown in the window.

If it shows DHCP, click Change TCP/IP to enter the IP address and other network configuration values for the machine. Before entering the IP address for the machine, you must know the computer's network configuration information. If the computer is set to DHCP, you must contact the network administrator to get the static IP address. For example, If the computer's network information is as shown below, -IP address: 169.



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide
<http://somemanuals.com/dref/4128961>

133.42 -Subnet Mask: 255.255.0.0 Then, the machine's network information should be as follows: -IP address: 169.254.133.43 -Subnet Mask: 255.255.0.

0 (Use the computer's subnet mask.) -Gateway: 169.254.133.1 Wi-Fi Direct Option: · Wi-Fi Direct option appears on the screen only if your printer supports this feature. · Can start to build Wi-Fi Direct by using Samsung Easy Printer Manager (see "Setting up Wi-Fi Direct" on page 131). 10 When the window that tells you that the network cable connection is confirmed appears, disconnect the network cable and click Next. If the network cable is connected, it may have trouble finding the machine when configuring the wireless network. 11 Wireless network setting is completed. To print from a Wi-Fi Direct supported mobile device, set the Wi-Fi Direct Option (see "Setting up WiFi Direct" on page 131).

2. Using a network-connected machine 114 Wireless network setup · Network Name(SSID): The default Network Name is the model name and the maximum length is 22 characters (not including "Direct-xx-"). · Network Key is the numeric string, and the size is 8 ~ 64 characters. Access point via WPS button (without a USB cable connection) For models that have a WPS button, you can set the wireless network using the WPS button (without a USB connection) and access point (or a router) WPS button. 12 13 14 15 16 17 18 When the wireless network set up is completed, disconnect the USB cable between the computer and machine.

Click Next. Click Next when the Confirm Printer Connection window appears. Select the components to be installed. Click Next. After selecting the components, you can also change the machine name, set the machine to be shared on the network, set the machine as the default machine, and change the port name of each machine.

Click Next. After installation is finished, a window asking you to print a test page appears. If you want to print a test page, click Print a test page. Otherwise, just click Next and go to step 18. If the test page prints out correctly, click Yes. If not, click No to reprint it. If you want to register your machine with the Samsung web site and receive useful information, click On-line Registration. If not, click Finish. Items to prepare · · · · Access point (or wireless router) Network-connected computer Software CD that was provided with your machine The machine installed with a wireless network interface Creating the infrastructure network 1 2 3 4 Turn on your computer, access point, and machine. Insert the supplied software CD into your CD-ROM drive.

Select the Wireless Setting and Installation option. Read the License Agreement, and select I accept the terms of the License Agreement. Then, click Next. 2. Using a network-connected machine 115 Wireless network setup 5 Select Using the WPS button and click Next. 7 Follow the instructions on the window to set up the wireless network. ·For models with a display screen, follow the steps below. aPress and hold the 2-4 seconds. (WPS) button on the control panel for about The machine waits up to 2 minutes for the WPS button on the access point (or a router) to be pressed. bPress the WPS (PBC) button on the access point (or wireless router).

The messages are displayed on the display screen in the order below: -Connecting: The machine is connecting to the access point (or wireless router). · For models that support WPS button, the above window appears. · If your machine is connected with a USB cable, the above window does not appear. Disconnect the USB cable if you want to set up the wireless network using the WPS button. · If you want to set up the wireless network using the USB cable, refer to "Access point via USB cable" on page 111.

-Connected: When the machine is successfully connected to the wireless network, the WPS LED light stays on. 6 The next window asks you to check if your access point (or wireless router) supports WPS or not.



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide
<http://somemanuals.com/dref/4128961>

If the access point (or wireless router) has a WPS button, select Yes and click Next. 2. Using a network-connected machine 116 Wireless network setup -SSID Type: After completing the wireless network connection process, the AP's SSID information appears on the display.

For models without a display screen, follow the steps below. aPress and hold the (WPS) button on the control panel for about 2 - 4 seconds until the status LED blinks quickly. The machine starts connecting to the wireless network. The LED blinks slowly for up to two minutes until you press the PBC button on the access point (or wireless router). bPress the WPS (PBC) button on the access point (or wireless router). -The light blinks fast on the WPS LED while it is connecting to the access point (or wireless router). -When the machine is successfully connected to the wireless network, the WPS LED light stays on. 12 13 14 After the installation is finished, a window asking you to print a test page appears. If you want to print a test page, click Print a test page. Otherwise, just click Next and go to step 14.

If the test page prints out correctly, click Yes. If not, click No to reprint it. If you want to register your machine with the Samsung web site and receive useful information, click On-line Registration. If not, click Finish. Ad hoc via USB cable If you do not have an access point (AP), you may still connect the machine wirelessly to your computer by setting up an ad-hoc wireless network by following the simple steps below. 8 9 10 11 The Wireless Network Setting Complete window appears. Click Next. Click Next when the Confirm Printer Connection window appears. Select the components to be installed. Click Next.

After selecting the components, you can also change the machine name, set the machine to be shared on the network, set the machine as the default machine, and change the port name of each machine. Click Next. Items to prepare Network-connected computer Software CD that was provided with your machine A machine installed with a wireless network interface USB cable 2. Using a network-connected machine 117 Wireless network setup Creating the ad hoc network in Windows 1 2 3 4 5 6 Check whether the USB cable is connected to the machine. Turn on your computer and the wireless network machine. Insert the supplied software CD into your CD-ROM drive. Select the Wireless Setting and Installation option. Read the License Agreement, and select I accept the terms of the License Agreement. Then, click Next. The software searches the wireless network.

If you want to change the ad hoc settings, click the Advanced Setting button. Enter the wireless Network Name: Enter the SSID name you want (SSID is case-sensitive). Operation Mode: Select ad hoc. Channel: Select the channel. (Auto Setting or 2412 MHz to 2467 MHz). Authentication: Select an authentication type. Open System: Authentication is not used, and encryption may or may not be used, depending on the need for data security. Shared Key: Authentication is used. A device that has a proper WEP key can access the network. Encryption: Select the encryption (None, WEP64, WEP128).

Network Key: Enter the encryption network key value. Confirm Network Key: Confirm the encryption network key value. WEP Key Index: If you are using WEP Encryption, select the appropriate WEP Key Index. The wireless network security window appears when the ad hoc network has security enabled. Select Open System or Shared Key for the authentication and click Next. WEP (Wired Equivalent Privacy) is a security protocol preventing unauthorized access to your wireless network. WEP encrypts the data portion of each packet exchanged on a wireless network using a 64-bit or 128-bit WEP encryption key. If the software has failed to search the network, check if the USB cable is connected properly between the computer and machine, and follow the instructions in the window.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

7 After searching the wireless networks, a list of wireless networks your machine has searched appears. If you want to use the Samsung default ad hoc setting, select the last wireless network on the list, Network Name(SSID) is Portthru and Signal is Printer Self Network. Then, click Next. If you want to use other ad hoc settings, select another wireless network from the list. 8 The window showing the wireless network setting appears. Check the settings and click Next. 2.

Using a network-connected machine 118 Wireless network setup Before entering the IP address for the machine, you must know the computer's network configuration information. If the computer's network configuration is set to DHCP, the wireless network setting should also be DHCP. Likewise, if the computer's network configuration is set to Static, the wireless network setting should also be Static. If your computer is set to DHCP and you want to use the Static wireless network setting, you must contact the network administrator to get the static IP address. · For the DHCP method If the IP address assignment method is DHCP, check if DHCP is shown in the Wireless Network Setting Confirm window.

If it shows Static, click Change TCP/IP to change the assignment method to Receive IP address automatically (DHCP). · For the Static method If the IP address assignment method is Static, check if Static is shown in the Wireless Network Setting Confirm window. If it shows DHCP, click Change TCP/IP to enter the IP address and other network configuration values for the machine. For example, If the computer's network information is as shown follows: -IP address: 169.254.133.42 -Subnet Mask: 255.255.0.0 Then, the machine's network information should be as below: -IP address: 169.

254.133.43 -Subnet Mask: 255.255.0.0 (Use the computer's subnet mask.) -Gateway: 169.254.133.1 9 10 The Wireless Network Setting Complete window appears.

Click Next. When the wireless network settings are completed, disconnect the USB cable between the computer and machine. Click Next. If the Change PC Network Setting window appears, follow the steps in the window. Click Next if you are finished with the computer's wireless network settings.

If you set the computer's wireless network to DHCP, it will take several minutes to receive the IP address. 11 12 13 14 15 Click Next when the Confirm Printer Connection window appears. Select the components to be installed. Click Next. After selecting the components, you can also change the machine name, set the machine to be shared on the network, set the machine as the default machine, and change the port name of each machine.

Click Next. After the installation is finished, a window asking you to print a test page appears. If you want to print a test page, click Print a test page. Otherwise, just click Next and go to step 16. If the test page prints out correctly, click Yes. If not, click No to reprint it. 2. Using a network-connected machine 119 Wireless network setup 16 If you want to register your machine with the Samsung web site and receive useful information, click On-line Registration. If not, click Finish. 17 Setup using Macintosh Items to prepare Access point Network-connected computer Software CD that was provided with your machine A machine installed with a wireless network interface USB cable 5 6 7 8 9 10 11 Double-click the MAC_Installer folder > Installer OS X icon.

Click Continue. Read the license agreement and click Continue. Click Agree to agree to the license agreement. When the message that warns that all applications will close on your computer appears, click Continue. Click Wireless Network Setting button on the User Options Pane. The software searches the wireless network. If the software has failed to search the network, check if the USB cable is connected properly between the computer and machine, and follow the instructions in the window. Access point via USB cable 1 2 3 4 Check whether the USB cable is connected to the machine.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Turn on your computer, access point, and machine. Insert the supplied software CD into your CD-ROM drive.

Double-click the CD-ROM icon that appears on your Macintosh desktop. 2. Using a network-connected machine 120 Wireless network setup · If wireless network setting has been set before, Wireless Network Setting Information window appears. If you want to reset the wireless settings, check the check box and click Next. · For models that support the WPS button (without a USB cable connection), the window shown below will appear.

12 Select the method to use from the wireless set up method window. · Configure the wireless settings manually.: Go to step 13. · Configure the wireless settings by pressing the WPS button on the access point.: Connect to the wireless network by press the WPS button on the access point (or a wireless router).

· With a USB Cable: Connect the USB cable and click Next, then go to step 7. · Using the WPS Button: See "Access point via WPS button (without a USB cable connection)" on page 115. · Follow the instructions in the window. When you are done setting the wireless network settings, go to step 16. 13 After searching,

the window shows the wireless network devices. Select the name (SSID) of the access point you are using and click Next. When you set the wireless configuration manually, click Advanced Setting. · Enter the wireless Network Name: Enter the SSID of the access point (SSID is case-sensitive). · Operation Mode: Select Infrastructure. 2.

Using a network-connected machine 121 Wireless network setup · Authentication: Select an authentication type. Open System: Authentication is not used, and encryption may or may not be used, depending on the need for data security. Shared Key: Authentication is used. A device that has a proper WEP key can access the network. WPA Personal or WPA2 Personal: Select this option to authenticate the print server based on the WPA Pre-Shared Key. This uses a shared secret key (generally called Pre Shared Key pass phrase) that is manually configured on the access point and each of its clients. · Encryption: Select the encryption. (None, WEP64, WEP128, TKIP, AES, TKIP, AES) · Network Key: Enter the encryption network key value. · Confirm Network Key: Confirm the encryption network key value. · WEP Key Index: If you are using WEP Encryption, select the appropriate WEP Key Index.

The wireless network security window appears when the access point has security enabled. The wireless network security window appears. The window may differ according to its security mode: WEP or WPA. · WEP Select Open System or Shared Key for the authentication and enter the WEP security key. Click Next.

WEP (Wired Equivalent Privacy) is a security protocol preventing unauthorized access to your wireless network. WEP encrypts the data portion of each packet exchanged on a wireless network using a 64-bit or 128-bit WEP encryption key. · WPA Enter the WPA shared key and click Next. WPA authorizes and identifies users based on a secret key that changes automatically at regular intervals. WPA also uses TKIP (Temporal Key Integrity Protocol) and AES (Advanced Encryption Standard) for data encryption.

2. Using a network-connected machine 122 Wireless network setup 14 The window shows the wireless network settings and check if settings are right. Click Next. · For the DHCP method If the IP address assignment method is DHCP, check if DHCP is shown in the window. If it shows Static, click Change TCP/IP to change the assignment method to DHCP. · For the Static method If the IP address assignment method is Static, check if Static is shown in the window. If it shows DHCP, click Change TCP/IP to enter the IP address and other network configuration values for the machine. Before entering the IP address for the machine, you must know the computer's network configuration information. If the computer is set to DHCP, you must contact the network administrator to get the static IP address.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)
<http://somenmanuals.com/dref/4128961>

For example: If the computer's network information is shown as follows: -IP address: 169.

254.133.42 -Subnet Mask: 255.255.0.0 Then, the machine's network information should be as shown below: -IP address: 169.254.133.43 -Subnet Mask: 255.255.

0.0 (Use the computer's subnet mask.) -Gateway: 169.254.133.

1 Wi-Fi Direct Option: · Wi-Fi Direct Option appears on the screen only if your printer supports this feature. · Can start to build Wi-Fi Direct by using Samsung Easy Printer Manager (see "Setting up Wi-Fi Direct" on page 131). 15 When the window that tells you that the network cable connection is confirmed appears, disconnect the network cable and click Next. If the network cable is connected, it may have trouble finding the machine when configuring the wireless network. 16 Wireless network setting is completed.

To print from a Wi-Fi Direct supported mobile device, set the Wi-Fi Direct Option (see "Setting up WiFi Direct" on page 131). 2. Using a network-connected machine 123 Wireless network setup · Network Name(SSID): The default Network Name is the model name and the maximum length is 22 characters (not including "Direct-xx-"). · Network Key is the numeric string, and the size is 8 ~ 64 characters. · Software CD that was provided with your machine A machine installed with a wireless network interface Creating the infrastructure network 17 18 When the wireless network settings are completed, disconnect the USB cable between the computer and machine. Wireless network set up is completed. After the installation is finished, click Quit. After completing the wireless network connection, you need to install a machine driver to print from an application (see "Installation for Macintosh" on page 83). Setting the access point using the WPS button For models that have a WPS button, you can set the wireless network using the WPS button (without a USB connection) and access point (or a router) WPS button. 1 2 3 4 5 6 7 8 9 Turn on your computer, access point, and machine.

Insert the supplied software CD into your CD-ROM drive. Double-click the CD-ROM icon that appears on your Macintosh desktop. Double-click the MAC_Installer folder > Installer OS X icon. Click Continue. Read the license agreement and click Continue. Click Agree to agree to the license agreement. When the message that warns that all applications will close on your computer appears, click Continue. Click the Wireless Network Setting button on the User Options Pane. Items to prepare · Access point (or wireless router) Network-connected computer 2. Using a network-connected machine 124 Wireless network setup 10 Select Using the WPS button and click Next.

12 Follow the instructions in the window to set up the wireless network. ·For models with a display screen, follow the steps below: aPress and hold the 2-4 seconds. (WPS) button on the control panel for about The machine waits up to 2 minutes for the WPS button on the access point (or a router) to be pressed. bPress the WPS (PBC) button on the access point (or wireless router). The messages are displayed on the display screen in the order below: -Connecting: The machine is connecting to the access point (or wireless router).

· For models that support the WPS button, the above window appears. · If your machine is connected with a USB cable, the above window does not appear. Disconnect the USB cable if you want to set up the wireless network using the WPS button. · If you want to set up the wireless network using the USB cable, refer to "Access point via USB cable" on page 120. -Connected: When the machine is successfully connected to the wireless network, the WPS LED light stays on.

11 The next window asks you to check if your access point (or wireless router) supports WPS or not. If the access point (or wireless router) has a WPS button, select Yes and click Next. 2. Using a network-connected machine 125 Wireless network setup -SSID Type: After completing the wireless network connection process, the AP's SSID information appears on the display.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

-For models without a display screen, follow the steps below: aPress and hold the (WPS) button on the control panel for about 2 - 4 seconds until the status LED blinks quickly. The machine starts connecting to the wireless network. The LED blinks slowly for up to two minutes until you press the PBC button on the access point (or wireless router). bPress the WPS (PBC) button on the access point (or wireless router). -The light blinks fast on the WPS LED. The machine is connecting to the access point (or wireless router).

-When the machine is successfully connected to the wireless network, the WPS LED light stays on. Ad hoc via USB cable If you do not have an access point (AP), you may still connect the machine wirelessly to your computer by setting up an ad hoc wireless network by following these simple directions. Items to prepare Network-connected computer Software CD that was provided with your machine A machine installed with a wireless network interface USB cable Creating the ad hoc network in Macintosh 13 Wireless network set up is completed. After installation is finished, click Quit. After completing the wireless network connection, you need to install a machine driver to print from an application (see "Setup using Macintosh" on page 120). 1 2 3 4 5 6 7 Check whether the USB cable is connected to the machine. Turn on your computer and the wireless network machine. Insert the supplied software CD into your CD-ROM drive. Double-click the CD-ROM icon that appears on your Macintosh desktop. Double-click the MAC_Installer folder > Installer OS X icon.

Click Continue. Read the license agreement and click Continue. 2. Using a network-connected machine 126 Wireless network setup 8 9 10 11 Click Agree to agree to the license agreement. When the message that warns that all applications will close on your computer appears, click Continue.

Click Wireless Network Setting button on the User Options Pane. The software searches for wireless network devices. · Authentication: Select an authentication type. Open System: Authentication is not used, and encryption may or may not be used, depending on the need for data security. Shared Key: Authentication is used.

A device that has a proper WEP key can access the network. · Encryption: Select the encryption (None, WEP64, WEP128). · Network Key: Enter the encryption network key value. · Confirm Network Key: Confirm the encryption network key value. If the search has failed, check if the USB cable is connected between the computer and machine properly, and follow the instructions in the window. · WEP Key Index: If you are using WEP Encryption, select the appropriate WEP Key Index. The wireless network security window appears when the ad hoc network has security setting. Select Open System or Shared Key for the authentication and click Next. · WEP (Wired Equivalent Privacy) is a security protocol preventing unauthorized access to your wireless network. WEP encrypts the data portion of each packet exchanged on a wireless network using a 64-bit or 128-bit WEP encryption key.

12 After searching the wireless networks, a list of wireless networks your machine has searched appears. If you want to use the Samsung default ad hoc setting, select the last wireless network on the list, which Network Name(SSID) is Portthru and Signal is Printer Self Network. Then, click Next. If you want to use other ad hoc settings, select another wireless network from the list. 13 The window showing the wireless network settings appears. Check the settings and click Next. If you want to change ad hoc settings, click the Advanced Setting button. · Enter the wireless Network Name: Enter the SSID name (SSID is casesensitive). · Operation Mode: Select ad hoc. · Channel: Select the channel (Auto Setting or 2412 MHz to 2467 MHz).

2. Using a network-connected machine 127 Wireless network setup Before entering the IP address for the machine, you must know the computer's network configuration information.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somanuals.com/dref/4128961)
<http://somanuals.com/dref/4128961>

If the computer's network configuration is set to DHCP, the wireless network setting should also be DHCP. Likewise, if the computer's network configuration is set to Static, the wireless network setting should also be Static. If your computer is set to DHCP and you want to use Static wireless network setting, you must contact the network administrator to get the static IP address.

· For the DHCP method If the IP address assignment method is DHCP, check if DHCP is shown in the Wireless Network Setting Confirm window. If it shows Static, click Change TCP/IP to change the assignment method to Receive IP address automatically (DHCP). · For the Static method If the IP address assignment method is Static, check if Static is shown in the Wireless Network Setting Confirm window. If it shows DHCP, click Change TCP/IP to enter the IP address and other network configuration values for the machine. For example, If the computer's network information is shown as follows: -IP address: 169.254.133.42 -Subnet Mask: 255.255.0.0 Then, the machine's network information should be as shown below: -IP address: 169.254.133.43 -Subnet Mask: 255.255.

0.0 (Use the computer's subnet mask.) -Gateway: 169.254.133.1 14 When the window that tells you that the network cable connection is confirmed appears, disconnect the network cable and click Next. If the network cable is connected, it may have trouble finding the machine when configuring the wireless network. 15 16 The wireless network connects according to the network configuration. Wireless network set up is completed. After installation is finished, click Quit.

After completing the wireless network connection, you need to install a machine driver to print from an application (see "Installation for Macintosh" on page 83). 18 Using a network cable Machines that do not support the network interface will not be able to use this feature (see "Rear view" on page 17). Your machine is a network compatible machine. To enable your machine to work with your network, you will need to perform some configuration procedures. 2. Using a network-connected machine 128 Wireless network setup · After completing the wireless network connection, you need to install a machine driver to print from an application (see "Installing driver over the network" on page 93). · See your network administrator, or the person that set up your wireless network, for information about your network configuration. IP setting using SetIP Program (Windows) This program is used to manually set the network IP address of your machine using its MAC address to communicate with the machine. The MAC address is the hardware serial number of the network interface and can be found in the Network Configuration Report. See "Setting IP address" on page 90.

Items to prepare Access point Network-connected computer Software CD that was provided with your machine A machine installed with a wireless network interface Network cable Configuring the machine's wireless network Before starting you will need to know the network name (SSID) of your wireless network and the network key if it is encrypted. This information was set when the access point (or wireless router) was installed. If you do not know about your wireless environment, please ask the person who set up your network. To configure wireless parameters, you can use SyncThru™ Web Service. Printing a network configuration report You can identify the network settings of your machine by printing a network configuration report. See "Printing a network configuration report" on page 90. Using SyncThru™ Web Service Before starting wireless parameter configuration, check the cable connection status. 2. Using a network-connected machine 129 Wireless network setup 1 2 Check whether or not the network cable is connected to the machine. If not, connect the machine with a standard network cable.

Start a web browser such as Internet Explorer, Safari, or Firefox and enter your machine's new IP address in the browser window.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

For example, 7 Select the one Network Name(SSID) in the list. ·SSID: SSID (Service Set Identifier) is a name that identifies a wireless network, access points, and wireless devices attempting to connect to a specific wireless network must use the same SSID. The SSID is case sensitive. ·Operation Mode: Operation Mode refers to the type of wireless connections (see "Wireless network name and network key" on page 104). ·Ad-hoc: Allows wireless devices to communicate directly with each other in a peer-to-peer environment. ·Infrastructure: Allows wireless devices to communicate with each other through an access point. 3 4 Click Login on the upper right of the SyncThru™ Web Service website. Type in the ID and Password then click Login. ·ID: admin ·Password: sec00000 5 6 When the SyncThru™ Web Service window opens, click Network Settings.

Click Wireless > Wizard. If your network's Operation Mode is Infrastructure, select the SSID of the access point. If the Operation Mode is Ad-hoc, select the machine's SSID. Note that "portthru" is the default SSID of your machine. 8 Wizard will help you setup the wireless network configuration.

However, if you want to set the wireless network directly, select Custom. Click Next. If the wireless security setting window appears, enter the registered password (network key) and click Next. 9 The confirmation window appears, please check your wireless setup. If the setup is right, click Apply.

2. Using a network-connected machine 130 Wireless network setup Disconnect the network cable (standard or network). Your machine should then start communicating wirelessly with the network. In case of Ad-hoc mode, you can use a wireless LAN and wired LAN simultaneously. 5 6 20 When the SyncThru™ Web Service window opens, click Network Settings. Click Wireless > Custom. You can also turn the Wi-Fi network on/off. 19 Turning the Wi-Fi network on/off Setting the Wi-Fi Direct for mobile printing Wi-Fi Direct is an easy-to-setup peer-to-peer connecting between method for your printer and a mobile device that provides a secure connection and better throughput than ad hoc mode. With Wi-Fi Direct, you can connect your printer to a Wi-Fi Direct network while concurrently connecting to an access point, You can also use a wired network and a Wi-Fi Direct network simultaneously so multiple users can access and print documents both from Wi-Fi Direct and from a wired network. If your machine has a display, you can also turn on/off the Wi-Fi from the machine's control panel using the Network menu.

1 2 Check whether the network cable is connected to the machine. If not, connect the machine with a standard network cable. Start a web browser such as Internet Explorer, Safari, or Firefox and enter your machine's new IP address in the browser window. For example, · You cannot connect to the internet through the printer's Wi-Fi Direct. · The supported protocol list may differ from your model, Wi-Fi Direct networks do NOT support IPv6, network filtering, IPSec, WINS, and SLP services. 3 4 Click Login on the upper right of the SyncThru™ Web Service website. Type in the ID and Password, then click Login.

·ID: admin ·Password: sec00000 You can enable Wi-Fi Direct feature by one of the following methods. 2. Using a network-connected machine Setting up Wi-Fi Direct 131 Wireless network setup From the USB cable-connected computer(recommended) · When setting from the supplied software CD, see the access point via USB cable.

·Windows user, see "Access point via USB cable" on page 111. ·Macintosh user, see "Access point via USB cable" on page 120. · After the driver installation is complete, Samsung Easy Printer Manager can be set and changes in the Wi-Fi Direct can be made. · · Group Owner: Activate this option to assign the printer the Wi-Fi Direct group's owner. The Group Owner acts similar to a wireless access point.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)

<http://somemanuals.com/dref/4128961>

We recommend activating this option. Network Key: If your printer is a Group Owner, a Network Key is required for other mobile devices to connect to your printer. You can configure a network key yourself, or can remember the given Network Key that is randomly generated by default. From the machine (Machines with a display screen) Samsung Easy Printer Manager is Available for Windows and Macintosh OS users only. Select Network > Wireless > Wi-Fi Direct from the control panel.

Enable Wi-Fi Direct. -From the Start menu, select Programs or All Programs > Samsung Printers > Samsung Easy Printer Manager > Device Settings > Network. Wi-Fi Direct On/Off: Select On to enable. Device Name: Enter the printer's name for searching for your printer on a wireless network. By default, the device name is the model name. IP Address: Enter the IP address of the printer. This IP address is used only for the local network and not for the infrastructure wired or wireless network. We recommend using the default local IP address (the default local IP address of the printer for Wi-Fi Direct is 192.168.3.

1) From the network-connected computer If your printer is using a network cable or a wireless access point, you can enable and configure Wi-Fi Direct from SyncThru™ Web Service. · Access SyncThru™ Web Service, select Settings > Network Settings > Wireless > Wi-Fi Direct. Enable or disable Wi-Fi Direct and set other options. · For Linux OS users, -Print an IP network configuration report to check the output (see "Printing a network configuration report" on page 90). 2. Using a network-connected machine 132 Wireless network setup -Access SyncThru Web Service, select Settings > Network Settings > Wireless > Wi-Fi Direct. -Enable or disable Wi-Fi Direct. 21 Troubleshooting Problems during setup or driver installation Setting up the mobile device Printers Not Found · After setting up Wi-Fi Direct from the printer, refer to the user manual of the mobile device you are using to set its Wi-Fi Direct. After setting up Wi-Fi Direct, you need to download the mobile printing application (For example: Samsung Mobile printer) to print from your smartphone. · · · · When you have found the printer you want to connect to from your mobile device, select the printer and the printer's LED will blink.

Press the WPS button on the printer and it will be connected to your mobile device. · If your mobile device does not support WPS, you need to enter the "Network Key" of a printer instead of pushing the WPS button. Your machine may not be turned on. Turn on your computer and the machine. USB cable is not connected between your computer and machine.

Connect the machine to your computer using the USB cable. The machine does not support wireless networking. Check the machine's user's guide included on the software CD supplied with your machine and prepare a wireless network machine. Connecting Failure - SSID Not Found · The machine is unable to find the network name (SSID) you have selected or entered. Check the network name (SSID) on your access point and try connecting again.

Your access point is not turned on. Turn on your access point. · 2. Using a network-connected machine 133 Wireless network setup Connecting Failure - Invalid Security · Security is not configured correctly. Check the configured security on your access point and machine. Subnet Mask: 255.255.0.0 Then the machine's network information should be as below: IP address: 169.254.

133.43 Subnet Mask: 255.255.0.0 (Use the computer's subnet mask.) Connecting Failure - General Connection Error · Your computer is not receiving a signal from your machine. Check the USB cable and your machine's power. Gateway: 169.254.133.

1 Other problems If problems occur while using the machine on a network, check the following: Connecting Failure - Connected Wired Network · Your machine is connected with a wired network cable.



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide
<http://somanuals.com/dref/4128961>

Remove the wired network cable from your machine. For information on the access point (or wireless router), refer to its own user's guide. PC Connection Error · The configured network address is unable to connect between your computer and machine. -For a DHCP network environment The receives the IP address automatically (DHCP) when computer is configured to DHCP.

-For a Static network environment The machine uses the static address when the computer is configured to static address. For example, If the computer's network information is as shown below: IP address: 169.254.133.42 2.

Using a network-connected machine · · Your computer, access point (or wireless router), or machine may not be turned on. Check the wireless reception around the machine. If the router is far from the machine or there is an obstacle, you might have difficulty receiving the signal. Cycle the power for the access point (or wireless router), machine, and computer. Sometimes cycling the power can recover network communication. · 134 Wireless network setup · Check whether firewall software (V3 or Norton) is blocking the communication. If the computer and the machine are connected on the same network and it cannot be found when searching, firewall software might be blocking the communication. Refer to the user's guide for the software to turn it off and try searching for the machine again. · · Check whether the machine's IP address is allocated correctly. You can check the IP address by printing the network configuration report.

Check whether the access point (or wireless router) has a configured security (password). If it has a password, refer to the access point (or wireless router) administrator. Check the machine's IP address. Reinstall the machine driver and change the settings to connect to the machine on the network. Due to the characteristics of DHCP, the allocated IP address could change if the machine is not used for a long time or if the access point has been reset. Register the product's MAC address when you configure the DHCP server on the access point (or wireless router). Then you can always use the IP address that is set with the MAC address. You can identify the Mac address of your machine by printing a network configuration report (see "Printing a network configuration report" on page 90). · Check the wireless environment. You might not be able to connect to the network in the infrastructure environment where you need to type in a user's information before connecting to the access point (or wireless router).

This machine only supports IEEE 802.11 b/g/n and Wi-Fi. Other wireless communication types (e.g., Bluetooth) are not supported.

· When using the ad hoc mode, in operating systems such as Windows Vista, you might need to set the wireless connection setting every time you use the wireless machine. You cannot use infrastructure mode and ad hoc mode at the same time for Samsung wireless network machines. The machine is within the range of the wireless network. The machine is located away from obstacles that could block the wireless signal. Remove any large metal objects between the access point (or wireless router) and the machine.

Make sure the machine and wireless access point (or wireless router) are not separated by poles, walls, or support columns containing metal or concrete. · The machine is located away from other electronic devices that may interfere with the wireless signal. Many devices can interfere with the wireless signal, including a microwave oven and some Bluetooth devices. · Whenever the configuration of your access point (or wireless router) changes, you must do the product's wireless network setup again. · · · · 2. Using a network-connected machine 135 Samsung MobilePrint 22 24 What is Samsung MobilePrint?

Samsung MobilePrint is a free application that enables users to print photos, documents, and web pages directly from your smartphone or tablet.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)

<http://somemanuals.com/dref/4128961>

Samsung MobilePrint is not only compatible with your Android, Windows and iOS smart phones but also with your iPod Touch and tablet PC. It connects your mobile device to a network connected Samsung printer or to a wireless printer through a Wi-Fi access point. Installing a new driver or configuring network settings isn't necessary just simply install the Samsung MobilePrint application, and it will automatically detect compatible Samsung printers. Besides printing photos, web pages, and PDFs, scanning is also supported.

If you have Samsung multifunction printer, scan any document into a JPG, PDF, or PNG format for quick and easy viewing on your mobile device. . . . 25 Supported Mobile OS Android OS 2.1 or higher iOS 4.0 or higher Windows Phone 7 or higher Supported devices . . . iOS 4.0 or higher: iPod Touch, iPhone, iPad Android 2.1 or higher: Galxy S, Galaxy S2, Galaxy Tab, and Android mobile devices Windows Phone 7 or higher: Samsung Focus, Omnia7, and OminaW, and Windows mobile devices 23 Downloading Samsung MobilePrint To download Samsung MobilePrint, go to the application store (Samsung Apps, Android Market, App Store, Marketplace) on your mobile device, and just search for "Samsung MobilePrint." You can also visit iTunes for Apple devices or Marketplace for Windows devices on your computer. 2. Using a network-connected machine 136 3. Special features This chapter explains special printing features.

· Altitude adjustment · Changing the default print settings · Setting your machine as a default machine · Using advanced print features · Using Direct Printing Utility (Windows only) · Using memory/hard drive features · Macintosh printing · Linux printing · Unix printing The procedures in this chapter are mainly based on Windows 7. 138 139 140 141 149 150 151 153 155 Altitude adjustment Print quality is affected by atmospheric pressure, which is determined by the height of the machine above sea level. The following information will guide you on how to set your machine for the best print quality. Before you set the altitude value, determine the altitude where you are. 4,000 m (13,123 ft) 1 3,000 m (9,842 ft) 2 2,000 m (6,561 ft) 1,000 m (3,280 ft) 3 4 0 1 2 3 4 High 3 High 2 High 1 Normal . . For Windows and Macintosh users, see "Device Settings" on page 165.

For Linux users, see "Using Smart Panel" on page 169. · If your machine is connected to the network, you can set the altitude via SyncThru™ Web Service. · You can also set the altitude in System Setup option on the machine's display. 3. Special features 138 Changing the default print settings 1 2 Click the Windows Start menu.

For Windows Server 2000, select Settings > Printers. · For Windows XP/Server 2003, select Printer and Faxes. · For Windows Server 2008/Vista, select Control Panel > Hardware and Sound > Printers. · For Windows 7, select Control Panel > Devices and Printers. · For Windows Server 2008 R2, select Control Panel > Hardware > Devices and Printers. If you want to change the settings for each print job, change it in Printing Preferences. 3 4 Right-click on your machine. For Windows XP/Server 2003/Server 2008/Vista, select Printing Preferences. For Windows 7 or Windows Server 2008 R2, from context menus, select Printing preferences. If Printing preferences has a ?, you can select other printer drivers connected to the selected printer.

5 6 Change the settings on each tab. Click OK. 3. Special features 139 Setting your machine as a default machine 1 2 Click the Windows Start menu. For Windows Server 2000, select Settings > Printers. · For Windows XP/Server 2003, select Printer and Faxes. · For Windows Server 2008/Vista, select Control Panel > Hardware and Sound > Printers. · For Windows 7, select Control Panel > Devices and Printers.



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide
<http://somemanuals.com/dref/4128961>

·For Windows Server 2008 R2, select Control Panel > Hardware > Devices and Printers. 3 4 Select your machine. Right-click your machine and select Set as Default Printer. For Windows 7 or Windows Server 2008 R2, if Set as default printer has a ?, you can select other printer drivers connected to the selected printer. 3. Special features 140 Using advanced print features XPS printer driver: used to print XPS file format. · See "Features by models" on page 6.

·The XPS printer driver can be installed only on Windows Vista OS or higher. · Install optional memory when an XPS job does not print because the printer is out of memory. · For models that provide XPS driver from the Samsung website, www.samsung.com > find your product > Support or Downloads.

1 Check the Print to file box in the Print window. 1 Printing to a file (PRN) You will sometimes need to save the print data as a file. 2 3 Click Print. Type in the destination path and the file name, and then click OK. For example, c:\Temp\file name. If you type in only the file name, the file is automatically saved in My Documents, Documents and Settings, or Users. The saved folder may differ, depending on your operating system or the application you are using. 3. Special features 141 Using advanced print features 2 Understanding special printer features You can use advanced printing features when using your machine. To take advantage of the printer features provided by your printer driver, click Properties or Preferences in the application's Print window to change the print settings.

The machine name, that appears in the printer properties window may differ depending on the machine in use. · Some menus may not appear on the display depending on options or models. If so, it is not applicable to your machine. · Select the Help or click the 36). button from the window or press F1 on your keyboard and click on any option you want to know about (see "Using help" on page Item Multiple Pages per Side Description Selects the number of pages to print on a single sheet of paper. To print more than one page per sheet, the pages will be reduced in size and arranged in the order you specify. You can print up to 16 pages on one sheet. 3. Special features 142 Using advanced print features Item Description Prints a single-page document onto 4 (Poster 2x2), 9 (Poster 3x3), or 16 (Poster 4x4) sheets of paper, for the purpose of pasting the sheets together to form one poster-size document. Select the Poster Overlap value.

Specify Poster Overlap in millimeters or inches by selecting the radio button on the upper right of Basic tab to make it easier to paste the sheets together. Poster Printing Prints your document on both sides of a sheet of paper and arranges the pages so that the paper can be folded in half after printing to produce a booklet. Booklet Printing 9 If you want to make a booklet, you need to print on Letter, Legal, A4, US Folio, or Oficio sized print media. 8 The Booklet Printing option is not available for all paper sizes. Select the available paper Size option under the Paper tab to see what paper sizes are available. If you select an unavailable paper size, this option can be automatically canceled. Select only available paper (paper without or mark). 3. Special features 143 Using advanced print features Item · Double-sided Printing a · Double-sided Printing (Manual) a · You can use this feature with Letter, Legal, A4, US Folio or Oficio sized paper · If your machine does not have a duplex unit, you should complete the printing job manually. The machine prints every other page of the document first.

After that, a message appears on your computer. · Skip Blank Pages feature does not work when you select the duplex option. · We recommend not to print on both sides of the special media, such as labels, envelopes, or thick paper. It may cause a paper jam or damage the machine.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Description Print on both sides of a sheet of paper (duplex). Before printing, decide how you want your document oriented. · Printer Default: If you select this option, this feature is determined by the settings you have selected on the control panel of the machine. This option is available only when you use the PCL / XPS printer driver (see "Features by models" on page 6). · None: Disables this feature. · Long Edge: This option is the conventional layout used in bookbinding.

· Short Edge: This option is the conventional layout used in calendars. · Reverse Double-Sided Printing: Check this option to reverse the print order when duplex printing. This option is not available when you use the Reverse Double-Sided Printing (Manual). 3. Special features 144 Using advanced print features Item Paper Options Description Changes the size of a document to appear larger or smaller on the printed page by entering in a percentage by which to enlarge or decrease the document. Watermark The watermark option allows you to print text over an existing document. For example, you use it when you want to have large gray letters reading "DRAFT" or "CONFIDENTIAL" printed diagonally across the first page or all pages of a document. Watermark (Creating a watermark) aTo change the print settings from your software application, access Printing Preferences. bClick the Advanced tab, select Edit from the Watermark drop-down list. The Edit Watermarks window appears.

cEnter a text message in the Watermark Message box. You can enter up to 256 characters. The message displays in the preview window. aTo change the print settings from your software application, access Printing Preferences. bClick the Advanced tab, select Edit from the Watermark drop-down list.

The Edit Watermarks window appears. cSelect the watermark you want to edit from the Current Watermarks list and change the watermark message and options. dClick Update to save the changes. eClick OK or Print until you exit the Print window. aTo change the print settings from your software application, access Printing Preferences.

bClick the Advanced tab, select Edit from the Watermark drop-down list. The Edit Watermarks window appears. cSelect the watermark you want to delete from the Current Watermarks list and click Delete. dClick OK or Print until you exit the Print window. Watermark (Editing a watermark) Watermark (Deleting a watermark) 3. Special features 145 Using advanced print features Item Description This option is available only when you use the PCL/SPL printer driver (see "Software" on page 6). An overlay is text and/or images stored in the computer hard disk drive (HDD) as a special file format that can be printed on any document. Overlays are often used to take the place of letterhead paper. Rather than using preprinted letterhead, you can create an overlay containing exactly the same information that is currently on your letterhead. To print a letter with your company's letterhead, you do not need to load preprinted letterhead paper in the machine: just print the letterhead overlay on your document.

To use a page overlay, you must create a new page overlay containing your logo or image. Overlaya · The overlay document size must be the same as the document you print with the overlay. Do not create an overlay with a watermark. · The resolution of the overlay document must be the same as that of the document you will print with the overlay. Overlay (Creating a new page overlay) aTo save the document as an overlay, access Printing Preferences. bClick the Advanced tab, and select Edit from the Text drop-down list. Edit Overlay window appears. cIn the Edit Overlay window, click Create. dIn the Save As window, type a name up to eight characters in the File name box. Select the destination path, if necessary (The default is C:\Formover). eClick Save. The name appears on the Overlay List. fClick OK or Print until you exit the Print window. The file is not printed.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somanuals.com/dref/4128961)
<http://somanuals.com/dref/4128961>

Instead, it is stored on your computer hard disk drive.

3. Special features 146 Using advanced print features Item Overlay (Using a page overlay) Description aClick the Advanced tab. bSelect the desired overlay from the Text drop-down list. cIf the overlay file you want does not appear in the Text drop-down list, select Edit. from the list and click Load. Select the overlay file you want to use. If you have stored the overlay file you want to use in an external source, you can also load the file when you access the Open window. After you select the file, click Open. The file appears in the Overlay List box and is available for printing. Select the overlay from the Overlay List box. dIf necessary, check Confirm Page Overlay When Printing box. If this box is checked, a message window appears each time you submit a document for printing, asking you to confirm printing an overlay on your document. If this box is not checked and an overlay has been selected, the overlay automatically prints with your document. eClick OK or Print until you exit the Print window. aIn the Printing Preferences window, click the Advanced tab.

bSelect Edit in the Text drop down list. cSelect the overlay you want to delete from the Overlay List box. dClick Delete. eWhen a confirming message window appears, click Yes. fClick OK or Print until you exit the Print window. You can delete page overlays that you no longer use. Overlay (Deleting a page overlay)

3. Special features 147 Using advanced print features Item Description · This feature is available only if you have installed the optional memory or mass storage device (HDD). · Some menus may not appear on the display depending on options or models. If so, it is not applicable to your machine.

· Print Mode: The default Print Mode is Normal, which is for printing without saving the printing file in the memory. - Normal: This mode prints without storing your document in the optional memory. - Proof: This mode is useful when you print more than one copy. You can print one copy first to check, then print the rest of the copies later. - Confidential: This mode is used for printing confidential documents.

You need to enter a password to print. - Store: Select this setting to save a document in the hard disk without printing. - Store and Print: This mode is used when printing and storing document at the same time. - Spool: This option can be useful when handling large amounts of data. If you select this setting, the printer spools the document into the hard disk and then prints it from the hard disk queue, decreasing the computer's work load.

- Print Schedule: Select this setting to print the document at a specified time. · User ID: This option is used when you need to find a saved file using the control panel. · Job Name: This option is used when you need to find a saved file using the control panel. a. This option is not available when you use XPS driver. Print Mode 3. Special features 148 Using Direct Printing Utility (Windows only) 3 What is Direct Printing Utility? Direct Printing Utility is a

program that sends PDF files directly to your machine to print without having to opening the file. To install this program, select Advanced Installation > Custom Installation and put a check mark in this program when you install the printer driver. 1 2 3 4 5 5 From the Start menu select Programs or All

Programs > Samsung Printers > Direct Printing Utility > Direct Printing Utility. The Direct Printing Utility window appears.

Select your machine from the Select Printer drop-down list and click Browse. Select the file you wish to print and click Open. The file is added in the Select Files section. · Mass storage device (HDD) should be installed on your machine, to print files using this program. · You cannot print PDF files that are restricted. Deactivate the printing restriction feature and retry printing. · You cannot print PDF files that are restricted by a password.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)

<http://somenmanuals.com/dref/4128961>

Deactivate the password feature, and retry printing. · Whether or not a PDF file can be printed using the Direct Printing Utility program depends on how the PDF file was created. · The Direct Printing Utility program supports PDF version 1.

7 and below. For higher versions, you must open the file to print it. Customize the machine settings for your needs. Click Print. The selected PDF file is sent to the machine.

Using the right-click menu 1 2 3 4 Right-click on the PDF file to print and select Direct Printing. The Direct Printing Utility window appears with the PDF file is added. Select the machine to use. Customize the machine settings. Click Print.

The selected PDF file is sent to the machine. 4 Printing There are several ways you can print using the Direct Printing Utility. 3. Special features 149 Using memory/hard drive features · Some menus may not appear on the display depending on options or models. If so, it is not applicable to your machine. Held Job

Timeout: The machine can automatically delete a stored job after a certain period of time. You can set the time the machine will wait before deleting the stored job. Image Overwrite: Image Overwrite is a security measure for customers who are concerned about unauthorized access and duplication of classified or private document. · 6 From the printer driver After installing the optional memory, you can use advanced printing features, such as proofing a job and specifying of printing a private job in the Print window. Select Properties or Preference, and configure the printing mode.

After installing the hard drive, you can also print the predefined document templates from the Form Menu. 7 From the control panel If your machine has optional memory or an optional hard drive, you can use these features from the Job Management menu. · Active Job: All of the print jobs waiting to be printed are listed in the active job queue in the order you sent them to the printer. You can delete a job from the queue before printing, or promote a job to print sooner. File Policy: You can choose the file policy for generating file name before you proceed with the job through optional memory. If the optional memory already has the same name when you entered a new file name, you can rename or overwrite it. Stored Job: You can print or delete a stored job. · · 3. Special features 150 Macintosh printing 9 Some features may not be available depending on models or options. It means that the features are not supported.

Changing printer settings You can use advanced printing features when using your machine. 8 Printing a document When you print with a Macintosh, you need to check the printer driver settings in each application you use. Follow the steps below to print from a Macintosh: Open an application and select Print from the File menu. The machine name, which appears in the printer properties window, may differ depending on the machine in use. Except for the name, the composition of the printer properties window is similar to the following.

10 1 2 3 4 5 6 Open the document to print. Open the File menu and click Page Setup (Document Setup in some applications). Choose your paper size, orientation, scaling, other options, and make sure that your machine is selected. Click OK. Open the File menu and click Print.

Choose the number of copies and indicate which pages to print. Click Print. Printing multiple pages on one sheet You can print more than one page on a single sheet of paper. This feature provides a cost-effective way to print draft copies. 1 2 3 4 Open an application, and select Print from the File menu. Select Layout from the drop-down list under Orientation. In the Pages per Sheet drop-down list, select the number of pages you want to print on one sheet of paper. Select the other options to use. Click Print. The machine prints the selected number of pages to print on one sheet of paper.

3. Special features 151 Macintosh printing 11 Printing on both sides of the paper If you print more than 2 copies, the first copy and the second copy might print on the same sheet of paper.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)
<http://somenmanuals.com/dref/4128961>

Avoid printing on both sides of paper when you are printing more than 1 copy. Some features may not be available depending on models or options. It means that the features are not supported. 12 Using help Before printing in the duplex mode, decide on which edge you will be binding your finished document. The binding options are, as follows: · Long-Edge Binding: This option is the conventional layout used in book binding. Short-Edge Binding: This option is the type often used with calendars. Click the question mark on the bottom-left corner of the window and click on the topic you want to know about. A pop-up window appears with information about that option's feature, which is provided from the driver.

1 2 3 4 5 From your Macintosh application, select Print from the File menu. Select Layout from the drop-down list under Orientation. Select a binding orientation from the Two-Sided option. Select the other options to use. Click Print and the machine prints on both sides of the paper.

3. Special features 152 Linux printing Some features may not be available depending on models or options. It means that the features are not supported. 4 Change the print job properties using the following four tabs displayed at the top of the window. ·General: Changes the paper size, the paper type, and the orientation of the documents.

It enables the duplex feature, adds start and end banners, and changes the number of pages per sheet. 13 Printing from applications There are a lot of Linux applications that allow you to print using Common UNIX Printing System (CUPS). You can print on your machine from any such application.

Automatic/manual duplex printing may not be available depending on models. You can alternatively use the lpr printing system or other applications for odd-even printing. ·Text: Specifies the page margins and set the text options, such as spacing or columns. ·Graphics: Sets image options that are used when printing image files, such as color options, image size, or image position. ·Advanced: Sets the print resolution, paper source, and destination. 1 2 3 Open an application, and select Print from the File menu Select Print directly using lpr. In the LPR GUI window, select the model name of your machine from the printer list and click Properties.

5 6 7 Click Apply to apply the changes and close the Properties window. Click OK in the LPR GUI window to start printing. The Printing window appears, allowing you to monitor the status of your print job. To abort the current job, click Cancel. 3. Special features 153 Linux printing 14 Printing files You can print many different types of files on your machine using the standard CUPS, directly from the command line interface. The CUPS lpr utility allows you to do that, but the driver's package replaces the standard lpr tool by a much more user-friendly LPR GUI program. To print any document file: 1 2 3 Open the Unified Driver Configurator. If necessary, switch to Printers configuration. Select your machine on the available printers list and click Properties.

The Printer Properties window appears. The following five tabs display at the top of the window: ·General: Allows you to change the printer location and name. The name entered in this tab displays on the printer list in Printers configuration. ·Connection: Allows you to view or select another port. If you change the machine port from USB to parallel or vice versa while in use, you must re-configure the machine port in this tab.

·Driver: Allows you to view or select another machine driver. By clicking Options, you can set the default device options. ·Jobs: Shows the list of print jobs. Click Cancel job to cancel the selected job and select the Show completed jobs check box to see previous jobs on the job list. ·Classes: Shows the class that your machine is in.

Click Add to Class to add your machine to a specific class or click Remove from Class to remove the machine from the selected class.



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide

<http://somemanuals.com/dref/4128961>

1 Enter `lpr <file_name>` from the Linux shell command line and press Enter. The LPR GUI window appears. When you type only `lpr` and press Enter, the Select file(s) to print window appears first. Just select any files you want to print and click Open. 2 3 15 In the LPR GUI window, select your machine from the list, and change the print job properties. Click OK to start printing. Configuring Printer Properties Using the Printer Properties window provided by the Printers configuration, you can change the various properties for your machine as a printer. 4 Click OK to apply the changes and close the Printer Properties window. 3.

Special features 154 Unix printing Some features may not be available depending on models or options. It means that the features are not supported. 5 17 Press OK to start the print job. Changing the machine settings 16 Proceeding the print job After installing the printer, choose any of the image, text, PS or HPGL files to print. The UNIX printer driver Print Job Manager in which the user can select various print options in printer Properties. The following hot keys may also be used: "H" for Help, "O" for OK, "A" for Apply, and "C" for Cancel. 1 Execute "`printui <file_name_to_print>`" command. For example, if you are printing "document1" `printui document1` This will open the UNIX Printer Driver Print Job Manager in which the user can select various print options. General tab Paper Size: Set the paper size as A4, Letter, or other paper sizes, according to your requirements. Paper Type: Choose the type of the paper.

Options available in the list box are Printer Default, Plain, and Thick. Paper Source: Select from which tray the paper is used. By default, it is Auto Selection. Orientation: Select the direction in which information is printed on a page. Duplex: Print on both sides of paper to save paper.

2 3 4 Select a printer that has been already added. Select the printing options from the window such as Page Selection. Select how many copies are needed in Number of Copies. To take advantage of the printer features provided by your printer driver, press Properties (see "Changing printer settings" on page 151). 3.

Special features 155 Unix printing Margins tab Automatic/manual duplex printing may not be available depending on models. You can alternatively use the `lpr` printing system or other applications for odd-even printing. . . . Multiple pages: Print several pages on one side of the paper. Page Border: Choose any of the border styles (e.g., Single-line hairline, Double-line hairline) . Use Margins: Set the margins for the document. By default, margins are not enabled. The user can change the margin settings by changing the values in the respective fields. Set by default, these values depend on the page size selected. Unit: Change the units to points, inches, or centimeters.

Printer-Specific Settings tab Image tab In this tab, you can change the brightness, resolution, or image position of your document. Select various options in the JCL and General frames to customize various settings. These options are specific to the printer and depend on the PPD file. Text tab Set the character margin, line space, or the columns of the actual print output. HPGL/2 tab . . Use only black pen: To print all graphics in black. Fit plot to page: Fit the entire graphic into a single page. 3. Special features 156 4. Useful management tools This chapter introduces management tools provided to help you make full use of your machine. . Samsung AnyWeb Print . Easy Eco Driver . Using SyncThru™ Web Service . Using Samsung Easy Printer Manager . Using Samsung Printer Status . Using Smart Panel . Using the Linux Unified Driver Configurator 158 159 161 164 167 169 171 Samsung AnyWeb Print Available for Windows and Macintosh OS users only.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

This tool helps you screen-capture, preview, scrap, and print pages more easily, than when you use an ordinary program. To open the Program: · · For Windows: Select Start > All Programs > Samsung Printers > Samsung AnyWeb Print > Download the latest version. For Macintosh: Open the Applications folder > Samsung folder > Samsung AnyWeb Print. 4. Useful management tools 158 Easy Eco Driver With the Easy Eco Driver, you can apply Eco features to save paper and toner before printing.

To use this application, Start Easy Eco Driver before printing job checkbox in the printer properties should be checked. Easy Eco Driver also allows you simple editing such as removing images and texts, changing fonts, and more. You can save frequently used settings as a preset. Available for Windows OS users only. How to use: 1 Open a document to print.

2 Print the document. A preview window appears. 3 Select the options you want to apply to the document. You can see the preview of the applied features. 4

Click Print. 4. Useful management tools 159 Understanding Easy Capture Manager Capture your screen and launch Easy Capture Manager by simply pressing the Print Screen key on the keyboard. Now you can easily print your captured screen as captured or edited. 4. Useful management tools 160 Using SyncThruTM Web Service · Internet Explorer 6.

0 or higher is the minimum requirement for SyncThruTM Web Service. · SyncThruTM Web Service explanation in this user's guide may differ from your machine depending on its options or models. · Network model only. 2 1 2 Click Login on the upper right of the SyncThruTM Web Service website. Type in the ID and Password then click Login. ·ID: admin ·Password: sec00000 1 SyncThruTM Web Service overview Accessing SyncThruTM Web Service 1 2 Access a web browser, such as Internet Explorer, from Windows. Enter the machine IP address of your printer (http://xxx.xxx.xxx.xxx) in the address field and press the Enter key or click Go.

Your machine's embedded website opens. Some tabs may not appear depending on your model. Logging into SyncThruTM Web Service Before configuring options in SyncThruTM Web Service, you need to log-in as an administrator. You can still use SyncThruTM Web Service without logging in but you won't have access to Settings tab and Security tab. Information tab This tab gives you general information about your machine.

You can check things, such as remaining amount of toner. You can also print reports, such as an error report. · · Active Alerts: Shows the alerts that have occurred in the machine and their severity. Supplies: Shows how many pages are printed and amount of toner left in the cartridge. 4.

Useful management tools 161 Using SyncThruTM Web Service · · · Usage Counters: Shows the usage count by print types: simplex and duplex. Current Settings: Shows the machine's and network's information. Print information: Prints reports such as system related reports and font reports. Maintenance tab This tab allows you to maintain your machine by upgrading firmware and setting contact information for sending emails. You can also connect to Samsung website or download drivers by selecting the Link menu. · Firmware Upgrade: Upgrade your machine's firmware. Contact Information: Shows the contact information. Link: Shows links to useful sites where you can download or check information. Settings tab This tab allows you to set configurations provided by your machine and network. You need to log-in as an administrator to view this tab.

· · 3 · · Machine Settings tab: Sets options provided by your machine. Network Settings tab: Shows options for the network environment. Sets options such as TCP/IP and network protocols. E-mail notification setup You can receive emails about your machine's status by setting this option. By setting information such as IP address, host name, e-mail address and SMTP server information, the machine status (toner cartridge shortage or machine error) will be sent to a certain person's e-mail automatically.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

This option may be used more frequently by a machine administrator. Security tab This tab allows you to set system and network security information. You need to log-in as an administrator to view this tab. · System Security: Sets the system administrator's information and also enables or disables machine features. Network Security: Sets settings for HTTPs, IPsec, IPv4/IPv6 filtering, and 802.

1x. 1 2 3 Start a web browser, such as Internet Explorer, from Windows. Enter the machine IP address (http://xxx.xxx.xxx.xxx) in the address field and press the Enter key or click Go. Your machine's embedded website opens. From the Settings tab, select Machine Settings > E-mail Notification. 4. Useful management tools 162 Using SyncThru™ Web Service If you have not configured outgoing server environment, go to Settings > Network Settings > Outgoing Mail Server(SMTP) to configure network environment before setting e-mail notification. 1 2 3 4 5 Start a web browser, such as Internet Explorer, from Windows. Enter the machine IP address (http://xxx.xxx.xxx.xxx) in the address field and press the Enter key or click Go. Your machine's embedded website opens. From the Security tab, select System Security > System Administrator Enter the name of the administrator, phone number, location, and email address. Click Apply. 4 5 6 Select Enable check box to use the E-mail Notification. Click Add button to add e-mail notification user.

Set the recipient name and e-mail address(es) with notification items you want to receive an alert for. Click Apply. If the firewall is activated, the e-mail may not be sent successfully. In that case, contact the a network administrator. 4 Setting the system administrator's information This setting is necessary for using the e-mail notification option. 4. Useful management tools 163 Using Samsung Easy Printer Manager Samsung Easy Printer Manager is an application that combines Samsung machine settings into one location. Samsung Easy Printer Manager combines device settings as well as printing environments, settings/actions and launching. All of these features provide a gateway to conveniently use your Samsung machine. Samsung Easy Printer Manager provides two different user interfaces for the user to choose from: the basic user interface and the advanced user interface.

Switching between the two interfaces is easy: just click button. The Samsung Easy Printer Manager interface is comprised of various basic sections as described in the table that follows: The screenshot may differ depending on operating system you are using. · Available for Windows or Macintosh OS users only. · For Windows, Internet Explorer 6.0 or higher is the minimum requirement for Samsung Easy Printer Manager.

5 Understanding Samsung Easy Printer Manager To open the program: For Windows, Select Start > Programs or All Programs > Samsung Printers > Samsung Easy Printer Manager > Samsung Easy Printer Manager. For Macintosh, Open the Applications folder > Samsung folder > Samsung Easy Printer Manager. 1 Printer List The printer list displays the installed printer icons on your computer. 4. Useful management tools 164 Using Samsung Easy Printer Manager Printer Information This area gives you general information about your machine.

You can check information, such as the machine's model name, IP address (or Port name), and machine status. Contents Area 5 Displays information about the selected machine, remaining toner level, and paper. The information will vary based on the machine selected. Some machines do not have this feature. 2 User's Guide button: This button opens Troubleshooting Guide when an error occurs. You can directly open the necessary section in the user's guide. 6 Order Supplies Click on the Order button from the supply ordering window. You can order replacement toner cartridge(s) from online. Click the Help () button from the upper-right corner of the window and click on any option you want to know about.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Application information 3 The button is used to change the user interface to the advanced settings user interface.

Includes links for changing to the advanced settings, preference, help, and about. 6 Advanced settings user interface overview The advanced user interface is intended to be used by the person responsible for managing the network and machines. Quick links Displays Quick links to machine specific functions. This section also includes links to applications in the advanced settings. Device Settings You can configure various machine settings such as machine setup, paper, layout, emulation, network, and print information. 4 If you connect your machine to a network, the SyncThru™ Web Service icon is enabled. 4. Useful management tools 165 Using Samsung Easy Printer Manager Alert Settings (Windows only) This menu includes settings related to error alerting. . . .

Printer Alert: Provides settings related to when alerts will be received. Email Alert: Provides options relating to receiving alerts via email.

History Alert: Provides a history of device and toner related alerts. Job Accounting Provides querying of quota information of the specified job accounting user. This quota information can be created and applied to devices by job accounting software such as SyncThru™ or CounThru™ admin software. 4.

Useful management tools 166 Using Samsung Printer Status The Samsung Printer Status is a program that monitors and informs you of the machine status. Icon Mean Normal · Available for Windows users. · The Samsung Printer Status window and its contents shown in this user's guide may differ depending on the machine or operating system in use. · Check the operating system(s) that are compatible with your machine (see "System requirements" on page 64).

Warning Description The machine is in ready mode and experiencing no errors or warnings. The machine is in a state where an error might occur in the future.

For example, it might be in toner low status, which may lead to toner empty status. The machine has at least one error. Error 7 Samsung Printer Status overview If an error occurs while operating, you can check the error from the Samsung Printer Status. Samsung Printer Status is installed automatically when you install the machine software. You can also launch Samsung Printer Status manually. Go to the Printing Preferences , click the Basic tab > Printer Status button. These icons appear on the Windows task bar: 1 Toner Level You can view the level of toner remaining in each toner cartridge. The machine and the number of toner cartridge(s) shown in the above window may differ depending on the machine in use. Some machines do not have this feature. You can set Printing Job Alert related settings.

2 Option 4. Useful management tools 167 Using Samsung Printer Status 3 Order Supplies You can order replacement toner cartridge(s) from online. You can directly open the troubleshooting section in the user's guide. Close the window. 4 5 Troubleshooting Close 4. Useful management tools 168 Using Smart Panel Smart Panel is a program that monitors and informs you of the machine's status, and allows you to customize the machine's settings. You can download Smart Panel from the Samsung website (see "Installing the Smart Panel" on page 85). 1 · Available for Linux OS users only. · The Smart Panel window and its contents shown in this user's guide may differ depending on the machine or operating system in use. · Check the operating system(s) that are compatible with your machine (see "Installing the driver locally" on page 21).

2 Buy Now Toner Level You can view the level of toner remaining in each toner cartridge. The machine and the number of toner cartridge(s) shown in the above window may differ depending on the machine in use. If you cannot see this feature, it is not applicable to your machine. You can order replacement toner cartridge(s) from online.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

You can view the online User's Guide.

User's Guide 8 3 Smart Panel overview If an error occurs while operating, you can check the error from the Smart Panel. You can also launch Smart Panel manually. Double-click the Smart Panel icon() in the Notification Area. 4 2 3 4 1 This button opens the Troubleshooting Guide when an error occurs. You can directly open the troubleshooting section in the user's guide.

Printer Setting You can configure various machine settings in the Printer Settings Utility window. Some machines do not have this feature. If you connect your machine to a network, the SyncThru™ Web Service icon is enabled. 4. Useful management tools 169 Using Smart Panel 9 Changing Smart Panel 's settings

Right-click on the Smart Panel icon and select Configure Smart Panel. Select the settings you want from the Configure Smart Panel window. 4. Useful management tools 170 Using the Linux Unified Driver Configurator The Unified Driver Configurator is a tool primarily intended for configuring machine devices. You need to install Unified Linux Driver to use Unified Driver Configurator (see "Installation for Linux" on page 85). After the driver is installed on your Linux system, the Unified Driver Configurator icon will automatically be created on your desktop.

10 Opening Unified Driver Configurator 1 2 Double-click the Unified Driver Configurator on the desktop. You can also click the Startup Menu icon and select Samsung Unified Driver > Unified Driver Configurator. Click each button on the left to switch to the corresponding configuration window. To use the on screen help, click Help. 1 Printer Configuration 2 Port Configuration 3 11 After changing the configurations, click Exit to close the Unified Driver Configurator. Printers configuration Printers configuration has the two tabs: Printers and Classes. 4. Useful management tools 171 Using the Linux Unified Driver Configurator Printers tab View the current system's printer configuration by clicking on the machine icon button on the left side of the Unified Driver Configurator window. . . . Set as Default: Sets the current selected machine as a default machine. Stop/Start: Stops/starts the machine.

Test: Allows you to print a test page to ensure the machine is working properly. Properties: Allows you to view and change the printer's properties. Classes tab The Classes tab shows a list of available machine classes. 1 1 2 3 Switches to Printers configuration. Shows all of the installed machines.

Shows the status, model name, and URI of your machine. 2 The printer control buttons are, as follows: . . . Refresh: Renews the available machines list. Add Printer: Allows you to add a new machines. Remove Printer: Removes the selected machine. 4.

Useful management tools 172 Using the Linux Unified Driver Configurator 1 2 Shows all of the machine classes. Shows the status of the class and the number of machines in the class. 1 2 3 Switches to Ports configuration. Shows all of the available ports. Shows the port type, device connected to the port, and status. . . 12 Refresh: Renews the classes list. Add Class: Allows you to add a new machine class. Remove Class: Removes the selected machine class. . . Refresh:

Renews the available ports list. Release port: Releases the selected port.

Ports configuration In this window, you can view the list of available ports, check the status of each port and release a port that is stalled in a busy state when its owner has terminated the job for any reason. 2 1 3 4. Useful management tools 173 5. Troubleshooting This chapter gives helpful information for what to do if you encounter an error. . Paper feeding problems . Power and cable connecting problems . Printing problems . Printing quality problems . Operating system problems 175 176 177 181 189 Paper feeding problems Condition Paper jams during printing.



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide

<http://somemanuals.com/dref/4128961>

Paper sticks together. Clear the paper jam. · Check the maximum paper capacity of the tray . · Make sure that you are using the correct type of paper. · Remove paper from the tray and flex or fan the paper.

- Humid conditions may cause some paper to stick together. Multiple sheets of paper do not feed. Paper does not feed into the machine. Different types of paper may be stacked in the tray. Load paper of only one type, size, and weight.*
- Remove any obstructions from inside the machine. · Paper has not been loaded correctly. Remove paper from the tray and reload it correctly. · There is too much paper in the tray. Remove excess paper from the tray.*
- The paper is too thick. Use only paper that meets the specifications required by the machine. The paper keeps jamming. · There is too much paper in the tray. Remove excess paper from the tray. If you are printing on special materials, feed manually in the tray. · An incorrect type of paper is being used. Use only paper that meets the specifications required by the machine. · There may be debris inside the machine. Open the top cover and remove any debris.*

Envelopes skew or fail to feed correctly. Ensure that the paper guides are against both sides of the envelopes. Suggested solutions 5. Troubleshooting 175 Power and cable connecting problems Condition The machine is not receiving power, or the connection cable between the computer and the machine is not connected properly. · Connect the machine to the electricity supply first and press the · Disconnect the machine's cable and reconnect it. (Power) button on the control panel. Suggested solutions 5. Troubleshooting 176 Printing problems Condition The machine does not print. Possible cause The machine is not receiving power. The machine is not selected as the default machine.

Check the machine for the following: · The top cover is not closed. Close the top cover. · Paper is jammed. Clear the paper jam (see "Clearing paper jams" on page 52). · No paper is loaded.

Load paper (see "Loading paper in the tray" on page 26). · The toner cartridge is not installed. Install the toner cartridge (see "Replacing the toner cartridge" on page 44). · Make sure the protect cover and sheets are removed from the toner cartridge (see "Replacing the toner cartridge" on page 44). If a system error occurs, contact your service representative.

The connection cable between the computer and the machine is not connected properly. The connection cable between the computer and the machine is defective. The port setting is incorrect. Disconnect the machine cable and reconnect it (see "Rear view" on page 17). Suggested solutions Check the power cord connections. Check the power switch and the power source. Select your machine as your default machine in Windows. If possible, attach the cable to another computer that is working properly and print a job. You can also try using a different machine cable. Check the Windows printer settings to make sure that the print job is sent to the correct port.

If the computer has more than one port, make sure that the machine is attached to the correct one. Check the Printing Preferences to ensure that all of the print settings are correct. The machine may be configured incorrectly. 5. Troubleshooting 177 Printing problems Condition The machine does not print. Possible cause The printer driver may be incorrectly installed. The machine is malfunctioning. Suggested solutions Uninstall and reinstall the machine's driver. Check the display message on the control panel to see if the machine is indicating a system error. Contact a service representative.

Get more hard disk space and print the document again. The document size is so big that the hard disk space of the computer is insufficient to access the print job. The output tray is full. The machine selects print materials from the wrong paper source. The paper option that was selected in the Printing Preferences may be incorrect.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Once the paper is removed from the output tray, the machine resumes printing. For many software applications, the paper source selection is found under the Paper tab within the Printing Preferences (see "Opening printing preferences" on page 35). Select the correct paper source. See the printer driver help screen (see "Using help" on page 36). Reduce the complexity of the page or try adjusting the print quality settings.

A print job is extremely slow. Half the page is blank. The job may be very complex. The page orientation setting may be incorrect. Change the page orientation in your application (see "Opening printing preferences" on page 35). See the printer driver help screen (see "Using help" on page 36). Ensure that the paper size in the printer driver settings matches the paper in the tray. Or, ensure that the paper size in the printer driver settings matches the paper selection in the software application settings you use (see "Opening printing preferences" on page 35). The paper size and the paper size settings do not match. 5.

Troubleshooting 178 Printing problems Condition The machine prints, but the text is wrong, garbled, or incomplete. Possible cause The machine cable is loose or defective. Suggested solutions Disconnect the machine cable and reconnect. Try a print job that you have already printed successfully. If possible, attach the cable and the machine to another computer that you know works and try a print job. Finally, try a new machine cable. Check the application's printer selection menu to ensure that your machine is selected. Try printing a job from another application. Exit Windows and reboot the computer. Turn the machine off and back on again.

Redistribute the toner, if necessary. If necessary, replace the toner cartridge. · See "Redistributing toner" on page 43. · See "Replacing the toner cartridge" on page 44. The file may have blank pages.

Some parts, such as the controller or the board, may be defective. The machine does not print PDF files correctly. Some parts of graphics, text, or illustrations are missing. Incompatibility between the PDF file and the Acrobat products. Check the file to ensure that it does not contain blank pages. Contact a service representative. The wrong printer driver was selected. The software application is malfunctioning. The operating system is malfunctioning. Pages print, but they are blank. The toner cartridge is defective or out of toner. Printing the PDF file as an image may enable the file to print. Turn on Print As Image from the Acrobat printing options. It will take longer to print when you print a PDF file as an image. The print quality of photos is not good.

Images are not clear. The resolution of the photo is very low. Reduce the photo size. If you increase the photo size in the software application, the resolution will be reduced. 5. Troubleshooting 179 Printing problems Condition Before printing, the machine emits vapor near the output tray. The machine does not print special-sized paper, such as billing paper. The printed billing paper is curled. Possible cause Using damp paper can cause vapor during printing.

Suggested solutions This is not a problem.

Just keep printing. Paper size and paper size setting do not match. Set the correct paper size in the Custom in Paper tab in Printing Preferences (see "Opening printing preferences" on page 35). The paper type setting does not match. Change the printer option and try again.

Go to Printing Preferences, click Paper tab, and set type to Thick (see "Opening printing preferences" on page 35). 5. Troubleshooting 180 Printing quality problems If the inside of the machine is dirty or paper has been loaded improperly, there might be a reduction in print quality. See the table below to clear the problem. Condition Light or faded print Suggested Solutions · If a vertical white streak or faded area appears on the page, the toner supply is low.

Install a new toner cartridge (see "Replacing the toner cartridge" on page 44).



You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide
<http://somemanuals.com/dref/4128961>

· The paper may not meet paper specifications; for example, the paper may be too moist or rough. · If the entire page is light, the print resolution setting is too low or the toner save mode is on. Adjust the print resolution and turn the toner save mode off. See the help screen of the printer driver. · A combination of faded or smeared defects may indicate that the toner cartridge needs cleaning. Clean the inside of your machine (see "Cleaning the machine" on page 46). · The surface of the LSU part inside the machine may be dirty. Clean the inside of your machine (see "Cleaning the machine" on page 46). If these steps do not correct the problem, contact a service representative.

The top half of the paper is printed lighter than the rest of the paper The toner might not adhere properly to this type of paper. · Change the printer option and try again. Go to Printing Preferences, click the Paper tab, and set the paper type to Recycled (see "Opening printing preferences" on page 35). 5.

Troubleshooting 181 Printing quality problems Condition Toner specks Suggested Solutions · The paper may not meet specifications; for example, the paper may be too moist or rough. · The transfer roller may be dirty. Clean the inside of your machine (see "Cleaning the machine" on page 46). · The paper path may need cleaning. Contact a service representative (see "Cleaning the machine" on page 46). Aa b c BC Aa b c BC Aa b c BC Aa b c BC Aa b c BC

Dropouts If faded areas, generally rounded, occur randomly on the page: · A single sheet of paper may be defective.

Try reprinting the job. A aBb C A aBb C A aBb C A aBb C A aBb C White Spots · The moisture content of the paper is uneven or the paper has moist spots on its surface. Try a different brand of paper. · The paper lot is bad. The manufacturing processes can cause some areas to reject toner.

Try a different kind or brand of paper. · Change the printer option and try again. Go to Printing Preferences, click the Paper tab, and set type to Thick or Thicker (see "Opening printing preferences" on page 35). If these steps do not correct the problem, contact a service representative. If white spots appear on the page: · The paper is too rough and a lot of dirt from paper falls to the inner components within the machine, so the transfer roller may be dirty.

Clean the inside of your machine (see "Cleaning the machine" on page 46). · The paper path may need cleaning. Clean the inside of your machine (see "Cleaning the machine" on page 46). If these steps do not correct the problem, contact a service representative. 5. Troubleshooting 182 Printing quality problems Condition Vertical lines If black vertical streaks appear on the page: · The surface (drum part) of the toner cartridge inside the machine has probably been scratched. Remove the toner cartridge and install a new one (see "Replacing the toner cartridge" on page 44). If white vertical streaks appear on the page: · The surface of the LSU part inside the machine may be dirty. Clean the inside of your machine (see "Cleaning the machine" on page 46). If these steps do not correct the problem, contact a service representative.

Black background If the amount of background shading becomes unacceptable: · Change to a lighter weight paper. · Check the environmental conditions: very dry conditions or a high level of humidity (higher than 80% RH) can increase the amount of background shading. · Remove the old toner cartridge and install a new one (see "Replacing the toner cartridge" on page 44). · Thoroughly redistribute the toner (see "Redistributing toner" on page 43). Toner smear · Clean the inside of the machine (see "Replacing the toner cartridge" on page 44). · Check the paper type and quality. · Remove the toner cartridge and install a new one (see "Replacing the toner cartridge" on page 44). Suggested Solutions 5.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)

<http://somenmanuals.com/dref/4128961>

Troubleshooting 183 Printing quality problems Condition Vertical repetitive defects Suggested Solutions If marks repeatedly appear on the printed side of the page at even intervals: · The toner cartridge may be damaged. If you still have the same problem, remove the toner cartridge and, install a new one (see "Replacing the toner cartridge" on page 44).

· Parts of the machine may have toner on them. If the defects occur on the back of the page, the problem will likely correct itself after a few more pages. · The fusing assembly may be damaged. Contact a service representative. Background scatter Background scatter results from bits of toner randomly distributed on the printed page.

· The paper may be too damp. Try printing with a different batch of paper. Do not open packages of paper until necessary so that the paper does not absorb too much moisture. · If background scatter occurs on an envelope, change the printing layout to avoid printing over areas that have overlapping seams on the reverse side. Printing on seams can cause problems.

Or select Thick Envelope from the Printing Preferences window (see "Opening printing preferences" on page 35). · If background scatter covers the entire surface area of a printed page, adjust the print resolution through your software application or in Printing Preferences (see "Opening printing preferences" on page 35). Ensure the correct paper type is selected. For example: If Thicker Paper is selected, but Plain Paper actually used, an overcharging can occur causing this copy quality problem. · If you are using a new toner cartridge, redistribute the toner first (see "Redistributing toner" on page 43). Toner particles are around bold characters or pictures The toner might not adhere properly to this type of paper. · Change the printer option and try again. Go to Printing Preferences, click the Paper tab, and set the paper type to Recycled (see "Opening printing preferences" on page 35). · Ensure the correct paper type is selected. For example: If Thicker Paper is selected, but Plain Paper actually used, an overcharging can occur causing this copy quality problem.

A 5. Troubleshooting 184 Printing quality problems Condition Misformed characters Suggested Solutions · If characters are improperly formed and producing hollow images, the paper stock may be too slick. Try different paper. Page skew · Ensure that the paper is loaded properly. · Check the paper type and quality. · Ensure that the guides are not too tight or too loose against the paper stack. Curl or wave · Ensure that the paper is loaded properly. · Check the paper type and quality. Both high temperature and humidity can cause paper curl. · Turn the stack of paper over in the tray.

Also try rotating the paper 180° in the tray. 5. Troubleshooting 185 Printing quality problems Condition Wrinkles or creases · Ensure that the paper is loaded properly. · Check the paper type and quality. · Turn the stack of paper over in the tray.

Also try rotating the paper 180° in the tray. Suggested Solutions Back of printouts are dirty · Check for leaking toner. Clean the inside of the machine (see "Cleaning the machine" on page 46). Solid color or black pages · The toner cartridge may not be installed properly. Remove the cartridge and reinsert it. · The toner cartridge may be defective. Remove the toner cartridge and install a new one (see "Replacing the toner cartridge" on page 44). · The machine may require repairing. Contact a service representative. A 5. Troubleshooting 186 Printing quality problems Condition Loose toner Suggested Solutions · Clean the inside of the machine (see "Cleaning the machine" on page 46). · Check the paper type and quality. · Remove the toner cartridge and then, install a new one (see "Replacing the toner cartridge" on page 44).



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)

<http://somemanuals.com/dref/4128961>

If the problem persists, the machine may require repair. Contact a service representative.

Character voids Character voids are white areas within parts of characters that should be solid black: · You may be printing on the wrong surface of the paper. Remove the paper and turn it around. A Horizontal stripes · The paper may not meet paper specifications. If horizontally aligned black streaks or smears appear: · The toner cartridge may be installed improperly. Remove the cartridge and reinsert it. · The toner cartridge may be defective. Remove the toner cartridge and install a new one (see "Replacing the toner cartridge" on page 44). If the problem persists, the machine may require repairing. Contact a service representative. 5.

Troubleshooting 187 Printing quality problems Condition Curl Suggested Solutions If the printed paper is curled or paper does not feed into the machine: · Turn the stack of paper over in the tray. Also try rotating the paper 180° in the tray. · Change the printer's paper option and try again. Go to Printing Preferences, click the Paper tab, and set type to Thin (see "Opening printing preferences" on page 35). · An unknown image Your machine is probably being used at an altitude of 1,000 m (3,281 ft) or above.

repetitively appears on a few The high altitude may affect the print quality, such as loose toner or light imaging. Change the altitude setting for your machine (See sheets "Altitude adjustment" on page 138). · Loose toner · Light print or contamination occurs 5. *Troubleshooting 188 Operating system problems 1 Common Windows problems Condition "File in Use" message appears during installation. "General Protection Fault", "Exception OE", "Spool 32", or "Illegal Operation" messages appear.*

"Fail To Print", "A printer timeout error occurred" message appear. Suggested solutions Exit all software applications. Remove all software from the startup group, then restart Windows. Reinstall the printer driver. Close all other applications, reboot Windows and try printing again. These messages may appear during printing. Just keep waiting until the machine finishes printing. If the message appears in ready mode or after printing has completed, check the connection and/or whether an error has occurred. Refer to the Microsoft Windows 2000/XP/2003/Vista User's Guide that came with your computer for further information on Windows error messages. 5.

Troubleshooting 189 Operating system problems 2 Common Macintosh problems Condition The machine does not print PDF files correctly. Some parts of graphics, text, or illustrations are missing. Suggested solutions Printing the PDF file as an image may enable the file to print. Turn on Print As Image from the Acrobat printing options. It will take longer to print when you print a PDF file as an image. Some letters are not displayed normally during cover page printing. When printing a document in Macintosh with Acrobat Reader 6.0 or higher, colors print incorrectly. Mac OS cannot create the font while printing the cover page. The English alphabet and numbers are displayed normally on the cover page.

Make sure that the resolution setting in your machine driver matches the one in Acrobat Reader. Refer to the Macintosh User's Guide that came with your computer for further information on Macintosh error messages. 5. *Troubleshooting 190 Operating system problems 3 Common Linux problems Condition* The machine does not print. Suggested solutions · Check if the printer driver is installed in your system.

Open Unified Driver Configurator and switch to the Printers tab in the Printers configuration window to look at the list of available machines. Make sure that your machine is displayed on the list. If not, open Add new printer wizard to set up your device. · Check if the machine is started. Open Printers configuration and select your machine from the printers list.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Look at the description in the Selected printer pane. If its status contains Stopped, press the Start button. Normal operation of the machine should be restored. The "stopped" status might be activated when some problems in printing occur. · Check if your application has special print options such as "-oraw". If "-oraw" is specified in the command line parameter, then remove it to print properly. For Gimp front-end, select "print" -> "Setup printer" and edit the command line parameter in the command item. The machine does not print whole pages, and output is printed on half the page. "Cannot open port device file" error message appears when printing a document. It is a known problem that occurs when a color machine is used on version 8.

51 or earlier of Ghostscript, 64-bit Linux OS, and has been reported to bugs.ghostscript.com as Ghostscript Bug 688252. The problem is solved in AFPL Ghostscript v. 8.52 or above. Download the latest version of AFPL Ghostscript from <http://sourceforge.net/projects/ghostscript/> and install it to solve this problem. Avoid changing print job parameters (e.g.

via LPR GUI) while a print job is in progress. Known versions of CUPS server break the print job whenever print options are changed and then try to restart the job from the beginning. Since Unified Linux Driver locks the port while printing, the abrupt termination of the driver keeps the port locked and unavailable for subsequent print jobs. If this situation occurs, try to release the port by selecting Release port in the Port configuration window. Refer to the Linux User's Guide that came with your computer for further information on Linux error messages.

5. Troubleshooting 191 Operating system problems 4 Common PostScript problems The following situations are PS language specific and may occur when several printer languages are used. Problem The PostScript file cannot be printed. Possible cause The PostScript driver may not be installed correctly.

Solution · Install the PostScript driver (see "Software installation" on page 82).

· Print a configuration page and verify that the PS version is available for printing. · If the problem persists, contact a service representative. Limit Check Error report prints. A PostScript error page prints. The print job was too complex. The print job may not be PostScript. You might need to reduce the complexity of the page or install more memory. Make sure that the print job is a PostScript job. Check to see whether the software application expected a setup or PostScript header file to be sent to the machine. Open the PostScript driver properties, select the Device Options tab, and set the tray option.

The optional tray is not selected in the driver. The printer driver has not been configured to recognize the optional tray. 5. Troubleshooting 192 Contact SAMSUNG worldwide If you have any comments or questions regarding Samsung products, contact the Samsung customer care center. Country/Region

ALBANIA ARGENTINE ARMENIA AUSTRALIA AUSTRIA AZERBAIJAN BAHRAIN BELARUS Customer Care Center 42 27 5755 0800-333-3733
0-800-05-555 1300 362 603 0810-SAMSUNG (7267864, 0.07/min) 088-55-55-555 8000-4726 810-800-500-55-500 02-201-24-18 BELGIUM
www.samsung.com/be (Dutch) www.samsung.com/be_fr (French) 05 133 1999 0800-124-421 4004-0000 07001 33 11 1-800-SAMSUNG (726-7864) www.samsung.com
www.samsung.com www.samsung.com www.samsung.com www.samsung.com

www.samsung.com CZECH REPUBLIC www.samsung.com Web Site Country/Region CHILE CHINA COLOMBIA COSTA RICA CROATIA Customer Care Center
800-SAMSUNG (726-7864) 400-810-5858 01-8000112112 0-800-507-7267 062 SAMSUNG (062 726 7864) 800-SAMSUNG (800-726786) Web Site
www.samsung.com www.samsung.com www.samsung.com www.samsung.com

www.samsung.com www.samsung.com www.samsung.com Samsung Zrt., česká organizační složka, Oasis Florenc, Sokolovská 394/17, 180 00, Praha 8 70 70 19 70
1-800-751-2676 1-800-10-7267 0800-726786 0818 717100 800-6225 800-7267 030-6227 515 01 48 63 00 00 01805 - SAMSUNG (726-7864 0,14/min) www.samsung.com



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://www.samsung.com)
<http://somemanuals.com/dref/4128961>

samsung.com www.samsung.

com www.samsung.com www.samsung.com www.

samsung.com www.samsung.com www.samsung.

com www.samsung.com www.samsung.com www.samsung.com DENMARK DOMINICA ECUADOR EGYPT EIRE EL SALVADOR ESTONIA FINLAND
FRANCE GERMANY BOSNIA BRAZIL BULGARIA CANADA Contact SAMSUNG worldwide 193 Contact SAMSUNG worldwide Country/Region GEORGIA
Customer Care Center 8-800-555-555 IT and Mobile : 80111-SAMSUNG (80111 7267864) from land line, local charge/ from mobile, 210 6897691 GREECE
Cameras, Camcorders, Televisions and Household Appliances From mobile and fixed 2106293100 GUATEMALA HONDURAS 1-800-299-0013
800-27919267 (852) 3698-4698 HONG KONG www.samsung.com LITHUANIA www.samsung.

com LUXEMBURG www.samsung.com/hk www.samsung.com/ hk_en/ 06-80-SAMSUNG (726-7864) 3030 8282 1800 3000 8282 0800-112-8888

021-5699-7777 021-8255 800-SAMSUNG (726-7864) www.samsung.com www.samsung.com NETHERLANDS www.samsung.

com www.samsung.com www.samsung.com MALAYSIA MACEDONIA MEXICO MOLDOVA MONTENEGRO MOROCCO NIGERIA 1800-88-9999 023 207
777 01-800-SAMSUNG (726-7864) 00-800-500-55-500 020 405 888 080 100 2255 080-SAMSUNG(726-7864) 0900-SAMSUNG (0900-7267864) (0,10/min)
www.

samsung.com www.samsung.com www.samsung.

com www.samsung.com www.samsung.com 261 03 710 www.samsung.com 8-800-77777 www.samsung.com www.samsung.

com Web Site Country/Region JAMAICA JAPAN JORDAN KAZAKHSTAN KOSOVO KUWAIT KYRGYZSTAN LATVIA Customer Care Center

1-800-234-7267 0120-327-527 800-22273 Web Site www.samsung.com www.samsung.com www.samsung.com 8-10-800-500-55-500 (GSM:7799)

www.samsung.com +381 0113216899 183-2255 00-800-500-55-500 8000-7267 www.samsung.

com www.samsung.com www.samsung.com HUNGARY INDIA INDONESIA IRAN ITALY Contact SAMSUNG worldwide 194 Contact SAMSUNG worldwide
Country/Region NEW ZEALAND NICARAGUA NORWAY OMAN PANAMA PERU Customer Care Center 0800 SAMSUNG (0800 726 786)
00-1800-5077267 815-56 480 800-SAMSUNG (726-7864) 800-7267 0-800-777-08 1800-10-SAMSUNG (726-7864) PHILIPPINES 1-800-3-SAMSUNG
(726-7864) 1-800-8-SAMSUNG (726-7864) 02-5805777 POLAND PORTUGAL PUERTO RICO 0 801 1SAMSUNG (172678) 022-607-93-33
80820-SAMSUNG (726-7864) 1-800-682-3180 08010 SAMSUNG (08010 726 7864) only from landline, local network Romtelecom - local tariff / 021 206 01
10 for landline and mobile, normal tariff.

www.samsung.com www.samsung.com THAILAND www.

samsung.com TRINIDAD & TOBAGO TURKEY U.A.E www.samsung.com TADJIKISTAN TAIWAN 8-10-800-500-55-500 0800-329-999 1800-29-3232

02-689-3232 1-800-SAMSUNG (726-7864) www.samsung.com SWITZERLAND Web Site www.samsung.com www.

samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.

samsung.com Country/Region RUSSIA SAUDI ARABIA SERBIA SINGAPORE SLOVAKIA SOUTH AFRICA SPAIN SWEDEN Customer Care Center
8-800-555-55-55 9200-21230 0700 SAMSUNG (0700 726 7864) 1800-SAMSUNG (726-7864) 0800-SAMSUNG (726-7864) 0860 SAMSUNG (726-7864)
902-1-SAMSUNG(902 172 678) 0771 726 7864 (SAMSUNG) 0848-SAMSUNG (7267864, CHF 0.08/min) Web Site www.samsung.com www.

samsung.com www.samsung.com www.samsung.

com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.

com/ch www.samsung.com/ ch_fr/ www.samsung.com www.samsung.com www.samsung.com RUMANIA 444 77 11 800-SAMSUNG (726-7864)

www.samsung.

com www.samsung.com Contact SAMSUNG worldwide 195 Contact SAMSUNG worldwide Country/Region U.K U.S.

A Customer Care Center 0330 SAMSUNG (726-7864) 1-800-SAMSUNG (726-7864) 0-800-502-000 UKRAINE Web Site www.samsung.com

www.samsung.com www.

samsung.com/ua www.samsung.com/ ua_ru 8-10-800-500-55-500 0-800-100-5303 1 800 588 889 www.samsung.com www.samsung.com www.samsung.com
UZBEKISTAN VENEZUELA VIETNAM Contact SAMSUNG worldwide 196 Glossary ADF The following glossary helps you get familiar with the product by
understanding the terminologies commonly used with printing as well as mentioned in this user's guide.

An Automatic Document Feeder (ADF) is a scanning unit that will automatically feed an original sheet of paper so that the machine can scan some amount of
the paper at once. 802.11 802.11 is a set of standards for wireless local area network (WLAN) communication, developed by the IEEE LAN/MAN Standards
Committee (IEEE 802).



**You're reading an excerpt. Click here to read official SAMSUNG
ML-2160 user guide**
<http://somemanuals.com/dref/4128961>

AppleTalk AppleTalk is a proprietary suite of protocols developed by Apple, Inc for computer networking. It was included in the original Macintosh (1984) and is now deprecated by Apple in favor of TCP/IP networking. 802.11b/g/n 802.11b/g/n can share same hardware and use the 2.4 GHz band. 802.11b supports bandwidth up to 11 Mbps, 802.11n supports bandwidth up to 150 Mbps. 802.11b/g/n devices may occasionally suffer interference from microwave ovens, cordless telephones, and Bluetooth devices.

BIT Depth A computer graphics term describing the number of bits used to represent the color of a single pixel in a bitmapped image. Higher color depth gives a broader range of distinct colors. As the number of bits increases, the number of possible colors becomes impractically large for a color map. 1-bit color is commonly called as monochrome or black and white. **Access point** Access Point or Wireless Access Point (AP or WAP) is a device that connects wireless communication devices together on wireless local area networks (WLAN), and acts as a central transmitter and receiver of WLAN radio signals.

BMP A bitmapped graphics format used internally by the Microsoft Windows graphics subsystem (GDI), and used commonly as a simple graphics file format on that platform. **Glossary 197 Glossary BOOTP** Bootstrap Protocol. A network protocol used by a network client to obtain its IP address automatically. This is usually done in the bootstrap process of computers or operating systems running on them. The BOOTP servers assign the IP address from a pool of addresses to each client. **BOOTP** enables 'diskless workstation' computers to obtain an IP address prior to loading any advanced operating system. **Coverage** It is the printing term used for a toner usage measurement on printing. For example, 5% coverage means that an A4 sided paper has about 5% image or text on it. So, if the paper or original has complicated images or lots of text on it, the coverage will be higher and at the same time, a toner usage will be as much as the coverage. **CSV** **CCD** Charge Coupled Device (CCD) is a hardware which enables the scan job.

CCD Locking mechanism is also used to hold the CCD module to prevent any damage when you move the machine. **Comma Separated Values (CSV)**. A type of file format, CSV is used to exchange data between disparate applications. The file format, as it is used in Microsoft Excel, has become a de facto standard throughout the industry, even among non-Microsoft platforms. **Collation** Collation is a process of printing a multiple-copy job in sets. When collation is selected, the device prints an entire set before printing additional copies. **DADF** A Duplex Automatic Document Feeder (DADF) is a scanning unit that will automatically feed and turn over an original sheet of paper so that the machine can scan on both sides of the paper. **Control Panel Default** A control panel is a flat, typically vertical, area where control or monitoring instruments are displayed. They are typically found in front of the machine. The value or setting that is in effect when taking a printer out of its box state, reset, or initialized.

Glossary 198 Glossary DHCP A Dynamic Host Configuration Protocol (DHCP) is a client-server networking protocol. A DHCP server provides configuration parameters specific to the DHCP client host requesting, generally, information required by the client host to participate on an IP network. DHCP also provides a mechanism for allocation of IP addresses to client hosts. **DPI** Dots Per Inch (DPI) is a measurement of resolution that is used for scanning and printing. Generally, higher DPI results in a higher resolution, more visible detail in the image, and a larger file size.

DRPD Distinctive Ring Pattern Detection. Distinctive Ring is a telephone company service which enables a user to use a single telephone line to answer several different telephone numbers. **DIMM** Dual Inline Memory Module (DIMM), a small circuit board that holds memory.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)
<http://somenmanuals.com/dref/4128961>

DIMM stores all the data within the machine like printing data, received fax data. Duplex DLNA The Digital Living Network Alliance (DLNA) is a standard that allows devices on a home network to share information with each other across the network.

A mechanism that will automatically turn over a sheet of paper so that the machine can print (or scan) on both sides of the paper. A printer equipped with a Duplex Unit can print on both sides of paper during one print cycle. DNS The Domain Name Server (DNS) is a system that stores information associated with domain names in a distributed database on networks, such as the Internet. Duty Cycle Duty cycle is the page quantity which does not affect printer performance for a month. Generally the printer has the lifespan limitation such as pages per year. The lifespan means the average capacity of print-outs, usually within the warranty period. For example, if the duty cycle is 48,000 pages per month assuming 20 working days, a printer limits 2,400 pages a day.

Dot Matrix Printer A dot matrix printer refers to a type of computer printer with a print head that runs back and forth on the page and prints by impact, striking an ink-soaked cloth ribbon against the paper, much like a typewriter. Glossary 199 Glossary ECM Error Correction Mode (ECM) is an optional transmission mode built into Class 1 fax machines or fax modems. It automatically detects and corrects errors in the fax transmission process that are sometimes caused by telephone line noise.

EtherTalk A suite of protocols developed by Apple Computer for computer networking. It was included in the original Macintosh (1984) and is now deprecated by Apple in favor of TCP/IP networking. Emulation Emulation is a technique of one machine obtaining the same results as another. An emulator duplicates the functions of one system with a different system, so that the second system behaves like the first system. Emulation focuses on exact reproduction of external behavior, which is in contrast to simulation, which concerns an abstract model of the system being simulated, often considering its internal state.

FDI Foreign Device Interface (FDI) is a card installed inside the machine to allow a third party device such as a coin operated device or a card reader. Those devices allow the pay-for-print service on your machine. FTP A File Transfer Protocol (FTP) is a commonly used protocol for exchanging files over any network that supports the TCP/IP protocol (such as the Internet or an intranet). Ethernet Ethernet is a frame-based computer networking technology for local area networks (LANs). It defines wiring and signaling for the physical layer, and frame formats and protocols for the media access control (MAC)/data link layer of the OSI model.

Ethernet is mostly standardized as IEEE 802.3. It has become the most widespread LAN technology in use during the 1990s to the present. Fuser Unit The part of a laser printer that fuses the toner onto the print media. It consists of a heat roller and a pressure roller. After toner is transferred onto the paper, the fuser unit applies heat and pressure to ensure that the toner stays on the paper permanently, which is why paper is warm when it comes out of a laser printer. Glossary 200 Glossary Gateway A connection between computer networks, or between a computer network and a telephone line. It is very popular, as it is a computer or a network that allows access to another computer or network. IEEE The Institute of Electrical and Electronics Engineers (IEEE) is an international non-profit, professional organization for the advancement of technology related to electricity. Grayscale A shades of gray that represent light and dark portions of an image when color images are converted to grayscale; colors are represented by various shades of gray.

IEEE 1284 The 1284 parallel port standard was developed by the Institute of Electrical and Electronics Engineers (IEEE). The term "1284-B" refers to a specific connector type on the end of the parallel cable that attaches to the peripheral (for example, a printer).



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)
<http://somemanuals.com/dref/4128961>

Halfone Intranet An image type that simulates grayscale by varying the number of dots. Highly colored areas consist of a large number of dots, while lighter areas consist of a smaller number of dots. A private network that uses Internet Protocols, network connectivity, and possibly the public telecommunication system to securely share part of an organization's information or operations with its employees. Sometimes the term refers only to the most visible service, the internal website. *HDD* Hard Disk Drive (HDD), commonly referred to as a hard drive or hard disk, is a non-volatile storage device which stores digitally-encoded data on rapidly rotating platters with magnetic surfaces. *IP* address An Internet Protocol (IP) address is a unique number that devices use in order to identify and communicate with each other on a network utilizing the Internet Protocol standard. *Glossary 201* *Glossary* *IPM* The Images Per Minute (IPM) is a way of measuring the speed of a printer. An IPM rate indicates the number of single-sided sheets a printer can complete within one minute.

ITU-T The International Telecommunication Union is an international organization established to standardize and regulate international radio and telecommunications. Its main tasks include standardization, allocation of the radio spectrum, and organizing interconnection arrangements between different countries to allow international phone calls. A -T out of ITU-T indicates telecommunication. *IPP* The Internet Printing Protocol (IPP) defines a standard protocol for printing as well as managing print jobs, media size, resolution, and so forth. IPP can be used locally or over the Internet to hundreds of printers, and also supports access control, authentication, and encryption, making it a much more capable and secure printing solution than older ones. *ITU-T No. 1* chart Standardized test chart published by ITU-T for document facsimile transmissions. *IPX/SPX* IPX/SPX stands for Internet Packet Exchange/Sequenced Packet Exchange. It is a networking protocol used by the Novell NetWare operating systems. IPX and SPX both provide connection services similar to TCP/IP, with the IPX protocol having similarities to IP, and SPX having similarities to TCP.

IPX/SPX was primarily designed for local area networks (LANs), and is a very efficient protocol for this purpose (typically its performance exceeds that of TCP/IP on a LAN). *JBIG* Joint Bi-level Image Experts Group (JBIG) is an image compression standard with no loss of accuracy or quality, which was designed for compression of binary images, particularly for faxes, but can also be used on other images. *JPEG* Joint Photographic Experts Group (JPEG) is a most commonly used standard method of lossy compression for photographic images. It is the format used for storing and transmitting photographs on the World Wide Web. *ISO* The International Organization for Standardization (ISO) is an international standard-setting body composed of representatives from national standards bodies.

It produces world-wide industrial and commercial standards. *Glossary 202* *Glossary* *LDAP* The Lightweight Directory Access Protocol (LDAP) is a networking protocol for querying and modifying directory services running over TCP/IP. *MH* Modified Huffman (MH) is a compression method for decreasing the amount of data that needs to be transmitted between the fax machines to transfer the image recommended by ITU-T T.4. MH is a codebook-based run-length encoding scheme optimized to efficiently compress white space. As most faxes consist mostly of white space, this minimizes the transmission time of most faxes. *LED* A Light-Emitting Diode (LED) is a semiconductor device that indicates the status of a machine. *MMR* MAC address Media Access Control (MAC) address is a unique identifier associated with a network adapter. MAC address is a unique 48-bit identifier usually written as 12 hexadecimal characters grouped in pairs (e. g., 00-00-0c-34-11-4e).



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somanuals.com/dref/4128961)
<http://somanuals.com/dref/4128961>

This address is usually hard-coded into a Network Interface Card (NIC) by its manufacturer, and used as an aid for routers trying to locate machines on large networks. Modified Modified READ (MMR) is a compression method recommended by ITUT T.6. Modem A device that modulates a carrier signal to encode digital information, and also demodulates such a carrier signal to decode transmitted information.

MFP MR Multi Function Peripheral (MFP) is an office machine that includes the following functionality in one physical body, so as to have a printer, a copier, a fax, a scanner and etc. Modified Read (MR) is a compression method recommended by ITU-T T.4. MR encodes the first scanned line using MH. The next line is compared to the first, the differences determined, and then the differences are encoded and transmitted. Glossary 203 Glossary NetWare A network operating system developed by Novell, Inc. It initially used cooperative multitasking to run various services on a PC, and the network protocols were based on the archetypal Xerox XNS stack. Today NetWare supports TCP/IP as well as IPX/SPX. OSI Open Systems Interconnection (OSI) is a model developed by the International Organization for Standardization (ISO) for communications. OSI offers a standard, modular approach to network design that divides the required set of complex functions into manageable, self-contained, functional layers.

The layers are, from top to bottom, Application, Presentation, Session, Transport, Network, Data Link and Physical. OPC Organic Photo Conductor (OPC) is a mechanism that makes a virtual image for print using a laser beam emitted from a laser printer, and it is usually green or rust colored and has a cylinder shape. An imaging unit containing a drum slowly wears the drum surface by its usage in the printer, and it should be replaced appropriately since it gets worn from contact with the cartridge development brush, cleaning mechanism, and paper. PABX A private automatic branch exchange (PABX) is an automatic telephone switching system within a private enterprise. PCL Printer Command Language (PCL) is a Page Description Language (PDL) developed by HP as a printer protocol and has become an industry standard.

Originally developed for early inkjet printers, PCL has been released in varying levels for thermal, dot matrix printer, and laser printers. Originals The first example of something, such as a document, photograph or text, etc, which is copied, reproduced or translated to produce others, but which is not itself copied or derived from something else. PDF Portable Document Format (PDF) is a proprietary file format developed by Adobe Systems for representing two dimensional documents in a device independent and resolution independent format. Glossary 204 Glossary PostScript PostScript (PS) is a page description language and programming language used primarily in the electronic and desktop publishing areas. - that is run in an interpreter to generate an image.

Protocol A convention or standard that controls or enables the connection, communication, and data transfer between two computing endpoints. PS Printer Driver See PostScript. A program used to send commands and transfer data from the computer to the printer. PSTN The Public-Switched Telephone Network (PSTN) is the network of the world's public circuit-switched telephone networks which, on industrial premises, is usually routed through the switchboard. Print Media The media like paper, envelopes, labels, and transparencies which can be used in a printer, a scanner, a fax or, a copier. RADIUS PPM Pages Per Minute (PPM) is a method of measurement for determining how fast a printer works, meaning the number of pages a printer can produce in one minute.

Remote Authentication Dial In User Service (RADIUS) is a protocol for remote user authentication and accounting. RADIUS enables centralized management of authentication data such as usernames and passwords using an AAA (authentication, authorization, and accounting) concept to manage network access.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)
<http://somenmanuals.com/dref/4128961>

PRN file Resolution An interface for a device driver, this allows software to interact with the device driver using standard input/output system calls, which simplifies many tasks. The sharpness of an image, measured in Dots Per Inch (DPI).

The higher the dpi, the greater the resolution. Glossary 205 Glossary SMB Server Message Block (SMB) is a network protocol mainly applied to share files, printers, serial ports, and miscellaneous communications between nodes on a network. It also provides an authenticated Inter-process communication mechanism. TCP/IP The Transmission Control Protocol (TCP) and the Internet Protocol (IP); the set of communications protocols that implement the protocol stack on which the Internet and most commercial networks run. TCR SMTP Simple Mail Transfer Protocol (SMTP) is the standard for e-mail transmissions across the Internet. SMTP is a relatively simple, text-based protocol, where one or more recipients of a message are specified, and then the message text is transferred. It is a client-server protocol, where the client transmits an email message to the server. Transmission Confirmation Report (TCR) provides details of each transmission such as job status, transmission result and number of pages sent. This report can be set to print after each job or only after failed transmissions. TIFF Tagged Image File Format (TIFF) is a variable-resolution bitmapped image format.

TIFF describes image data that typically come from scanners. TIFF images make use of tags, keywords defining the characteristics of the image that is included in the file. This flexible and platform-independent format can be used for pictures that have been made by various image processing applications.

SSID Service Set Identifier (SSID) is a name of a wireless local area network (WLAN). All wireless devices in a WLAN use the same SSID in order to communicate with each other.

The SSIDs are case-sensitive and have a maximum length of 32 characters. Toner Cartridge Subnet Mask The subnet mask is used in conjunction with the network address to determine which part of the address is the network address and which part is the host address. A kind of bottle or container used in a machine like a printer which contains toner. Toner is a powder used in laser printers and photocopiers, which forms the text and images on the printed paper.

Toner can be fused by a combination of heat/pressure from the fuser, causing it to bind to the fibers in the paper.

Glossary 206 Glossary TWAIN An industry standard for scanners and software. By using a TWAIN-compliant scanner with a TWAIN-compliant program, a scan can be initiated from within the program. It is an image capture API for Microsoft Windows and Apple Macintosh operating systems. Watermark A watermark is a recognizable image or pattern in paper that appears lighter when viewed by transmitted light. Watermarks were first introduced in Bologna, Italy in 1282; they have been used by papermakers to identify their product, and also on postage stamps, currency, and other government documents to discourage counterfeiting.

UNC Path WEP Uniform Naming Convention (UNC) is a standard way to access network shares in Window NT and other Microsoft products. The format of a UNC path is: \\<servername>\<sharename>\<Additional directory> Wired Equivalent Privacy (WEP) is a security protocol specified in IEEE 802.11 to provide the same level of security as that of a wired LAN. WEP provides security by encrypting data over radio so that it is protected as it is transmitted from one end point to another. URL Uniform Resource Locator (URL) is the global address of documents and resources on the Internet.

The first part of the address indicates what protocol to use, the second part specifies the IP address or the domain name where the resource is located. WIA Windows Imaging Architecture (WIA) is an imaging architecture that is originally introduced in Windows Me and Windows XP.



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somenmanuals.com/dref/4128961)
<http://somenmanuals.com/dref/4128961>

A scan can be initiated from within these operating systems by using a WIA-compliant scanner. USB WPA Universal Serial Bus (USB) is a standard that was developed by the USB Implementers Forum, Inc., to connect computers and peripherals. Unlike the parallel port, USB is designed to concurrently connect a single computer USB port to multiple peripherals. Wi-Fi Protected Access (WPA) is a class of systems to secure wireless (Wi-Fi) computer networks, which was created to improve upon the security features of WEP. Glossary 207 Glossary WPA-PSK WPA-PSK (WPA Pre-Shared Key) is special mode of WPA for small business or home users. A shared key, or password, is configured in the wireless access point (WAP) and any wireless laptop or desktop devices. WPA-PSK generates a unique key for each session between a wireless client and the associated WAP for more advanced security.

WPS The Wi-Fi Protected Setup (WPS) is a standard for establishing a wireless home network. If your wireless access point supports WPS, you can configure the wireless network connection easily without a computer. XPS XML Paper Specification (XPS) is a specification for a Page Description Language (PDL) and a new document format, which has benefits for portable document and electronic document, developed by Microsoft. It is an XML-based specification, based on a new print path and a vector-based deviceindependent document format..



[You're reading an excerpt. Click here to read official SAMSUNG ML-2160 user guide](http://somemanuals.com/dref/4128961)

<http://somemanuals.com/dref/4128961>