



myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for MAKITA HR2470FT. You'll find the answers to all your questions on the MAKITA HR2470FT in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MAKITA HR2470FT
User guide MAKITA HR2470FT
Operating instructions MAKITA HR2470FT
Instructions for use MAKITA HR2470FT
Instruction manual MAKITA HR2470FT



[Your user manual](#)
[MAKITA HR2470FT](#)

Manual abstract:

22. Use the power tool, accessories and tool bits etc. In accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation. **SERVICE** 23. Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained. Keep handles dry, clean and free from oil and grease. Use auxiliary handles supplied with the tool. loss of control can cause personal injury.

Hold power tools by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord. Contact with a "live" wire will make exposed metal parts of the tool "live" and shock the operator. Wear a hard hat (safety helmet), safety glasses and/or face shield.

Ordinary eye or sun glasses are NOT safety glasses. it is also highly recommended that you wear a dust mask and thickly padded gloves.

Be sure the bit is secured in place before operation. under normal operation , the tool is designed to produce vibration. The screws can come loose easily, causing a breakdown or accident. check tightness of screws carefully before operation. In cold weather or when the tool has not been used for a long time, let the tool warm up for a while by operating it under no load.

Always be sure you have a firm footing. Be sure no one is below when using the tool in high locations. hold the tool firmly with both hands. Keep hands away from moving parts. Do not point the tool at any one in the area when operating. The bit could fly out and injure someone seriously. Do not touch the bit or parts close to the bit immediately after operation; they may be extremely hot and could burn your skin. Some material contains chemicals which may be toxic.

Take caution to prevent dust inhalation and skin contact. Follow material supplier safety data.

MISUSE or failure to follow the safety rules stated in this instruction manual may cause serious personal injury. **DO NOT** let comfort or familiarity with product (gained from repeated use) replace strict adherence to rotary hammer safety rules. If you use this tool unsafely or incorrectly, you can suffer serious personal injury. Volts amperes hertz alternating current no load speed Class II Construction revolutions or reciprocation per minute number of blow

CAUTION: Do not look in the light or see the source of light directly. To turn on the lamp, pull the trigger. Release the trigger to turn it off. Use a dry cloth to wipe the dirt off the lens of lamp. Be careful not to scratch the lens of lamp, or it may lower the illumination. **CAUTION:** Always be sure that the tool is switched off and unplugged before adjusting or checking function on the tool. **CAUTION:** Before plugging in the tool, always check to see that the switch trigger actuates properly and returns to the "OFF" position when released.

to start the tool , simply pull the switch trigger. Tool speed is increased by increasing pressure on the switch trigger. release the switch trigger to stop. For continuous operation, pull the switch trigger and then push in the lock button. To stop the tool from the locked position, pull the switch trigger fully, then release it.

Use the reversing switch only after the tool comes to a complete stop. Changing the direction of rotation before the tool stops may damage the tool. For model HR2470T/HR2470FT The quick change chuck for SDS-plus can be easily exchanged for the quick change drill chuck. **CAUTION:** Before removing the quick change chuck for SDS-plus, always remove the bit. Grasp the change cover of the quick change chuck for SDS-plus and turn in the direction of the arrow until the change cover line moves from the symbol to the symbol.

For drilling in wood, metal or plastic materials, depress the lock button and rotate the action mode changing knob to the symbol. Use a twist drill bit or wood bit. Use a bull point, cold chisel, knob to the scaling chisel, etc. **CAUTION:** Do not rotate the action mode changing knob when the tool is running under load. the tool will be damaged..



[Your user manual](#)
[MAKITA HR2470FT](#)