

DC/DC Switching Regulators	Function
----------------------------	----------

The soft start function is created by an external capacitor connected to the DTC pin, during start-up the DTC pin voltage is gradually increasing. The soft start initiates from a Maxduty value of 0% and the output voltage ramps up gradually, preventing an inrush current. The soft start time can be adjusted by the capacitance of the capacitor.

