

# Main Application Page

## Header Section:

- Application Title
- Application Version
- Logged in username
- Logout icon

### AxeOS Device: Name

- Current Hashrate
- Expected Hashrate
- Difficulty (Best & Session)
- Pool Difficulty
- Shares
- ASIC Temp
- VR Temp
- Fan Speed %
- Fan Speed RPMs

### AxeOS Device: Name

- Current Hashrate
- Expected Hashrate
- Difficulty (Best & Session)
- Pool Difficulty
- Shares
- ASIC Temp
- VR Temp
- Fan Speed %
- Fan Speed RPMs

### AxeOS Device: Name

- Current Hashrate
- Expected Hashrate
- Difficulty (Best & Session)
- Pool Difficulty
- Shares
- ASIC Temp
- VR Temp
- Fan Speed %
- Fan Speed RPMs

### AxeOS Device: Name

- Current Hashrate
- Expected Hashrate
- Difficulty (Best & Session)
- Pool Difficulty
- Shares
- ASIC Temp
- VR Temp
- Fan Speed %
- Fan Speed RPMs

### For each mining pool configured

#### Mining Core Instance: Pool Name

- Network Hashrate
- Network Difficulty
- Last Block Time
- Block Height
- Connected Peers
- Node Version
- Connected Miners
- Pool Hashrate
- Rewards: Total Paid
- Rewards: Total Blocks
- Rewards: Total Confirmed Blocks
- Rewards: Total Pending Blocks
- Rewards: Last Pool Block Time
- Rewards: Block Reward

### For each mining pool configured

#### Mining Core Instance: Pool Name

- Network Hashrate
- Network Difficulty
- Last Block Time
- Block Height
- Connected Peers
- Node Version
- Connected Miners
- Pool Hashrate
- Rewards: Total Paid
- Rewards: Total Blocks
- Rewards: Total Confirmed Blocks
- Rewards: Total Pending Blocks
- Rewards: Last Pool Block Time
- Rewards: Block Reward

## Footer Section:

- Copy right notice
- Author: Scott Walter
- Last updated timestamp
- Application version

# AxeOS Chart Modal


## Bitaxe1 - Real-time Statistics



Live   Update interval: 25s   Hashrate: 1.54 Th/s   Average: 1.39 Th/s   ASIC Temp: 60.1°C

Last update: 8:10:48 AM

— Hashrate   — ASIC Temp



# AxeOS Settings Modal

Settings for Bitaxe1

Device

Hostname: bitaxe1

Invert Screen: ☐

Screen Rotation: 0°

Display Timeout (mins): -1

WIFI

SSID: MMXXF

Password: Leave blank to keep current

Mining

Stats Frequency (s): 30

Primary Pool

URL: 192.168.7.149

Port: 5001

Username: D8HCqTxcZkSvejhx7ByLXAPsEpaBzZS.bitaxe1

Password: Leave blank to keep current

Suggested Difficulty: 1000

Extranonce Subscribe: ☒

Fallback Pool

URL: sha256.unmineable.com

Port: 3333

Username: DGB-D8HCqTxcZkSvejhx7ByLXAPsEpaBzZS.Bitaxe1

Password: Leave blank to keep current

Suggested Difficulty: 1000

Extranonce Subscribe: ☒

Performance

Enable Overclock: ☒

Frequency (MHz): 675

Core Voltage (mV): 1160

Auto Fan Speed: ☒

Manual Fan Speed (%): 57

Minimum Fan Speed (%): 25

Target Temp (°C): 60

Cancel

Save Changes

# Application Configuration Modal

[illegible]

# Bootstrap Page

Bitaxe Dashboard - First Time Setup

Version: 2.0

Welcome to Bitaxe Dashboard

This appears to be your first time running the application. Please configure the initial settings below.

!!!! If you are running Bitaxe-Dashboard via Docker make sure you have mapped the config folder to your local filesystem !!!!

Docker Run Example:

```
sudo docker run -d --name bitaxe-dashboard -p 3000:3000/tcp -v  
(/your/local/config_path):/app/config scottwalker/bitaxe-dashboard:latest
```

Basic Settings

Dashboard Title

Bitaxe Dashboard

The title that will appear at the top of your dashboard

Web Server Port

3000

Port number for the web server (3024-20523)

Authentication Settings

☒ Enable Authentication

Uncheck to disable login requirements (not recommended for production)  
Application must be running in HTTPS / SSL if enabled

Admin Username

admin

Username for administrative access

Admin Password

Strong password recommended

Confirm Password

JWT Secret Key

ntmLCoZq3lt3ghu4dyLweqzQW7APQW

Generate Key

32-character secret key for session tokens

Session Duration

1 Hour

How long users stay logged in

Bitaxe Devices

Add your Bitaxe device URLs below. You can add more later through the configuration menu.

Device Name	Device URL
Bitaxe1	http://192.168.1.100

Add Another Device

Mining Core Integration (Optional)

☒ Enable Mining Core Integration

Connect to a mining pool server for additional statistics

Mining Core API URL

http://192.168.1.100:8000

URL to your mining core API endpoint

Create Configuration

# Login Page

## Bitaxe Dashboard

Version: 2.00

### Login

---

**Username**

**Password**

Login