


ESP8266 with AT Commands – Flashing/Updating the Firmware (step by step)

Home (<http://flower-platform.com>) / Flower Platform (<http://flower-platform.com/category/flower-platform/>) / ESP8266 with AT Commands – Flashing/Updating the Firmware (step by step)

< Previous (<http://flower-platform.com/2015/10/23/introducing-flowerino-draw-diagrams-and-generate-code-for-arduino/>)

Next >



([http://flower-platform.com/wp-content/uploads/2015/12/ESP8266-pc-generic\\_bb.png](http://flower-platform.com/wp-content/uploads/2015/12/ESP8266-pc-generic_bb.png))

ESP8266 with AT Commands – Flashing/Updating the Firmware (step by step)

The ESP8266 (<http://espressif.com/en/products/esp8266/>) is a remarkable system on a chip (SoC), for its features and price. It can be used in multiple modes. E.g. :

- Used as a WiFi adapter, by a master micro controller (e.g. Arduino (<http://arduino.cc/>) or Raspberry Pi (<https://www.raspberrypi.org/>));

Q

Recent Posts

- > Flowerino v0.6.0 Release Notes.  
New Sample Project: Control Lights with Arduino + ESP8266 WiFi (<http://flower-platform.com/2015/12/18/flowerino-v0-6-0-release-notes-new-sample-project-control-lights-with-arduino-esp8266-wifi/>)
- > ESP8266 with AT Commands – Connect from PC with PuTTY (<http://flower-platform.com/2015/12/16/esp8266-with-at-commands-connect-from-pc-with-putty/>)
- > ESP8266 with AT Commands – Flashing/Updating the Firmware (step by step) (<http://flower-platform.com/2015/12/16/esp8266-with-at-commands-flashingupdating-the-firmware-step-by-step/>)
- > Introducing Flowerino. Draw diagrams and generate code for Arduino (<http://flower-platform.com/2015/10/23/introducing-flowerino-draw-diagrams-and-generate-code-for-arduino/>)
- > Flower Platform MDA is ready (<http://flower-platform.com/2015/09/05/flower-platform-mda-is-ready/>)

Recent Comments

- > SAMAS on ESP8266 with AT Commands – Flashing/Updating the Firmware (step by step) (<http://flower-platform.com/2015/12/16/esp8266-with-at-commands-flashingupdating-the-firmware-step-by-step/#comment-52>)

Archives

- > December 2015 (<http://flower-platform.com/2015/12/>)
- > October 2015 (<http://flower-platform.com/2015/10/>)
- > September 2015 (<http://flower-platform.com/2015/09/>)

- Programmed in C++ via the Arduino IDE (<https://www.arduino.cc/en/Main/Software>);
- Programmed in Lua script using the NodeMCU (<http://nodemcu.com>) firmware.

In this post we are focusing on the first use case: i.e. using the ESP8266 board with the AT Commands firmware. We are going to **upload (flash) the latest official firmware** from Espressif (<http://espressif.com/en/products/esp8266/>) (the manufacturer of the ESP8266 chip).


**HINT** We recommend to upload the latest firmware right after buying an ESP8266 board. Older versions (official or forks), are not really 100% compatible with the specs, and may even contain errors in the AT command syntax.

**SEE ALSO** This post (<http://flower-platform.com/2015/12/16/esp8266-with-at-commands-connect-from-pc-with-putty/>), for instructions on how to communicate with the ESP8266 from the PC, with PuTTY.

## Hardware Used

- ESP8266 based board (e.g. ESP-01 or ESP-201)
- 3.3V FTDI programmer or 5V FTDI programmer and voltage regulator
- 3.3KOhm or 4.7KOhm resistor (pull-up resistor for CHIP\_EN pin)
- Breadboard and jumper wires

## Wiring



([http://flower-platform.com/wp-content/uploads/2015/12/ESP8266-pc-generic\\_bb.png](http://flower-platform.com/wp-content/uploads/2015/12/ESP8266-pc-generic_bb.png))

As depicted in the diagram, the 2 wires at the bottom (IO0, IO2) are **needed only when uploading the firmware**. For normal communication via serial interface (e.g. from within Putty, or Arduino), these 2 wires should be removed.

**REMARK ON POWER** If the ESP8266 chip behaves strangely (e.g. garbage output at serial, random resets, repeated unsuccessful firmware updates, etc.), then it's probably related to the power supply. In this case we recommend to use a step down voltage regulator, connected to a relatively powerful (e.g. 500 mA) power source (e.g. an USB port instead of the FTDI output or an external power supply). This post (<https://hackaday.io/post/14647>) addresses various problems that may appear when using the ESP8266 module.

Below, we have particularized the fritzing diagram for the popular **ESP-01 module**:

> January 2015 (<http://flower-platform.com/2015/01/>)

### Categories

> Flower Platform (<http://flower-platform.com/category/flower-platform/>)


### Meta

> Log in (<http://flower-platform.com/wp-login.php>)

> Entries RSS (Really Simple Syndication) (<http://flower-platform.com/feed/>)

> Comments RSS (Really Simple Syndication) (<http://flower-platform.com/comments/feed/>)

> WordPress.org (<https://wordpress.org/>)



fritzing

([http://flower-platform.com/wp-content/uploads/2015/12/ESP8266-pc-examples-01\\_bb.png](http://flower-platform.com/wp-content/uploads/2015/12/ESP8266-pc-examples-01_bb.png))... and for the **ESP-201 module**.

Please note that in the diagram, the pin headers on the ESP8266 boards are on the other side of the board. Keep this in mind while connecting the jumper wires, if you hold the board facing the pin header side towards you.

flower platform


(<http://flower-platform.com>)

Flower Platform IoT Documentation (<http://flower-platform.com/iot/documentation/>)

Blog (<http://flower-platform.com/blog/>)

Forum (/forum)

Q



fritzing


([http://flower-platform.com/wp-content/uploads/2015/12/ESP8266-pc-examples-201\\_bb.png](http://flower-platform.com/wp-content/uploads/2015/12/ESP8266-pc-examples-201_bb.png))

## Download Software

1. Download the latest **Flash Download Tools (v2.4\_150924)** at the time of writing) from here (<http://bbs.espressif.com/viewtopic.php?f=5&t=433>).
2. Download the latest **AT release (v0.50)** at the time of writing) from here (<http://bbs.espressif.com/viewtopic.php?f=46&t=850>).

## Flashing Procedure

- 1 **Power on** the circuit.
- 2 **Detect module parameters.** Start *ESP Flash Download Tool*, set the COM port corresponding to your FTDI programmer, then click the **START** button in order to detect the specs of the board. After detection, you should see something like this:



([http://flower-platform.com/wp-content/uploads/2015/11/esp\\_flash\\_download\\_tool\\_01.jpg](http://flower-platform.com/wp-content/uploads/2015/11/esp_flash_download_tool_01.jpg))

3 **Gather information.** Make a note of the **flash memory size**. In this example, we have a 4Mbit flash. The size is shown in the “DETECTED INFO” text area, in the “flash” section (e.g. QUAD;4Mbit ).

From the AT release folder, open the `readme.txt` (e.g. `esp_iot_sdk_v1.4.0\bin\at\readme.txt`) file containing the information for flashing the firmware. Inside the file, there should be a “NON-BOOT MODE” section, as follows:

```
*****NON-BOOT MODE*****
```

```
download
```

```
eagle.flash.bin 0x00000
```

```
eagle.irom0text.bin 0x40000
```

```
blank.bin
```

```
Flash size 4Mbit: 0x3e000 & 0x7e000
```

```
Flash size 8Mbit: 0x7e000 & 0xfe000
```

```
Flash size 16Mbit: 0x7e000 & 0x1fe000
```

```
Flash size 16Mbit-C1: 0xfe000 & 0x1fe000
```

```
Flash size 32Mbit-C1: 0xfe000 & 0x3fe000
```

```
esp_init_data_default.bin (optional)
```

```
Flash size 4Mbit: 0x7c000
```

```
Flash size 8Mbit: 0xfc000
```

```
Flash size 16Mbit: 0x1fc000
```

```
Flash size 16Mbit-C1: 0x1fc000
```

```
Flash size 32Mbit: 0x3fc000
```

```
Flash size 32Mbit-C1: 0x3fc000
```

```
*NOTICE*:
```


```
UPDATE is not supported in non-boot mode
```

```
*****
```

4 **Indicate firmware files & addresses.** The firmware is broken down into several files (e.g. 3). They need to be provided to the **ESP Flash Download Tool**, together with the corresponding addresses (offsets) found in the `readme.txt` file above. So, in **ESP Flash Download Tool**, fill in (browse for) the files indicated in the **non-boot** section of the `readme.txt` file, and their corresponding offsets.

- eagle.flash.bin, e.g. from `esp_iot_sdk_v1.4.0\bin\at\noboot`
- eagle.irom0text.bin, e.g. from the same location
- blank.bin, e.g. from `esp_iot_sdk_v1.4.0\bin`. This file **appears twice**, with 2 different offsets.

After filling in the paths and offsets, you should have something similar to this:



([http://flower-platform.com/wp-content/uploads/2015/11/esp\\_flash\\_download\\_tool\\_02.jpg](http://flower-platform.com/wp-content/uploads/2015/11/esp_flash_download_tool_02.jpg))

**NOTE** Your `readme.txt` may differ from the section pasted above. Please use the addresses/offsets from your file!

5 Then, click the **START** button and wait until the flashing process is over.

By Cristian (<http://flower-platform.com/author/admin/>) | December 16th, 2015 | Flower Platform (<http://flower-platform.com/category/flower-platform/>) | 1 Comment (<http://flower-platform.com/2015/12/16/esp8266-with-at-commands-flashingupdating-the-firmware-step-by-step/#comments>)

Share

This

Story,

Choose

Your

Platform!

f

([http://www.facebook.com/sharer.php?m2w&s=100&p\[url\]=http://flower-platfon](http://www.facebook.com/sharer.php?m2w&s=100&p[url]=http://flower-platfon))

t

(<https://twitter.com/share?text=ESP8266%20with%20AT%20Commands%20%E2%80%93%20Flashing%20Updating%20the%20Firmw>)

p

(t

1

in

(<http://linkedin.com/shareArticle?mini=true&url=http://flower-platform.com/2015/12/16/esp8266-with-at-commands-flashingupdating-the>)

reddit

(<http://reddit.com/submit?url=http://flower-platform.com/2015/12/16/esp8266-with-at-commands-flashingupdating-the>)

step%2F&title=ESP8266%20with%20AT%20Commands%20%E2%80%93%20Flashing%20Updating%20the%20Firmware%20%E2%80%93%20step%20

✉

(mailto:?subject=ESP8266 with AT Comma

About the Author: Cristian (<http://flower-platform.com/author/admin/>)

Flower Platform IoT Documentation (<http://flower-platform.com/iot/documentation/>)

Blog (<http://flower-platform.com/blog/>)

Forum (/forum)

One Comment

Q

SAMAS

March 25, 2016 at 12:44 am - Reply (<http://flower-platform.com/2015/12/16/esp8266-with-at-commands-flashingupdating-the-firmware-step-by-step/?replytocom=52#respond>)

THANKS

Leave A Comment

Comment...

Name (required)

Email (required)

Website

POST COMMENT

Copyright Crispico Resonate (<http://crispico.com>) | All Rights Reserved

f

(<https://www.facebook.com/flower.platform.by.crispico>)

t

([https://twitter.com/flower\\_platform](https://twitter.com/flower_platform))

y

(<https://www.youtube.com/user/flowerplatform/videos>)

<http://flower-platform.com/2015/12/16/esp8266-with-at-commands-flashingupdating-the-firmware-step-by-step/>

5/5