



# I Can't Get MatterControl to Connect to My Printer

First, you should ensure that you have downloaded and installed the [RAMBO driver](#)

Instructions for installing this driver can be found in the assembly/user manual.

You should also ensure that your printer and computer are connected via a USB cable and that the printer is powered on and firmware has been installed.