



Where Can I Find Slicing Settings For MatterControl?

If you've downloaded MatterControl from our website (our official version) it comes with optimized starting settings to generate your prints with. You can update MatterControl with default slicing settings by adding a "New Printer." This can be accomplished by clicking on the printer name in the upper left corner of the program. Once you have setup the "new printer" you will have a fresh set of default settings ready to print.