

DIGITAL PROJECTION MANUAL



Turn on both sound towers
Non-sync 2 sound; default level 5.3
Turn on fan
Left breaker (#9 & 10—the old now gone 16 mm projector) marked DVD (or digital??)
Projector Motor 1: Right breaker box, right side #4
Power on back of Digital Projector

Press and hold “on/standby” on side of projector (projector is upside down b/c of keystoneing)

Select input: On remote: Menu Address>Source Select (2nd from top)>S3: SDI1 (for DVD player)
S1: Video
S1: SVideo
S2: RGB
S3: SDI1

Types of inputs:

4 analog:

Composite: 1 signal/1 cable (2 pin)
SVideo: 4 pin (luminens/cromens)
Component: GRB
?VGA: 15 pin (best analog format)

2 Digital:

DVI-D

??

Cue DVD past all start up crap to beginning

Press pause

On DVD projector, press Ctrl + Shutter (toggles)

To eliminate seeing “play” wait a few seconds after starting DVD to toggle DVD projector shutter

Mute: 3 buttons

- 1) Picture mute
- 2) Sound mute
- 3) OSD (On screen display) mute (date/time stamp)

Aspect Ratio

DVD default is 4:3 (set for TV)

Use 16mm masking and then play with upper lower masking

DVD Player: Denon DVD-2910-955

2 buttons on DVD Deck: Use remote

On/Standby

Power

Modules:

Unit 1: Composite (CVSB)

Unit 2: VGA Cable

Unit 3: ~

Unit 4: DVI

Turning Projector Off:

Hold “On/Standby” button til starts to cool (3 minutes).

Only once/til “on standby” then can turn off