

AIRCRAFT RADIO NAVIGATION VARIABLES

The tables below indicate the properties for the [Simulation Variables](#) that can be used to get and set properties related to the various radio navigation systems of an aircraft and Air Traffic Control. For information on the units listed for each variable, please see here: [Simulation Variable Units](#)

NOTE: When Microsoft Flight Simulator is running in multiplayer mode, only a small number of variables are communicated between aircraft. Those variables that are available will say so in the description as being either for "All Aircraft" or for "Shared Cockpit".

You can find a complete index of all available SimVars here: [SimVar Index](#)

ADF

Simulation Variable	Description	Units	Settable
<code>ADF ACTIVE FREQUENCY:index</code>	<i>ADF</i> frequency. Index of 1 or 2.	Frequency ADF BCD32	
<code>ADF AVAILABLE:index</code>	True if ADF is available	Bool	
<code>ADF CARD</code>	ADF compass rose setting	Degrees	
<code>ADF EXT FREQUENCY</code> <i>Deprecated</i>	Deprecated, use <code>ADF ACTIVE FREQUENCY</code>	Frequency BCD16	

<code>ADF FREQUENCY</code> <i>Deprecated</i>	Deprecated, use <code>ADF ACTIVE FREQUENCY</code>	Frequency BCD16	
<code>ADF IDENT</code>	<i>ICAO code</i>	String	
<code>ADF LATLONALT:index</code>	Returns the latitude, longitude and altitude of the station the radio equipment is currently tuned to, or zeros if the radio is not tuned to any ADF station. Index of 1 or 2 for ADF 1 and ADF 2.	<code>SIMCONNECT_DATA_LATLONALT</code> structure	
<code>ADF NAME:index</code>	Descriptive name	String	
<code>ADF RADIAL:index</code>	Current direction from <i>NDB</i> station	Degrees	
<code>ADF RADIAL MAG:index</code>	Returns the magnetic bearing to the currently tuned ADF transmitter.	Degrees	
<code>ADF SIGNAL:index</code>	Signal strength	Number	
<code>ADF SOUND:index</code>	<i>ADF</i> audio flag. Index of 0 or 1.	Bool	

ADF STANDBY AVAILABLE:index	True if <i>ADF</i> Standby is available	Bool	
ADF STANDBY FREQUENCY:index	<i>ADF</i> standby frequency	Hz	
ADF VOLUME	Returns the volume of the <i>ADF</i>	<i>Percent Over 100</i>	

ATC

Simulation Variable	Description	Units	Settable
ATC AIRLINE	The name of the Airline used by ATC, as a string with a maximum length of 50 characters.	String	
ATC AIRPORT IS TOWERED	If the airport is controlled, this boolean is true.	Bool	
ATC CLEARED IFR	Returns whether or not the user has filed an IFR flightplan that has been cleared by the sim ATC	Bool	
ATC CLEARED LANDING	Whether the ATC has cleared the plane for landing.	Bool	
ATC CLEARED TAKEOFF	Whether the ATC has cleared the plane for takeoff.	Bool	
ATC CLEARED TAXI	Whether the ATC has cleared the plane for taxi.	Bool	
ATC CURRENT WAYPOINT ALTITUDE	Returns the target altitude for the current ATC flightplan waypoint.	Bool	

ATC FLIGHT NUMBER	Flight Number used by ATC, as a string with a maximum number of 6 characters.	String	
ATC FLIGHTPLAN DIFF ALT	Altitude between the position of the aircraft and his closest waypoints in the flightplan.	Meters	
ATC FLIGHTPLAN DIFF DISTANCE	Returns the lateral distance the user's plane is from the ATC flight plan track.	Meters	
ATC FLIGHTPLAN DIFF HEADING	Heading between the position of the aircraft and his closest waypoints in the flightplan.	Degrees	
ATC HEAVY	Is this aircraft recognized by ATC as heavy.	Bool	
ATC ID	ID used by ATC, as a string with a maximum number of 10 characters.	String	
ATC IFR FP TO REQUEST	Returns true if the user has a valid IFR flight plan they can as for clearance for with ATC at the airport they are currently at.	Bool	
ATC MODEL	Model used by ATC, as a string with a maximum number of 10 characters.	String	
ATC ON PARKING SPOT	Is ATC aircraft on parking spot.	Bool	
ATC PREVIOUS WAYPOINT ALTITUDE	Returns the target altitude for the previous ATC flightplan waypoint.	Meters	
ATC RUNWAY AIRPORT NAME	The name of the airport of the runway assigned by the ATC. Returns "" if no runway is assigned.	String	
ATC RUNWAY DISTANCE	This float represents the distance between the player's	Meters	

	plane and the center of the runway selected by the ATC.		
ATC RUNWAY END DISTANCE	This is a float corresponding to the horizontal distance between the player's plane and the end of the runway selected by the ATC.	Meters	
ATC RUNWAY HEADING DEGREES TRUE	This float represents the true heading of the runway selected by the ATC.	Degrees	
ATC RUNWAY LENGTH	The length of the runway assigned by the ATC. Returns -1 if no runway is assigned.	Meters	
ATC RUNWAY RELATIVE POSITION X	This is a float corresponding to the player's main gear relative X (transverse) position on the runway selected by the ATC.	Meters	
ATC RUNWAY RELATIVE POSITION Y	This is a float corresponding to the player's main gear relative Y (height) position on the runway selected by the ATC.	Meters	
ATC RUNWAY RELATIVE POSITION Z	This is a float corresponding to the player's main gear relative Z (longitudinal) position on the runway selected by the ATC.	Meters	
ATC RUNWAY SELECTED	This is a boolean corresponding to whether or not the ATC has pre-selected a runway for the player's plane. If this is false, every other ATC RUNWAY * SimVar will return default values.	Bool	
ATC RUNWAY START DISTANCE	This is a float corresponding to the horizontal distance between the player's plane and the start of the runway selected by the ATC.	Meters	

ATC RUNWAY TDPOINT RELATIVE POSITION X	This float represents the player's main gear relative X (transverse) position according to the aiming point of the runway selected by the ATC.	Meters	
ATC RUNWAY TDPOINT RELATIVE POSITION Y	This float represents the player's main gear relative Y (height) position according to the aiming point of the runway selected by the ATC.	Meters	
ATC RUNWAY TDPOINT RELATIVE POSITION Z	This float represents the player's main relative Z (longitudinal) position according to the aiming point of the runway selected by the ATC.	Meters	
ATC RUNWAY WIDTH	The width of the runway assigned by the ATC. Returns -1 if no runway is assigned.	Meters	
ATC SUGGESTED MIN RWY LANDING	Suggested minimum runway length for landing. Used by ATC.	Feet	
ATC SUGGESTED MIN RWY TAKEOFF	Suggested minimum runway length for takeoff. Used by ATC.	Feet	
ATC TAXIPATH DISTANCE	Returns the lateral distance the user's plane is from the path of the currently issued ATC taxi instructions.	Meters	
ATC TYPE	Type used by ATC.	String (30)	

COM

Simulation Variable	Description	Units	Settable
---------------------	-------------	-------	----------

<div>COM1</div> <div>STORED</div> <div>FREQUENCY</div> <div>COM2</div> <div>STORED</div> <div>FREQUENCY</div> <div>COM3</div> <div>STORED</div> <div>FREQUENCY</div>	The stored COM 1/2/3 frequency value.	Frequency BCD16	
<div>COM ACTIVE</div> <div>BEARING:index</div>	Gives the bearing (in degrees) of the active COM station (airport) or a value less than 0 if the station does not belong to an airport. Index is 1, 2 or 3.	Degrees	
<div>COM ACTIVE</div> <div>DISTANCE:index</div>	Gives the distance (in meters) to the active COM station (airport) or a value less than -180° if the station does not belong to an airport. Index is 1, 2 or 3.	Meters	
<div>COM ACTIVE</div> <div>FREQUENCY:index</div>	Com frequency. Index is 1, 2 or 3.	Frequency BCD16	
<div>COM ACTIVE FREQ</div> <div>IDENT:index</div>	The identity of the station that is tuned on the indexed active COM radio. Index is 1, 2, or 3.	String	

COM ACTIVE FREQ TYPE:index	<p>The type of COM frequency for the active indexed COM system. Index is 1, 2, or 3.</p>	<p>String:</p> <p>"ATIS" - Atis "UNI" - Unicom "CTAF" - CTAF "GND" - Ground "TW" - Tower "CLR" - Clearance</p> <p>Delivery "APPR" - Approach "DEP" - Departure "FSS" - FSS "AWS" - AWOS</p>	
COM ACTIVE LATLONALT:index	<p>This will return the latitude, longitude and altitude corresponding to the indexed COM station associated with the active COM frequency. If the station is not associated with an airport, then the lat/lon/alt values returned will be -15943°, 80°, -10000 (this means that you can simply check that the altitude value is greater than 0 to assure the validity of the returned struct). Index is 1, 2 or 3.</p>	<p>Struct:</p> <p>SIMCONNECT_DATA_LATLONALT</p>	
COM AVAILABLE:index	<p>True if COM1, COM2 or COM3 is available</p>	<p>Bool</p>	

	(depending on the index, either 1, 2, or 3)		
COM LATLONALT:index	<i>Not currently used in the simulation.</i>	Struct: SIMCONNECT_DATA_LATLONALT	
COM RECEIVE:index	Whether or not the plane is receiving on the indexed com channel or not (either 1, 2, or 3 for the index).	Bool	
COM RECEIVE ALL	Toggles all COM radios to receive on	Bool	
COM RECEIVE EX1:index	Whether or not the plane is receiving on the indexed com channel. Index is 1, 2 or 3.	Bool	
COM SPACING MODE:index	The COM radio frequency step. Index is 1, 2 or 3.	Enum: 0 = 25kHz 1 = 8.33kHz	
COM STANDBY FREQUENCY:index	Com standby frequency. Index is 1, 2 or 3.	Frequency BCD16	
COM STANDBY FREQ IDENT:index	The identity of the station that is tuned on the indexed standby COM radio. Index is 1, 2, or 3.	String	
COM STANDBY FREQ TYPE:index	The type of COM frequency for the standby	String: "ATIS" - Atis "UNI" - Unicom	

	indexed COM system. Index is 1, 2, or 3.	"CTAF" - CTAF "GND" - Ground "TWR" - Tower "CLR" - Clearance Delivery "APPR" - Approach "DEP" - Departure "FSS" - FSS "AWS" - AWOS	
COM STATUS:Index	Radio status flag for the indexed com channel. Index is 1, 2 or 3.	Enum: -1 = Invalid 0 = OK 1 = Does not exist 2 = No electricity 3 = Failed	
COM TEST:Index	Enter an index of 1, 2 or 3. Will return TRUE if the COM system is working, FALSE otherwise.	Bool	
COM TRANSMIT:Index	Audio panel com transmit state. Index of 1, 2 or 3.	Bool	
COM VOLUME	The volume of the COM Radio.	Percent	

FLARM

Simulation Variable	Description	Units	Settable
FLARM AVAILABLE	Whether the FLARM is available (TRUE, 1) or not (FALSE, 0).	Bool	

FLARM THREAT BEARING	The bearing of the FLARM threat aircraft, relative to track.	Degrees	
FLARM THREAT DATA	<p>The FLARM threat aircraft data structure, which contains data about the perceived threat, returned as a struct. Struct member variables are as follows:</p> <p>id (U62): the network id of the intruding plane so that they are remembered in order to compute their trajectory.</p> <p>bearing (FLOAT64): The threat bearing, in degrees (this is bearing from track axis and not bearing from the airplane axis).</p> <p>heading (FLOAT64): The threat heading.</p> <p>distance (FLOAT64): The distance between the aircraft and the threat, in meters.</p> <p>verticalBearing (FLOAT64): The vertical bearing between the aircraft and the threat, in degrees.</p> <p>relativeAltitude (FLOAT64): The relative altitude of the threat to the aircraft, in meters.</p> <p>timeToCollision (FLOAT64): The estimated time to a collision, in seconds.</p>	Struct	
FLARM THREAT DISTANCE	The distance to the FLARM threat object.	Meters	
FLARM THREAT HEADING	The heading to the FLARM threat object.	Degrees	
FLARM THREAT RELATIVE ALTITUDE	The relative altitude of the threat object.	Meters	
FLARM THREAT TIME TO COLLISION	The estimated time to a collision.	Seconds	
FLARM THREAT VERTICAL BEARING	The vertical bearing towards the threat.	Degrees	

GPS

When using these SimVars, it is worth noting that to correctly set those that can be set, you should first use the SimVar `GPS_OVERRIDEN` and set it to `TRUE`. If you don't set this SimVar, then any changes that are made to the other GPS variables will be overridden by the simulation GPS system moments after you set them.

Simulation Variable	Description	Units	Settable
<code>GPS_APPROACH_AIRPORT_ID</code>	ID of airport.	String	
<code>GPS_APPROACH_APPROACH_ID</code>	ID of approach.	String	
<code>GPS_APPROACH_APPROACH_INDEX</code>	Index of approach for given airport.	Number	
<code>GPS_APPROACH_APPROACH_TYPE</code>	Approach type.	Enum: 0 = None 1 = <i>GPS</i> 2 = <i>VOR</i> 3 = <i>NDB</i> 4 = <i>ILS</i> 5 = Localizer 6 = <i>SDF</i> 7 = <i>LDA</i> 8 = <i>VOR/DME</i> 9 = <i>NDB/DME</i> 10 = <i>RNAV</i> 11 = Backcourse	
<code>GPS_APPROACH_IS_FINAL</code>	Is approach transition final approach segment.	Bool	
<code>GPS_APPROACH_IS_MISSED</code>	Is approach segment missed approach segment.	Bool	

GPS APPROACH IS WP RUNWAY	Waypoint is the runway.	Bool	
GPS APPROACH MODE	Sub mode within approach mode.	Enum: 0 = None 1 = Transition 2 = Final 3 = Missed	
GPS APPROACH SEGMENT TYPE	Segment type within approach.	Enum: 0 = Line 1 = Arc clockwise 2 = Arc counter-clockwise	
GPS APPROACH TIMEZONE DEVIATION	Deviation of local time from GMT.	Seconds	
GPS APPROACH TRANSITION ID	ID of approach transition.	String	
GPS APPROACH TRANSITION INDEX	Index of approach transition.	Number	
GPS APPROACH WP COUNT	Number of waypoints.	Number	
GPS APPROACH WP INDEX	Index of current waypoint.	Number	
GPS APPROACH WP TYPE	Waypoint type within approach mode.	Enum: 0 = None 1 = Fix 2 = Procedure turn left 3 = Procedure turn right 4 = Dme arc left 5 = Dme arc right 6 = Holding left	

		7 = Holding right 8 = Distance 9 = Altitude 10 = Manual sequence 11 = Vector to final	
GPS CDI NEEDLE	The course deviation of the needle for a CDI instrument. The SimVar displays the deviation from -127 to +127. It returns a value if a flight plan is set (otherwise it will return 0) even if the autopilot isn't on GPS mode. Scaling can also be set through the GPS CDI SCALING simvar.	Number	
GPS CDI SCALING	The full scale deflection of the CDI due to GPS cross-track error, in meters.	Meters	
GPS COURSE TO STEER	Suggested heading to steer (for autopilot).	Radians	
GPS DRIVES NAV1	GPS is driving Nav 1 indicator. Note this setting will also affect the SimVars HSI_STATION_IDENT and HSI_BEARING .	Bool	
GPS ETA	Estimated time of arrival at destination.	Seconds	
GPS ETE	Estimated time en route to destination.	Seconds	
GPS FLIGHTPLAN TOTAL DISTANCE	This is the complete flightplan length from start to end. Essentially the cumulative length of	Meters	

	all the flight plan legs added together.		
GPS FLIGHT PLAN WP COUNT	Number of waypoints.	Number	
GPS FLIGHT PLAN WP INDEX	Index of waypoint.	Number	
GPS GROUND MAGNETIC TRACK	Current magnetic ground track.	Radians	
GPS GROUND SPEED	Current ground speed.	Meters per second	
GPS GROUND TRUE HEADING	Current true heading.	Radians	
GPS GROUND TRUE TRACK	Current true ground track.	Radians	
GPS GSI SCALING	The full scale deflection of the vertical GSI due to GPS glidepath deviation, in meters.	Meters	
GPS HAS GLIDEPATH	Whether or not the GPS system has a presently available glidepath for guidance. Only applicable with GPS_OVERRIDDEN . When true and in GPS_OVERRIDDEN , HSI_GSI_NEEDLE_VALID will also be true.	Bool	
GPS HSI NEEDLE	The glide deviation of the needle for a CDI instrument. The simvar displays the deviation from -127 to +127. It returns a value if a flight plan is set (otherwise it will return 0) even if the autopilot isn't on GPS mode. Scaling can also be	Number	

	set through the GPS CDI SCALING simvar.		
GPS IS ACTIVE FLIGHT PLAN	Flight plan mode active.	Bool	
GPS IS ACTIVE WAY POINT	Waypoint mode active.	Bool	
GPS IS ACTIVE WP LOCKED	Is switching to next waypoint locked.	Bool	
GPS IS APPROACH ACTIVE	Is approach mode active.	Bool	
GPS IS APPROACH LOADED	Is approach loaded.	Bool	
GPS IS ARRIVED	Is flight plan destination reached.	Bool	
GPS IS DIRECTTO FLIGHTPLAN	Is Direct To Waypoint mode active.	Bool	
GPS MAGVAR	Current GPS magnetic variation.	Radians	
GPS OBS ACTIVE	Whether or not the OBS mode is currently active (disable the automatic sequencing of waypoints in GPS flight plan).	Bool	
GPS OBS VALUE	This is the currently selected OBS course in degrees, from 0 to 360.	Degrees	
GPS OVERRIDDEN	When it is active, all sim GPS system updates are suspended. This must be set to TRUE to be able to correctly set to any other GPS SimVar.	Bool	

GPS POSITION ALT	Current GPS altitude.	Meters	
GPS POSITION LAT	Current GPS latitude.	Degrees	
GPS POSITION LON	Current GPS longitude.	Degrees	
GPS TARGET ALTITUDE	Altitude of GPS target.	Meters	
GPS TARGET DISTANCE	Distance to target.	Meters	
GPS VERTICAL ANGLE	Glidepath in degrees.	Degrees	
GPS VERTICAL ANGLE ERROR	Vertical error in degrees from GlidePath.	Degrees	
GPS VERTICAL ERROR	Vertical deviation in meters from GlidePath.	Meters	
GPS WP BEARING	Magnetic bearing to waypoint.	Radians	
GPS WP CROSS TRK	Cross track distance.	Meters	
GPS WP DESIRED TRACK	The required heading (magnetic) from the previous waypoint to the next waypoint.	Radians	
GPS WP DISTANCE	Distance to waypoint.	Meters	
GPS WP ETA	Estimated time of arrival at waypoint.	Seconds	
GPS WP ETE	Estimated time en route to waypoint.	Seconds	
GPS WP NEXT ALT	Altitude of next waypoint.	Meters	

GPS WP NEXT ID	ID of next GPS waypoint.	String	
GPS WP NEXT LAT	Latitude of next waypoint.	Degrees	
GPS WP NEXT LON	Longitude of next waypoint.	Degrees	
GPS WP PREV ALT	Altitude of previous waypoint.	Meters	
GPS WP PREV ID	ID of previous GPS waypoint.	String	
GPS WP PREV LAT	Latitude of previous waypoint.	Degrees	
GPS WP PREV LON	Longitude of previous waypoint.	Degrees	
GPS WP PREV VALID	Is previous waypoint valid (i.e. current waypoint is not the first waypoint).	Bool	
GPS WP TRACK ANGLE ERROR	Tracking angle error to waypoint.	Radians	
GPS WP TRUE BEARING	True bearing to waypoint.	Radians	
GPS WP TRUE REQ HDG	Required true heading to waypoint.	Radians	
GPS WP VERTICAL SPEED	Vertical speed to waypoint.	Meters per second	

HSI

Simulation Variable	Description	Units	Settable
HSI BEARING	If the GPS_DRIVES_NAV1 variable is true and the HSI	Degrees	

	BEARING_VALID variable is true, this variable contains the HSI needle bearing. If the GPS_DRIVES_NAV1 variable is false and the HSI_BEARING_VALID variable is true, this variable contains the ADF1 frequency.		
HSI_BEARING_VALID	This will return true if the HSI_BEARING variable contains valid data.	Bool	
HSI_CDI_NEEDLE	Needle deflection (+/- 127).	Number	
HSI_CDI_NEEDLE_VALID	Signal valid.	Bool	
HSI_DISTANCE	DME/GPS distance.	Nautical miles	
HSI_GSI_NEEDLE	Needle deflection (+/- 119).	Number	
HSI_GSI_NEEDLE_VALID	Signal valid.	Bool	
HSI_HAS_LOCALIZER	Station is a localizer.	Bool	
HSI_SPEED	DME/GPS speed.	Knots	
HSI_STATION_IDENT	Returns the ident of the the next GPS waypoint, if GPS_DRIVES_NAV1 is true. If GPS_DRIVES_NAV1 is false, it returns the identity of the station that is tuned on nav radio 1.	String	
HSI_TF_FLAGS	Nav TO/FROM flag.	Enum: 0 = Off 1 = TO 2 = FROM	

MARKERS

Simulation Variable	Description	Units	Settable
INNER MARKER	Inner marker state.	Bool	
INNER MARKER LATLONALT	Returns the latitude, longitude and altitude of the inner marker of an approach to a runway, if the aircraft is within the required proximity, otherwise it will return zeros.	<u>SIMCONNECT_DATA_LATLONALT</u> structure	
MARKER AVAILABLE	True if Marker is available.	Bool	
MARKER BEACON SENSITIVITY HIGH	Whether or not the Marker Beacon is in High Sensitivity mode.	Bool	
MARKER BEACON STATE	Marker beacon state.	Enum: 0 = None 1 = Outer 2 = Middle 3 = Inner	
MARKER BEACON TEST MUTE	Whether or not the Marker Beacon is in Test/Mute mode.	Bool	
MARKER SOUND	Marker audio flag.	Bool	

MIDDLE MARKER	Middle marker state.	Bool	
MIDDLE MARKER LATLONALT	Returns the latitude, longitude and altitude of the middle marker.	<u>SIMCONNECT_DATA_LATLONALT</u> structure	
OUTER MARKER	Outer marker state.	Bool	
OUTER MARKER LATLONALT	Returns the latitude, longitude and altitude of the outer marker.	<u>SIMCONNECT_DATA_LATLONALT</u> structure	

NAV

Simulation Variable	Description	Units	Settable
NAV ACTIVE FREQUENCY:index	Nav active frequency. Index is 1 or 2.	MHz	
NAV AVAILABLE:index	Flag if Nav equipped on aircraft.	Bool	
NAV BACK COURSE FLAGS:index	Returns the listed bit flags.	Flags: BIT0:[index] 1=back course available BIT1:[index] 1=localizer tuned in BIT2:[index] 1=on course BIT7:[index] 1=station active	
NAV CDI:index	CDI needle deflection (+/- 127).	Number	
NAV CLOSE DME:index	Closest DME distance. Requires an index value from 1 to 4 to set which NAV to target.	Nautical miles	

	<p>Note that this SimVar will only work if the NAV1_CLOSE_FREQ_SET key event has been set to 1 (TRUE).</p>		
NAV CLOSE FREQUENCY:index	<p>Closest Localizer course frequency. Requires an index value from 1 to 4 to set which NAV to target.</p> <p>Note that this SimVar will only work if the NAV1_CLOSE_FREQ_SET key event has been set to 1 (TRUE).</p>	Hz	
NAV CLOSE IDENT:index	<p>ICAO code. Requires an index value from 1 to 4 to set which NAV to target.</p> <p>Note that this SimVar will only work if the NAV1_CLOSE_FREQ_SET key event has been set to 1 (TRUE).</p>	String	
NAV CLOSE LOCALIZER:index	<p>Closest Localizer course heading. Requires an index value from 1 to 4 to set which NAV to target.</p> <p>Note that this SimVar will only work if the NAV1_CLOSE_FREQ_SET key event has been set to 1 (TRUE).</p>	Degrees	
NAV CLOSE NAME:index	<p>Descriptive name. Requires an index value from 1 to 4 to set which NAV to target.</p> <p>Note that this SimVar will only work if the</p>	String	

	NAV1_CLOSE_FREQ_SET key event has been set to 1 (TRUE).		
NAV CODES	Returns bit flags with the listed meaning.	Flags: BIT7:[index] 0= VOR 1= Localizer BIT6:[index] 1= glideslope available BIT5:[index] 1= no localizer backcourse BIT4:[index] 1= DME transmitter at glide slope transmitter BIT3:[index] 1= no nav signal available BIT2:[index] 1= voice available BIT1:[index] 1= TACAN available BIT0:[index] 1= DME available	
NAV DME	DME distance.	Nautical miles	
NAV DMESPEED	DME speed.	Knots	
NAV DME LATLONALT:index	Returns the DME station.	<u>SIMCONNECT_DATA_LATLONALT</u> structure	
NAV FREQUENCY	Localizer course frequency	Hz	
NAV GLIDE SLOPE	The glide slope gradient. The value returned is an integer value formed as follows: <div> $\sin(\text{slope}) * 65536 * 2$ </div> So, for example, a glide slope of 2.7° would return a value of 6174. TO get the value in degrees, then	Number	

	use NAV_RAW_GLIDE_SLOPE instead.		
NAV_GLIDE_SLOPE_ERROR	Difference between current position and glideslope angle. Note that this provides 32 bit floating point precision, rather than the 8 bit integer precision of NAV GSI.	Degrees	
NAV_GLIDE_SLOPE_LENGTH	The distance between the plane and the Glide beacon.	Feet	
NAV_GSI	Glideslope needle deflection (+/- 119). Note that this provides only 8 bit precision, whereas NAV GLIDE SLOPE ERROR provides 32 bit floating point precision.	Number	
NAV_GS_FLAG	Glideslope flag.	Bool	
NAV_GS_LATLONALT:index	Returns the glide slope.	SIMCONNECT_DATA_LATLONALT structure	
NAV_GS_LLA64	Nav GS latitude, longitude, altitude.	SIMCONNECT_DATA_LATLONALT structure	
NAV_HAS_CLOSE_DME	Flag if found a close station with a DME.	Bool	
NAV_HAS_CLOSE_LOCALIZER	Flag if found a close localizer station.	Bool	
NAV_HAS_DME	Flag if tuned station has a DME.	Bool	
NAV_HAS_GLIDE_SLOPE	Flag if tuned station has a glideslope.	Bool	

NAV HAS LOCALIZER	Flag if tuned station is a localizer.	Bool	
NAV HAS NAV	Flag if Nav has signal.	Bool	
NAV HAS TACAN	Flag if Nav has a <i>Tacan</i> .	Bool	
NAV IDENT	ICAO code.	String	
NAV LOCALIZER	Localizer course heading.	Degrees	
NAV LOC AIRPORT IDENT	The airport ICAO ident for the localizer that is currently tuned on the nav radio (like 'EGLL' or 'KJFK')	String	
NAV LOC RUNWAY DESIGNATOR	The letter code for the runway that the currently tuned localizer is tuned to.	String 'L' - Left 'R' - Right 'C' - Center 'W' - Water 'A' - A 'B' - B	
NAV LOC RUNWAY NUMBER	NAV LOC RUNWAY NUMBER - The number portion of the runway that the currently tuned localizer is tuned to (so if the runway was 15L, this would be 15).	String '1' - '36' 'N' 'NE' 'E' 'SE' 'S' 'SW' 'W' 'NW'	
NAV MAGVAR	Magnetic variation of tuned Nav station.	Degrees	
NAV NAME	Descriptive name.	String	
NAV OBS	OBS setting. Index of 1 or 2.	Degrees	

NAV RADIAL	Radial that aircraft is on.	Degrees	
NAV RADIAL ERROR	Difference between current radial and OBS tuned radial.	Degrees	
NAV RAW GLIDE SLOPE	The glide slope angle.	Degrees	
NAV RELATIVE BEARING TO STATION	Relative bearing to station.	Degrees	
NAV SIGNAL	Nav signal strength.	Number	
NAV SOUND:index	Nav audio flag. Index of 1 or 2.	Bool	
NAV STANDBY FREQUENCY:index	Nav standby frequency. Index is 1 or 2.	MHz	
NAV TOFROM	Returns whether the Nav is going to or from the current radial (or is off).	Enum: 0 = Off 1 = TO 2 = FROM	
NAV VOLUME	The volume of the Nav radio.	Percent	
NAV VOR DISTANCE	Distance of the VOR beacon.	Meters	
NAV VOR LATLONALT:index	Returns the VOR station latitude, longitude and altitude.	<u>SIMCONNECT_DATA_LATLONALT</u> structure	
NAV VOR LLAF64	Nav VOR latitude, longitude, altitude.	<u>SIMCONNECT_DATA_LATLONALT</u> structure	

TACAN

The table below lists all the SimVars related to the *Tacan* system on an aircraft. You can have either 1 or 2 of these systems, and in so all these

SimVars require an index value of 1 or 2, depending on which one you want to target. Note that you must have first enabled the Tacan using the `Tacan.N` parameter in the [systems.cfg](#) file.

Simulation Variable	Description	Units	Settable
<code>TACAN ACTIVE CHANNEL:index</code>	The active channel used by the indexed <i>Tacan</i> receiver on the aircraft, from 1 to 127.	Number	
<code>TACAN ACTIVE MODE:index</code>	The active mode used by the indexed <i>Tacan</i> receiver on the aircraft, where 0 = X and 1 = Y.	Bool	
<code>TACAN AVAILABLE:index</code>	Will be TRUE (1) if NAV1, NAV2, NAV3 or NAV4 can receive <i>Tacan</i> (depending on the index - 1, 2, 3, or 4), or FALSE (0) otherwise.	Bool	
<code>TACAN DRIVES NAV1:index</code>	Tells whether the <i>Tacan</i> is driving the Nav 1 indicator (TRUE, 1) or not (FALSE, 0), for autopilot purposes.	Bool	
<code>TACAN OBS:index</code>	The <i>Tacan</i> OBS setting, in degrees.	Degrees	

<code>TACAN_STANDBY_CHANNEL:index</code>	The standby channel used by the indexed <i>Tacan</i> receiver on the aircraft, from 1 to 127.	Number	
<code>TACAN_STANDBY_MODE:index</code>	Indicates the indexed <i>Tacan</i> receiver standby mode, where 0 = X and 1 = Y.	Bool	
<code>TACAN_STATION_CDI:index</code>	The CDI needle deflection amount(course deviation) to the station. Can be +/- 127.	Number	
<code>TACAN_STATION_DISTANCE:index</code>	The distance between the <i>Tacan</i> station position and the aircraft position. The index value refers to the Tacan receiver connected to the station (1 or 2).	Meter	
<code>TACAN_STATION_IDENT:index</code>	The tuned station identifier for the indexed <i>Tacan</i> .	String	
<code>TACAN_STATION_LATLONALT:index</code>	Retrieves the latitude, longitude and altitude of the <i>Tacan</i> station.	<code>SIMCONNECT_DATA_LATLONALT</code> structure	
<code>TACAN_STATION_RADIAL:index</code>	The radial between the <i>Tacan</i> station and the aircraft.	Degrees	

TACAN STATION RADIAL ERROR: <code>index</code>	Difference between the current radial and OBS tuned radial, in degrees.	Degrees.	
TACAN STATION TOFROM: <code>index</code>	Returns whether the indexed <i>Tacan</i> is going <i>to</i> or <i>from</i> the current radial (or is off).	Enum: 0 = Off 1 = TO 2 = FROM	
TACAN VOLUME: <code>index</code>	The volume value of the indexed <i>Tacan</i> receiver on the aircraft.	<i>Percent Over 100</i>	

Misc.

Simulation Variable	Description	Units	Settable
COPILOT TRANSMITTER TYPE	On which channel the copilot is transmitting.	Enum: 0 = COM1 1 = COM2 2 = COM3 3 = TEL 4 = NONE	
COPILOT TRANSMITTING	Whether or not the copilot is transmitting.	Bool	
PILOT TRANSMITTER TYPE	On which channel the pilot is transmitting.	Enum: 0 = COM1 1 = COM2	

		2 = COM3 3 = TEL 4 = NONE	
PILOT TRANSMITTING	Whether or not the pilot is transmitting.	Bool	
RADIOS AVAILABLE	<i>Currently not used within the simulation.</i>	-	
RADIO HEIGHT	Radar altitude.	Feet	