

# AIRCRAFT SYSTEM VARIABLES

The tables below indicate the properties for the [Simulation Variables](#) that can be used to get and set properties related to the various aircraft controls and systems. For information on the units listed for each variable, please see here: [Simulation Variable Units](#)

**NOTE:** When Microsoft Flight Simulator is running in multiplayer mode, only a small number of variables are communicated between aircraft. Those variables that are available will say so in the description as being either for "All Aircraft" or for "Shared Cockpit".

You can find a complete index of all available SimVars here: [SimVar Index](#)

## General

Simulation Variable	Description	Units	Settable
<a href="#">AIRSPEED TRUE CALIBRATE</a>	Angle of True calibration scale on airspeed indicator.	Degrees	
<a href="#">ALTERNATE STATIC SOURCE OPEN:index</a>	Alternate static air source.	Bool	
<a href="#">ANEMOMETER PCT RPM</a>	Anemometer rpm as a percentage.	<i>Percent Over 100</i>	
<a href="#">ANGLE OF ATTACK INDICATOR</a>	<i>AoA</i> indication.	Radians	
<a href="#">ANNUNCIATOR SWITCH</a>	<i>Currently not used in the simulation.</i>	Bool	
<a href="#">APPLY HEAT TO SYSTEMS</a>	Used when too close to a fire.	Bool	
<a href="#">AUDIO PANEL AVAILABLE</a>	True if the audio panel is available.	Bool	
<a href="#">AUDIO PANEL VOLUME</a>	The Volume of the Audio Panel.	Percent	

<b>AUTOTHROTTLE ACTIVE</b>	Auto-throttle active.	Bool	
<b>AUTO COORDINATION</b>	Is auto-coordination active.	Bool	
<b>AVIONICS MASTER SWITCH:index</b>	The avionics master switch position, <b>true</b> if the switch is ON. Use an avionics circuit index when referencing.	Bool	
<b>CABIN NO SMOKING ALERT SWITCH</b>	True if the No Smoking switch is on.	Bool	
<b>CABIN SEATBELTS ALERT SWITCH</b>	True if the Seatbelts switch is on.	Bool	
<b>CANOPY OPEN</b>	Percent primary door/exit open.	<i>Percent Over 100</i>	
<b>CARB HEAT AVAILABLE</b>	True if carburetor heat available.	Bool	
<b>DELTA HEADING RATE</b>	Rate of turn of heading indicator.	Radians per second	
<b>DME SOUND</b>	<i>DME</i> audio flag.	Bool	
<b>ELT ACTIVATED</b>	Whether or not the Emergency Locator Transmitter is active.	Bool	
<b>EXTERNAL SYSTEM VALUE</b>	Generic SimVar.	Number	
<b>FIRE BOTTLE DISCHARGED</b>	True if the fire bottle is discharged.	Bool	
<b>FIRE BOTTLE SWITCH</b>	True if the fire bottle switch is on.	Bool	
<b>GLASSCOCKPIT AUTOMATIC BRIGHTNESS</b>	This variable will return a value between 0 and 1 for the automatic brightness setting for glass cockpit displays, where 0 is the dimmest and 1 is the brightest. This value will vary depending on the time of day.	Number	
<b>GPWS SYSTEM ACTIVE</b>	True if the Ground Proximity Warning System is active.	Bool	

<b>GPWS WARNING</b>	True if Ground Proximity Warning System installed.	Bool	
<b>GYRO DRIFT ERROR</b>	Angular error of heading indicator.	Radians	
<b>HAS STALL PROTECTION</b>	Will return whether the aircraft has stall protection (true) or not (false).	Bool	
<b>HEADING INDICATOR</b>	Heading indicator (directional gyro) indication.	Radians	
<b>INDICATED ALTITUDE</b>	The indicated altitude.	Feet	
<b>INDICATED ALTITUDE CALIBRATED</b>	Indicated altitude with the altimeter calibrated to current sea level pressure.	Feet	
<b>INDICATED ALTITUDE EX1</b>	Similar to <b>INDICATED_ALTITUDE</b> but doesn't affect actual plane position when setting this variable.	Feet	
<b>INDUCTOR COMPASS HEADING REF</b>	Inductor compass heading.	Radians	
<b>INDUCTOR COMPASS PERCENT DEVIATION</b>	Inductor compass deviation reading.	<i>Percent Over 100</i>	
<b>INSTRUMENTS AVAILABLE</b> <i>Deprecated</i>	<b>Deprecated, do not use!</b>	Mask	
<b>INTERCOM MODE</b>	Intercom Mode	Enum: 0 = ISO 1 = ALL 2 = CREW	
<b>INTERCOM SYSTEM ACTIVE</b>	Whether or not the intercom system is active.	Bool	
<b>IS ALTITUDE FREEZE ON</b>	True if the altitude of the aircraft is frozen.	Bool	
<b>IS ATTITUDE FREEZE ON</b>	True if the attitude (pitch, bank and heading) of the aircraft is frozen.	Bool	
<b>IS LATITUDE LONGITUDE FREEZE ON</b>	True if the lat/lon of the aircraft (either user or AI controlled) is	Bool	

	<p>frozen. If this variable returns true, it means that the latitude and longitude of the aircraft are not being controlled by ESP, so enabling, for example, a SimConnect client to control the position of the aircraft. This can also apply to altitude and attitude.</p> <p>Also refer to the range of KEY_FREEZE..... Event IDs.</p>		
<p>KOHLSMAN SETTING</p> <p>HG:index</p>	<p>The value for the given altimeter index in inches of mercury.</p> <div> <p><b>IMPORTANT!</b> In the <a href="#">system.cfg</a> file, altimeters are indexed from 0, but the SimVar indexes from 1. So, altimeter 0 in that file is accessed using <b>KOHLSMAN SETTING HG:1</b>, 1 by <b>KOHLSMAN SETTING HG:2</b>, etc...</p> </div>	Inches of Mercury, <i>inHg</i>	
<p>KOHLSMAN SETTING</p> <p>MB:index</p>	<p>The value for the given altimeter index in millibars.</p> <div> <p><b>IMPORTANT!</b> In the <a href="#">system.cfg</a> file, altimeters are indexed from 0, but the SimVar indexes from 1. So, altimeter 0 in that file is accessed using <b>KOHLSMAN SETTING MB:1</b>, 1 by <b>KOHLSMAN SETTING MB:2</b>, etc...</p> </div>	Millibars	
<p>KOHLSMAN SETTING</p> <p>STD:index</p>	<p>True if the indexed altimeter is in "Standard" mode, or false otherwise.</p> <div> <p><b>IMPORTANT!</b> In the <a href="#">system.cfg</a> file, altimeters are indexed from 0, but the SimVar indexes from 1. So, altimeter 0 in that file is accessed using <b>KOHLSMAN</b></p> </div>	Bool	

	<div> <div>SETTING STD:1, 1 by KOHLSMAN</div> <div>SETTING STD:2, etc...</div> </div>		
MAGNETIC COMPASS	Compass reading.	Degrees	
MANUAL FUEL PUMP HANDLE	Position of manual fuel pump handle. 1 is fully deployed.	Percent Over 100	
OVERSPEED WARNING	Overspeed warning state.	Bool	
PANEL ANTI ICE SWITCH	True if panel anti-ice switch is on.	Bool	
PITOT ICE PCT	Amount of pitot ice. 100 is fully iced.	Percent Over 100	
PITOT HEAT	Pitot heat active.	Bool	
PITOT HEAT SWITCH:index	Pitot heat switch state.	Enum:  0 = Off  1 = On  2 = Auto	
PLANE HEADING DEGREES GYRO	Heading indicator (directional gyro) indication.	Radians	
PRESSURE ALTITUDE	Standard Altitude, ie: at a 1013.25 hPa (1 atmosphere) setting.	Meters	
PRESSURIZATION CABIN ALTITUDE	The current altitude of the cabin pressurization.	Feet	

<b>PRESSURIZATION CABIN ALTITUDE GOAL</b>	<p>The set altitude of the cabin pressurization as initialised from the <a href="#">Design Cabin Pressure</a> value in the <code>systems.cfg</code> file. Pressure is converted into an altitude using a standard condition table.</p> <p>You can adjust the goal pressure using the <a href="#">PRESSURIZATION_PRESSURE_ALT_INC</a> and <a href="#">PRESSURIZATION_PRESSURE_ALT_DEC</a> events.</p>	Feet	
<b>PRESSURIZATION CABIN ALTITUDE RATE</b>	The rate at which cabin pressurization changes.	Feet per second	
<b>PRESSURIZATION DUMP SWITCH</b>	True if the cabin pressurization dump switch is on.	Bool	
<b>PRESSURIZATION PRESSURE DIFFERENTIAL</b>	The difference in pressure between the set altitude pressurization and the current pressurization.	Pounds per square foot, <i>psf</i>	
<b>RAD INS SWITCH</b>	True if Rad INS switch on.	Bool	
<b>SELECTED DME</b>	Selected DME.	Number	
<b>SMOKESYSTEM AVAILABLE</b>	<p>Smoke system available.</p> <div> <p><b>NOTE:</b> There is no default "smoke system" that this SimVar works on and this is a legacy variable that is available for use should you wish to use it but it affects nothing by default.</p> </div>	Bool	
<b>SMOKE ENABLE</b>	Set to True to activate the smoke system, if one is available. Please see the notes for <a href="#">SMOKESYSTEM AVAILABLE</a> for more information.	Bool	
<b>SPEAKER ACTIVE</b>	Whether or not the speaker is active.	Bool	

<b>STALL HORN AVAILABLE</b>	True if stall alarm available.	Bool	
<b>STALL PROTECTION OFF LIMIT</b>	Alpha below which the Stall Protection can be disabled. See the <a href="#">[STALL PROTECTION]</a> section for more information.	Radians	
<b>STALL PROTECTION ON GOAL</b>	The alpha that the Stall Protection will attempt to reach when triggered. See the <a href="#">[STALL PROTECTION]</a> section for more information.	Radians	
<b>STALL PROTECTION ON LIMIT</b>	Alpha above which the Stall Protection timer starts. See the <a href="#">[STALL PROTECTION]</a> section for more information.	Radians	
<b>STALL WARNING</b>	Stall warning state.	Bool	
<b>STRUCTURAL DEICE SWITCH</b>	True if the aircraft structure deice switch is on.	Bool	
<b>SUCTION PRESSURE</b>	Vacuum system suction pressure.	Inches of Mercury, <i>inHg</i>	
<b>SYSTEMS AVAILABLE</b> <i>Deprecated</i>	<b>Deprecated, do not use!</b>	Mask	
<b>TAILHOOK HANDLE</b>	True if the tailhook handle is engaged.	Bool	
<b>TAILHOOK POSITION</b>	Percent tail hook extended.	<i>Percent Over 100</i>	
<b>TOW RELEASE HANDLE</b>	Position of tow release handle. 100 is fully deployed.	<i>Percent Over 100</i>	
<b>TRUE AIRSPEED SELECTED</b>	True if True Airspeed has been selected.	Bool	
<b>TURN COORDINATOR BALL</b>	Turn coordinator ball position.	Position 128 (-127 to 127)	

<b>TURN COORDINATOR BALL INV</b>	Turn coordinator ball position inverted (upside down).	Position 128 (-127 to 127)	
<b>TURN INDICATOR RATE</b>	Turn indicator reading.  <b>NOTE:</b> This is available in multiplayer to all <b>near</b> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer</a> .	Radians per second	
<b>TURN INDICATOR SWITCH</b>	True if turn indicator switch is on.	Bool	
<b>WINDSHIELD DEICE SWITCH</b>	True if the aircraft windshield deice switch is on.	Bool	
<b>WISKEY COMPASS INDICATION DEGREES</b> <b>Deprecated</b>	<b>Deprecated, do not use!</b> Use <b>MAGNETIC_COMPASS</b> instead.	Degrees	

## Variometer

Simulation Variable	Description	Units	Settable
<b>VARIOMETER MAC CREADY SETTING</b>	The MacCready setting used to fly an optimal speed between thermals.	Meters per second	
<b>VARIOMETER NETTO</b>	Variometer rate using Netto (Total Energy - polar sinkRate).	Feet per second	
<b>VARIOMETER RATE</b>	The variometer rate.	Feet per second	
<b>VARIOMETER SPEED TO FLY</b>	Optimal speed to fly between thermals using polar curve and MacCready setting.	Kilometers per hour	



<b>VARIOMETER SPEED TO FLY GLIDE RATIO</b>	The glide ratio at optimal speed to fly.	Number	
<b>VARIOMETER SWITCH</b>	True if the variometer switch is on, false if it is not.	Bool	
<b>VARIOMETER TOTAL ENERGY</b>	<p>The variometer rate using total energy.</p> <div> <math display="block">\text{Total Energy} = \text{Potential Energy} + \text{Kinetic Energy}</math> </div>	Feet per second	

## Water Ballast

Simulation Variable	Description	Units	Settable
<b>WATER BALLAST TANK CAPACITY:index</b>	The capacity of the indexed water ballast tank.	Pounds	
<b>WATER BALLAST TANK NUMBER</b>	The number of water ballast tank available.	Number	
<b>WATER BALLAST TANK QUANTITY:index</b>	The quantity of water ballast in the indexed tank.	Pounds	
<b>WATER BALLAST VALVE</b>	True (1) if a water ballast valve is available, False (0) otherwise.	Bool	
<b>WATER BALLAST VALVE FLOW RATE</b>	The flow rate of the water ballast valve.	<i>Gallons</i> per hour	
<b>WATER BALLAST EVERY VALVE OPEN</b>	This variable will return 1 (TRUE) if all the ballast tank valves are open, or 0 (FALSE) otherwise.	Bool	

# Lights

Simulation Variable	Description	Units	Settable
IS ANY INTERIOR LIGHT ON	Will return true if any interior light is on or false otherwise.	Bool	
LANDING LIGHT PBH	Landing light pitch bank and heading.	<a href="#">SIMCONNECT_DATA_XYZ</a> structure	
LIGHT BEACON	<p>Light switch state.</p> <div> <p><b>NOTE:</b> This is available in multiplayer to all <b>far</b> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer.</a></p> </div>	Bool	
LIGHT BEACON ON	Returns <b>true</b> if the target beacon light is functioning or if the switch is ON. Use beacon <b>lightdef</b> index.	Bool	
LIGHT BACKLIGHT INTENSITY	Vehicle backlights current intensity (0 = off, 1 = full intensity).	<i>Percent Over 100</i>	
LIGHT BRAKE ON	Returns <b>true</b> if the target brake light is functioning or if the switch is ON.	Bool	
LIGHT CABIN	Light switch state.	Bool	
LIGHT CABIN ON	Returns <b>true</b> if the target cabin light is functioning or if the switch is ON. Use the cabin <b>lightdef</b> index.	Bool	

LIGHT CABIN POWER SETTING	The current cabin light power setting. Requires the cabin <a href="#">lightdef</a> index.	Percent	
LIGHT GLARESHIELD	Whether or not the Light switch for the Glareshield is enabled.	Bool	
LIGHT GLARESHIELD ON	Returns <a href="#">true</a> if the target glareshield light is functioning <i>or</i> if the switch is ON. Use the glareshield <a href="#">lightdef</a> index.	Bool	
LIGHT GLARESHIELD POWER SETTING	The current glareshield light power setting. Requires the glareshield <a href="#">lightdef</a> index.	Percent	
LIGHT GYROLIGHT INTENSITY	Vehicle gyrolights current intensity (0 = off, 1 = full intensity).	<i>Percent Over 100</i>	
LIGHT HEAD ON	Returns <a href="#">true</a> if the target navigation light is functioning <i>or</i> if the switch is ON.	Bool	
LIGHT HEADLIGHT INTENSITY	Vehicle headlights current intensity (0 = off, 1 = full intensity).	<i>Percent Over 100</i>	
LIGHT LANDING ON	Returns <a href="#">true</a> if the target landing light is functioning <i>or</i> if the switch is ON. Use landing <a href="#">lightdef</a> index.	Bool	
LIGHT LANDING	Light switch state for landing light.  <b>NOTE:</b> This is available in multiplayer to all <b>far</b> aircraft. See <a href="#">here</a> for more information: <a href="#">Note</a>	Bool	

	<a href="#">On SimVars In Multiplayer.</a>		
LIGHT LOGO	<p>Light switch state for logo light.</p> <p><b>NOTE:</b> This is available in multiplayer to all <b>far</b> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer.</a></p>	Bool	
LIGHT LOGO ON	Returns <code>true</code> if the target logo light is functioning or if the switch is ON. Use the logo <code>lightdef</code> index.	Bool	
LIGHT NAV ON	Returns <code>true</code> if the target navigation light is functioning or if the switch is ON. Use navigation <code>lightdef</code> index.	Bool	
LIGHT NAV	Light switch state for the NAV light.	Bool	
LIGHT ON STATES	<p>Bit mask:[index]</p> <p>0x0001:[index] Nav 0x0002:[index] Beacon 0x0004:[index] Landing 0x0008:[index] Taxi 0x0010:[index] Strobe 0x0020:[index] Panel 0x0040:[index] Recognition 0x0080:[index] Wing 0x0100:[index] Logo 0x0200:[index] Cabin</p>	Mask	

LIGHT PANEL	Light switch state of the panel light.	Bool	
LIGHT PANEL ON	Returns <code>true</code> if the target panel light is functioning or if the switch is ON. Use the panel <code>lightdef</code> index.	Bool	
LIGHT PANEL POWER SETTING	The current panel light power setting. Requires the panel <code>lightdef</code> index.	Percent	
LIGHT PEDESTAL	Whether or not the Light switch for the Pedestal is enabled.  <b>NOTE:</b> This is available in multiplayer to all <i>far</i> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer</a> .	Bool	
LIGHT PEDESTAL ON	Returns <code>true</code> if the target pedestal light is functioning or if the switch is ON. Requires the pedestal <code>lightdef</code> index.	Bool	
LIGHT PEDESTAL POWER SETTING	The current pedestal light power setting. Requires the pedestal <code>lightdef</code> index.	Percent	
LIGHT POTENTIOMETER:index	Adjust the potentiometer of the indexed lighting. Index is defined in the appropriate <code>lightdef</code> hashmap setting.	<i>Percent Over 100</i>	
LIGHT RECOGNITION	Light switch state for the recognition light.	Bool	

	<p><b>NOTE:</b> This is available in multiplayer to all <b>far</b> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer</a>.</p>		
LIGHT RECOGNITION ON	Returns <code>true</code> if the target recognition light is functioning or if the switch is ON. Use the recognition <code>lightdef</code> index.	Bool	
LIGHT STATES	<p>Same as <code>LIGHT_ON_STATES</code>.</p> <p><b>NOTE:</b> This is available in multiplayer to all <b>far</b> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer</a>.</p>	Mask	
LIGHT STROBE	<p>Light switch state for the strobe lights.</p> <p><b>NOTE:</b> This is available in multiplayer to all <b>far</b> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer</a>.</p>	Bool	
LIGHT STROBE ON	Returns <code>true</code> if the target strobe light is functioning or if the switch is ON. Use the strobe <code>lightdef</code> index.	Bool	

	<p><b>NOTE:</b> This is available in multiplayer to all <b>far</b> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer</a>.</p>		
LIGHT TAXI	<p>Light switch state for the taxi light.</p> <p><b>NOTE:</b> This is available in multiplayer to all <b>far</b> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer</a>.</p>	Bool	
LIGHT TAXI ON	<p>Returns <code>true</code> if the target taxi light is functioning <i>or</i> if the switch is ON. Use taxi <code>lightdef</code> index.</p>	Bool	
LIGHT WING	<p>Light switch state for the wing lights.</p> <p><b>NOTE:</b> This is available in multiplayer to all <b>far</b> aircraft. See here for more information: <a href="#">Note On SimVars In Multiplayer</a>.</p>	Bool	
LIGHT WING ON	<p>Returns <code>true</code> if the target wing light is functioning <i>or</i> if the switch is ON. Use the wing <code>lightdef</code> index.</p>	Bool	

<b>MANUAL INSTRUMENT LIGHTS</b>	True if instrument lights are set manually.	Bool	
<b>STROBES AVAILABLE</b>	True if strobe lights are available.	Bool	
<b>STROBE FLASH</b> <i>Deprecated</i>	<b>Deprecated, do not use!</b>	Bool	

## Hydraulics

Simulation Variable	Description	Units	Settable
<b>HYDRAULIC PRESSURE: <i>index</i></b>	Hydraulic system pressure. Indexes start at 1.	Pound force per square foot	
<b>HYDRAULIC RESERVOIR PERCENT: <i>index</i></b>	Hydraulic pressure changes will follow changes to this variable. Indexes start at 1.	<i>Percent Over 100</i>	
<b>HYDRAULIC SWITCH</b>	True if hydraulic switch is on.	Bool	
<b>HYDRAULIC SYSTEM INTEGRITY</b>	Percent system functional.	<i>Percent Over 100</i>	

## Partial Panels

Simulation Variable	Description	Units	Settable
<b>PARTIAL PANEL ADF</b>	Gauge fail flag.	Enum: 0 = ok 1 = fail 2 = blank	



<b>PARTIAL PANEL AIRSPEED</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL ALTIMETER</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL ATTITUDE</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL AVIONICS</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL COMM</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL COMPASS</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL ELECTRICAL</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL ENGINE</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail	

		2 = blank	
<b>PARTIAL PANEL FUEL INDICATOR</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL HEADING</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL NAV</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL PITOT</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL TRANSPONDER</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL TURN COORDINATOR</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL VACUUM</b>	Gauge fail flag.	Enum:  0 = ok 1 = fail 2 = blank	
<b>PARTIAL PANEL VERTICAL VELOCITY</b>	Gauge fail flag.	Enum:  0 = ok	

		1 = fail 2 = blank	
--	--	--------------------------	--

## Payload Stations

Simulation Variable	Description	Units	Settable
<b>DROPPABLE OBJECTS</b> <b>COUNT: <u>index</u></b>	The number of droppable objects at the station number identified by the index.	Number	
<b>DROPPABLE OBJECTS</b> <b>TYPE: <u>index</u></b>	The type of droppable object at the station number identified by the index.	String	
<b>DROPPABLE OBJECTS</b> <b>UI NAME: <u>index</u></b>	Descriptive name, used in User Interface dialogs, of a droppable object, identified by index.	String	
<b>PAYLOAD STATION</b> <b>COUNT</b>	Number of payload stations (1 to 15).	Number	
<b>PAYLOAD STATION</b> <b>NAME: <u>index</u></b>	Descriptive name for payload station.	String	
<b>PAYLOAD STATION</b> <b>NUM</b> <b>SIMOBJECTS: <u>index</u></b>	The number of objects at the payload station.	Number	
<b>PAYLOAD STATION</b> <b>OBJECT: <u>index</u></b>	Places the named object at the payload station identified by the index (starting from 1). The string is the Container name (refer to the title property of Simulation Object Configuration Files).	String	
<b>PAYLOAD STATION</b> <b>WEIGHT: <u>index</u></b>	Individual payload station weight.	Pounds	

# Warning Variables

Simulation Variable	Description	Units	Settable
<code>WARNING FUEL</code>	This is the current state of the fuel warning, either on ( <code>true</code> ) or off ( <code>false</code> ).	Bool	
<code>WARNING FUEL LEFT</code>	This is the current state of the left fuel tank warning, either on ( <code>true</code> ) or off ( <code>false</code> ).	Bool	
<code>WARNING FUEL RIGHT</code>	This is the current state of the right fuel tank warning, either on ( <code>true</code> ) or off ( <code>false</code> ).	Bool	
<code>WARNING LOW HEIGHT</code>	This is the current state of the low height warning, either on ( <code>true</code> ) or off ( <code>false</code> ).	Bool	
<code>WARNING OIL PRESSURE</code>	This is the current state of the oil pressure warning, either on ( <code>true</code> ) or off ( <code>false</code> ).	Bool	
<code>WARNING VACUUM</code>	This is the current state of the vacuum system warning, either on ( <code>true</code> ) or off ( <code>false</code> ).	Bool	
<code>WARNING VACUUM LEFT</code>	This is the current state of the left vacuum system warning, either on ( <code>true</code> ) or off ( <code>false</code> ).	Bool	
<code>WARNING VACUUM RIGHT</code>	This is the current state of the right vacuum system warning, either on ( <code>true</code> ) or off ( <code>false</code> ).	Bool	
<code>WARNING VOLTAGE</code>	This is the current state of the electrical system voltage warning, either on ( <code>true</code> ) or off ( <code>false</code> ).	Bool	

# Yoke

Simulation Variable	Description	Units	Settable
YOKE X INIDICATOR	Yoke position in horizontal direction.	Position (-16K to 0)	
YOKE X POSITION	Percent control deflection left/right (for animation).	Position (-16K to 0)	
YOKE X POSITION WITH AP	Percent control deflection left/right (for animation). Also includes AP's inputs.	Position (-16K to 0)	
YOKE Y INIDICATOR	Yoke position in vertical direction.	Position (-16K to 0)	
YOKE Y POSITION	Percent control deflection fore/aft (for animation).	Position (-16K to 0)	
YOKE Y POSITION WITH AP	Percent control deflection fore/aft (for animation). Also includes AP's inputs.	Position (-16K to 0)	