

## SenNet IoT TH Sigfox

### General description

SenNet IoT TH Sigfox is a low power device, that take samples of **temperature**, **humidity** with a interval of time setup.

Use sigfox network to connect with your cloud or platform.

These are the reference at depend of power supply type battery or AC power:

Reference	Power supply type
TH Sigfox bat ++	Battery 3.6v@18000mAh (LS26500 x2)
TH Sigfox AC	AC Power supply 100-265Vac


### Wired & Setup



**Temperatura**  
-10°C +60°C  
(+/-1°C) \*



**Humedad**  
0-100%RH  
(+/-5%) \*



### Basic steps to intall:

1. Set interval to send (**by default 15 minutes**).
2. Take note ID / PAC to sign the device on Sigfox Cloud.
3. Plug-in pack batteries or AC power supply.

### Setup parameters methods:

- Throught donwlink message (see donwlink message seccion) , recommend method.
- By cable micro-USB with PC console enter menu to set these parameters.

### Battery life



This device is desing to very long life. Life of batteries will depend of three variables: type message , interval to send, number of impulses readed. Adjust interval to send and type of message by customer requeriment

Battery life estimation	
<b>11 minutes sends</b>	3 years
<b>20 minutes sends</b>	5.5 years
<b>30 minutes sends</b>	8 years

### Holding case


<b>IP Grade</b>	IP-65
<b>Temperature details</b>	
Working temperature	-10°C...+60°C
Store temperature	-20°C...+75°C
<b>Holding</b>	
Dimensions	119 x 111 x 53 mm
Type mount	Wall or din rail
Plastic Material	ABS – V0

\*If you need an upper grade contact with out support team.

wall mount (by default)	rail din mount (accessory)
 <p>Diagram illustrating the wall mount installation. The device is shown with its internal components and external casing. Red arrows point to the mounting points on the back of the device, labeled "wall fixing screws".</p>	 <p>Diagram illustrating the rail din mount installation. The device is shown with its internal components and external casing. A red box highlights the mounting points on the back of the device, labeled "auxiliar plate" and "rail din support".</p> <p>*specify on your order</p>

### Type Message

SenNet IoT TH Sigfox is an very low power device capable to measure temperature / humidity. There is only one type of message 02, and its format to use on parser function is:



A common point in all types of messages is the head (defined with 2 bytes) that includes important information embedded in the message (type device/type message/errors.. etc). In the next table are defined the mean of these info-fields.

Field Info																
Byte	Byte 1															
	<u>Type Device</u>			<u>Type Message</u>				Low level Battery	Internal Error Sensor	Downlink error	Not used			Not used		
	01 - Easy Meter 02 – Pulse Counter 03 – Not defined <b>04 – Enviroment Sensor</b> 05 – Not defined 06 – GW Modbus 07 – Not defined			type 0 (info) type 1 → CO2 + Temp + Hum <b>type 2 → Temp + Hum</b> type 3 (not defined) type 4 (not defined) .. type 15 (not defined)												
	<u>Feedback Error</u>															
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
	Byte1 Bit 7-6-5			Byte1 Bit 4-3-2-1				Byte1 Bit 0	Byte2 Bit 7-6		Byte2 Bit 5-4-3			Byte2 Bit 2-1-0		


Table 1

Type 2 : Temperature + Humidity				
Field	Info		Temperature	Humidity
Type data	See Table 1		1 byte temperature Payload [-10°C...60°C] conversion function Temperature=Payload*0.2745-10	1 byte humidity Payload [0-100%] Humidity=Payload
Byte	1	2	3	4

First message after power on the device is debug message with internal information about build firmware. This message must be not parser by client platform, and requeriment a donwlink message for remote settings.

Type 0 : debug message						
Field	Info		HW device	Version FW	Revision FW	Not used
Type data	See Table 1					-
Byte	1	2	3	4	5	6-9

Sequence of messages:



## Downlink Message

It's possible set the device in the cloud without interacting with it locally, setting interval to send. That method is optional but it's not necessary.

Byte	1		2 - 5	6	7	8
Field	Setup byte (1byte)		Not used (4 bytes)	Not used (1 byte)	Interval to send (minutes)	Not used
Value	Bit 7	1 (by default)	0x00 0x00 0x00 0x00	00	[11...59]	0x00
	Bit 6	0 (by default)				
	Bit 5	0 (by default)				
	Bit 4	1/0 enable/disable set Interval to send				
	Bit 3	0 (by default)				
	Bit 2	0 (by default)				
	Bit 1	0 (by default)				
	Bit 0	0 (by default)				

Example for downlink message:

90 00 00 00 00 00 0F 00 → With this downlink message setup interval to send to 15minutes.

## Warranty

Satel Spain guarantees its products against all manufacturing defects for a period of 1 year.



No return of material will be accepted, nor will any equipment be repaired if it is not accompanied by a report (RMA) indicating the defect observed or the reasons for the return.

The warranty will be void if the equipment has suffered "misuse" or the storage, installation or maintenance instructions in this manual have not been followed. "Misuse" is defined as any use or storage situation contrary to the National Electrical Code or that exceeds the limits indicated in this manual.

Satel Spain declines all responsibility for possible damage to the equipment or to other parts of the installations and will not cover possible penalties derived from a possible breakdown, poor installation or "misuse" of the equipment. Consequently, the guarantee is not applicable to breakdowns produced in the following cases.

- Due to overvoltage and/or electrical disturbances in the supply.
- By water, if the product does not have the appropriate IP rating.
- For exposing the equipment to extreme temperatures, which exceed the operating or storage temperature limit.
- Due to a modification of the product by the client without prior notice to Satel Spain.

Faced with possible errors in this technical sheet, keep it updated in our website.