

Manual page for the PrehKeyTec 'copy2mci' V0.5 *(Linux x86 / Linux x64)*

SYNOPSIS

copy2mci [OPTION]... [filename]

DESCRIPTION

'copy2mci' – download utility for MCI family keyboards.

COPY a configuration file (mwx binary keytable) TO MCI keyboards via USB.
In addition 'copy2mci' can read out the binary keytable to a file, send commands to the keyboard, read the keyboards version string or read out the checksum of the current keytable in the keyboard.

OPTIONS

- h, --help**
Prints this usage message and exits.
- V, --version**
Print version and exits.
- v, --verbose**
Print verbose messages.
- leds**
Use keyboard leds as an activity indicator.
- u#, --usb=#**
Select usb device index (default: 1).
- sxy., --sendcmd=xy..**
Send command xy.. (hex) to keyboard.
- r, --read**
Read binary keytable to a mwx file.
- c, --checksum**
Show checksum of keyboards keytable.
- i, --info**
Show keyboard version string.

EXAMPLES

Copy keytable to the keyboard:

```
copy2mci <filename>
```

Read keytable from keyboard:

```
copy2mci --read <filename>
```

Read device info block:

```
copy2mci --info
```

Send command:

```
copy2mci --sendcmd=xyxy...xy
```

NOTES

- (1) If there is no file extension then '.mwx' is appended.
- (2) By default the devices 'hiddev#' are limited in read/write access. The easiest way is to run this tool with 'root' grants to avoid access problems.

COPYRIGHT

Copyright © 2015 PrehKeyTec GmbH