



LNR50 Series Linear Long-travel Translation Stage

User Guide



Contents

- Chapter 1 Safety 3**
 - 1.1 Safety Information 3
 - 1.2 General Warnings 3
- Chapter 2 Getting Started 4**
 - 2.1 Linear Long-travel Translation Stage 4
- Chapter 3 Operation 8**
 - 3.1 Manual Differential Drives and Differential Micrometer Drives 8
 - 3.2 Motor Drives 8
 - 3.3 Piezo Actuators 10
- Chapter 4 Installation 11**
 - 4.1 Unpacking 11
 - 4.2 Mounting 11
 - 4.3 Fitting and Removal of Drives 17
 - 4.4 Reconfiguring the Actuator Position 18
 - 4.5 Mounting Equipment to the Stage 21
 - 4.6 Transportation 21
 - 4.7 Dimensions 22
- Chapter 5 Specifications 26**
 - 5.1 General Specifications 26
 - 5.2 Piezoactuated Stage Specifications 26
 - 5.3 Stepper Motor Stage Specifications 26
 - 5.4 DC Motor Stage Specifications 26
 - 5.5 Stepper Motor Connector Pin Out 27
 - 5.6 DC Motor Connector Pin Out 27
- Chapter 6 Parts and Consumables 28**
 - 6.1 Parts List 28
- Chapter 7 Regulatory 29**
 - 7.1 Declarations Of Conformity 29
 - 7.2 Waste Electrical and Electronic Equipment (WEEE) Directive 30
- Chapter 8 Thorlabs Worldwide Contacts 32**

Chapter 1 Safety

1.1 Safety Information

For the continuing safety of the operators of this equipment, and the protection of the equipment itself, the operator should take note of the **Warnings, Cautions** and **Notes** throughout this handbook and, where visible, on the product itself.

The following safety symbols may be used throughout the handbook and on the equipment itself.



Shock Warning



Given when there is a risk of injury from electrical shock.



Warning



Given when there is a risk of injury to users.



Caution



Given when there is a risk of damage to the product.

Note

Clarification of an instruction or additional information.

1.2 General Warnings



Warnings



If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. Do not operate the instrument outside its rated supply voltages or environmental range. In particular, excessive moisture may impair safety.

Spillage of fluid, such as sample solutions, should be avoided. If spillage does occur, clean up immediately using absorbant tissue. Do not allow spilled fluid to enter the internal mechanism.

The equipment is for indoor use only.

When running custom move sequences, or under fault conditions, the stage may move unexpectedly. Operators should take care when working inside the moving envelope of the stage.

Chapter 2 Getting Started

2.1 Linear Long-travel Translation Stage

The LNR50 single-axis linear long travel stage has been designed to integrate seamlessly into the Thorlabs modular electronic or benchtop positioning systems. The unique combination of long-travel actuators and high-precision piezoelectric elements provides solutions to applications such as manipulation, alignment and assembly of photonics products, and microscope examination of large samples. When fitted with a piezoelectric actuator, the stage is compatible with the Thorlabs NanoTrak™ autoalignment module, allowing automated or semi-automated optical alignment systems to be constructed around customer specific applications.

Stages can be bolted together in and XY, XZ or XYZ configurations for applications where movement is required in more than one axis..




Fig. 2.1 LNR50 series linear long travel stage – typical XYZ configuration

2.1.1 Drives

Stages are supplied pre-configured with either manual or motor drives. However, various motorized drives and piezo drives are available, which can easily be fitted later, as the application needs change – see Table 2.1, Fig. 2.2, Fig. 2.3 and Section 2.1.2.

Note

The DRV013 and DRV014 trapezoidal stepper motor drives must be used in conjunction with the BSCxxx or MSTxxx series stepper motor controllers. The DRV414 DC motor drives should be used with a Thorlabs BDC10x DC motor controller.

Table 2.1 Drive Options

Drives Type	Travel (mm)	Resolution (μm)	Product Number
Trapezoidal stepper motor	25.0	0.05	DRV013
Trapezoidal stepper motor	50.0	0.05	DRV014
DC servo motor	50.0	0.3	DRV414




Fig. 2.2 DRV014 stepper motor drive




Fig. 2.3 DRV414 DC servo motor drive

2.1.2 Piezo Actuators

Piezoelectric actuators have been developed for optical and fiber-optical applications, to provide linear motions up to 100 μm – see Table 2.2 and Fig. 2.4.




Fig. 2.4 A typical piezo actuator

Table 2.2 Piezo Actuator Options

Extension (μm at 75V dc, zero load)	Standard actuator	Feedback actuator
20	PAS005	PAZ005
40	PAS009	PAZ009
100	PAS015	PAZ015

Note

The piezo actuators are supplied with a PAA001 flat tip. Other tips are available separately as shown below.

Table 2.3 Piezo Tip Options

End Type	Thread	Product Number
Flat end	—	PAA001
Drive ball end	—	PAA005
Threaded	M4	PAA007
Threaded	8 - 32 UNC	PAA013

Chapter 3 Operation

3.1 Manual Differential Drives and Differential Micrometer Drives

3.1.1 Adjusting Micrometer Drives

Turn the coarse adjuster clockwise until the platform begins to move. By careful use of the fine adjuster, sub-micron resolution is now achievable.




Fig. 3.1 Adjusting a differential drive

3.2 Motor Drives

To ensure that a particular stage is driven properly by the system, a number of parameters must first be set. These parameters relate to the physical characteristics of the stage being driven (e.g. min and max positions, leadscrew pitch, homing direction etc.).

To assist in setting these parameters correctly, it is possible, using the APT Config utility, to associate a specific stage type and axis with the motor controller channel. Once this association has been made, the APT server applies automatically, suitable default parameter values on boot up of the software.

To ensure correct operation, it is important to select the correct stage type for your controller. If using a BDC103 series controller, select the 'DRV414' option. If using a BSC20x series controller, select the appropriate 'HS 17DRVxxx' option. If using a legacy BSC0xx or BSC10x controller, choose a 17DRVxxx option without the 'HS' prefix.

- 1) Shut down all applications using the APT server (e.g. APT User or your own custom application).
- 2) Run the APT Config utility - Start/All Programs/Thorlabs/APT Config/APT Config.

- 3) From the 'APT Configuration Utility' window, click the 'Stage' tab.




Fig. 3.2 APT Configuration Utility - Stage Tab

- 4) In the 'Motor' field, select the serial number of the motor controller to be configured (this number can be found on the rear panel of the controller unit).

Note

To ensure correct operation, it is important to select the correct stage and axis type. If using a BDC103 series controller, select the 'DRV414' option. If using a BSC20x series controller, select the appropriate 'HS 17DRVxxx' option. If using a legacy BSC0xx or BSC10x controller, choose a 17DRVxxx option without the 'HS' prefix.

Selecting an incompatible stage/axis type could result in reduced velocity and resolution.

- 5) In the 'Stage' field, select your actuator type from the list displayed (e.g. HS 17DRV014 50mm).
- 6) Click the 'Add Stage Association' button.
- 7) A default configuration is set at the factory and stored in the non-volatile memory of the motor controller. The server reads in the stage and controller information on start up. See the handbook supplied with the motor controller for further information.

3.3 Piezo Actuators

Piezo actuators are used to give nanometric positioning of the platform over a range of 20 to 100 microns – see Table 2.2. They can also modulate the position of the platform at high frequency.

On a piezo-actuated stage, position feedback may be incorporated to enhance the repeatability and linearity of piezo motion.

The piezo-actuated stage should be used together with one of the Thorlabs piezoelectric controllers – see the handbook supplied with the relevant piezoelectric controller for more information.

Chapter 4 Installation

4.1 Unpacking

Note

Retain the packing in which the unit was shipped, for use in future transportation.



Caution



Once removed from its packaging, the stage is easily damaged by mishandling.

The stage is shipped with a plate fitted to the side, which locks the carriage during transit. These plates should be removed before the stage is used. Retain the plates for future use.

4.2 Environmental Conditions



Warning



Operation outside the following environmental limits may adversely affect operator safety.

Location Indoor use only

Maximum altitude 2000 m

Temperature range 5°C to 40°C

Maximum Humidity Less than 80% RH (non-condensing) at 31°C

To ensure reliable operation the unit should not be exposed to corrosive agents or excessive moisture, heat or dust.

If the unit has been stored at a low temperature or in an environment of high humidity, it must be allowed to reach ambient conditions before being powered up.

The unit must not be used in an explosive environment.

4.3 Mounting

4.3.1 General

The LNR50 series stages can be mounted directly to the work surface as shown in Section 4.3.2. For additional versatility, a base plate and angle bracket are available for use in horizontal or vertical mounting configurations - see Section 4.3.3. to Section 4.3.5. When mounting the stage close to other equipment, ensure that the travel of the moving platform is not obstructed. If equipment mounted on the moving platform is driven against a solid object, damage to the internal mechanism could occur.

The range of travel on each axis is 50 mm total, that is ± 25 mm about the nominal position.

The stage is shipped with the drives configured for right handed use, however they can be repositioned for applications where left handed use is more convenient - see Section 4.5. for more details.



Caution



When mounting components, or fitting the stage within an application, do not apply excessive pressure to the moving platform as this may damage the bearing mechanism.

Note

The LNR series stages can quickly be assembled into XY, XZ, YZ and XYZ configurations - see Section 4.3.4. and Section 4.3.5. The brackets and plates are supplied complete with dowels, which ensure an accurate, orthogonal assembly.

4.3.2 Mounting Directly to the Work Surface

Referring to Fig. 4.2, proceed as follows:

- 1) Adjust the actuator to position the moving carriage central in its range of travel, and ensure that the mounting holes in the base are clearly visible through the holes in the top plate.
- 2) Fit two bolts (M6 x 10 or 1/4-20 x 3/8", not supplied) through the holes in the top platform and tighten to secure the stage to the work surface.




Fig. 4.1 Bolting the stage to the work surface

4.3.3 Fitting and Removing the Base Plate

Referring to Fig. 4.2, proceed as follows:

- 1) Adjust the actuator to position the moving carriage central in its range of travel, and ensure that the mounting holes in the base are clearly visible through the holes in the top plate.
- 2) Fit the dowels supplied to the base plate (LNR50P1).
- 3) Position the stage on the base plate, ensuring that the dowels locate correctly in the holes in the lower surface of the stage.
- 4) Fit two bolts (M6 x 12 or 1/4-20 x 1/2", not supplied) through the holes in the top plate and into the base plate. Tighten to secure the stage in place.




Fig. 4.2 Fitting the base plate

- 5) Fit three bolts (M6 or 1/4-20, not supplied) through each end of the base plate to fix the stage to the work surface.
- 6) To remove the base plate, reverse the procedure above.

4.3.4 Building an XY Configuration

Bolt the X-axis stage to the work surface as detailed in Section 4.3.3. then, referring to Fig. 4.3, proceed as follows:

- 1) Fit the dowels supplied to the moving platform of the lower stage.

Note

If the XY configuration is being constructed using stages fitted with stepper motor drives, a spacer plate (LNR50P3) will be required between the two stages before proceeding to item (2)

- 2) Fit the Y-axis stage into place ensuring that the dowels in the lower stage locate correctly in the holes in the lower surface of the upper stage.




Fig. 4.3 Building an XY Configuration

- 3) Fit two bolts (M6 x 12 or 1/4-20 x 1/2", not supplied) through the holes in the upper stage and tighten to secure the stage to the moving platform of the stage beneath.



Caution



Use only bolts of the stated length. Longer bolts will protrude into the stage and damage the internal mechanism.

4.3.5 Building an XYZ Configuration

Assemble an XY configuration as detailed in Section 4.3.4. then, referring to Fig. 4.4, and Fig. 4.5 proceed as follows:

- 1) Fit the dowels supplied, into the moving platform on the upper stage of the XY assembly.
- 2) Fit the angle bracket (LNR50P2) onto the moving platform of the stage, ensuring that the dowels fitted at item (1) locate correctly in the holes on the underside of the angle bracket..




Fig. 4.4 Fitting the Angle Bracket

- 3) Fit six bolts (M6 x 16 or 1/4-20 x 5/8", not supplied), through the holes in the base of the angle bracket, and tighten to secure the bracket to the XY assembly.



Caution



Use only bolts of the stated length. Longer bolts will protude into the stage and damage the internal mechanism.

- 4) Fit the dowels supplied into the holes in the back surface of the angle bracket.
- 5) Fit the vertical-axis stage into place ensuring that the dowels fitted at item (4) locate correctly in the holes on the underside of the stage.
- 6) Fit two bolts (M6 x 12 or 1/4-20 x 1/2", not supplied), through the holes in the top plate, and screw into the rear face of the angle bracket.



Caution



Use only bolts of the stated length. Longer bolts will protrude into the stage and damage the internal mechanism.




Fig. 4.5 Adding a Vertical Axis Stage

4.4 Fitting and Removal of Drives

4.4.1 Removing/Fitting a Micrometer Drive

- 1) Loosen the mounting block actuator pinch bolts.
- 2) Remove the existing drive.
- 3) Fit the replacement drive.
- 4) Tighten the mounting block pinch bolts.
- 5) Adjust the actuator to its center position.
- 6) Loosen the push block pinch bolts and position the push block such that the stage is in its center of travel.
- 7) Tighten the push block pinch bolts.




Fig. 4.6 Fitting/removing a micrometer drive

4.4.2 Fitting a Motor Drive

Referring to Fig. 4.7...

- 1) Loosen the mounting block actuator pinch bolts.
- 2) Remove the existing drive.
- 3) Loosen the actuator mounting block fixing bolts, and remove the mounting block together with its bolts.
- 4) Using the screws supplied with the motor, fit the motor actuator to the stage.
- 5) Adjust the actuator to its center position.
- 6) Loosen the push block pinch bolts and position the push block such that the stage is in its center of travel.

7) Tighten the push block pinch bolts..




Fig. 4.7 Fitting a motor drive

4.5 Reconfiguring the Actuator Position

The stage is shipped with the drives configured for a right handed configuration, however they can be repositioned for left handed use. This is achieved by swapping the position of the actuator clamp and the push block as follows:

Referring to Fig. 4.8:

- 1) Remove the actuator as detailed in Section 4.4.
- 2) Undo the mounting block attachment bolts and remove the mounting block.
- 3) Loosen the push block pinch bolts.
- 4) Remove the push block.

- 5) Undo the push block mounting bolts and remove the push block mounting block.




Fig. 4.8 Removing the Actuator Clamp and Push Block

Referring to Fig. 4.9 on the next page:

- 6) Refit the push block mounting block on the opposite side of the stage as shown in Fig. 4.9 and tighten the attachment bolts.
- 7) Refit the push block.
- 8) Tighten the push block pinch bolts.
- 9) Refit the actuator mounting block as shown in Fig. 4.9 and tighten the attachment bolts.
- 10) Refit the actuator, then tighten the mounting block pinch bolts.
- 11) Adjust the actuator to its center position.
- 12) Loosen the push block pinch bolts and position the push block such that the stage is in its center of travel.
- 13) Tighten the push block pinch bolts




Fig. 4.9 Reconfiguring the Actuator Position

4.6 Mounting Equipment to the Stage



Caution



The weight attached to the moving platform must not exceed 10 kg.

Do not apply excessive forces to the moving platform.

Thorlabs manufacture a variety of fibre chucks, holders and fixtures to fit the linear stage. All of these accessories are mounted to the stage via a top platform, see Fig. 4.10.




Fig. 4.10 Top platform

4.7 Transportation



Caution



The drives should be removed before transporting the stage.

When packing the unit for shipping, use the original packing. If this is not available, use a strong box and surround the stage with at least 100 mm of shock absorbent material.

4.8 Dimensions

4.8.1 Motors




Fig. 4.11 Dimensions – stepper motor drives





Fig. 4.12 Dimensions – DC motor drives

4.8.2 External Piezo Actuators

all dimensions in mm (inches)



Standard actuator	Length A mm (in.)	Feedback actuator	Length A mm (in.)
PAS005	59 (2.32)	PAZ005	59 (2.32)
PAS009	95 (3.74)	PAZ009	95 (3.74)
PAS015	203 (7.99)	PAZ015	203 (7.99)

Fig. 4.13 Dimensions – piezo actuators

dimensions in mm (inches)






Fig. 4.14 Dimensions – end tips

4.8.3 Manual Drives

all dimensions in inches (mm)



Micrometer drive (151-411ST)




Differential drive (DRV8)

Fig. 4.15 Dimensions – manual drives

4.8.4 LNR50 Linear Stage

all dimensions in mm (inches)



Note

2 holes 'A' (M6 or 1/4in.) 20mm clearance for mounting stages to tables or for X-Y and X-Y-Z configurations.

Spacer plates are required between and below stages when fitting stepper motor drives.

Fig. 4.16 Dimensions – LNR50 series linear stage (shown with stepper motor drive fitted)

Chapter 5 Specifications

5.1 General Specifications

Travel	2" (50 mm)
Max Horizontal Load Capacity*	66 lb (30 kg)
Weight (without drives)	3.96 lb (1.8 kg)

5.2 Piezoactuated Stage Specifications

**Caution**

The stage should only be used in conjunction with the appropriate Thorlabs Piezoelectric Controllers.

Maximum Input Voltage	75 V
Operating Temperature	–20°C to 80°C

5.3 Stepper Motor Stage Specifications

Max Velocity*	20 mm/sec
Max Acceleration	20 mm/sec/sec
Min Incremental Movement	0.05 µm
Backlash	<6 µm
Absolute On-axis Accuracy	10 µm
Bidirectional Repeatability	0.5 µm
Home Switch Accuracy	± 1µm


* The velocity quoted above is only achievable with light loads. When using heavy loads, the velocity should be reduced accordingly.

5.4 DC Motor Stage Specifications

Max Velocity	50 mm/sec
Min Incremental Movement	0.2 µm
Absolute On-axis Accuracy	83 µm
Backlash	<11 µm
Bidirectional Repeatability	5 µm
Home Switch Accuracy	<10 µm

5.5 Stepper Motor Connector Pin Out

The Motor D-Type connector provides connection to the Stepper motor controller. The pin functions are detailed in Fig. 5.1




Pin	Description	Pin	Description
1	Ground/Return	6	Motor Phase A -
2	CCW Limit Switch	7	Motor Phase A +
3	CW Limit Switch	8 to 14	Not Used
4	Motor Phase B -	15	Braid/Screen
5	Motor Phase B +		

Fig. 5.1 Stepper Motor Connector Pin Descriptions

5.6 DC Motor Connector Pin Out

The Motor D-Type connector provides connection to the DC motor controller. The pin functions are detailed in Fig. 5.2.



Pin	Description	Pin	Description
1	Ground/Return	9	Encoder A +
2	CCW Limit Switch	10	Encoder A -
3	CW Limit Switch	11	Encoder B +
4		12	Encoder B -
5		13	5V
6	Motor +	14	
7	Motor -	15	Braid/Screen
8			



Fig. 5.2 DC Motor Connector Pin Descriptions

Chapter 6 Parts and Consumables

6.1 Parts List

Part Number	Description
Base plate	LNR50P1
Angle bracket	LNR50P2
Spacer (to allow x-y mounting)	LNR50P3
SMC connector lead	166038
LEMO connector lead	134667
Mounting cleat	131030
Cable clamp	120992
50 mm Micrometer Drive	1510411ST
50 mm Differential Drive	DRV008
25mm Travel Stepper motor	DRV013
50mm Travel Stepper motor	DRV014
50mm Travel DC Servo Motor	DRV414
Piezo Actuators	See Section 2.1.2.
Handbook	ha0106T

6.2 Preventive Maintenance

**Warning**

The equipment contains no user servicable parts. There is a risk of severe electrical shock if the equipment is operated with the covers removed.

Only personnel authorized by Thorlabs Ltd and trained in the maintenance of this equipment should attempt any repairs or adjustments. Maintenance is limited to scleaning as described in the following sections.

Chapter 7 Regulatory

7.1 Declarations Of Conformity

7.1.1 For Customers in Europe

This equipment has been tested and found to comply with the EC Directives 89/336/EEC 'EMC Directive' and 73/23/EEC 'Low Voltage Directive' as amended by 93/68/EEC.

Compliance was demonstrated by conformance to the following specifications which have been listed in the Official Journal of the European Communities:

Safety	EN61010: 2001 Installation Category II, Pollution Degree II.
EMC	EN61326: 1997

7.1.2 For Customers In The USA

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by the company could void the user's authority to operate the equipment.

7.2 Waste Electrical and Electronic Equipment (WEEE) Directive

7.2.1 Compliance

As required by the Waste Electrical and Electronic Equipment (WEEE) Directive of the European Community and the corresponding national laws, we offer all end users in the EC the possibility to return "end of life" units without incurring disposal charges.

This offer is valid for electrical and electronic equipment

- sold after August 13th 2005
- marked correspondingly with the crossed out "wheelie bin" logo (see Fig. 1)
- sold to a company or institute within the EC
- currently owned by a company or institute within the EC
- still complete, not disassembled and not contaminated



Fig. 7.1 Crossed out "wheelie bin" symbol

As the WEEE directive applies to self contained operational electrical and electronic products, this "end of life" take back service does not refer to other products, such as

- pure OEM products, that means assemblies to be built into a unit by the user (e. g. OEM laser driver cards)
- components
- mechanics and optics
- left over parts of units disassembled by the user (PCB's, housings etc.).

If you wish to return a unit for waste recovery, please contact Thorlabs or your nearest dealer for further information.

7.2.2 Waste treatment on your own responsibility

If you do not return an "end of life" unit to the company, you must hand it to a company specialized in waste recovery. Do not dispose of the unit in a litter bin or at a public waste disposal site.

7.2.3 Ecological background

It is well known that WEEE pollutes the environment by releasing toxic products during decomposition. The aim of the European RoHS directive is to reduce the content of toxic substances in electronic products in the future.

The intent of the WEEE directive is to enforce the recycling of WEEE. A controlled recycling of end of life products will thereby avoid negative impacts on the environment.

7.3 CE Certificate



E C Declaration of Conformity

We,

Thorlabs Ltd
1 Saint Thomas Place,
Cambridgeshire Business Park,
Ely, Cambridgeshire
CB7 4EX

declare that the motorized or piezo equipped travelling stages of the LNR50 series comply with the following Harmonized European Standards:

BS EN 61326-1:1998
BS EN 61000-3-2: 2000
BS EN 61000-3-3: 1995
EN 61010-1: 2001

And is in conformity with

93/68/EEC – CE Marking Directive (1996)
89/336/EEC – EMC Directive (1996)
73/23/EEC – Low Voltage Directive (1997)

Signed in **Ely**
(place)

On the 11 day of July 2012
(day) (month) (year)

Name: Keith Dhese

Position: General Manager

Chapter 8 Thorlabs Worldwide Contacts

USA, Canada, and South America

Thorlabs, Inc.
56 Sparta Ave
Newton, NJ 07860
USA
Tel: 973-579-7227
Fax: 973-300-3600
www.thorlabs.com
www.thorlabs.us (West Coast)
email: feedback@thorlabs.com
Support: techsupport@thorlabs.com

Europe

Thorlabs GmbH
Hans-Böckler-Str. 6
85221 Dachau
Germany
Tel: +49-(0)8131-5956-0
Fax: +49-(0)8131-5956-99
www.thorlabs.de
email: Europe@thorlabs.com

UK and Ireland

Thorlabs Ltd.
1 Saint Thomas Place, Ely
Cambridgeshire CB7 4EX
Great Britain
Tel: +44 (0)1353-654440
Fax: +44 (0)1353-654444
www.thorlabs.de
email: sales.uk@thorlabs.com
Support: techsupport.uk@thorlabs.com

France

Thorlabs SAS
109, rue des Côtes
78600 Maisons-Laffitte
France
Tel: +33 (0) 970 444 844
Fax: +33 (0) 811 381 748
www.thorlabs.de
email: sales.fr@thorlabs.com

Scandinavia

Thorlabs Sweden AB
Box 141 94
400 20 Göteborg
Sweden
Tel: +46-31-733-30-00
Fax: +46-31-703-40-45
www.thorlabs.de
email: scandinavia@thorlabs.com

Japan

Thorlabs Japan Inc.
Higashi Ikebukuro
Q Building 1st Floor 2-23-2
Toshima-ku, Tokyo 170-0013
Japan
Tel: +81-3-5979-8889
Fax: +81-3-5979-7285
www.thorlabs.jp
email: sales@thorlabs.jp

China

Thorlabs China
Oasis Middlering Centre
3 Building 712 Room
915 Zhen Bei Road
Shanghai
China
Tel: +86 (0)21-32513486
Fax: +86 (0)21-32513480
www.thorlabs.com
email: chinasales@thorlabs.com

Brazil

Thorlabs Vendas de Fotônicos Ltda.
Rua Riachuelo, 171
São Carlos, SP 13560-110
Brazil
Tel: +55-16-3413 7062
Fax: +55-16-3413 7064
www.thorlabs.com
Email: brasil@thorlabs.com



Thorlabs Inc.
56 Sparta Ave
Newton, NJ07860
USA
Tel: +1 973 579 7227
Fax: +1 973 300 3600
www.thorlabs.com

Thorlabs Ltd.
Saint Thomas Place, Ely
Cambridgeshire CB7 4EX,
UK
Tel: +44 (0) 1353 654440
Fax: +44 (0) 1353 654444
www.thorlabs.com