



Linux CAN 开发指南

版本号: 1.0
发布日期: 2022.02.21

版本历史

版本号	日期	制/修订人	内容描述
1.0	2022.02.21	AWA1730	添加初版



目 录

1 前言	1
1.1 文档简介	1
1.2 目标读者	1
1.3 相关术语介绍	1
2 模块配置介绍	2
2.1 设备树配置	2
2.2 内核 menuconfig 配置	2
2.3 buildroot 的 menuconfig 配置	4
3 FAQ	6
3.1 调试等级	6
3.2 驱动加载	6
3.3 通讯测试	7
3.4 常见问题	9
3.4.1 情况一	9
3.4.2 情况二	10
3.4.3 情况三	11

插 图

2-1 内核配置 1	3
2-2 内核配置 2	3
2-3 buildroot 配置 1	4
2-4 buildroot 配置 2	4
2-5 buildroot 配置 3	5
3-1 调试等级	6
3-2 上电 log0	7
3-3 上电 log1	7
3-4 RX 的 log	8
3-5 TX 的 log	9
3-6 Device Drivers	9
3-7 bus-off	10
3-8 查找 can0 失败	10
3-9 驱动加载报错	11

1 前言

1.1 文档简介

介绍 CAN 模块的使用方法，方便开发人员使用。

1.2 目标读者

CAN 模块的驱动开发/维护人员。

1.3 相关术语介绍

表 1-1: 术语介绍

术语	解释说明
Sunxi	指 Allwinner 的一系列 SOC 硬件平台

2 模块配置介绍

2.1 设备树配置

CAN 模块的设备树配置位于 device/config/chips/{ic}/configs/{board}}/board.dts 下面为打开 can0 的配置：

```
can0: can@0x0 {  
    #address-cells = <1>;  
    #size-cells = <0>;  
    compatible = "allwinner,sun8i-can";  
    device_type = "can0";  
    id = <0>;  
    status = "disabled";  
};
```

注意：id = <0> 表示指 can0, id = <1> 表示 can1; status = "okay" 表示打开 can 模块, status = "disabled" 表示关闭 can 模块。

2.2 内核 menuconfig 配置

SDK 根目录中执行 ./build.sh menuconfig 打开配置项界面； ./build.sh saveconfig 保存配置项选择。

- 首先，CAN 模块配置，如下图所示：




图 2-1: 内核配置 1

- 然后, 选择 allwinner CAN 选项, 如下图所示:




图 2-2: 内核配置 2




图 2-5: buildroot 配置 3

3 FAQ

3.1 调试等级

调低打印等级 (8 为最低, 0 为最高), 保证 CAN 驱动调试信息能够输出

```
env.cfg
1
2 #kernel command arguments
3 earlyprintk=sunxi-uart,0x02500000
4 initcall_debug=0
5 console=ttyS0,115200
6 nand_root=ubi0_5
7 mmc_root=/dev/mmcblk0p5
8 mtd_name=sys
9 rootfstype=ubifs,rw
10 init=/init
11 loglevel=8
12 cma=8M
13 mac=
14 wifi_mac=
15 bt_mac=
16 specialstr=
17 keybox_list=widevine,ec_key,ec_cert1,ec_cert2,ec_cert3,rsa_key,rsa_cert1,rsa_cert2,rsa_cert3
18 dsp0_partition=dsp0
19 #set kernel cmdline if boot.img or recovery.img has no cmdline we will use this
20 setargs_nand=setenv bootargs ubi.mtd={mtd_name} earlyprintk=${earlyprintk} clk_ignore_unused initcall_debug=${initcall_debug} console=${console} loglevel=${loglevel} root=${nand_root} rootfstype=${rootfstype} init=${init} partitions=${partitions} cma=${cma} snum=${snun} mac_addr=${mac} wifi_mac=${wifi_mac} bt_mac=${bt_mac} specialstr=${specialstr} gpt=1
21 setargs_nand_ubi=setenv bootargs ubi.mtd={mtd_name} earlyprintk=${earlyprintk} clk_ignore_unused initcall_debug=${initcall_debug} console=${console} loglevel=${loglevel} root=${nand_root} rootfstype=${rootfstype} init=${init} partitions=${partitions} cma=${cma} snum=${snun} mac_addr=${mac} wifi_mac=${wifi_mac} bt_mac=${bt_mac} specialstr=${specialstr} gpt=1
22 setargs_mmc=setenv bootargs earlyprintk=${earlyprintk} clk_ignore_unused initcall_debug=${initcall_debug} console=${console} loglevel=${loglevel} root=${mmc_root} init=${init} partitions=${partitions} cma=${cma} snum=${snun} mac_addr=${mac} wifi_mac=${wifi_mac} bt_mac=${bt_mac} specialstr=${specialstr} gpt=1
23 #nand command syntax: sunxi_flash read address partition name read_bytes
24 #0x4007f000 = 0x40080000(kernel entry) - 0x800(boot img header 2k)
25 boot_dsp0=sunxi_flash read 45000000 ${dsp0_partition};bootr 45000000 0 0
26 boot_normal=sunxi_flash read 45000000 boot;bootm 45000000
27 boot_recovery=sunxi_flash read 45000000 recovery;bootm 45000000
28 boot_fastboot=fastboot
29
30 #uboot system env config
31 bootdelay=0
32 #default bootcmd, will change at runtime according to key press
33 #default nand boot
34 bootcmd=run setargs_nand boot_dsp0 boot_normal

NORMAL ~/T113_release/device/config/chips/t113/configs/default/env.cfg  cfg utf-8[unix] 41% = 14/34 ln:9
```

图 3-1: 调试等级

3.2 驱动加载

板上电检查 log

```

[ 1.672256] disp 5000000.disp: Adding to iommu group 0
[ 1.679352] [DISP] disp_init,line:2308:
[ 1.679358] smooth display screen:0 type:1 mode:4
[ 1.698933] display_fb_request,fb_id:0
[ 1.713985] disp_al_manager_apply output type:1
[ 1.719770] [DISP] lcd clk config,line:735:
[ 1.719783] disp 0, clk: pll(364000000),clk(364000000),dclk(52000000) dsi_rate(364000000)
[ 1.719783] clk real:pll(360000000),clk(360000000),dclk(51428571) dsi_rate(0)
[ 1.719798] wait for new fb take effect
[ 1.720143] sun8iw20-pinctrl pio: pio supply vcc-pd not found, using dummy regulator
[ 1.770713] Freeing logo buffer memory: 2400K
[ 1.773131] [DISP]disp_module_init finish
[ 1.787773] sunxi_sld_init(1551) - insmod ok
[ 1.801227] sun8iw20-pinctrl pio: pio supply vcc-pg not found, using dummy regulator
[ 1.801648] uart uart3: get regulator failed
[ 1.801670] uart uart3: uart3 supply uart not found, using dummy regulator
[ 1.808772] uart3: ttyS3 at MMIO 0x2500c00 (irq = 34, base baud = 1500000) is a SUNXI
[ 1.808810] sw console setup()1784 - console setup baud 115200 parity n bits 8, flow n
[ 2.663269] printk: console [ttyS3] enabled
[ 2.678438] misc dump reg init
[ 2.740296] libphy: Fixed MDIO Bus: probed
[ 2.744983] CAN device driver interface
[ 2.749655] sunxi-can can0x0: can driver start probe 驱动开始加载
[ 2.755545] sunxi-can can0x0 (unnamed net device) (uninitialized): request pinctrl handle fail!
[ 2.772536] sunxi-can can0x0: can driver probe ok ...
[ 2.787921] ehci-hcd: USB 2.0 "Enhanced" Host Controller (EHCI) Driver 驱动加载成功
[ 2.795276] sunxi-ehci: EHCI SUNXI driver
[ 2.800280] ohci-hcd: USB 1.1 'Open' Host Controller (OHCI) Driver
[ 2.807274] sunxi-ohci: OHCI SUNXI driver
[ 2.818608] usbcore: registered new interface driver uas
[ 2.824767] usbcore: registered new interface driver usb-storage
[ 2.831646] usbcore: registered new interface driver ums-alauda
[ 2.841467] usbcore: registered new interface driver ums-cypress
[ 2.848341] usbcore: registered new interface driver ums-datafab
[ 2.855212] usbcore: registered new interface driver ums-eneub250
[ 2.868306] usbcore: registered new interface driver ums-freecom
[ 2.875185] usbcore: registered new interface driver ums-isd200
[ 2.881925] usbcore: registered new interface driver ums-jumpshot
[ 2.892015] usbcore: registered new interface driver ums-karma
[ 2.898676] usbcore: registered new interface driver ums-onetouch
[ 2.905662] usbcore: registered new interface driver ums-realtek
[ 2.912535] usbcore: registered new interface driver ums-sddr09
[ 2.919296] usbcore: registered new interface driver ums-sddr55
[ 2.929093] usbcore: registered new interface driver ums-usb4

```

图 3-2: 上电 log0

进入终端后，检查 CAN 是否存在，输入命令

```
ifconfig can0
```

可以看到输出 log，证明已经存在 can0

```

# ifconfig can0
can0      Link encap:UNSPEC  HWaddr 00-00-00-00-00-00-00-00-00-00-00-00-00-00-00-00
          NOARP  MTU:16  Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:10
          RX bytes:0 (0.0 B)  TX bytes:0 (0.0 B)
          Interrupt:3

```

图 3-3: 上电 log1

3.3 通讯测试

准备两块板子 A 和 B，A 号版子作为 TX，B 号板子作为 RX。

A 号板子 CAN_H 连接到 B 号板子 CAN_H，A 号板子 CAN_L 连接到 B 号板子 CAN_L。

在 B 号板子输入命令：

```

ip -detail link show can0

ip link set can0 down

ip link set can0 type can bitrate 100000

ip -detail link show can0

```



```
ifconfig
can0    Link encap:UNSPEC HWaddr 00-00-00-00-00-00-00-00-00-00-00-00-00-00-00-00
UP NOARP MTU:16 Metric:1
RX packets:7 errors:4 dropped:0 overruns:0 frame:0
TX packets:0 errors:0 dropped:1 overruns:0 carrier:1
collisions:0 txqueuelen:10
RX bytes:56 (56.0 B) TX bytes:0 (0.0 B)
Interrupt:43

lo      Link encap:Local Loopback
inet addr:127.0.0.1 Mask:255.0.0.0
inet6 addr: ::1/128 Scope:Host
UP LOOPBACK RUNNING MTU:65536 Metric:1
RX packets:0 errors:0 dropped:0 overruns:0 frame:0
TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
collisions:0 txqueuelen:1000
RX bytes:0 (0.0 B) TX bytes:0 (0.0 B)
```

发现有rx有错误

图 3-7: bus-off

根据以上情况一般为板子上 CAN 收发器，或者线路上阻抗匹配存在问题。后由硬件同事确认为 CAN 收发器问题，修改硬件电路后解决。

3.4.2 情况二

终端查看 can0，发现无法找到 can0，此时有可能出现 2 种情况

```
#
# ifconfig can0
ifconfig: can0: error fetching interface information: Device not found
#
```

图 3-8: 查找 can0 失败

- 第一种情况，查看启动 log，假如出现以下报错，表明改芯片不支持 CAN 功能。

```
[ 1.779818] disp_al_manager_apply output type:1
[ 1.785815] [DISP] lcd clk config,line:735:
[ 1.785828] disp 0, clk: pll(364000000),clk(364000000),dclk(52000000) dsi_rate(364000000)
[ 1.785828] clk real:pll(360000000),clk(360000000),dclk(51428571) dsi_rate(0)
[ 1.785843] wait for new fb take effect
[ 1.786189] sun8iw20-pinctrl pio: pio supply vcc-pd not found, using dummy regulator
[ 1.835482] Freeing logo buffer memory: 2400K
[ 1.844407] [DISP]disp module init finish
[ 1.854336] sunxi_sid_init(551) - insmod ok
[ 1.867940] sun8iw20-pinctrl pio: pio supply vcc-pg not found, using dummy regulator
[ 1.874074] uart uart3: get regulator failed
[ 1.874185] uart uart3: uart3 supply uart not found, using dummy regulator
[ 1.878094] uart3: ttyS3 at MMIO 0x2500c00 (irq = 34, base_baud = 1500000) is a SUNXI
[ 1.878099] sw console setup(11784) - console setup baud 115200 parity n bits 8, flow n
[ 2.732579] printk: console [ttyS3] enabled
[ 2.747599] misc dump reg init
[ 2.810767] libphy: Fixed MDIO Bus: probed
[ 2.815517] CAN device driver interface
[ 2.820202] sun8i-can can0@0x0: can driver start probe
E/TC:0 platform_smc handle:430 *** can0_driver err code = -2 ***
[ 2.832332] ehci_hcd: USB 2.0 'Enhanced' Host Controller (EHCI) Driver
[ 2.839720] sunxi-ehci: EHCI SUNXI driver
[ 2.847235] ohci_hcd: USB 1.1 'Open' Host Controller (OHCI) Driver
[ 2.854271] sunxi-ohci: OHCI SUNXI driver
[ 2.865846] usbcore: registered new interface driver uas
[ 2.871949] usbcore: registered new interface driver usb-storage
[ 2.878866] usbcore: registered new interface driver ums-alauda
[ 2.885634] usbcore: registered new interface driver ums-cypress
[ 2.892437] usbcore: registered new interface driver ums-datafab
[ 2.902279] usbcore: registered new interface driver ums_eneub6250
[ 2.909366] usbcore: registered new interface driver ums-freecom
[ 2.916269] usbcore: registered new interface driver ums-isd200
[ 2.922981] usbcore: registered new interface driver ums-jumpshot
[ 2.929941] usbcore: registered new interface driver ums-karma
[ 2.942685] usbcore: registered new interface driver ums-onetouch
[ 2.949719] usbcore: registered new interface driver ums-realtek
[ 2.956572] usbcore: registered new interface driver ums-sddr09
[ 2.963318] usbcore: registered new interface driver ums-sddr55
[ 2.970105] usbcore: registered new interface driver ums-usbata
[ 2.989935] ts probe start
[ 3.002722] input: 2009c00.rtp as /devices/platform/soc@3000000/2009c00.rtp/input/input1
[ 3.015302] ts probe success
[ 3.021837] sunxi_gpadc_init,2137, success
[ 3.036319] sunxi_gpadc_setup: get channel scan data failed
```

← 驱动加载过程中报错

图 3-9: 驱动加载报错

- 第二种情况，查看启动 log，假如无任何 can 驱动加载信息，表明驱动没有加载，请查看《模块配置介绍》章节，核对配置是否正确。

3.4.3 情况三

打开 can0 时候，出现以下报错：

```
# ip link set can0 type can bitrate 1000000
ip: either "dev" is duplicate, or "type" is garbage
# ifconfig can0 up
[ 1647.050606] sun4i_can 1c2bc00.can can0: bit-timing not yet defined
ifconfig: SIOCSIFFLAGS: Invalid argument
<3>[ 1647.050606] sun4i_can 1c2bc00.can can0: bit-timing not yet defined
```

ip 工具相关依赖配置没有选择正确，请查看《模块配置介绍》章节，核对配置是否正确。

著作权声明

版权所有 © 2022 珠海全志科技股份有限公司。保留一切权利。

本文档及内容受著作权法保护，其著作权由珠海全志科技股份有限公司（“全志”）拥有并保留一切权利。

本文档是全志的原创作品和版权财产，未经全志书面许可，任何单位和个人不得擅自摘抄、复制、修改、发表或传播本文档内容的部分或全部，且不得以任何形式传播。

商标声明

、 **全志科技** （不完全列举）均为珠海全志科技股份有限公司的商标或者注册商标。在本文档描述的产品中出现的其它商标，产品名称，和服务名称，均由其各自所有人拥有。

免责声明

您购买的产品、服务或特性应受您与珠海全志科技股份有限公司（“全志”）之间签署的商业合同和条款的约束。本文档中描述的全部或部分产品、服务或特性可能不在您所购买或使用的范围内。使用前请认真阅读合同条款和相关说明，并严格遵循本文档的使用说明。您将自行承担任何不当使用行为（包括但不限于如超压，超频，超温使用）造成的不利后果，全志概不负责。

本文档作为使用指导仅供参考。由于产品版本升级或其他原因，本文档内容有可能修改，如有变更，恕不另行通知。全志尽全力在本文档中提供准确的信息，但并不确保内容完全没有错误，因使用本文档而发生损害（包括但不限于间接的、偶然的、特殊的损失）或发生侵犯第三方权利事件，全志概不负责。本文档中的所有陈述、信息和建议并不构成任何明示或暗示的保证或承诺。

本文档未以明示或暗示或其他方式授予全志的任何专利或知识产权。在您实施方案或使用产品的过程中，可能需要获得第三方的权利许可。请您自行向第三方权利人获取相关的许可。全志不承担也不代为支付任何关于获取第三方许可的许可费或版税（专利税）。全志不对您所使用的第三方许可技术做出任何保证、赔偿或承担其他义务。