

## RZ/T2M and RZ/N2L

Rev.1.03  
October 14, 2022

### PROFINET IRT PLC Connection Guide

---

#### Outline

This application note describes the procedure for PROFINET IRT connection between the RZ/T2M and RZ/N2L Starter Kit board and a Siemens PLC controller by using the PLC Engineering Tool "TIA Portal".

#### Applicable devices

RZ/T2M

RZ/N2L

## Contents

<b>1. Start.....</b>	<b>3</b>
<b>2. Creating a New Project .....</b>	<b>4</b>
<b>3. Registering PLC .....</b>	<b>5</b>
<b>4. Registering the Device.....</b>	<b>7</b>
<b>5. Making a Connection between PLC and Device.....</b>	<b>10</b>
<b>6. Configuration of PROFINET IRT .....</b>	<b>11</b>
<b>7. Downloading a Project.....</b>	<b>14</b>
7.1 Configuration of PC Networking Card .....	14
7.2 Compile the project.....	14
7.3 Download the project to the PLC.....	15
7.4 Checking Online Connection.....	20
<b>Revision History .....</b>	<b>21</b>

# PROFINET PLC Connection Guide


## 1. Start

Below a list of recommended equipment to run successful PROFINET IRT.

List of equipment for PROFINET IRT				
Name	Pcs	Description	Order Number	Webpage
PROFINET Controller	1	SIEMENS CPU 1516-3 PN/DP V2.6	6ES7 516-3AN01-0AB0	<a href="https://mall.industry.siemens.com/mall/en/WW/Catalog/Product/6ES7516-3AN01-0AB0">https://mall.industry.siemens.com/mall/en/WW/Catalog/Product/6ES7516-3AN01-0AB0</a>
Hilscher Netanalyzer	1	Netanalyzer	NANL-B500G-RE	<a href="https://www.hilscher.com/en/products/netanalyzer/nanl-b500g-re">NANL-B500G-RE   netANALYZER real time Ethernet analyzer, box   hilscher.com</a>
TIA Portal Software	1	Configuration software PLC	6ES78221AA070Y A5	<a href="https://www.siemens.com/industrial-automation/tia-portal">Product Details - Industry Mall - Siemens RC-DE</a>

### HW Setup for PROFINET IRT

The simple HW setup can be used for an easy demo for PROFINET IRT. Basically, it is a direct connection between the controller and the device. The NetAnalyzer is necessary to capture the PROFINET frames.




After a successful hardware and software installation the TIA portal software of Siemens can be started by selecting from the Windows Start menu or clicking on the "TIA Portal" button that appears on the desktop after installation.

## 2. Creating a New Project

From the top menu, select "Create new project" and create a new project.


After a project has been created, click "Open the project view" to open the Project window.



### 3. Registering PLC


Set the PLC to be used for PROFINET communication.

On the Devices tab, double-click "Add new device".




From the tree, select the PLC to be used, and then click the [OK] button.

Confirm the model number provided on the PLC body.




# PROFINET PLC Connection Guide

On the Devices tab, double-click "Devices & networks".



Perform the following procedure to set the PLC's IP address. (Set a unique IP address.)

- 1) On the Network tab, select the PLC.
- 2) Select the Properties tab.
- 3) On the General tab, select the PROFINET interface.
- 4) Set the IP address.




### 4. Registering the Device


Set the device to be used for PROFINET communication.

To register a new device on the Network, install the GSDML file.

From the Options menu, select "Manage general station description files (GSD)".




Specify the folder that contains the GSD file you want to register, select the checkbox of the file to be installed, and then click the [Install] button.




## PROFINET PLC Connection Guide

The installation result is displayed. Click the [Close] button to close the window.



The catalog information is updated, and the device is added to the Catalog window. Select the device and drag and drop it on the Network view tab.






# PROFINET PLC Connection Guide

Perform the following procedure to set the device's IP address. (Set a unique IP address.)


- 1) On the Network view tab, select a device.
- 2) Select the Properties tab.
- 3) On the General tab, select the PROFINET interface.
- 4) Set the IP address of the device.
- 5) The PROFINET identifies devices with the PROFINET device name. Set the device name that is set for the device to be used as a PROFINET device name by clearing the check in the box. The device name setting field is provided under the IP address setting field. (A device name is automatically set by default.)



## 5. Making a Connection between PLC and Device

Connect the PLC to a device.


Select the Network view tab, select the PLC's Ethernet port and then drag and drop the selected port to the device's Ethernet port to make a connection between PLC and device.



Ports that allow connection can be restricted by the topology setting.

Select the Topology view tab, and then select connectable Ethernet ports of the PLC and the device.

The following example shows that the device has two ports and the PLC is connected to port 1 (Connection to port 2 is not allowed.)




# PROFINET PLC Connection Guide


## 6. Configuration of PROFINET IRT

This chapter describes the configuration of PROFINET IRT.

The first step is the configuration of the PLC. In our case the PLC should be the Sync Master.




For the configuration of the time domain (click on "Domain settings") and configure the RT Class of the device ("rzt2") to "IRT" and the synchronization role to "Sync Slave".



# PROFINET PLC Connection Guide


If isochronous mode is required, implement the following settings.

Follow steps 1 through 3 to add blocks for synchronization.




- 1) Click on "Add new block"
- 2) Select the block "Synchronous Cycle"
- 3) Finish the configuration by click on "OK"

Now the device itself has to be configured for IRT. Open the device properties and click on "Isochronous Mode". Here the check boxes "Isochronous Mode" as well as for the Input Submodule and Output Submodule have to be enabled.



# PROFINET PLC Connection Guide

The final step the configuration of the submodule. Make a double-click on the Input- submodule and click on "I/O addresses". Choose "Synchronous Cycle" for the Organization block. Set output-submodule in the same way.



# PROFINET PLC Connection Guide

## 7. Downloading a Project

### 7.1 Configuration of PC Networking Card

This section describes the procedure to download a project file to the PLC.

Connect the PLC to a PC through the Ethernet port.

Open the Ethernet port properties window of the PC and set the PC's IP address with TCP/IPv4.


Set a network address equal to the IP address set in the PLC.

### 7.2 Compile the project.

To compile the project, please click on the icon “Compile”


After the project has been compiled, the compilation result is displayed on the Compile tab at the lower part of the window.

Make sure that the compilation has been successfully completed.



## 7.3 Download the project to the PLC

On the Device tab, right-click PLC in the tree and select Download to device > Hardware configuration.





## PROFINET PLC Connection Guide


Search the PLC to which the project is downloaded.

- 1) In the "Type of the PG/PC interface" field, select "PN/IE".
- 2) In the "PG/PC interface" field, select the network connected to the PLC.
- 3) In the "Connection to subnet" field, select "PN/IE\_1".
- 4) Click the [Refresh] button to search PLCs and select the target PLC.
- 5) Click the [Load] button.

The Load Preview window opens.


If the action status of "Stop modules" and "Device configuration" indicates "No action", select "Stop all" for "Stop modules" and select "Download to device" for "Device configuration" from each drop-down list.

When no error is present, click the [Load] button.




Select the "Start all" checkbox of Start modules, and then click the [Finish] button.






Connect the real PLC to the real device in accordance with the topology configuration.



When the ERROR indicator on the real PLC does not light and the RUN/STOP indicator lights green, the PROFINET connection has been successfully established.

# PROFINET PLC Connection Guide



For checking online connection, see section


Checking Online Connection.

# PROFINET PLC Connection Guide

## 7.4 Checking Online Connection

The network connection status and the status of device's modules can be monitored on the TIA portal by connecting a PC to the same network using a switching hub.

Select "Go online" from the menu.



When the connection is successfully established, the icon is indicated as "✅".

When an error is present, the icon is indicated as "❌".

The example below shows an error if a PC is connected to a port that is not set in the topology.

Check other icons from Help on the TIA portal.

# PROFINET PLC Connection Guide

---

All trademarks and registered trademarks are the property of their respective owners.

## Revision History

Rev.	Date	Description	
		Page	Summary
1.00	March 29, 2022	-	First version
1.01	July 19, 2022	11	Corrected Chapter 6.
1.02	August 25, 2022	12	Added isochronous mode setting to Chapter 6.
1.03	October 14, 2022	12	Added description to add synchronization block

---

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
  2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
  3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
  4. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
  5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
  6. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
  7. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
  8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
  9. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
  10. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
  11. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
  12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.
- (Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.
- (Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.4.0-1 November 2017)

## Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,  
Koto-ku, Tokyo 135-0061, Japan  
[www.renesas.com](http://www.renesas.com)

## Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

## Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:  
[www.renesas.com/contact/](http://www.renesas.com/contact/)