

HVAC Tutorial

Place Splits



Version 2014



Copyright

© 1999-2014 Intergraph® Corporation and/or its affiliates. All Rights Reserved.

Warning: This computer program, including software, icons, graphical symbols, file formats, and audio-visual displays; may be used only as permitted under the applicable software license agreement; contains confidential and proprietary information of Intergraph and/or third parties which is protected by patent, trademark, copyright and/or trade secret law and may not be provided or otherwise made available without proper authorization.

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraphs (c) (1) and (2) of Commercial Computer Software -- Restricted Rights at 48 CFR 52.227-19, as applicable.

Unpublished - rights reserved under the copyright laws of the United States.

Terms of Use

Use of this software product is subject to the End User License Agreement ("EULA") delivered with this software product unless the licensee has a valid signed license for this software product with Intergraph Corporation. If the licensee has a valid signed license for this software product with Intergraph Corporation, the valid signed license shall take precedence and govern the use of this software product. Subject to the terms contained within the applicable license agreement, Intergraph Corporation gives licensee permission to print a reasonable number of copies of the documentation as defined in the applicable license agreement and delivered with the software product for licensee's internal, non-commercial use. The documentation may not be printed for resale or redistribution.

Warranties and Disclaimers

All warranties given by Intergraph Corporation about software are set forth in the EULA provided with the software or with the applicable license for the software product signed by Intergraph Corporation, and nothing stated in, or implied by, this document or its contents shall be considered or deemed a modification or amendment of such warranties.

Intergraph believes the information in this publication is accurate as of its publication date. Intergraph Corporation is not responsible for any error that may appear in this document. The information and the software discussed in this document are subject to change without notice.

Trademarks

Intergraph and the Intergraph logo are registered trademarks of Intergraph Corporation. Hexagon and the Hexagon logo are registered trademarks of Hexagon AB or its subsidiaries. Microsoft and Windows are registered trademarks of Microsoft Corporation. Other brands and product names are trademarks of their respective owners.

SESSION 6

Place Splits

Objective


By the end of this session, you will be able to:


- Place a split part at a specific position in an HVAC duct.

Before Starting this Procedure

- SP3D Overview
- SP3D Common Sessions
- Routing a Duct
- Placing Fittings


Overview

You can place splits in a duct run to divide the duct into sections that could be easily manufactured, assembled, and dismantled. You use **Insert Split**  to cut a duct along a straight section into two straight duct features. You can then insert a split feature to connect the ends of the two ducts created by cutting the main duct. The split feature generates split parts. Examples of split parts are flange set, sleeve, and rivet joint. The split parts that you can place in a duct run are listed in the **Select Part** dialog box.




Insert Split Parts in a Duct Run


Insert four flange sets in the duct run of Unit **U06**.





Before starting, make sure the objects are assigned to the appropriate permission group. If necessary, set the **Active Permission Group** to **HVAC**.

1. Define your workspace to include all objects located in Unit **U06**.
2. If you are not in the HVAC task, click **Tasks > HVAC**.


3. Click **Zoom Area**  on the **Common** toolbar, and zoom into the area displayed in the following figure:




4. Click **PinPoint**  on the **Common** toolbar to activate the **PinPoint** ribbon.
5. Click **Reposition Target**  on the **PinPoint** ribbon. **Reposition Target** helps you define a reference point to place the split feature.

Place Splits

- Click to select the starting point of the duct straight feature highlighted in the following figure as the reference point to place the first flange set.




- Click **Insert Split**  on the vertical toolbar.
- Select the duct straight feature highlighted in the previous figure.
*The **Part** list on the **Insert Split** ribbon opens.*
- Select **More** from the **Part** list to select the split parts to place.



*The **Select Part** dialog box displays.*

The **Select Part** dialog box displays a list of the available split parts that you can place in a duct run. These split parts are already defined in the Catalog.


10. Navigate to the **Rect_FlatFlange** folder, and select **RECTFF**.




11. Click **OK** to close the **Select Part** dialog box.

TIP You can preview the split parts you are going to place by clicking **Preview**

An outline of the flange set displays in the model.




12. Set the **Split Mode** to **Single Split** on the **Insert Split** ribbon.
13. Click the **Position** button on the **Insert Split** ribbon.
14. Type **-7 ft** in the **E** box on the **PinPoint** ribbon to place the flange set at a distance of 7 feet in the West direction from the starting point.




15. Click in the graphic view to define the active placement point of the flange set.

Place Splits


16. Click **Finish** on the **Insert Split** ribbon to place the flange set.




17. Repeat the previous steps to place three more flange sets at distances of **14 ft**, **21 ft**, and **28 ft** from the starting point of the duct straight feature.




Insert Multiple Splits in a Duct


1. Click the **Insert Split**  command on the vertical toolbar.
2. Select the duct straight feature as shown below.



3. The Part drop-down menu on the **Insert Split** ribbon opens. Select **RECTFF**.




4. On the ribbon bar, change the **Split Mode** to **Multi-Split**.
5. Enter **5 ft** in the **Duct Length** field.



6. In the **Reference** field, select **End**. Notice that the splits are now placed from the other end of the straight feature.

Place Splits

7. In the **Reference** field, select **Start**.
8. Click **Finish** to place multiple splits. Your final output should look like below.



For more information related to inserting splits in a duct run, see *Insert a Split* in the **HVACUsersGuide.pdf** file.