

# Series 2400 SourceMeter®

## User's Manual

2400S-900-01 Rev. K / September 2011

# 2400 Series SourceMeter® User's Manual

©2011, Keithley Instruments, Inc.

All rights reserved.

Cleveland, Ohio, U.S.A.

Document Number: 2400S-900-01 Rev. K / September 2011

The following safety precautions should be observed before using this product and any associated instrumentation. Although some instruments and accessories would normally be used with non-hazardous voltages, there are situations where hazardous conditions may be present.

This product is intended for use by qualified personnel who recognize shock hazards and are familiar with the safety precautions required to avoid possible injury. Read and follow all installation, operation, and maintenance information carefully before using the product. Refer to the user documentation for complete product specifications.

If the product is used in a manner not specified, the protection provided by the product warranty may be impaired.

The types of product users are:

**Responsible body** is the individual or group responsible for the use and maintenance of equipment, for ensuring that the equipment is operated within its specifications and operating limits, and for ensuring that operators are adequately trained.

**Operators** use the product for its intended function. They must be trained in electrical safety procedures and proper use of the instrument. They must be protected from electric shock and contact with hazardous live circuits.

**Maintenance personnel** perform routine procedures on the product to keep it operating properly, for example, setting the line voltage or replacing consumable materials. Maintenance procedures are described in the user documentation. The procedures explicitly state if the operator may perform them. Otherwise, they should be performed only by service personnel.

**Service personnel** are trained to work on live circuits, perform safe installations, and repair products. Only properly trained service personnel may perform installation and service procedures.

Keithley Instruments products are designed for use with electrical signals that are rated Measurement Category I and Measurement Category II, as described in the International Electrotechnical Commission (IEC) Standard IEC 60664. Most measurement, control, and data I/O signals are Measurement Category I and must not be directly connected to mains voltage or to voltage sources with high transient over-voltages. Measurement Category II connections require protection for high transient over-voltages often associated with local AC mains connections. Assume all measurement, control, and data I/O connections are for connection to Category I sources unless otherwise marked or described in the user documentation.

Exercise extreme caution when a shock hazard is present. Lethal voltage may be present on cable connector jacks or test fixtures. The American National Standards Institute (ANSI) states that a shock hazard exists when voltage levels greater than 30V RMS, 42.4V peak, or 60VDC are present. A good safety practice is to expect that hazardous voltage is present in any unknown circuit before measuring.

Operators of this product must be protected from electric shock at all times. The responsible body must ensure that operators are prevented access and/or insulated from every connection point. In some cases, connections must be exposed to potential human contact. Product operators in these circumstances must be trained to protect

themselves from the risk of electric shock. If the circuit is capable of operating at or above 1000V, no conductive part of the circuit may be exposed.

Do not connect switching cards directly to unlimited power circuits. They are intended to be used with impedance-limited sources. NEVER connect switching cards directly to AC mains. When connecting sources to switching cards, install protective devices to limit fault current and voltage to the card.

Before operating an instrument, ensure that the line cord is connected to a properly-grounded power receptacle. Inspect the connecting cables, test leads, and jumpers for possible wear, cracks, or breaks before each use.

When installing equipment where access to the main power cord is restricted, such as rack mounting, a separate main input power disconnect device must be provided in close proximity to the equipment and within easy reach of the operator.

For maximum safety, do not touch the product, test cables, or any other instruments while power is applied to the circuit under test. ALWAYS remove power from the entire test system and discharge any capacitors before: connecting or disconnecting cables or jumpers, installing or removing switching cards, or making internal changes, such as installing or removing jumpers.

Do not touch any object that could provide a current path to the common side of the circuit under test or power line (earth) ground. Always make measurements with dry hands while standing on a dry, insulated surface capable of withstanding the voltage being measured.


The instrument and accessories must be used in accordance with its specifications and operating instructions, or the safety of the equipment may be impaired.


Do not exceed the maximum signal levels of the instruments and accessories, as defined in the specifications and operating information, and as shown on the instrument or test fixture panels, or switching card.


When fuses are used in a product, replace with the same type and rating for continued protection against fire hazard.

Chassis connections must only be used as shield connections for measuring circuits, NOT as safety earth ground connections.

If you are using a test fixture, keep the lid closed while power is applied to the device under test. Safe operation requires the use of a lid interlock.


If a  screw is present, connect it to safety earth ground using the wire recommended in the user documentation.

The  symbol on an instrument means caution, risk of danger. The user should refer to the operating instructions located in the user documentation in all cases where the symbol is marked on the instrument.

The  symbol on an instrument means caution, risk of danger. Use standard safety precautions to avoid personal contact with these voltages.

The  symbol on an instrument shows that the surface may be hot. Avoid personal contact to prevent burns.

The  symbol indicates a connection terminal to the equipment frame.

If this  symbol is on a product, it indicates that mercury is present in the display lamp. Please note that the lamp must be properly disposed of according to federal, state, and local laws.

The **WARNING** heading in the user documentation explains dangers that might result in personal injury or death. Always read the associated information very carefully before performing the indicated procedure.

The **CAUTION** heading in the user documentation explains hazards that could damage the instrument. Such damage may invalidate the warranty.

Instrumentation and accessories shall not be connected to humans.

Before performing any maintenance, disconnect the line cord and all test cables.

To maintain protection from electric shock and fire, replacement components in mains circuits - including the power transformer, test leads, and input jacks - must be purchased from Keithley Instruments. Standard fuses with applicable national safety approvals may be used if the rating and type are the same. Other components that are not safety-related may be purchased from other suppliers as long as they are equivalent to the original component (note that selected parts should be purchased only through Keithley Instruments to maintain accuracy and functionality of the product). If you are unsure about the applicability of a replacement component, call a Keithley Instruments office for information.

To clean an instrument, use a damp cloth or mild, water-based cleaner. Clean the exterior of the instrument only. Do not apply cleaner directly to the instrument or allow liquids to enter or spill on the instrument. Products that consist of a circuit board with no case or chassis (e.g., a data acquisition board for installation into a computer) should never require cleaning if handled according to instructions. If the board becomes contaminated and operation is affected, the board should be returned to the factory for proper cleaning/servicing.

# Table of contents

---

Section	Title	Page
<b>1</b>	<b>Getting Started</b>	
	General information .....	1-2
	Contact information .....	1-2
	Manual addenda .....	1-2
	Safety symbols and terms .....	1-2
	Inspection .....	1-3
	Options and accessories .....	1-3
	Product overview .....	1-5
	Front and rear panel familiarization .....	1-6
	Front panel summary .....	1-6
	Rear panel summary .....	1-7
	Power-up .....	1-9
	Line power connection .....	1-9
	Power-up sequence .....	1-10
	Line frequency setting .....	1-11
	Fuse replacement .....	1-11
	Cooling fan .....	1-12
	Display .....	1-13
	Display format .....	1-13
	EDIT key .....	1-13
	TOGGLE key .....	1-13
	Status and error messages .....	1-14
	Remote display programming .....	1-14
	Front panel tests .....	1-14
	Default settings .....	1-15
	Saving and restoring user setups .....	1-15
	Factory default settings .....	1-16
	Remote setups .....	1-18
	Menus .....	1-19

Main menu .....	1-19
Rules to navigate menus .....	1-22
Editing source and compliance values .....	1-23
Toggling the source and measure display fields .....	1-23
Disabling front panel display .....	1-24
Configuration menus .....	1-24

## 2 Connections

Connection overview .....	2-2
Front/rear terminals selection .....	2-2
Connections to DUT .....	2-3
Sensing methods .....	2-5
Guarding methods .....	2-8

## 3 Basic Source-Measure Operation

WARNING - CAUTION .....	3-2
Operation overview .....	3-4
Source-measure capabilities .....	3-4
Compliance limit .....	3-6
Setting the compliance limit .....	3-8
Basic circuit configurations .....	3-9
Operation considerations .....	3-10
Warm-up .....	3-10
Auto zero .....	3-10
NPLC caching .....	3-11
V-source protection .....	3-12
Source delay .....	3-13
Basic source-measure procedure .....	3-15
Front panel source-measure procedure .....	3-15
Remote command source-measure procedure .....	3-18
Measure only .....	3-20
Front panel measure only .....	3-20
Remote command measure only .....	3-21
Sink operation .....	3-22
Battery charging/discharging .....	3-22
Sink programming example .....	3-24

## 4 Ohms Measurements

Ohms configuration menu .....	4-2
Ohms measurement methods .....	4-3
Selecting ohms measurement method .....	4-4
Ohms measurement procedure .....	4-4
Ohms sensing .....	4-6

Sense selection .....	4-7
Offset-compensated ohms .....	4-8
Enabling/disabling offset-compensated ohms .....	4-8
Ohms accuracy calculations .....	4-9
Ohms source readback .....	4-11
Ohms source readback selection .....	4-11
6-wire ohms measurements .....	4-12
Remote ohms programming .....	4-13
Remote ohms commands .....	4-13
Ohms programming example .....	4-14

## 5 Pulse Mode Operation (Model 2430 only)

Overview .....	5-2
Pulse characteristics .....	5-3
Pulse width .....	5-4
Output off-time .....	5-6
Pulse duty cycle .....	5-6
Fast pulse output .....	5-7
Pulse jitter .....	5-8
Pulse energy limitations (10A range) .....	5-9
Pulse Mode configuration .....	5-10
Front panel Pulse Mode configuration .....	5-10
Remote command Pulse Mode configuration .....	5-11
Pulse-measure considerations .....	5-12
Measurement speed .....	5-12
Filter .....	5-12
Auto range .....	5-12
Concurrent measurements .....	5-12
Ohms source readback .....	5-12
Toggle key .....	5-13
Offset-compensated ohms .....	5-13
Source delay .....	5-13
Trigger delay .....	5-14
Input triggers .....	5-14
Output triggers .....	5-14
Auto output-off .....	5-14
Output-off state .....	5-15
Turning source on .....	5-15
SCPI signal oriented measurement commands .....	5-15

## 6 Source-Measure Concepts

Compliance limit .....	6-2
Types of compliance .....	6-2
Maximum compliance values .....	6-3



Compliance examples .....	6-4
Determining compliance limit .....	6-4
Overheating protection .....	6-6
Overheating conditions .....	6-6
Source-delay-measure cycle .....	6-7
Sweep waveforms .....	6-9
Operating boundaries .....	6-10
Source or sink .....	6-10
Duty cycle .....	6-10
I-Source operating boundaries .....	6-15
V-Source operating boundaries .....	6-19
Source I measure I and source V measure V .....	6-22
Basic circuit configurations .....	6-23
Source I .....	6-23
Source V .....	6-24
Measure only (V or I) .....	6-25
Guard .....	6-27
Cable guard .....	6-27
Ohms guard .....	6-28
Guard sense .....	6-32
Data flow .....	6-34
Buffer considerations .....	6-36

## 7 Range, Digits, Speed, and Filters

Range and digits .....	7-2
Range .....	7-2
Digits .....	7-5
Remote range and digits programming .....	7-5
Speed .....	7-7
Setting speed .....	7-7
Remote speed programming .....	7-8
Filters .....	7-9
Front panel filter control .....	7-10
Remote filter programming .....	7-12

## 8 Relative and Math

Relative .....	8-2
Front panel rel .....	8-2
Remote rel programming .....	8-3
Math operations .....	8-4
Built-in math functions .....	8-4
Front panel math operations .....	8-6
Remote math operations .....	8-7
User-defined math functions .....	8-7

<b>9</b>	<b>Data Store</b>	
	Data store overview .....	9-2
	Front panel data store .....	9-2
	Storing readings .....	9-2
	Recalling readings .....	9-2
	Buffer statistics .....	9-3
	Timestamp format .....	9-4
	Buffer considerations .....	9-5
	Remote command data store .....	9-5
	Data store commands .....	9-5
	Data store programming example .....	9-5
<b>10</b>	<b>Sweep Operation</b>	
	Sweep types .....	10-2
	Linear staircase sweep .....	10-2
	Logarithmic staircase sweep .....	10-4
	Abort on compliance .....	10-5
	Custom sweep .....	10-6
	Source memory sweep .....	10-6
	Configuring and running a sweep .....	10-12
	Front panel sweep operation .....	10-12
	Remote sweep operation .....	10-19
	Pulse Mode sweeps (Model 2430 only) .....	10-24
	Front panel Pulse Mode sweep procedure .....	10-25
	Remote Pulse Mode sweep operation .....	10-26
<b>11</b>	<b>Triggering</b>	
	Front panel trigger operation .....	11-2
	Front panel trigger model .....	11-2
	Configuring triggering .....	11-7
	Remote trigger operation .....	11-10
	Remote trigger model .....	11-10
	Remote trigger commands .....	11-18
	Trigger link .....	11-19
	Input trigger requirements .....	11-19
	Output trigger specifications .....	11-20
	Pulse Mode triggering (Model 2430) .....	11-20
	Trigger models .....	11-20
	Invalid trigger settings .....	11-24
<b>12</b>	<b>Limit Testing</b>	
	Types of limits .....	12-2
	Pass/fail information .....	12-2

Data flow .....	12-3
Limit 1 test (compliance) .....	12-3
Limit 2, limit 3, and limit 5-12 tests .....	12-3
Limit 4 .....	12-3
Limit test modes .....	12-3
Binning .....	12-4
Operation overview .....	12-4
Grading mode .....	12-4
Sorting mode .....	12-7
Binning systems .....	12-10
Handler interface .....	12-10
Handler types .....	12-12
Basic binning systems .....	12-13
Digital output clear pattern .....	12-14
Configuring and performing limit tests .....	12-16
Configuring limit tests .....	12-16
Performing front panel limit tests .....	12-19
Remote limit testing .....	12-20
Limit commands .....	12-20

## 13 Digital I/O Port, Output Enable, & Output Configuration

Digital I/O port .....	13-2
Port configuration .....	13-2
Digital output configuration .....	13-3
Controlling digital output lines .....	13-4
Output enable line .....	13-6
Front panel output configuration .....	13-7
Configure OUTPUT menu .....	13-8
Output-off states .....	13-9
Output-off states and inductive loads .....	13-11
Remote output configuration .....	13-12
Output configuration commands .....	13-12

## 14 Remote Operations

Differences: remote vs. local operation .....	14-2
Operation enhancements (remote operation) .....	14-2
Local-to-remote transition .....	14-2
Remote-to-local transition .....	14-3
Selecting an interface .....	14-3
GPIB operation .....	14-4
GPIB standards .....	14-4
GPIB connections .....	14-4
Primary address .....	14-4
General bus commands .....	14-5

Front panel GPIB operation .....	14-5
Error and status messages .....	14-5
GPIB status indicators .....	14-5
LOCAL key .....	14-6
Programming syntax .....	14-6
Command words .....	14-6
Query commands .....	14-9
Case sensitivity .....	14-9
Long-form and short-form versions .....	14-9
Short-form rules .....	14-10
Response messages .....	14-12
Message exchange protocol .....	14-13
RS-232 interface operation .....	14-13
Sending and receiving data .....	14-13
Baud rate .....	14-14
Data bits and parity .....	14-14
Terminator .....	14-14
Flow control (signal handshaking) .....	14-15
RS-232 connections .....	14-15
Error messages .....	14-17

## 15 Status Structure

Overview .....	15-2
Status byte and SRQ .....	15-2
Status register sets .....	15-2
Queues .....	15-2
Clearing registers and queues .....	15-4
Programming and reading registers .....	15-5
Programming enable registers .....	15-5
Reading registers .....	15-6
Status byte and service request (SRQ) .....	15-7
Status byte register .....	15-8
Service request enable register .....	15-9
Serial polling and SRQ .....	15-9
Status byte and service request commands .....	15-10
Status register sets .....	15-11
Register bit descriptions .....	15-11
Condition registers .....	15-16
Event registers .....	15-16
Event enable registers .....	15-17
Queues .....	15-18
Output queue .....	15-18
Error queue .....	15-19

## 16 Common Commands

Command summary .....	16-2
Command reference .....	16-3
*IDN? — identification query .....	16-3
*OPC — operation complete .....	16-3
*OPC? — operation complete query .....	16-3
*SAV <NRf> — save .....	16-3
*RCL <NRf> — recall .....	16-3
**RST — reset .....	16-4
*TRG — trigger .....	16-4
**TST? — self-test query .....	16-4
*WAI — wait-to-continue .....	16-5

## 17 SCPI Signal Oriented Measurement Commands

Command summary .....	17-2
Configuring measurement function .....	17-2
:CONFigure:<function> .....	17-2
Acquiring readings .....	17-3
:FETCH? .....	17-3
[:SENSe[1]]:DATA[:LATest]? .....	17-4
:READ? .....	17-4
:MEASure[:<function>]? .....	17-5

## 18 SCPI Command Reference

Reference tables .....	18-2
Calculate subsystems .....	18-26
CALCulate[1] .....	18-26
Select (create) math expression name .....	18-26
Assign unit suffix .....	18-28
Define math expression .....	18-29
Enable and read math expression result .....	18-32
CALCulate2 .....	18-33
Select input path .....	18-33
Null feed reading .....	18-34
Read CALC2 .....	18-34
Configure and control limit tests .....	18-35
Composite testing .....	18-39
Clear test results .....	18-42
CALCulate3 .....	18-43
Select statistic .....	18-43
Acquire statistic .....	18-43
DISPlay subsystem .....	18-44
Control display .....	18-44

Read display .....	18-46
Define :TEXT messages .....	18-46
FORMat subsystem .....	18-47
Data format .....	18-47
Data elements .....	18-49
CALC data elements .....	18-53
Byte order .....	18-54
Status register format .....	18-54
OUTPut subsystem .....	18-55
Turn source on or off .....	18-55
Output enable line .....	18-56
Output-off states .....	18-56
ROUTe subsystem .....	18-57
Select input jacks .....	18-57
SENSe1 subsystem .....	18-58
Select measurement functions .....	18-58
Select measurement range .....	18-62
Select auto range .....	18-65
Current range holdoff .....	18-66
Set compliance parameters .....	18-67
Set measurement speed .....	18-69
Configure and control filter .....	18-70
SOURce subsystem .....	18-71
SOURce[1] .....	18-71
Control source output-off .....	18-71
Select function modes .....	18-72
Select sourcing mode .....	18-73
Select range .....	18-74
Set amplitude for fixed source .....	18-77
Set voltage limit .....	18-79
Set delay .....	18-82
Configure voltage and current sweeps .....	18-83
Abort on compliance .....	18-90
Configure list .....	18-91
Configure memory sweep .....	18-93
Set scaling factor .....	18-95
Soak time .....	18-96
Pulse Mode delays (Model 2430 only) .....	18-97
SOURce2 .....	18-98
Setting digital output .....	18-98
Clearing digital output .....	18-99
STATus subsystem .....	18-101
Read event registers .....	18-101
Program event enable registers .....	18-101
Read condition registers .....	18-101

Select default conditions .....	18-102
Error queue .....	18-102
SYSTem subsystem .....	18-103
Default conditions .....	18-103
Control remote sensing .....	18-104
Select guard mode .....	18-105
Initialize memory .....	18-106
Control beeper .....	18-106
Control auto zero .....	18-107
Control NPLC caching .....	18-107
Select power line frequency setting .....	18-108
Error queue .....	18-109
Simulate key presses .....	18-110
Read version of SCPI standard .....	18-112
RS-232 interface .....	18-112
Query timestamp .....	18-112
Reset timestamp .....	18-113
Auto reset timestamp .....	18-113
Auto range change mode .....	18-113
TRACe subsystem .....	18-114
Read and clear buffer .....	18-114
Configure and control buffer .....	18-114
Select timestamp format .....	18-116
TRIGger subsystem .....	18-116
Clear input triggers .....	18-116
Initiate source/measure cycle .....	18-117
Abort source/measure cycle .....	18-117
Program trigger model .....	18-117
Accuracy calculations .....	A-2
Measure accuracy .....	A-2
Source accuracy .....	A-2
Source-Delay-Measure (SDM) cycle timing .....	A-3
Definitions .....	A-3
Timing diagrams .....	A-4
Introduction .....	B-2
Status and error messages .....	B-2
Eliminating common SCPI errors .....	B-8
Introduction .....	C-2
FETCH? .....	C-3
CALCulate[1]:DATA? .....	C-4
CALCulate2:DATA? .....	C-4
TRACe:DATA? .....	C-4
CALCulate3:DATA? .....	C-4
Introduction .....	D-2
Bus description .....	D-3

Bus lines .....	D-5
Data lines .....	D-5
Bus management lines .....	D-5
Handshake lines .....	D-5
Bus commands .....	D-6
Addressed multiline commands .....	D-8
Address commands .....	D-8
Unaddress commands .....	D-8
Common commands .....	D-8
SCPI commands .....	D-8
Command codes .....	D-9
IEEE command groups .....	D-11
Interface function codes .....	D-12
Introduction .....	E-2
Introduction .....	F-2
Overview .....	F-2
Description .....	F-2
Operation .....	F-3
DUT connections .....	F-3
Contact check threshold resistances .....	F-4
Contact check failure indications .....	F-5
Auto and manual ohms .....	F-5
Trigger model operation .....	F-6
Sweep and binning considerations .....	F-6
Sweep limitations .....	F-6
Limit test sequence .....	F-7
Binning failure indications (grading mode) .....	F-10
Front panel contact check operation .....	F-11
Menu selections .....	F-11
Using contact check .....	F-12
Remote contact check operation .....	F-14
Contact check remote commands .....	F-14
Contact check programming example .....	F-15
Contact check command reference .....	F-17
Configure and control contact check .....	F-17
Configure and control contact check limit test .....	F-17
Configure and control contact check event detection .....	F-19
Contact check defaults .....	F-20
Introduction .....	G-2
Selecting the 488.1 protocol .....	G-2
Protocol differences .....	G-3
Message exchange protocol (MEP) .....	G-3
Using SCPI-based programs .....	G-4
NRFD hold-off .....	G-4
NDAC hold-off .....	G-4



Trigger-on-talk ..... [G-5](#)  
Message available ..... [G-5](#)  
General operation notes ..... [G-5](#)