


Robot Vacuum Cleaner User Manual



READ THESE INSTRUCTIONS CAREFULLY BEFORE
USING THE PRODUCT, AND KEEP IT PROPERLY.

Catalogue

- 1. IMPORTANT SAFETY INSTRUCTIONS..... 2
 - Packing List..... 5
- 2. PRODUCT OVERVIEW..... 6
 - 2.1 Parts Name..... 6
- 3. Product Use..... 8
 - 3.1 Attentions..... 8
 - 3.2 Preparation 9
 - 3.3 Robot Charging..... 9
 - 3.4 Install Integrated Water Tank and Dust Box..... 10
 - 3.5 Robot Operation..... 10
 - 3.6 Use the Magnetic Strip..... 11
- 4. Connect to the APP..... 11
 - APP Operation and Functions..... 12
- 5. Regular Care & Maintenance 14
 - 5.1 Cleaning & Maintaining Integrated Water Tank & Dust Box..... 14
 - 5.2 Cleaning and Maintaining Big dust box 14
 - 5.3 Cleaning & Maintaining Roller Brush , Side Brush, Driving Wheel and Universal Wheel..... 15
 - 5.4 Cleaning & Maintaining Charging Contacts, Anti-drop Sensors and TOF sensors..... 16
- 6. Troubleshooting..... 17
- 7. Fault Elimination..... 20
- 8. Product Parameter..... 22
- 9. Factory Default Reset..... 22
- 10. Environmental Protection Instructions..... 22

1. IMPORTANT SAFETY INSTRUCTIONS

READ THESE INSTRUCTIONS BEFORE USING THIS ROBOT VACUUM CLEANER. IT IS INTENDED FOR HOUSEHOLD USE ONLY. PLEASE KEEP ALERT WHEN USE THIS PRODUCT, AND RESPECT BELOW INSTRUCTIONS.

1. If you don't use it for one month, please turn off the power.
2. After the cleaning is finished, it should be connected with the charging base correctly.
3. In view of the problems that may appear in the cleaning process, ensure the following is done prior to cleaning: ①Remove the power cord and small objects on the ground to avoid the product being blocked or items damaged; ②Fold the carpet tassels under the carpet and keep the hanging curtains and tablecloths away from the ground; ③Remove low and light objects on the ground, such as slippers and small toys, to avoid pushing to the edge corner.
4. If there is a suspended environment such as stairs, please test the product first to see if it can detect the edge of the hanging area without falling. Protective fence shall be set at the edge of the suspended area to prevent the product from falling. Make sure that the protection does not cause tripping.
5. Please use the product according to the instruction manual. Use only accessories recommended or sold by the manufacturer.
6. Make sure the supply voltage is in accordance with the voltage marked on the charging base.
7. Make sure the dust box and filter material are installed in place before using the product.
8. If the power cord is damaged, in order to avoid danger, it must be replaced by the professional personnel of the manufacturer, its maintenance department or similar departments.
9. Before cleaning and maintaining the product, please turn off the power of the product and pull the plug out of the power socket.
10. Before discarding the product, please remove the product from the charging base, turn off the power switch and take out the battery.
11. Before discarding the product, remove and discard the product battery in accordance with local laws and regulations.
12. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge only if they have been given supervision or instruction concerning
13. use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Use only in household environment.
14. Do not use in outdoor, commercial and industrial areas. Do not use the product in the room where infants sleep.

15. Do not use the product when it cannot work normally due to falling, damage, outdoor use or water intrusion. To avoid injury, the product should be repaired by the manufacturer or its after-sales service department.

16. Please use the product according to the instructions in the manual. The company is not responsible for any loss or injury caused by improper use.

WARNINGS

1. Only applicable to the original charging base specially provided by the manufacturer. Users are not allowed to replace the battery without permission. If you suspect that the battery is damaged, please contact the manufacturer, authorized dealer or professionals of similar departments for replacement.

2. It is forbidden to use the product in the environment with open fire or fragile articles. It is forbidden to use the product in extremely hot (above 40°C) or extremely cold (below 0°C) environment.

3. While the Robot is working, keep hair, clothes, fingers and other parts of the human body away from the opening and operating parts of the product.

4. It is forbidden to use the product on wet ground or ground with accumulated water.

5. It is forbidden for the product to vacuum anything that may clog the product, such as stones, waste paper, etc.

6. It is forbidden for the product to vacuum any flammable materials, such as gasoline, and toner for printer or copier. It is forbidden to use products in areas with inflammables.

7. It is forbidden for the product to vacuum any burning articles, such as cigarettes, matches, ashes and other articles that may cause fire.

8. It is forbidden to place objects in the roller brush mouth. Do not use the product when the roller brush mouth is blocked. Clean the dust, cotton wadding, hair, etc. at the roller brush mouth to ensure smooth air circulation.

9. Use the power cord carefully to avoid damage. It is forbidden to use the power cord to drag or lift the product and its charging base, to use the power cord as a handle, to clamp the power cord in the crack of the door, and to pull the power cord at sharp corners. It is forbidden to run the product on the power cord, and the power cord should be away from the heat source.

10. It is forbidden to use the damaged charging base. If the charging base is damaged, in order to avoid danger, it must be repaired or replaced by the manufacturer, authorized dealer or professionals from similar departments.

11. Even if the product has been seriously damaged, it is forbidden to burn the product, or the product battery may cause explosion.

12. Do not use the mop holder module in a carpet environment.

13. It is forbidden to upgrade the software of the Robot under 15% battery capacity if not in charging.


RF Exposure Warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.






This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.

Output power of the WI - Fi module is less than 20dBm

SAVE THESE INSTRUCTIONS

Environment friendly disposal	
	<p>This marking indicates that this product should not be disposed with other household wastes throughout the EU.</p> <p>To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased.</p> <p>They can take this product for environmental safe recycling.</p>

Symbol description


	Class II equipment		Direct current
	For indoor use only		Alternating current
	Read operator's manual		

Hereby, **XXX** declares that this Robot Vacuum Cleaner is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.


A copy of the Declaration of conformity can be **XXX**

Packing List

Will differ per different configurations




Robot Vacuum Cleaner



Charging Base



Cleaning
tool brush




Side Brush




User Manual




High Efficiency Filter
and Sponge




Big Dust Box



Power Adapter
(for charging base)



Integrated Water Tank and
Dust Box (with washable
mop and holder)



Magnetic Strip



Remote control and
AAA Batteries




Roller Brush


2. PRODUCT OVERVIEW

2.1 Parts Name


Main Unit




Rear View




Integrated Water Tank and Dust Box



Big Dust Box





Charging Base



Remote Control

1. For Dust box version
2. For Integrated water tank and dust box




3. Product Use

3.1 Attentions


Check and arrange the area to be cleaned to ensure the operation is safe. Put the furniture and remove the unfriendly obstacles.

Remove or cover the low objects on the ground, such as the scale and the base of the floor fan, that may affect the Robot working.


If there are carpet tassels, please put the edge under the carpet in advance.



If the Robot is cleaning at the entrance of compound stairs and the edge of steps, please place protective fence to ensure its safety and smooth operation.



Remove all objects that may entangle the Robot, such as power cord, rope, etc. In addition, if the step is too high, it may get stuck.




Warm tips:

for the first time, please follow the Robot through the whole process to help eliminate some unfriendly small problems, so that it can clean smoothly. When follow the Robot, please be careful not to stand in front of it.


3.2 Preparation

- Before using the product, please remove the protective strip and protective film on the Robot and charging base.


Remove the protective strip



Remove the protective film




Install side brushes and lock screw




3.3 Robot Charging


1.Put the charging base flat against the wall. There should be no cliffs/stairs or other objects placed in the area 1m to the left and right and 2m in front, and keep objects with strong reflecting surface such as mirror or glass away;Keep charging base away from direct sunlight.



2.Turn on the power switch of the Robot, put it into the charging base, and connect the charging contacts at the bottom with the charging contacts of the charging base.Please note that the Robot cannot be charged when it's power off.



3.For first time use, please fully charge it. During the charging, the start button flashes breathing light in white; The light will be off when charging finishes. Charging time is about 4-5 hours.




Warm Reminder:


- 1.During daily use, please put the Robot onto the charging base and ensure that the charging base is connected to the power supply and the Robot power is on.
- 2.In daily use, pay attention to clean the charging contacts of the charging base to avoid affecting the charging effect.
- 3.If you do not use the Robot for a long time, please fully charge it, and turn off the power switch. Store it in a ventilated and dry place.
- 4.If the battery is over discharged or not used for a long time, the product may not be rechargeable. Please contact our after-sales service for maintenance. Do not disassemble it by yourself

3.4 Install Integrated Water Tank and Dust Box


1. open the cover and fill with the water tank with water




2. Close the lid of water inlet cover.
(Make sure the lid close well and no raised parts.)



3. Install the mop holder and mop cloth.



4. Press & hold the release key and insert the integrated water tank & dust box.





Warm Tips:

1. In order to prolong the service life of the water tank, it is recommended to use purified water or soft water.
2. Do not use the mopping function on the carpet.
3. After mopping, please empty the water tank in time and remove the mop holder.
4. After the mop holder is installed, the Robot will work as sweeping & mopping together. Suction power defaulted to mute level and can't be adjusted manually.
5. When the mop holder is not installed, the Robot will work as sweeping modes, vacuum and sweep without mopping.
6. It is normal that a little water remains in the water tank due to factory inspection.

3.5 Robot Operation



1.start

Press the start button of Robot or remote control, Robot will build a map based on its scan of the room, then splits each room into squares, cleaning the edges of the square first before covering the inside in a zigzag pattern, finally complete cleaning of all areas.





2.pause

When Robot is working, press the pause button of Robot or remote control to pause the robot.





3.Partial Clean

Press partial cleaning button of Robot or remote control, Robot will clean a 1.5m*1.5m square area centered on itself.



4.Recharge

Press recharging button of Robot or remote control, Robot will return to Charging Base



5.Sleep and wake up

Robot will sleep after full charged for 10 min.

If the Robot is not operated within 10 minutes, it will sleep.

When Robot is not in charging base and sleep for more than 4 hours, it will automatically shutdown.

When in sleep mode, press the button of Remote control, Robot and App to wake it up.


6.Child lock

Press partial cleaning button of Robot for five seconds, and the robot will enter the child lock mode.

The Robot Button, remote control and Smart speaker cannot work in this time.

Press it for 5S again to exit child lock mode.

Note: App can still operate Robot when in child lock mode.




3.6 Use the Magnetic Strip

The magnetic strip can be used to set the area where the Robot is not allowed to enter.

1.Make sure the magnetic strip is placed on the same surface as the Robot.

2.Keep the magnetic strip away from anything that gives off too much heat



4. Connect to the APP

1.APP download

Scan the QR code on the Charging Base, download and install APP according to the indications.

2.Add device

Open the APP to 'My Device' page, press upper right corner '+' and follow APP indication to add device.

Warm Reminder :

1. APP has requirements for mobile system version: IOS 9.0 & above, Android 5.0 & above. Please update the mobile system version before using APP.

2. Before WIFI connection, please make sure that the mobile phone and home network are connected.

3. For the house without WIFI network, please use your Mobile Network with Personal Hotspot to connect Robot.

APP Operation and Functions

Map management


Before use, it is recommended to switch on Map Save Mode to get advanced experience.

1.Map building: Selecting Full Cleaning mode, Robot starts cleaning from charging base, and returns to charging base after finished. It will build a map of partitions according to the layout of the house. You can save the map in APP. It is up to save 4 maps.

2.Map editing: You can split, merge or rename partitions of the map.

➤ **Full Cleaning**

Robot will build a map based on its scan of the room, then splits each room into squares, cleaning the edges of the square first before covering the inside in a zigzag pattern, finally complete cleaning of all areas.




➤ Room Cleaning

Robot will clean the Rooms selected in the app.

Tips:

- 1.It's necessary to switch on Map Save Mode in APP and save a map before starting Room Cleaning.
- 2.Room Cleaning can only be used to customize the cleaning area and not to isolate hazards. Please clear obstacles around the selected rooms.




➤ Zone Cleaning

Robot will clean the Zones drawn in App.


Tips:

Zone cleaning can only be used to customize the cleaning area and not to isolate hazards. Please clear obstacles around the drawn zones.



➤ **Pin n go**

Specify a point on the map, and Robot will automatically get there.




➤ **Breakpoint resume**

When the battery is low during the cleaning, Robot will automatically return to Charging Base for charging; After charging to 80%, it will continue cleaning from where it left off.


Tips:

- 1. The robot will not resume cleaning in Do Not Disturb mode;
- 2. Recharging manually or moving Robot, it will not resume cleaning.



➤ **Y-shape mopping**

When mop holder installed, press Y-shaped cleaning button in APP, and Robot will mop the floor in a Y-shape by simulating artificial work.




➤ **Restricted Area**

Create No-Go Zones, No-Mop Zones and virtual Wall in map to prevent robot from access certain areas and rooms. By default, No-Mop Zones will be activate only when Mop holder is in place.

Tips:

- 1.Restricted areas can be created on a saved or build-ing map.
- 2.Restricted Areas can only be used to customize cleaning area and not to isolate hazards.
- 3.Moving the robot or obvious changes of house environment may cause the map to become invalid, and the restricted area may be lost.




➤ **Scheduled cleaning.**

Set cleaning schedules in APP. Robot will clean at defined times and return to Charging Base when finished.

Tips:

Robot will not clean as scheduled when in low battery.




➤ **More Functions.**

Real-Time Map View	Carpet Boost	Positioning Robot	Remaining Power
Cleaning mode settings	Cleaning History	Firmware Updates	Voice settings
Maintenance Schedule	Remote Mode	Do Not Disturb (DND) mode


5. Regular Care & Maintenance

5.1 Cleaning & Maintaining Integrated Water Tank & Dust Box


1. Press & hold the release key and pull the integrated water tank & dust box.




2. Take out the mop holder and mop cloths.




3. Wash and dry the mop cloths.




4. Open the dust box with outwards force as shown in picture below and empty it.




5. Take out the High efficiency filter and filter sponge, tap to remove dust.




6. Clean the dust on the primary filter with cleaning tool brush. Clean both inside and outside.



7. Wash the dust box and filter sponge with water. High efficiency filter can't be washed. If it is accidentally soaked in water, please air-dry before use.




8. Empty the remaining water from the water tank. Air-dry the water tank, dust box and filter sponge in shade.




5.2. Cleaning and Maintaining Big dust box


1. Press & hold the release key to pull the big dust box.




2. Open the big dust box to sides as shown in picture below and empty it.




3. Open the dust box lock, take out the High efficiency filter and filter sponge, and tap to remove dust.




4. Clean the dust on the primary filter with cleaning tool brush. Clean both inside and outside.



5. Wash the dust box and filter sponge with water. High efficiency filter can't be washed. If it is accidentally soaked in water, please air-dry before use.




6. Air-dry the dust box and filter sponge in shade.




5.3 Cleaning & Maintaining Roller Brush , Side Brush, Driving Wheel and Universal Wheel

■Cleaning Roller Brush and Side Brush


1. Pull on the release tabs to unlock the brush guard as shown.




2. Lift the roller brush to remove it.



3. Clean the roller brush with the cleaning tool brush.




4. Clean the side brush with the cleaning tool brush.




■Clean the driving wheel

1. Use the cleaning tool brush to remove the hair and garbage on the driving wheel.




2. When the driving wheel is stuck, flip its gear in the opposite direction, trash will fall from the gap.




■Clean the universal wheel

Use the cleaning tool brush to clean the hair and garbage on the universal wheel.



5.4 Cleaning & Maintaining Charging Contacts, Anti-drop Sensors and TOF sensors.


Clean the Robot
Charging contacts




Clean the Charging
contacts of Charging
base



Clean the Anti-drop
Sensors



Clean TOF
sensors



Warm tips:

* The Charging contacts, Anti-drop sensors and TOF sensors all contain sensitive electronic components. Please use a dry rag when cleaning them, not a wet rag to prevent water damage.

6. Troubleshooting

During the use of the product, in case of the following conditions. It can be checked and solved independently by users.

No	Fault condition	Likely cause	What to do
01	Robot can't connect to APP	The router user name and password are incorrect	Configure the router network and make sure that the "user name" and "password" of the router are correct
		The robot is not within the network signal coverage of the router	Ensure that the robot is within the network signal coverage of the router
		Is the robot in the state to connect WIFI?	Only when the robot is in the state to connect WIFI, it can connect properly. When the robot is power on, press RECHARGE & PARTIAL Cleaning 5S until hearing 'Resetting WIFI'. WIFI LED flashes blue, indicating that the robot is in the state to connect WIFI.
		Not using 2.4G network	The robot does not support 5G network at present. Please choose 2.4G
		APP doesn't support the current router model device	Please check the specific supported models according to the APP prompts
02	Unable to install app	The version of mobile operating system is too low	For mobile phones with IOS 9.0 or above and Android 5.0 or above, you can download and use the APP.
03	The robot cannot be turned on	The power switch is turned off. Low power. Temperature is not suitable.	Please turn the power switch on the side of the robot to "I" state. Please charging the robot. Please use the robot in an environment of 0-40°C.
04	The robot can't charge	The power switch is turned off. Incorrect use of power adapter Charging base not connected to power supply	Please turn the power switch on the side of the robot to "I" Please check and use the adapter correctly Make sure the power supply and the charging base is connected and charging base indicator lights up
		The charging contacts of the robot and the charging base is not fully connected or the charging contacts are dirty.	Ensure that the charging contacts of the robot and charging base is fully connected, and the START key is flashing. Check whether the charging contacts of the robot and charging base are dirty, and refer to the part of [regular maintenance] in the manual for cleaning
		Temperature is not suitable	Please charge the robot in an environment of 0-40°C
		If the battery is not used for a long time, it will lead to over discharge	It is recommended to use this product frequently. If it is not used for a long time and cannot be charged, please contact the aftersales service personnel

No	Fault condition	Likely cause	What to do
05	Robot is not working	Low power The side brush & roller brush are entangled, and the dust box and filter material are blocked	Charging the robot Check whether the robot has abnormal alarm. It is recommended to clean and maintain the side brush, roller brush, dust box and filter material regularly
06	Robot walking back	There are obstacles ahead Bumper plate stuck The surface area of anti-drop sensor lens has dust	Clear the obstacles ahead Tap the bumper plate to check whether there is something stuck Clean the surface area of anti-drop sensor lens
07	Water tank or dust box falling off	The installation is not in place	When installing, please push hard and hear a "click" to ensure that it is installed in place
08	The water tank with no water or little water seepage after installation	No water in the water tank. Outlet of water tank is blocked. Mop holder is not installed.	Add water to the water tank. Clear up the outlet of water tank. Make sure the mop holder is installed.
09	Unable to return to the charging base automatically	The charging base is powered off or moved manually.	Please check whether the charging base is connected to the power. Do not move the charging base manually.
		The recharge route is blocked or too many obstacles are near the charging base	Please place the charging base in an open area and keep the recharge route smooth.
		It will regenerate the map in partial cleaning and may be unable to automatically recharge if the charging base is far away	Please manually put the robot into the charging base to charge
10	If the cleaning is not finished, the robot returns to charge	The robot feels that the power is low	The robot will automatically return to charging, and then performs a break-point resume
		Complex furniture environment will reduce cleaning efficiency, so it may not finish cleaning.	Arrange the furniture environment to make it easy to clean.
11	Abnormal noise during cleaning	The roller brush, side brush or driving wheel may be entangled, and the universal wheel may be entangled during the cleaning	Please clean it after power off. It is recommended to take them out and clean. Refer to regular maintenance
12	Noisy operation	The dust baffle at the air inlet of the dust box is stuck The suction is at high level	Take out the dust box and adjust the dust baffle to ensure its flexible movement. It is suggested that users can choose lower or mute suction power for cleaning when they are at home and use high-grade suction power when they go out

No	Fault condition	Likely cause	What to do
13	The robot is in trouble when working	The robot is entangled or obstructed by scattered wires, drooping curtain cloth or carpet tassels on the ground	The robot will try all kinds of ways to get rid of the trouble, if not, it is recommended to help it manually
		The main engine may be jammed by furniture of similar height to the robot	The robot will try all kinds of ways to get rid of the trouble, if not, it is recommended to help it manually
14	Driving wheel alarms	The driving wheel is entangled with something and stuck	Turn off the robot and put the bottom up; first turn the wheel counterclockwise and then clockwise to turn out the debris and garbage stuck in it; then press and slide the driving wheels on both sides at the same time to check whether it can rotate and whether it can rebound after releasing
15	The cleaning ability is reduced or the ash dropped	The dust box is full; The filter net is blocked The roller brush is entangled	Clean the dust box Clean the filter net Clean the roller brush
16	When the robot is working, there are some problems, such as route disorder, deviation, repeated cleaning and small area not cleaned	The wires, slippers and other objects placed on the ground affect the normal work of the Robot	Before the robot works, please tidy up the scattered wires, slippers and other objects on the ground, and reduce the scattered objects on the ground as much as possible. If there is uncleaned area, the robot will clean the area independently. Please do not interfere (such as moving the robot or blocking its route)
		When the robot climbs the steps, threshold and door strip, the driving wheel slipped with the ground, which will affect the judgment on the environment of the whole house	It is recommended to close the door of the area and clean the area separately. After cleaning, it will return to the starting point. Please rest assured to use it
		Working on a newly waxed, polished floor or smooth tile reduces the friction between the driving wheel and the ground	It is recommended that you wait for the floor wax to dry before using
		Due to the different house environment, the robot can not enter some areas	It is suggested to tidy up the home environment to ensure that the Robot can enter for cleaning
17	Not cleaning as scheduled	Scheduled appointment cancelled Low power The robot is in Do Not Disturb mode	Reset appointment Charge the robot It will not follow scheduled cleaning in Do Not Disturb (DND) mode, you can adjust the DND time in the APP or clean at other times

No	Fault condition	Likely cause	What to do
18	LDS Laser sensor abnormal	The laser sensor is blocked or stuck by something	Please turn off and clean it.
19	Not breakpoint resume cleaning	The robot is in Do Not Disturb mode	It will not follow scheduled cleaning in Do Not Disturb mode, you can adjust the Do Not Disturb mode time in the APP or clean at other times
		The robot didn't automatically return to the charging base last time.	Recharging or putting the robot to charging base manually, the robot will not follow breakpoint resume cleaning.
20	TOF along the wall sensor abnormal	The surface area of TOF sensor has dust	Please wipe with a soft towel
21	Water tank is leaking	The water tank is not closed completely	Make sure the lid of water inlet close well
22	Fan abnormal	Fan is entangled or blocked by something.	Please turn off the Robot and send it to the after-sales service point for professional maintenance.

If the trouble can't be solved by above operations, you can contact the after-sales person.

7. Fault Elimination

Robot Status	Light Indication	APP Indication	Voice Alarm
Fall (Anti-drop sensor alarm)	RED Light On	Cliff Sensor Error, please clean the cliff sensor and start the robot away from the cliff	Error 1, Anti-drop sensors error, pls put the robot on the ground to start it
LDS abnormal	RED Light On	LDS Error, please check LDS and move robot to new location and start	Error 2, please make sure the LDS LiDAR head is not blocked or stuck
Wheel electricity abnormal	RED Light On	Wheel Error, please turn the wheels and clear by hand	Error 3, please check whether the driving wheel is stuck
Wheel speed abnormal	RED Light On	Wheel decoder Error, please turn the wheels and clear by hand	Error 4, please check whether the driving wheel is normal
Main bumper abnormal	RED Light On	Bumper Error, please clean the bumper and tap it	Error 5, please check and tap the robot main bumper

Robot Status	Light Indication	APP Indication	Voice Alarm
LDS LiDAR bumper abnormal	RED Light On	LDS Bumper Error, please move robot and tap the LDS bumper	Error 6, please check whether the laser bumper is stuck
Fall (Wheel abnormal)	RED Light On	Wheel Suspended, please put the robot on the ground and start	Error 7, wheel suspended, please put the robot on the ground to start it
Robot stuck	RED Light On	Robot Stuck, please help Robot to get out of trouble	Error 8, please help the robot to get out of trouble
Side brush abnormal	RED Light On	Side brush Error, please check side brush and clean up	Error 9, please check the side brush whether it is entangled
Roller brush abnormal	RED Light On	Roll brush Error, please check roll brush and clean up	Error 10, please check the roller brush whether it is entangled
Charge abnormal	RED Light On	Adapter Error, please use the specified adapter	Error 11, please use the specified adapter for charging
Anti-drop sensor abnormal	RED Light On	Cliff Sensor Error, please clean the cliff sensor and start the robot away from the cliff	Error 12, please clean the anti-drop sensors, and start the robot away from the cliff
Fall (wheel abnormal)	RED Light On	Wheel Suspended, please put robot on the ground and start	Error 13, wheel suspended, please put the robot on the ground to start it
Robot leans	RED Light On	Robot tilt, please put robot on the ground and start	Error 14, please put the robot on a level ground to start
Power off charging alarm	RED Light On	Power Off, please turn the power on and recharge	Error 15, please turn the power on and charge
Magnetic field interruption	RED Light On	Magnetic induction Error, please put the robot away from magnetic area and start	Error 16, please move the robot away from the strong magnetic field to start
Start on the carpet with mop holder	RED Light On	Mopping Error, please put the robot away from carpet and start	Error 17, please move the robot away from the carpet to start
Start at forbidden area and alarm	RED Light On	Forbidden Zone Error, please put robot away from the forbidden area and start	Error 18, Forbidden area or virtual wall detected, please move the robot away and restart
Low battery alarm	RED Light On	Low Battery, please recharge	Error 19, Low battery, please recharge and start
TOF sensor abnormal	RED Light On	Wall Sensor Error, please clean the wall sensor	Error 20, please clean the along wall TOF sensors
Reset factory default	RED Light On		Error 21, please start after factory default reset
Partial cleaning Error	RED Light On	Partial cleaning Error, please put the robot in the area to be cleaned and then start partial cleaning	Error 22, please put the robot in the area to be cleaned and then start partial cleaning
The robot is trapped	RED Light On	The robot is trapped, please remove obstacles around the robot or move robot to a new location to start	Error 23, please remove obstacles around the robot or move robot to a new location to start

Robot Status	Light Indication	APP Indication	Voice Alarm
No Dust Box	RED Light On	Dust box detection Error, please install the dust box and start	Error 24, Please install the dust box in time and start
Fan Error	RED Light On	Fan Error, please check the fan parts	Error 25, Please check the Fan parts in time
Dust Full	RED Light On	Dust Full, please clean the dust box and start	Please clean the dust box and start

8. Product Parameter

Robot Vacuum Cleaner	
Model No	
Robot Size	33*32.5*10CM
Robot Rated Input	20V=== 1.2A 24W
Battery	14.4V/5200mAh Li-ion battery
Charging Time	4-5 Hours
Net Weight	2.65KGS
Charging Base	
Size	18*13.5*9.6CM
Input	20V=== 1.2A
Output	20V=== 1.2A
LiDAR	DC 5V, 240mA, Wavelength 775nm-800nm, Laser Class 1

This equipment should be operated with a minimum distance of 20cm between the radiator and your body.

9. Factory Default Reset

Long press RESET button on the side of the Robot for 10 seconds until hearing "Start factory default reset" and power on music, Robot will automatically restart, and related settings such as regular cleaning, map and WIFI will be restored to the default.

10. Environmental Protection Instructions

Due to chemical substances contained in the built-in lithium-ion battery of the robot may pollute the environment, please take out the battery before discarding product, and discard the lithiumion battery in accordance with relevant local laws and regulations.

Warm Tips:

- * Please make sure to remove the battery when the power switch is turned off.
- * Please disassemble the entire battery pack together, do not damage the battery pack shell, so as to avoid short circuit or material leakage. If accidentally contact with battery exudate, please rinse with plenty of water and seek medical advice in time.