

Raspberry-pi Initials

This presentation has the basic usability of raspberry-pi and initial guide to steer you through.

Things Needed

- The Raspberry-pi
- HDMI Cable
- Power Adapter
- Mouse
- Keyboard
- Monitor with HDMI input/LED TV having HDMI input

* make sure that your Raspberry-pi is included with a memory card and all your data will be stored into that only. Please handle with care

*HDMI cable is provided in the box.

Let's Start

- Plug in Mouse, Keyboard, HDMI cable first and then Plugin power to the raspberry-pi
- Make sure you are viewing something on your screen like some boot code and some graphics.
- Your raspberry-pi will get booted in 20-30 seconds please wait for that
- If you have Broadband at your home connect the RJ-45 cable with Raspberry-pi



Trash

Home Screen in your
Raspberry-pi

Alternative ways to operate your Raspberry-pi

- You could instead use your windows pc if you don't have a screen in spare but for first installation you need to have a screen
- Further steps as followed
 - Connect your Raspberry-pi to the wifi or with the broadband.
 - Click on the VNC logo on your Raspberry-pi prompted screen will tell you the IP address allotted to your raspberrypi
 - Install “**VNC VIEWER**” application in your windows PC .
 - Open the application and type the IP address on which your raspberry-pi is working and press next
 - A prompted screen would ask you to type your password your default password is “**raspberry**” and you are advised to don't change the password. And if you change it please return the Raspberry-pi having default password.
 - For better understanding follow screen guide next slide onwards.



Trash




18:59

Click here to obtain
your IP Address



Connectivity

 172.20.4.68

Connecting users can enter this address in [VNC Viewer](#)

[Sign in](#) to enable cloud connectivity or [learn more about the benefits](#)

► Other ways to connect

Note the IP
address

Security

Identity check

When prompted, connecting users should check for matching details

Signature

8c-e5-f7-fa-3e-cc-b9-86

Catchphrase

Level judo under. Betty race crimson

Authentication


When prompted, connecting users should enter their UNIX user name and password.

V2 172.20.4.66 - Properties

General

Options

Expert





Type your IP here
and give it any
name in column
below

VNC Server: 172.20.4.66

Name: Friendly identifier

Labels



Type your default password "raspberry" and click ok



Trash

Congratulations you can now use your Raspberry-pi on your windows pc in-case you don't have an another screen. But make sure that you are connected to the same network and bandwidth is good to use two devices for seamless work.

Points to remember

- 1) Avoid using the raspberry pi without the case. Any stray static may damage the board.
- 2) Only use the given power supply.
- 3) Heating is normal in the Pi. Don't worry.
- 4) Needless to say, keep it indoors and prevent any dust or moisture from entering the case.
- 5) Do not interface any 5V sensor directly with the GPIO pins. Although the board has 5V supply pins, avoid using them.

Basic Troubleshooting Tips

While connecting to some displays, the raspberry pi might not show up. Go to link: <https://howtoraspberrypi.com/raspberry-pi-hdmi-not-working/>

and follow the steps. It generally solves the problem.