

1. The new version of the code replaces pin 12 with pin 26, that is, the servo connecting pin 12 in the manual needs to be connected to pin 26 .
2. Please select 18650 battery with flat head .
3. Please fully charge the battery when using it for the first time .