
CLEANING BALLISTIC GLASS

0010 00

THIS WORK PACKAGE COVERS

Cleaning

INITIAL SETUP

Maintenance Level	Equipment Conditions
Operator	Vehicle parked on level ground (TM 9-2320-364-10)
Materials/Parts	Parking/Emergency Brake applied (TM 9-2320-364-10)
Detergent (Item 4, WP 0033 00)	Engine off (TM 9-2320-364-10)
Rag, Wiping (Item 7, WP 0033 00)	If equipped, Battery Disconnect Switch in OFF position (TM 9-2320-364-10)

CLEANING

CAUTION

- Remove rings or other hard objects from hands before cleaning ballistic glass. DO NOT use hard, dirty, or gritty cloths on ballistic glass. DO NOT apply water or detergent unless ballistic glass is cool and is protected from heating effects of sunlight. Failure to follow these instructions will damage ballistic glass.
- Do not use bug spray or other aerosol sprays on or near ballistic glass. Failure to follow these instructions will damage ballistic glass.

NOTE

Follow this procedure to clean inner plastic laminate surfaces of ballistic glass. Clean outside surfaces of ballistic glass as you would clean plain glass.

- Add detergent (as directed on label by manufacturer) to 1 gal. (3.8 L) of water.
- Saturate a soft, clean cloth with cleaning solution and lightly rub plastic surfaces.
- Flush off cleaning solution with water and dry with a soft, clean cloth.

END OF WORK PACKAGE

