

功能认证

Segger 的软件 6.12 以后版本已经取消功能认证的功能，所以需要安装 V6.12 版本软件实现认证。

Exec AddFeature JFlash	Jflash 认证命令
vcom enable	打开虚拟串口命令
Exec AddFeature GDB	;添加 GDB 认证
Exec AddFeature RDI	;添加 RDI
Exec AddFeature FlashBP	;添加 FlashBP
Exec AddFeature FlashDL	;添加 FlashDL
Exec AddFeature JFlash	;添加 JFlash
Exec AddFeature RDDI	;添加 RDDI

软件的安装请看文件“1.安装驱动”，安装完双击图标“J-Link Commander V6.12”，进入对话框。



```
J-Link Commander V6.12
SEGGER J-Link Commander V6.12 (Compiled Nov 25 2016 18:08:52)
DLL version V6.12, compiled Nov 25 2016 18:08:26

Connecting to J-Link via USB...O.K.
Firmware: J-Link V9 compiled May 7 2021 16:26:12
Hardware version: V9.20
S/N: 201901187
License(s): GDB, RDI, FlashBP, FlashDL, JFlash, RDDI
VTref = 3.266V

Type "connect" to establish a target connection, '?' for help
J-Link>vcom enable
```

输入这个命令按回车键接口启动虚拟串口

```
J-Link Commander V6.12
SEGGER J-Link Commander V6.12 (Compiled Nov 25 2016 18:08:52)
DLL version V6.12, compiled Nov 25 2016 18:08:26

Connecting to J-Link via USB...O.K.
Firmware: J-Link V9 compiled May 7 2021 16:26:12
Hardware version: V9.20
S/N: 201901187
License(s): GDB, RDI, FlashBP, FlashDL, JFlash, RDDI
VTref = 3.267V

Type "connect" to establish a target connection, '?' for help
J-Link>Exec AddFeature JFlash
O.K.
J-Link>
```

输入这个命令安回车即完成Jflash的认证，其他功能方法一样。