



8 Changing language washing machine

1. turn washing machine off

2. press the 3 buttons around the screen
(except fast)

and hold for ~~several~~ multiple seconds.
A beep will sound

3. Use the buttons on the right side
of the screen to select the language
you want

4. Confirm the language with the button
on the left side of the screen
(not the fast button)

* the lights will need a reset, we tried it
but it didn't work

* Parts of the spraying head of the tap

