


# Interfacing a Remote Control with an Arduino

Download and install the IR library:

<https://github.com/shirriff/Arduino-IRremote>

*Note: the IR sensor has three pins. Pin 1: VOUT (outputs HIGH when no signal is present). Pin 2: GND. Pin3: VCC.*

Create the following circuit:



Upload in-built example code to your Arduino:

File > Examples > IRremote > IRRecvDemo

Open the serial monitor and use the remote to see what values you're receiving. Hexadecimal alues you might get:

Power: E240  
Forward: E250  
Reverse: E248  
Volume+: E244  
Volume-: E254  
Mute: E24C7

Upload `demo_ir_remote.ino` to your Arduino and run!