



ZT1P77MP

Engine Maintenance

Manual

Foreword

All the materials, illustrations, photos, etc. collected in this manual are compiled according to the latest product of ZT 1P77MP Euro 5 . However, due to continuous improvement of products and changes in other aspects, there may be some inconsistencies between your motorcycle and this manual. For parts upgrades, please refer to the part codes on the official website of Zontes, which will not be listed in detail in this manual; if the names of parts in this manual are inconsistent with the official website of Zontes, the official website of Zontes shall prevail.

If some contents of this manual are insufficient, please refer to the "Driver's Manual" attached to the vehicle. You can download the latest version of the driver's manual as a PDF in the corresponding model introduction on the Zontes official website.



©Guangdong Tayo Motorcycle Technology Co., Ltd.

All rights reserved

Notice to users

This manual is compiled by Guangdong Tayo Motorcycle Technology Co., Ltd. and is used to guide dealers or service personnel. This manual cannot provide more detailed knowledge about motorcycles, and is only for reference for maintenance. If you do not have the corresponding knowledge such as electrician, machine repair, etc., improper assembly or maintenance failure may occur during repair.

If you need to clean or wash the body parts of this vehicle, you should use neutral motorcycle wash liquid or tap water or diesel oil, kerosene, etc. Acidic or alkaline motorcycle wash liquid will cause irreversible corrosion to the surface paint, electroplated surface, anodized surface, etc. of parts; gasoline will cause premature aging or hardening of sealants, gaskets, rubber parts, etc., reducing the service life. It should be wiped with a non-woven cloth that will not leave residues. Ordinary rags may leave rags or wool that will affect assembly or cause other adverse effects.

Our company tries to update this manual in a timely manner after product changes.

The following are the meanings of the icons marked in this manual:







 危险	Failure to comply will result in personal injury or death of the driver or maintenance personnel ; or serious damage to spare parts , shortened service life, etc.
 警告	Failure to comply may result in personal injury or death of the driver or maintenance personnel ; or damage to spare parts , abnormality, etc.
 注意	Failure to follow the warnings will result in personal injury to the driver or maintenance personnel ; or matters requiring special attention during disassembly.
	Indicates that there is a requirement for torque
	Indicates that the part needs to be replaced after disassembly
	Indicates that the location needs to be measured

Table of contents

Table of contents	4
Lubrication system	6
1. Diagram of lubrication system	6
2. Maintenance information	8
3. Common failure phenomenon/troubleshooting	8
4. Oil pump	9
Cylinder head cover, cylinder head	11
1. System components	11
2. Maintenance information	13
3. Fault phenomenon/fault analysis	14
4. Cylinder compression test	15
5. Cylinder head cover	15
6. Cylinder head	16
7. Guide bar	24
8. Tension strip	25
9. Tensioner	27
Cylinder, piston	28
1. System components	28
2. Maintenance information	29
3. Troubleshooting	29
4. Cylinder	29
5. Piston	30
Left crankcase cover, continuously variable clutch sub-assembly	33
1. System components	33
2. Maintenance information	35
3. Common failure phenomenon/troubleshooting	35
4. Left crankcase cover	36
5. CVT clutch sub-assembly	37
Right crankcase cover, magneto	40
1. System components	40
2. Right crankcase cover / magneto stator	41
3. Magneto rotor	43
4. Water pump	45
Gearbox	49
1. System components	49
2. Maintenance information	50
3. Fault phenomenon/fault analysis	50
4. Disassembly and decomposition of the gearbox	51
Five, gearbox gear, bearing inspection	52
6. Gear box assembly	53
Crankcase	54
1. System components	54
2. Maintenance information	55

3. Common failure phenomenon/troubleshooting	56
Fourth, the decomposition of the crankcase	57
5. Assembly of the crankcase	60
Sixth, left and right crankcase suspension disassembly, inspection	62
Seven, fine filter	62