




Shenzhen Big Tree Technology Co., Ltd.

BIGTREETECH TMC2130 V1.1

Parameter			
	TMC2100	TMC02208	TMC2130
			
Working Mode	Dir Step	Dir Step	Dir Step SPI
MicroPlyer	1/256	1/256	1/256
MicroPlyer Mode	Up to 256	1/2, 1/4, 1/8, 1/16,1/32	Up to 256
Driver Current	up to 1.7A	up to 2A	Up to 2A
Input Voltage	4.75-46V DC	4.75-36V DC	4.75-46V DC
Logical Voltage	3-5V	3-5V	3-5V
Decibel	< 10dB	< 10dB	< 10dB
RDSon	$\geq 0.5\Omega$	$\leq 0.3\Omega$	$\geq 0.5\Omega$
StealthChop(quiet)	Yes	Yes	Yes
SpreadCyle	Yes	Yes	Yes


1.Introduction:

TMC2130-V1.1 is a new module that is optimized and upgraded to solve the problem that older drivers cannot choose to use the SPI working mode.


SPI working mode of TMC2130-v1.1 can directly select driver current, driver subdivision and other parameters through firmware, which makes these parameters more accurate.Using sequexternal sequencers, it can greatly reduce the workload of the chip and effectively avoid problems such as running deviation, losing step and fault caused by the overload of the chip.

2.Dimensional parameters:

This module is similar to TMC2100, which will generate a lot of heat energy when it working. Therefore, **heat sink and heat dissipation fan** must be added to cool it down during the use, which reduce the occurrence of losing steps and running deviation)



3.STP/ DIR Working Mode:



- (1)Welding resistance at R5 position to make the driver STP/DIR working mode;
- (2)Work mode selection: SDI (CFG1), SCK (CFG2)

Standalone Operation(SPI_MODE=GND) STP/DIR MODE

CFG6/EN				
GND -> Driver enable				
Vio -> Driver disable				
Open-> Driver enable with ramp down from 100% to 34% after about 3s				
CFG2 CFG1 Steps Interpolation Chopper Mode				
GND	GND	1	NO	spreadcycle
GND	Vio	2	NO	spreadcycle
GND	Open	2	Yes to 256	spreadcycle
Vio	GND	4	NO	spreadcycle
Vio	Vio	16	NO	spreadcycle
Vio	Open	4	Yes to 256	spreadcycle
Open	GND	16	Yes to 256	spreadcycle
Open	Vio	4	Yes to 256	stealthchop
Open	Open	16	Yes to 256	stealthchop


SPI working mode wiring instructions:

Before wiring, you need to select the working mode of the driver module for hardware operation:


Weld CFG4 and CFG5 as shown in the red area (i.e., CFG4 to GND, CFG5 to VCC);
(spreadcycle mode can only be used with proper welding)



Remove the resistance at the R5 position so that the driver is in SPI working mode.



The wiring diagram is shown as follows:



Three lines common to all the devices:

MOSI (Master Out Slave In)
MISO (Master In Slave Out)
SCK (Serial Clock)

One line specific for every device:

SS (Slave Select) / CS (Chip Select)

The wiring diagram


Three lines common to all the devices:

MOSI (Master Out Slave In)
MISO (Master In Slave Out)
SCK (Serial Clock)

One line specific for every device:

SS (Slave Select) / CS (Chip Select)





Find the AUX-3 expansion port on the board and connect to the corresponding pin:

AUX-3 / SPI

GND	SCK D52	MISO D50	5V
NC	D53	MOSI D51	D49

Attention:

1. When choosing SPI working mode, please use soldering iron carefully to prevent scalding hands. When you have finished processing, you should carefully observe whether there is residual tin residue in the module. You must clean it up to prevent it from causing the module to short circuit and burn down.
2. When you connect, please pay attention to the line sequence and IO port. The wrong connection will directly cause the driver to fail to work. Please connect carefully to the above drawing.
3. When you insert the driver into the motherboard, you should be careful to see the driver direction clearly. And must not insert the driver backwards to prevent the drive from burning.
4. The driver must do a good job of heat dissipation before working (heat sink + cooling fan) to prevent the driver from working abnormally.

FAQ:

Q: When changing firmware, TMC2130 could not be found in configuration_adv.h

A: Because of your Arduino software lacks the TMC2130 Stepper-master library file. Simply download the library file and unzip it to your library.

Website:

<https://codeload.github.com/teemuatlut/TMC2130Stepper/zip/master>)

Q: How to add the TMC2130 Stepper-master library file

A: Download the TMC2130 stepper-master library file, unzip it, and then

Find your Arduino library, copy and paste it into your library. If your Arduino is installed on disk D, the folder path of the library is:

D:\Program Files

(x86)\Arduino\hardware\arduino\avr\libraries\TMC2130Stepper-master

If it installed on disk C, the folder path of the library is:

C:\Program


Files

(x86)\Arduino\hardware\arduino\avr\libraries\TMC2130Stepper-mas

Ter

Q:If the driver chooses SPI mode, but you want to work in STP/DIP as well, how can you do?

A:Disconnect the CFG4 and CFG5, and then connect the two pads of R5. The red part in the figure below needs to be soldered, and the red border is not connected.



Q:How to deal with the phenomenon of running deviation, fault and step loss in the printing process ?

A:Check whether the drive heat sink is loose, check whether the cooling fan can blow into the drive, and do a good job of cooling the drive, it is the best choice for you to print good products. Slowing down your printing speed can also double your printing effect