



4

Alphabetical List of Function Calls

LAmbiguousFillType 4-584
LBoolean 4-576
LBox_GetRect 4-272
LBox_New 4-268
LBox_Set 4-270
LCapType 4-537
LCell 4-521
LCell_ClearGenerateLayers 4-397
LCell_Copy 4-158
LCell_Delete 4-157
LCell_DeleteUserData 4-190
LCell_Find 4-160
LCell_Flatten 4-185



LCell_GenerateLayers 4-394
LCell_GenerateLayersEx99 4-395
LCell_GetAuthor 4-170
LCell_GetFile 4-161
LCell_GetInfoText 4-176
LCell_GetLastVisible 4-82
LCell_GetList 4-162
LCell_GetLock 4-164
LCell_GetMbb 4-183
LCell_GetMbbAll 4-184
LCell_GetName 4-166
LCell_GetNext 4-163
LCell_GetOrganization 4-173
LCell_GetUserData 4-186
LCell_GetView 4-180
LCell_GetVisible 4-81
LCell_HomeView 4-80
LCell_IsChanged 4-179
LCell_MakeVisible 4-83
LCell_MakeVisibleNoRefresh 4-84
LCell_New 4-156
LCell_SetAuthor 4-172
LCell_SetInfoText 4-178

LCell_SetLock 4-165
LCell_SetName 4-168
LCell_SetOrganization 4-175
LCell_SetUserData 4-188
LCell_SetView 4-181
LCIFParam 4-560
LCircle_GetCenter 4-278
LCircle_GetRadius 4-279
LCircle_GetRect 4-280
LCircle_New 4-274
LCircle_Set 4-276
LColor 4-553
LCoord 4-526
LCore 4-567
LCore_GetCore 4-477
LCore_GetLLHCap 4-478
LCore_GetLLVCap 4-480
LCore_SetLLHCap 4-479
LCore_SetLLVCap 4-481
LCursor_GetPosition 4-74
LCursor_GetPositionEx99 4-76
LCursor_GetSnappedPosition 4-75
LCursorType 4-519


LDerivationType 4-379
LDerivationType 4-586
LDerivedLayerAreaOperation 4-591
LDerivedLayerBoolOperation 4-588
LDerivedLayerOperation 4-587
LDerivedLayerParam 4-547
LDerivedLayerParamEx00 4-585
LDerivedLayerSelectOperation 4-589
LDesignRuleFlags 4-558
LDesignRuleParam 4-557
LDialog_AlertBox 4-63
LDialog_InputBox 4-66
LDialog_MsgBox 4-60
LDialog_MultiLineInputBox 4-68
LDialog_MultiLineMsgBox 4-61
LDialog_PickList 4-71
LDialog_YesNoBox 4-64
LDialogItem 4-514
LDisplay_Refresh 4-78
LDRC_Run 4-466
LDrcRule 4-555
LDrcRule_Add 4-453
LDrcRule_Delete 4-455



LDrcRule_Find 4-456
LDrcRule_GetList 4-458
LDrcRule_GetNext 4-459
LDrcRule_GetParameters 4-462
LDrcRule_SetParameters 4-464
LDrcRule_SetRuleSet 4-460
LDrcRule_SetTolerance 4-461
LDrcRuleType 4-556
LEntity_AssignBlobProperty 4-222
LEntity_AssignProperty 4-221
LEntity_BrowseProperties 4-229
LEntity_CopyAllProperties 4-225
LEntity_DeleteAllProperties 4-224
LEntity_DeleteProperty 4-223
LEntity_GetFirstProperty 4-226
LEntity_GetNextProperty 4-227
LEntity_GetPropertyType 4-218
LEntity_GetPropertyValue 4-220
LEntity_GetPropertyValueSize 4-219
LEntity_LoadBlobPropertyFromFile 4-230
LEntity_PropertyExists 4-217
LEntity_SaveBlobPropertyToFile 4-231
LEntity_SetCurrentProperty 4-228

LEnvironment 4-517
LExtract_GetOptions_Ex98 4-474
LExtract_Run 4-469
LExtract_Run_Ex98 4-473
LExtractOptions 4-562
LFile 4-515
LFile_Close 4-112
LFile_DeleteUserData 4-148
LFile_DisplayCellBrowser 4-102
LFile_Find 4-113
LFile_GetAuthor 4-122
LFile_GetCIFParameters 4-443
LFile_GetColorPalette 4-429
LFile_GetColorPaletteNumColors 4-431
LFile_GetColorPaletteSortBy 4-433
LFile_GetDesignRuleFlags 4-150
LFile_GetEnvironment 4-139
LFile_GetFabricationCell 4-125
LFile_GetGDSPParameters 4-448
LFile_GetGrid 4-141
LFile_GetInfoText 4-136
LFile_GetLayoutVersion 4-131
LFile_GetList 4-114

[LFile_GetLock](#) 4-117
[LFile_GetName](#) 4-120
[LFile_GetNext](#) 4-115
[LFile_GetOrganization](#) 4-128
[LFile_GetSelectionParam](#) 4-143
[LFile_GetSetupVersion](#) 4-133
[LFile_GetTechnology](#) 4-419
[LFile_GetUserData](#) 4-146
[LFile_IsChanged](#) 4-119
[LFile_New](#) 4-107
[LFile_Open](#) 4-108
[LFile_OpenCell](#) 4-103
[LFile_Save](#) 4-109
[LFile_SaveAs](#) 4-110
[LFile_SetAuthor](#) 4-124
[LFile_SetCIFParameters](#) 4-445
[LFile_SetColorPalette](#) 4-435
[LFile_SetColorPaletteNumColors](#) 4-437
[LFile_SetColorPaletteSortBy](#) 4-439
[LFile_SetDesignRuleFlags](#) 4-152
[LFile_SetEnvironment](#) 4-140
[LFile_SetFabricationCell](#) 4-126
[LFile_SetGDSPParameters](#) 4-450



LFile_SetGrid 4-142
LFile_SetInfoText 4-138
LFile_SetLastCurrent 4-149
LFile_SetLayoutVersion 4-132
LFile_SetLock 4-118
LFile_SetOrganization 4-130
LFile_SetSelectionParam 4-144
LFile_SetSetupVersion 4-134
LFile_SetTechnology 4-420
LFile_SetTechnologyLambdaDenom 4-426
LFile_SetTechnologyLambdaNum 4-425
LFile_SetTechnologyName 4-422
LFile_SetTechnologyUnitDenom 4-424
LFile_SetTechnologyUnitNum 4-423
LFile_SetUserData 4-147
LFileType 4-516
LGDSPParam 4-561
LGeomType 4-525
LGrid 4-520
LInstance 4-522
LInstance_Delete 4-196
LInstance_Find 4-201
LInstance_FindNext 4-202

LInstance_GetCell 4-209
LInstance_GetDelta 4-213
LInstance_GetList 4-203
LInstance_GetMbb 4-214
LInstance_GetName 4-205
LInstance_GetNext 4-204
LInstance_GetRepeatCount 4-212
LInstance_GetTransform 4-210
LInstance_GetTransform_Ex99 4-211
LInstance_New 4-192
LInstance_New_Ex99 4-194
LInstance_Set 4-197
LInstance_Set_Ex99 4-199
LInstance_SetName 4-207
LJoinType 4-538
LLayer 4-542
LLayer_Delete 4-355
LLayer_DestroyDerivedParameter 4-391
LLayer_DisableAllDerived 4-384
LLayer_EnableAllDerived 4-383
LLayer_Find 4-356
LLayer_GetCap 4-370
LLayer_GetCurrent 4-374

LLayer_GetDerivedList 4-378
LLayer_GetDerivedNext 4-381
LLayer_GetDerivedParameters 4-385
LLayer_GetDerivedParametersEx00 4-387
LLayer_GetDerivedParametersEx00 4-387
LLayer_GetList 4-358
LLayer_GetName 4-363
LLayer_GetNext 4-359
LLayer_GetParameters 4-366
LLayer_GetRenderingAttribute 4-409
LLayer_GetRenderingObjectName 4-415
LLayer_GetRho 4-372
LLayer_GetSpecial 4-399
LLayer_IsDerived 4-382
LLayer_New 4-353
LLayer_PrecedingLayer 4-360
LLayer_PrecedingLayerEx99 4-362
LLayer_SetCap 4-371
LLayer_SetCurrent 4-375
LLayer_SetDerivedParameters 4-388
LLayer_SetDerivedParametersEx00 4-390
LLayer_SetDerivedParametersEx00 4-390
LLayer_SetName 4-365

LLayer_SetParameters 4-368
LLayer_SetRenderingAttribute 4-412
LLayer_SetRho 4-373
LLayer_SetSpecial 4-400
LLayerParam 4-545
LLayerViewStatus 4-544
LLen 4-534
LMacro_BindToHotKey 4-86
LMacro_BindToMenu 4-87
LMacro_Register 4-85
LMagnification 4-531
LObject 4-523
LObject_Area 4-243
LObject_ChangeLayer 4-246
LObject_Delete 4-234
LObject_GetGDSIIDataType 4-250
LObject_GetGeometry 4-241
LObject_GetInstance 4-582
LObject_GetLayer 4-245
LObject_GetList 4-235
LObject_GetMbb 4-239
LObject_GetNext 4-236
LObject_GetShape 4-240

LObject_GetVertexList 4-242
LObject_Perimeter 4-244
LObject_SetGDSIIDataType 4-254
LObject_Transform 4-237
LObject_Transform_Ex99 4-238
LOrientation 4-529
LOrientation_Ex99 4-530
LOutlineStyle 4-596
LPalette 4-554
LPass 4-549
LPass_GetList 4-404
LPass_GetNext 4-405
LPass_GetParameters 4-406
LPass_New 4-403
LPass_SetParameters 4-408
LPassMode 4-550
LPassParam 4-552
LPassType 4-551
LPoint 4-527
LPoint_Add 4-485
LPoint_Set 4-484
LPoint_Subtract 4-486
LPoint_Transform 4-487

LPoint_Transform_Ex99 4-488
LPolygon_CircleToPolygon 4-297
LPolygon_New 4-293
LPolygon_WireToPolygon 4-295
LPort 4-539
LPort_Delete 4-302
LPort_Find 4-303
LPort_FindNext 4-304
LPort_GetLayer 4-312
LPort_GetList 4-305
LPort_GetMbb 4-313
LPort_GetNext 4-306
LPort_GetRect 4-314
LPort_GetText 4-307
LPort_GetTextSize 4-311
LPort_New 4-300
LPort_Set 4-315
LPort_SetText Size 4-317
LPort_SetText 4-309
LProp 4-572
LProp_AddExtractProp 4-471
LPropAttrib 4-575
LPropCount 4-574

LPropertyType 4-583
LPropItem 4-570
LPropItemType 4-571
LPropType 4-573
LPropVal 4-577
LRect 4-528
LRect_Set 4-490
LRect_Transform 4-492
LRect_Transform_Ex99 4-493
LRenderingAttribute 4-594
LRenderingAttributeIndex 4-593
LSelection 4-540
LSelection_AddAllObjectsInRect 4-334
LSelection_AddAllObjectsOnLayer 4-332
LSelection_AddObject 4-329
LSelection_ChangeLayer 4-339
LSelection_Clear 4-326
LSelection_Copy 4-323
LSelection_Cut 4-322
LSelection_DeselectAll 4-328
LSelection_Duplicate 4-341
LSelection_Flatten 4-344
LSelection_FlipHorizontal 4-346



LSelection_FlipVertical 4-347
LSelection_GetLayer 4-338
LSelection_GetList 4-336
LSelection_GetNext 4-337
LSelection_GetObject 4-331
LSelection_Group 4-342
LSelection_Merge 4-345
LSelection_Move 4-340
LSelection_Paste 4-324
LSelection_PasteToLayer 4-325
LSelection_RemoveAllObjectsInRect 4-335
LSelection_RemoveAllObjectsOnLayer 4-333
LSelection_RemoveObject 4-330
LSelection_Rotate 4-350
LSelection_SelectAll 4-327
LSelection_SliceHorizontal 4-348
LSelection_SliceVertical 4-349
LSelection_UnGroup 4-343
LSelectionParam 4-541
LShapeType 4-524
LSpecialLayer 4-548
LStatus 4-512
LStatusBar_SetMsg 4-79

LStipple 4-598
Ltech_unit_type 4-568
LTechnology 4-569
LTransform 4-532
LTransform_Add 4-501
LTransform_Add_Ex99 4-503
LTransform_Ex99 4-533
LTransform_Set 4-495
LTransform_Set_Ex99 4-497
LTransform_Subtract 4-505
LTransform_Subtract_Ex99 4-507
LTransform_Zero 4-499
LTransform_Zero_Ex99 4-500
LUpi_GetSerialNumber 4-90
LUpi_InQuietMode 4-92
LUpi_InsertMenuItemSeparator 4-95
LUpi_SetDrawingTool 4-94
LUpi_SetQuietMode 4-91
LUpi_SetSelectionTool 4-93
LVertex_GetArray 4-258
LVertex_GetCount 4-257
LVertex_GetNext 4-260
LVertex_GetPoint 4-262

LWindow 4-578
LWindow_Close 4-98
LWindow_CloseAll 4-99
LWindow_GetCell 4-101
LWindow_GetParameters 4-88
LWindow_GetType 4-100
LWindow_GetVisible 4-96
LWindow_MakeVisible 4-97
LWindowType 4-579
LWire_GetCapType 4-285
LWire_GetJoinType 4-286
LWire_GetLength 4-288
LWire_GetMiterAngle 4-287
LWire_GetResistance 4-290
LWire_GetSquares 4-289
LWire_GetWidth 4-284
LWire_New 4-282
LWireConfig 4-535
LWireConfigBits 4-536
LWireParam 4-543
UPIDrawingToolType 4-580