

Pizzabox Commands

The commands are received through RS-232 console port. They are processed by ShellDebug_Thread and processed by ConsoleCmd_Processer().

RS-232 settings:

Parameter	Value
Baudrate	115200
Data bits	8
Parity	No

Commands:

Command	Function	Comment
h	help()	Help.
?		
help		
ver	ver()	Display version information.
rev		
rst	console_reset()	
reset		
ipset	cmd_EEPROM_IP_Lookup_Setup()	Write EEPROM for IP related configuration.
setip		
ipget	cmd_ConsolReadEEPROM_IP_Info()	Read configuration information from EEPROM.
getip		
reg_wr_bit	console_reg_wr()	Write to module software register.
reg_wr_byte		
reg_wr_word		
reg_wr_dword		
reg_rd_dword	console_reg_rd()	Read module software register.