

TORQUE FUSE TROUBLE SHOOTING

(A) Shows a normal shear pattern.

(B) Shows what occurs when drive shaft has a vibration caused by:

1. Improper installation of Power Train Saver

(See Installation Instructions Pg. 4 in Parts Catalogue)

2. Torque Fuses not properly torqued down

(Torque Fuses must be torqued down to 220 Ft/Lbs)

(A) Normal Shear Pattern



(B) Vibration Shear Pattern

