

Thrust Washer

75890-30

4 Thrust Washers

2 3/16" O.D.



Installation Instructions

1. Drive out differential pinion pin retainer.
2. Remove pinion pin, pinions and washers.
3. Remove side gears and washers to allow replacement.