

## K2 Clutch/B1 Brake Control Valve Kit

### 25741-05K

- K2 Clutch/B1 Brake Control Sleeve
- K2 Clutch/B1 Brake Control Valve
- Spring


**NOTE:** Also fits VW/Audi 09D.

### Tool Kit

#### F-25741-TL5

- Reamer
- Reamer Jig
- Guide Pin


**NOTE:** Sonnax "F-Tool" kits designed to service a specific bore require the VB-FIX, a self-aligning valve body reaming fixture. More information and instructions are available at [www.sonnax.com](http://www.sonnax.com).



### 1. Disassembly

**NOTE:** The spring adjuster position must be recorded, and the adjuster returned to its OE position during reassembly.

- Measure and record the distance from the end of the adjuster to the valve body casting (**Figure 1**).
- Remove and save the solenoid retaining pin and solenoid, adjuster retainer and adjuster.
- Remove and discard OE valve and spring.



**Figure 1**

### 2. Bore Preparation

- Clean the bore thoroughly in a solvent tank.
- Generously lubricate the bore and reamer with cutting fluid (i.e. Mobilmet S-122, Lubegard Bio-Tap, Tap Magic™, etc.). For best results, provide a continuous flow of water-soluble cutting fluid (i.e. Mobilmet S-122) during the reaming process.
- The reamers should be turned using a low RPM, high-torque air drill regulated to a maximum of 200 RPM.
- Examine the bore after cleaning for surface finish, debris and burrs. Flashing and burrs on the exit side of land and bores must be carefully removed. A small piece of Scotch-Brite™ material attached to a wire and powered with a drill motor is ideal for the task. Scotch-Brite™ is a very abrasive material and all residual must be cleaned to insure particles do not migrate or remain imbedded into the surface. Post cleaning involves several progressive steps with solvent on a lint-free rag.

#### CAUTIONS AND SUGGESTIONS:

- Turning the reamer backward will dull it prematurely.
- Pushing on the reamer will result in poor surface finish and inadequate and sporadic material removal.
- Never use a crescent wrench, ratchet or pliers to turn the reamer.
- A dull reamer will cut a smaller hole. Reamers can be sharpened, but should only be done by a professional tool sharpener. Actual life of a Sonnax reamer before resharpening or replacing averages 50-70 bores.

# Aisin AW TR-60SN


**K2 Clutch/B1 Brake  
Control Valve Kit**

PART NUMBERS 25741-05K, F-25741-TL5

INSTRUCTION DATA SHEET

## 3. Bore Reaming

Use the associated "F-Tool" kit F-25741-TL5 and VB-FIX reaming fixture as illustrated below to ream the bore.



## 4. Installation & Assembly

- Be certain all debris has been removed from the valve bores and valve body.
- Install adjuster to position previously recorded during disassembly procedure, followed by the retainer.

**NOTE:** Component apply pressure leakage past the adjuster threads can be reduced by using an ATF compatible thread sealant, such as Permatex® 24163 Surface Prep and 24206 Thread Locker, on the spring adjuster. Compound must not create a permanent set.

- Install Sonnax spring between Sonnax valve and sleeve.
- Install Sonnax sleeve/spring/valve assembly. A deep well socket can be used for pressing the assembly into place.
- Reinstall the OE solenoid and solenoid retaining pin.

## 5. Final Testing

A vacuum test at indicated ports should yield 18 in-hg or greater of vacuum.

