


F-Trim Valve End Sleeve

37000-03

1 F-Trim Valve End Sleeve

Note: The F-trim end sleeve, valve and spring shown here are used in '04 and earlier valve body castings. These F-trim components differ from those in the later application, identified by the larger, high frequency TCC solenoid.



Installation & Assembly Steps

1. Remove retaining clip and all components of the bore.
2. Discard the OEM F-trim valve end sleeve.
3. Clean the bore thoroughly.
4. Install the OEM F-trim valve with replacement valve end sleeve.
5. Reinstall solenoid and clip.